




HELLOMOTO

Introducing your new **MOTORIZR™ Z8** 3G wireless phone. Here's a quick anatomy lesson.





Home Screen




1

Press and hold the **Power Key**  for a few seconds or until the display lights up to turn on your phone.

2

Press the Home Key to open the **Main Menu**.

Main Menu



3

Press the Navigation Key **up**, **down**, **left**, or **right** () to highlight a menu feature.

4

Press the Centre Key () to select it.

www.hellomoto.com

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

MOTOROLA and the Stylised M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries. Microsoft, Windows and Windows Me are registered trademarks of Microsoft Corporation; and Windows XP is a trademark of Microsoft Corporation. UIQ Technology and all UIQ Technology-based marks and logos are trademarks of UIQ Technology AB.

© Motorola, Inc., 2007.

Caution: Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

contents

menu map	7	store a phone number	25
safety information	8	call a stored phone number	26
FCC Notice	15	your phone number	26
use and care	17	main attractions	27
EU Conformance	18	home screen	27
recycling information	19	video calls	28
essentials	20	messaging	28
about this guide	20	contacts	29
SIM card	20	media studio	31
battery	21	Bluetooth™ wireless	40
memory card	23	web browser	44
turn it on & off	24	connect your phone to a computer . .	46
slider	25	phone updates	48
make a call	25	basics	49
answer a call	25	basic navigation	49
		Home screen	50
		main menu	50
		status indicators	51

text entry	52	other features	64
volume	55	advanced calling	64
lock and unlock keypad	56	restrict calls and messages	66
handsfree speaker	56	contacts	67
customise	57	messaging	69
profiles	57	device settings	72
home screen	59	call times & costs	72
managing themes	59	data calls	73
time & date	60	network	74
answer options	60	calendar	75
calls	61	tools	76
turn off a call alert	61	security	77
recent calls	61	pictures, videos and games	77
return a call	61	flight mode	78
redial	62	advanced Bluetooth features	79
caller ID	62	memory card	80
emergency calls	62	protected content	81
voicemail	63	SAR Data	82
		WHO Information	84
		index	85

menu map

main menu



Messaging

- Create message
- Call Voicemail
- Messages Inbox
- Email Inbox



Contacts



Calendar



Web



Recent Calls

- All
- Dialed
- Missed
- Received



Control panel

- Profiles
- Speed Dial
- Themes
- Home Settings
- Call Settings
- Install
- Uninstall
- Media Studio Settings
- Audio Routing
- Device
- Contacts
- Kill Filter
- Security
- Rights Manager
- Msg Settings
- Voicemail
- Internet Settings
- Network Settings
- Storage Wizard



Media Studio Settings

- Media Player
- Camera
- Camcorder
- Media Gallery
- Voice



Connectivity

- Bluetooth™
- Remote Sync
- Connections
- USB Selector



Tools

- Time
- To Do
- Calculator
- Jotter
- File Manager



SIM

- SIM Toolkit
- SIM Application



Games

- Vibe

* optional features

This is the standard main menu layout. Your phone's menu may be a little different.

Safety and General Information

This section contains important information on the safe and efficient operation of your mobile device. Read this information before using your mobile device.¹

Exposure to Radio Frequency (RF) Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device transmits.

Your Motorola mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

Operational Precautions

For optimal mobile device performance and to be sure that human exposure to RF energy does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions.

External Antenna Care

If your mobile device has an external antenna, use only a Motorola-supplied or approved replacement antenna. Use of unauthorised antennas, modifications or attachments could damage the mobile device and/or may result in your device not complying with local regulatory requirements in your country.

1. The information provided in this document supersedes the general safety information in user's guides published prior to May 1, 2006.

DO NOT hold the external antenna when the mobile device is IN USE. Holding the external antenna affects call quality and may cause the mobile device to operate at a higher power level than needed.

Product Operation

When placing or receiving a phone call, hold your mobile device just like you would a landline phone.

If you wear the mobile device on your body, always place the mobile device in a Motorola-supplied or approved clip, holder, holster, case or body harness. If you do not use a body-worn accessory supplied or approved by Motorola, keep the mobile device and its antenna at least 2.5 centimetres (1 inch) from your body when transmitting.

When using any data feature of the mobile device, with or without an accessory cable, position the mobile device and its antenna at least 2.5 centimetres (1 inch) from your body.

Using accessories not supplied or approved by Motorola may cause your mobile device to exceed RF energy exposure guidelines. For a list of Motorola-supplied or approved accessories, visit our Web site at:

www.motorola.com.

RF Energy Interference/ Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed or otherwise configured for RF energy compatibility. In some circumstances your mobile device may cause interference with other devices.

Follow Instructions to Avoid Interference Problems

Turn off your mobile device in any location where posted notices instruct you to do so. These locations include hospitals or health care facilities that may be using equipment that is sensitive to external RF energy.

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

Pacemakers

If you have a pacemaker, consult your doctor before using this device.

Persons with pacemakers should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimetres (8 inches) from your pacemaker when the mobile device is turned ON.

- DO NOT carry the mobile device in the breast pocket.
- Use the ear opposite the pacemaker to minimise the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some mobile devices may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer or doctor to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult your doctor or the manufacturer of your device to determine if it is adequately shielded from RF energy.

Driving Precautions

Check the laws and regulations on the use of mobile devices in the area where you drive. Always obey them.

When using your mobile device while driving, please:

- Give full attention to driving and to the road. Using a mobile device may be distracting. Discontinue a call if you cannot concentrate on driving.
- Use handsfree operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

Responsible driving practices can be found in the “Smart Practices While Driving” section at the end of this guide and/or at the Motorola Web site: www.motorola.com/callsmart.

Operational Warnings

Obey all posted signs when using mobile devices in public areas, such as health care facilities or blasting areas.

Automobile Air Bags

Do not place a mobile device in the air bag deployment area.

Potentially Explosive Atmospheres

Areas with potentially explosive atmospheres are often but not always posted and can include fuelling areas such as below decks on boats, fuel or chemical transfer or storage facilities or areas where the air contains chemicals or particles, such as grain, dust or metal powders.

When you are in such an area, turn off your mobile device and do not remove, install or charge batteries. In such areas, sparks can occur and cause an explosion or fire.

Damaged Products

If your mobile device or battery has been submerged in water, punctured or subjected to a severe fall, do not use it until you take it to a Motorola Authorised Service Centre. Do not attempt to dry it with an external heat source, such as a microwave oven.

Batteries and Chargers

If jewellery, keys, beaded chains or other conductive materials touch exposed battery terminals, this could complete an electrical circuit (short circuit), become very hot and could cause damage or injury. Be careful when handling a charged battery, particularly when placing it inside a pocket, purse or other container with metal objects. **Use only Motorola Original batteries and chargers.**



Caution: To avoid risk of personal injury, do not dispose of your battery in a fire.

Your battery, charger or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.
	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Do not throw your battery or mobile device in the trash.
	Your mobile device contains an internal lithium ion battery.

Symbol	Definition
	Do not let your battery, charger or mobile device get wet.
	Listening at full volume to music or voice through a headset may damage your hearing.

Choking Hazards

Your mobile device or its accessories may include detachable parts, which may present a choking hazard to small children. Keep your mobile device and its accessories away from small children.

Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product is dropped on a hard surface or receives a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service centre.

Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing video games. These may occur even if a person has never had a previous seizure or blackout.

If you have experienced seizures or blackouts or if you have a family history of such occurrences, please consult with your doctor before playing video games or enabling a flashing-lights feature (if available) on your mobile device.

Discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements or disorientation. It is always a good idea to hold the screen away from your eyes, leave the lights on in the room, take a 15-minute break every hour and stop use if you are very tired.

Caution About High Volume Usage



Listening at full volume to music or voice through a headset may damage your hearing.

Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck or other parts of your body. If you continue to have discomfort during or after such use, stop use and see a doctor.

FCC Notice To Users

The following statement applies to all products that have received FCC approval. Applicable products bear the FCC logo, and/or an FCC ID in the format FCC-ID:xxxxxx on the product label.

Motorola has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

If your mobile device or accessory has a USB connector, or is otherwise considered a computer peripheral device whereby it can be connected to a computer for purposes of transferring data, then it is considered a Class B device and the following statement applies:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Use and Care

To care for your Motorola phone, please keep it away from:



liquids of any kind

Don't expose your phone to water, rain, extreme humidity, sweat, or other moisture. If it does get wet, don't try to accelerate drying with the use of an oven or dryer, as this may damage the phone.



dust and dirt

Don't expose your phone to dust, dirt, sand, food, or other inappropriate materials.



extreme heat or cold

Avoid temperatures below -10°C/14°F or above 45°C/113°F.



cleaning solutions

To clean your phone, use only a dry soft cloth. Do not use alcohol or other cleaning solutions.



microwaves

Don't try to dry your phone in a microwave oven.



the ground

Don't drop your phone.

European Union Directives Conformance Statement




Hereby, Motorola declares that this product is in compliance with:

- The essential requirements and other relevant provisions of Directive 1999/5/EC
- All other relevant EU Directives

The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at www.motorola.com/rtte. To find your DoC, enter the product Approval Number from your product's label in the "Search" bar on the Web site.



Caring for the Environment by Recycling



This symbol on a Motorola product means the product should not be disposed of with household waste.

Recycling Mobile Phones and Accessories

Please do not dispose of mobile telephones or electrical accessories, such as chargers or headsets, with your household waste. In some countries or regions, collection systems have been set up to handle waste electrical and electronic items. Please contact your regional authorities for more details. If no suitable scheme exists, you may return unwanted mobile telephones and electrical accessories to any Motorola Approved Service Centre in your region.

about this guide

This guide shows how to open a menu feature as follows:

Find it:  >  **Messaging** > **Create new message**

This means that, from the home screen:

- 1 Press the *home key*  to open the main menu.
- 2 Press the *navigation key*  to scroll to  **Messaging**, and press the *centre key*  to select it.
- 3 Press the navigation key  to scroll to **Create new message**, and press the *centre key*  to select it.


symbols	
	This means a feature is network, SIM card, or subscription dependent and may not be available in all areas. Contact your service provider for more information.
	This means a feature requires an optional accessory.

SIM card

Caution: Don't bend or scratch your SIM card. Keep it away from static electricity, water, and dirt.

Your *Subscriber Identity Module* (SIM) card contains personal information like your phone number and contacts entries. It can also contain your voicemail, text message, and Internet access settings. If you put your SIM card in another phone, that phone uses your phone number.

SIM installation



battery

battery tips

Battery life depends on the network, signal strength, temperature, features, and accessories you use.

- Always use Motorola Original batteries and chargers. The warranty does not cover damage caused by non-Motorola batteries and/or chargers.
- New batteries or batteries stored for a long time may take more time to charge.
- When charging your battery, keep it near room temperature.



When storing your battery, keep it uncharged in a cool, dark, dry place.

- Never expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.
- It is normal for batteries to gradually wear down and require longer charging times. If you notice a change in your battery life, it is probably time to purchase a new battery.




Contact your local recycling centre for proper battery disposal.

Warning: Never dispose of batteries in a fire because they may explode.

Before using your phone, read the battery safety information in the “Safety and General Information” section included in this guide.


battery installation



Note: Your battery is intentionally tight fitting to ensure consistent connection.

battery charging

New batteries are not fully charged. Plug the battery charger into your phone and an



electrical outlet. Your phone might take several seconds to start charging the battery.

Your phone's battery charging icon, in the status bar, flashes while the battery is charging, and stops flashing when the battery is fully charged. Disconnect your charger once charging is complete.

Note: When you connect your phone to a computer with the USB cable, your phone will also be charged, see page 46.

The battery charger shipped with this device is designed for Motorola 3G mobile phones. Other chargers might take longer to charge your battery, or cause your calls to fail during charging.

memory card

You can use a removable memory microSD™ card with your phone to store and retrieve multimedia objects (such as photos and sounds). Some applications, such as **Camera** and **Camcorder**, allow you to store photos or videos on your phone or memory card. For more memory card features, see page 80.




Note: If you download a copyrighted file and store it on your memory card, you can use the file only while your memory card is inserted in your phone. You cannot send, copy, or change copyrighted files.

To transfer files to/from your memory card, see page 46.

install or remove a memory card

1 Open the rubber cover.

2 **To install the memory card,** make sure the memory card's metal contacts



are facing up, and slide the memory card into the slot until you hear a click.


To remove the memory card, push it in and release. The memory card slides a little way out of the slot. Pull the memory card out of the slot.

3 Replace the rubber cover.

turn it on & off

Caution: Some phones ask for your SIM card PIN code when you turn them on. If you enter an incorrect PIN code three times before the correct code, your SIM card is disabled, and your display shows **SIM Blocked**. Contact your service provider.

To turn on your phone, press and hold  for a few seconds. If prompted, enter your SIM card PIN.



To turn off your phone, press and hold . The power menu is briefly displayed. Continue to hold  to turn off your phone.

Tip: Release  when the power menu is displayed and you can select **Shut down**, **Lock keypad**, and **Flight Mode**.

slider

To open your slider, push the bumper bar up, see page 1

To close your slider, pull the bumper bar down.

make a call

To make a call, enter a phone number and press . **To “hang up,”** close the slider or press .

Tip: For the best microphone performance have the slider open during a call.

To make video calls, see page 28.

answer a call

To answer a call when your phone rings and/or vibrates, just open the slider or press

. **To “hang up,”** close the slider or press .

store a phone number

You can store a phone number in your **Contacts**:

- 1 Enter a phone number in the home screen.
- 2 Press **Options** > **Store**.
- 3 Enter a name and other details for the phone number. To select a highlighted item, press the *centre key* .
- 4 Press **Options** > **Save** to store the number.

Note: The number will be stored on your phone's memory.

For further **Contacts** details, see page 29.

call a stored phone number

Find it:  >  **Contacts**

1 Scroll to the contacts entry.

Shortcut: In contacts, press keypad keys to enter the first letters of an entry you want.

2 Press  to call the entry.

your phone number

From the home screen, press  > **SIM**
> **SIM Application** > **My Lines** to see your number.

main attractions

You can do much more with your phone than make and receive calls!

home screen

The *home screen* appears when you turn on the phone.



Note: Your home screen might look different from the one shown, depending on your service provider and selected plug-ins.

Your home screen displays important status information, such as messages and missed calls using plug-ins. The following plug-ins can be selected:

- **Calls** - Select to view missed calls or call a contact.
- **Messages** - Select to view or send messages.
- **Email** - Select to view or send email.
- **Calendar** - Select to view calendar reminders.
- **Profile** - Select to view current profile and settings.

- **Music** - Select to play music and access the **Media Gallery**.

In your home screen menu press **Options** > **Settings** to select the plug-ins you want to display. You can display up to five plug-ins.

To clear your plug-in status information highlight the plug-in, then press and hold .

For further home screen features, see page 50.

To customise your home screen, see page 50.

video calls

If you call someone who has a 3G video phone, you can see each other while you talk. If your phone is roaming on a **non-3G network**, video calls will not work (see the Roam indicator on page 51).



make a video call

- 1 Enter a phone number and press the video call key  or press **Options** > **Video call** to dial the number. For the video call key location, see page 1.
- 2 To end the call, press .

messaging

You can send and receive SMS, MMS, and email messages from the messaging feature. For more messaging features, see page 69.

send a message

Find it:  >  **Messaging** > **Create new message** > **SMS** or **MMS** or **Email**

- 1 Select **To** to add a recipient. Enter the recipient's number or address, or press **Contacts** and select a contact.

- 2 Select **Subject** to enter a subject (optional).
- 3 Scroll down to the text entry field and press keypad keys to enter text on the page (for details about text entry, see page 52).

To insert a **picture, sound, or other object** on the page, press **Options** and select the **Add** or **Insert** menu.

To insert **another page** in your MMS, press **Options > Add > New page**. You can enter more text and objects on the new page.

Note: SMS, MMS and email messages allow different types of objects to be added to your message. All available options are displayed in the **Add** and **Insert** menus.

- 4 When you finish the message, press the **Send** key to **send** the message.

receive a message

When you receive a new message, your phone plays an alert. Also, the display shows **New message** with a message indicator, such as , and the home screen messaging plug-in is updated. Press the **View** key to open the message.



To see all of your messages:

Find it:  >  **Messaging > Messages Inbox** or **Email Inbox**

Tip: You can use the  left and right keys to scroll between folders, such as **Inbox**, **Outbox**, **Draft**, **Sent**, **SIM**, and **Templates**.

contacts

You can manage the details of your contacts from the contacts feature.

For more contacts features, see page 67.

create a contact

You can store phone numbers, email addresses, postage addresses and much more for each contact in your contacts list.

Find it:  >  **Contacts** > **Options** > **New contact**

- 1 Enter a name and other details for the contact. To select a highlighted item, press the *centre key* .
- 2 Use the  left and right keys to scroll between tabs, such as **Basic**, **Detail**, and **Notes**. Enter more details for the contact as required.
- 3 Press **Options** > **Save** to store the contact.

use a contact

With a contact highlighted you can:

- press the *centre key*  to display the contacts details.

Tip: Use the  left and right keys to scroll between tabs, such as **Basic**, **Detail**, and **Notes**. For SIM contacts you can only store **Basic** information. If you want to store additional information then the contact must be stored on your phone's memory.

- press the  left and right keys to view individual details, such as Mobile number, Phone number, and email address.

Tip: With a number displayed, just press  to call the contact.

- press **Options** to make a voice call, make a video call, send a message and more.

SIM and phone contacts

You can show contacts stored in your **phone's memory** or on your **SIM card**. Press

 >  **Contacts** then press **Options** > **View category** > **All phone contacts** or **SIM**.

To store a SIM contact, set your category to **SIM** and create a contact from the **Contacts** feature.

To store a phone contact, set your category to **All phone contacts** or another category you have created and create a contact from the **Contacts** feature or the **Home** screen.

To copy contacts between your phone and SIM, see page 69.

media studio

Your phone's media studio contains:

- **Camera**
- **Camcorder**
- **Media Gallery**
- **Media Player**

- **Voice recorder**

camera

Your primary camera lens is on the back of your phone (see page 2), and your secondary camera lens is on the front of your phone (see page 1). **To get the clearest pictures, wipe the lens clean with a soft dry cloth before you take a picture.**


Note: Next to the camera lens on the back of your phone is a **camera on indicator**. This can blink when your camera is on to let people around you know that they might be in your photo or video.



take a photo

Note: To take a photo with the primary camera your slide must be closed. To take a photo with your secondary camera the slide must be open, see page 1.

- 1 Press the camera key or 
 - >  **Media Studio** > **Camera** to see the viewfinder.



- 2 Press the camera key or the *centre key*  to take the photo in the viewfinder.

After you capture your photo, you can use the navigation keys:

keys
centre Rename the photo file name.
up Save the photo and go to the Media Gallery.
down Save the photo and create an MMS message with the photo inserted in the message.
left Save and return to viewfinder.
right Discard and return to viewfinder.

photo features

Before you capture your photo, you can press **Options** to open the camera menu:

options
Capture Capture the photo.
Picture size Adjust your picture size between Small (QVGA), Medium (VGA), and Large (2MP - primary camera only).
Picture quality Adjust your picture quality between Standard and Fine .
Modes Change the mode of your camera (Normal , Indoor , Outdoor , Sports , Portrait , Night , and Backlight).

options
Effects Change the effect of your photo (None , Black & White , Negative , Sepia , and Solarise).
Flash Mode Set your flash mode to Always on , On once or Off .
Self timer Turn the self timer On or Off .
Settings Set more camera features.

camcorder

Your primary camera lens is on the back of your phone (see page 2), and your secondary camera lens is on the front of your phone (see page 1). **To get the clearest pictures, wipe the lens clean with a soft dry cloth before you take a picture.**


Note: Next to the camera lens on the back of your phone is a **camera on indicator**. This can blink when your camera is on to let people around you know that they might be in your photo or video.



record a video

Note: To take a video with the primary camera your slide must be closed. To take a video with your secondary camera the slide must be open (see page 1).

- 1 Press the camera key then the right navigation key or  >  **Media Studio** > **Camcorder** to see the viewfinder.



- 2 Press the camera key or the *centre key*  to start recording.
- 3 Press the camera key or the *centre key*  to stop recording and to preview.

After you record your video, you can use the navigation keys:

keys
centre Play/Pause (preview) the video.
up Save the video and go to the Media Gallery .
down Save and go to the MMS editor with the video inserted in the message.
left Save and return to viewfinder.
right Discard and return to viewfinder.

video features

Before you capture your video, you can press **Options** to open the camcorder menu:

options
Record Record the video.
Video Size Adjust your video size between Small (SQCIF), Medium (QCIF), and Large (QVGA).
Video Quality Adjust your video quality between Low , Medium , and High .
Modes Change the mode of your video (Normal , Indoor , Outdoor , Sports , Portrait , Night , and Backlight).

options
Effects Change the effect of your video (None, Black & White, Negative, Sepia, and Solarise).
Settings Set more video features.

media gallery

Use the Media Gallery to manage your multimedia content.

Tip: You can use a removable memory card with your phone to store more media files (see page 23).



Find it: > **Media Studio** > **Media Gallery**

play music

In the Media Gallery, press ◀▶ left or right to scroll to the music tab. Select a track from

Playlists, Artists, Tracks or **Albums** to start playing music.

For more music and media player details, see page 37.

view photos

In the Media Gallery, press ◀▶ left or right to scroll to the photos tab. Select a photo to view it. You can now press ◀▶ left or right to scroll through your photos.

To edit, or delete photos you've taken, see page 77.

play videos

In the Media Gallery, press ◀▶ left or right to scroll to the videos tab. Select a video to start playing it. You can now use the navigation key ◀▶ to play, pause, forward and rewind your video.

To delete, or manage videos you've recorded, see page 77.

play sounds and ring tones

In the Media Gallery, press  left or right to scroll to the sounds and ring tones tab. Select a sound or ring tone to start playing it.

download multimedia

To download music tracks, videos, pictures, sounds or ring tones from the Internet, see page 77.

media player

play music

Your phone can play and store AAC, AAC Plus, Enhanced AAC, and MP3 music files.

Note: Your phone may not play MP3 files that have a bit rate higher than 320 kbps. If you try to download or play one of these files, your phone might show you an error or ask you to delete the file.

Find it: Press the media player key or  >  **Media Studio** > **Media Player**. For the media player key location, see page 1.

If no tracks or playlists are loaded, you are first taken to the Media Gallery to select a song to play. From the music tab, open one of the following:

tab
Playlists Play and manage your playlists.
Artists Select an artist to show or play their songs.
Tracks Select a track to show or play songs.
Albums Select an album to show or play its songs.

Once the Media Player is displayed:

- **Play or pause** the song by pressing the *centre key* .
- **Tip:** You can also play or pause by pressing the media player key.
- **Stop** the song by pressing  down.
- **Play previous or next** by pressing  left or right.
- **Change volume** by pressing the volume keys.
- **Return to the Media Gallery** by pressing  up. Your music will continue to play.
- **Hide the player** by pressing  to return to the main menu. This lets you use other phone features while playing music.

Note: The Media Player is used to play music and videos. You cannot play both at the same time.

Tip: You can listen to music as you travel. Use Bluetooth™ A2DP enabled devices, such as stereo headphones, for enhanced music quality and use Bluetooth AVRCP enabled devices, such as car stereos, to control playback (see page 40). If you're on a plane, use a wired headset and flight mode to make your phone safe to use (see page 78).

manage playlists

Press  up or down to scroll to a Playlist, and press the *centre key*  to select it or press **Options** to open the menu:

options
Open
Show your playlists.

options
Play Play your selected playlist.
New playlist Create a new playlist (see below).
Rename Rename a playlist.
Delete Delete a playlist.
Sort by Sort your playlists by Name or Date .
Find Search for a playlist.
Details View details of a playlist.

To create a playlist:

- 1 In the **Playlists** tab press **Options > New playlist**.
- 2 Enter a name for your playlist and save the changes.
- 3 Open a song list, select each song you want to add and save your changes.

music router

To select which device you want to use to play your music or multimedia audio, such as handsfree headset or music system.

Find it:  >  **Control Panel > Audio Routing**

play videos

Find it:  >  **Media Studio > Media Gallery > (Video) tab**

Scroll to the video you want to play and press the *centre key* . Once the Media Player is displayed:

- **Play or pause** the video by pressing the *centre key* .
- **Stop** the video by pressing  down.
- **Skip back or forward** by pressing  left or right.
- **Change volume** by pressing the volume keys.
- **Return to the Media Gallery** by pressing  up.

Note: The Media Player is used to play music and videos. You cannot play both at the same time.

voice recorder

Find it:  >  **Media Studio** > **Voice**

Press the *centre key*  to start and stop recording. Your recorded sounds are saved in the **Media Gallery** sounds/ring tones folder.

Bluetooth™ wireless

Your phone supports Bluetooth wireless connections. You can connect your phone with a Bluetooth audio device, such as a handsfree headset or music system. You can also connect your phone with a phone or computer that supports Bluetooth connections to exchange files.

Note: The use of wireless phones while driving may cause distraction. Discontinue a call if you cannot concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

For maximum Bluetooth security, you should always connect Bluetooth devices in a safe, private environment.

use a handsfree or music device

Before you try to connect your phone with a handsfree or music device, make sure the device is **on** and **ready** in *pairing* or *bonding* mode (see the user's guide for the device).

Find it:  >  **Connectivity** > **Bluetooth**
> **Enabled audio devices** tab > **New device**

If Bluetooth is switched off, you will be prompted to turn it on. Your phone now lists the devices it finds within range.

- 1 Scroll to a device in the list and press the *centre key* .
- 2 If necessary, press the **Yes** or **OK** key to connect to the device.
- 3 If necessary, enter the device passkey (such as **0000**) and press the **OK** key.

When your phone is connected, the Bluetooth indicator  is highlighted in the status bar.

Shortcut: When your phone's Bluetooth power is on, your phone can automatically connect to a handsfree device you have used before. Just turn on the device, or move it near the phone. If the device doesn't connect, turn it off and back on. During a call, you can press **Options** > **Audio** > **Earpiece** to connect to a handsfree device you have used before.

connect to another Bluetooth device

Before you try to connect your phone with another Bluetooth device, make sure the device is **on**.

Find it:  >  **Connectivity** > **Bluetooth**
> **My devices** tab > **New device**

If Bluetooth is switched off, you will be prompted to turn it on. Your phone now lists the devices it finds within range.

- 1 Scroll to a device in the list and press the *centre key* .
- 2 If necessary, press the **Yes** or **OK** key to connect to the device.
- 3 If necessary, enter the device passkey (such as **0000**) and press the **OK** key.

When your phone is connected, the Bluetooth indicator  is highlighted in the status bar.

Shortcut: When your phone's Bluetooth power is on, your phone can automatically connect to a Bluetooth device you have used before. Just turn on the device, or move it near the phone. If the device doesn't connect, turn it off and back on.

send files to another device

You can send a media file, contacts entry, calendar event and more from your phone to a computer or other device.



Note: You cannot copy some copyrighted objects.

- 1 On your phone, scroll to the object that you want to copy to the other device.
- 2 Press **Options** > **Send As** > **Bluetooth**.
- 3 Select a recognised device name, or **New device** to search for the device where you want to copy the file.

If your phone could not send the file to the other device, make sure the device is **on** and **ready** in *discoverable* mode (see the user's guide for the device). Also, make sure the device is not busy with another similar Bluetooth connection.

Note: Once you connect your phone to a Bluetooth device, that device can start similar Bluetooth connections with your phone. Your display shows the highlighted Bluetooth indicator  in the status bar when there is a Bluetooth connection.

receive files from another device

If you do not see the Bluetooth indicator  at the top of your display, turn on your phone's Bluetooth feature by pressing  >  **Connectivity** > **Bluetooth** > **Bluetooth on**.



- 1 Place your phone near the device, and send the file from the device.

If your phone and the sending device don't recognise each other, place your phone in discoverable mode so the sending device can locate it, press  >  **Connectivity** > **Bluetooth** > **Visible to other devices**.

- 2 Press the **Accept** key on your phone to accept the file from the other device.

Your phone notifies you when file transfer is complete. A Bluetooth message is received in your Messaging inbox.

web browser

Your phone is provided with a fully featured WEB and WAP browser so you can connect to the Internet.



To start your Internet connection press  >  **Web.**

Use the navigation key  to scroll between items on the page.

Your browser provides shortcuts to common tasks from the **Options** menu:

key	shortcut
#1	Open a web page.
#2	Go to Bookmarks.
#3	Close current window.
#4	Go to your home page.
#5	Show images.
#6	Display in full screen mode.
#7	Display the next browser window.
#8	Set your Internet preferences.
#9	Add the current web page to your Bookmarks
#0	Stop (when page is loading) or refresh the current page.

key	shortcut
#	Go to the top or bottom of the page.
*	Find text on the current page.

To download music, videos, pictures, and more from the Internet, see page 77.

open a web page

Press **Options** > **Open web page** and enter the web address, such as `www.motorola.com`.

- 1 If necessary, select **Open in new page**.
- 2 Press **Options** > **Open**.

manage bookmarks

To see your bookmarks press **Options** > **Bookmarks**. To manage your

bookmarks press **Options** to open the bookmarks menu:

options
Open Opens your bookmarked web page.
Add bookmark Add a bookmark.
Edit bookmark Edit a bookmark.
Delete Delete a bookmark.
Send bookmark as Send bookmark in an MMS message or via Bluetooth.

screen format

You can choose the screen format used to display your web pages.


Press **Options** > **Settings** and select one or more from **Fit to screen**, **Full screen**, and **Landscape**.

connect your phone to a computer

You can use a USB cable or a Bluetooth connection to connect your phone to a computer.

cable connection

 Your phone has a mini-USB port so you can connect it to a computer to transfer data.



Note: Motorola Original USB data cables and supporting software may be sold separately. Check your computer or hand-held device to determine the type of cable you need.



On your phone:

- 1 Disconnect the cable from your phone, if it is connected, then press

 >  **Connectivity** > **USB Selector**.

- 2 Connect the cable to your phone and to an available USB port on your computer.
- 3 Select a USB personality from the list displayed:
 - **Modem** - Use your phone as a modem for your computer. To make **data calls** through a connected computer, see page 73.
 - **PC Connect** - Use your Motorola PcSync software to transfer data and synchronise contacts, calendar, tasks and email. See the help feature provided with the software for details.
 - **Mass Storage** - Access your memory card data using your computer's "My Computer" feature.

On your computer:

If you have selected **Mass Storage** as the USB personality:

- 1 Open your "My Computer" window, where your phone's memory card appears as a "Removable Disk" icon.
- 2 Click on the "Removable Disk" icon to access the files on your phone's memory card.
- 3 To store the desired files onto the memory card, drag and drop them as follows (you may need to create the folder structure on your memory card):
 - music:**
 - > Media files > audio > music
 - sounds and ringtones:**
 - > Media files > audio > ringtones
 - pictures:**
 - > Media files > image
 - videos:**
 - > Media files > video

- 4 When you finish, disconnect your phone by selecting the "Safely Remove Hardware" icon in the system tray at the bottom of your computer screen. Then disconnect the "USB Mass Storage Device."
- 5 Disconnect the cable from your phone and computer.

Bluetooth connection

You can use a Bluetooth connection to connect your phone to a computer. To do this see "connect to another Bluetooth device" on page 41. You can use your Motorola PcSync software to transfer data and synchronise contacts, calendar, tasks and email. See the help feature provided with the software for details.

phone updates

Sometimes we think of ways to make your phone's software faster or more efficient after you've purchased your phone. You can find out if your phone can be updated and register for free update notifications at:



<http://www.hellomoto.com/support/update>

Note: Software updates do not affect your contacts entries or other personal entries. If you receive a software update but choose to install it later, see page 75.

Note: You may want to copy your data to your memory card (see page 80) or computer (see page 46) to ensure no data is lost.

basics

See page 1 for a basic phone diagram.


Tip: Want some help? Press **Options** > **Help** within a feature, such as the home screen. Use the in-device help to find information about main phone features.

basic navigation

home key

Press  to switch between your home screen and the main menu.


You can press  at anytime to return to the main menu.



Tip: Press and hold  to display a list of your most recently used applications.

navigation key

Press the *navigation key*  up, down, left, or right to scroll to items in the display. When you scroll to an item, press the *centre key*  to select it.



tab scrolling

In some applications, such as Messaging, Contacts, and Media Studio, you can press the *navigation key*  left and right to scroll between tabs.

Home screen

The *home screen* appears when you turn on the phone, see page 27.

To dial a number from the home screen, enter a phone number and press . To “hang up,” close the slider or press .

Press  up and down in the home screen to highlight plug-ins, then press the *centre key*  to open the plug-in.

You can press  at anytime to return to the the home screen.

Soft Key Labels show the current soft key functions. For soft key locations, see page 1.

Press  to switch between your home screen and the main menu.

main menu

Press  up, down, left, or right in the main menu to highlight an application.

Press the *centre key*  to open the application.


You can press  at anytime to return to the main menu.

Soft Key Labels show the current soft key functions. For soft key locations, see page 1.

Press  to switch between your home screen and the main menu.

status indicators

Status indicators are displayed at the top of the phone's display:



1 Signal Strength Indicator – Vertical bars show the strength of the network connection. Network services such as calls may not be available when  or  appears.

2 Network Indicator – Shows when your phone is using a GSM  connection (standard network access), GPRS connection (high speed network access), 3G connection (highest speed network and video calling) or *flight mode* (no network connection, see page 74).

 GSM

 GPRS

 3G

 Flight mode

3 Roam Indicator – Shows when your phone is seeking or using a network outside your Home network. 

4 Bluetooth Indicator – Shows current Bluetooth status. Indicators may include:

 Bluetooth on (green)

 Bluetooth active (blue)

 sending

5 Calls Indicator – Shows various call states. Indicators may include:

 active voice call

 active video call

6 Message Indicator – Shows when you receive an SMS, MMS, email or voicemail message. Indicators can include:



 SMS

 email

 MMS

 voicemail

7 Sound Mode Indicator – Shows the current sound mode.


 silent

 speakerphone

8 Battery Level Indicator – Vertical bars show the battery charge level. Recharge the battery when your display shows a low battery.

text entry

Some features let you enter text.



Press  in a text entry view to select an entry mode:

Text Input Settings	
 or 	Your text entry mode can be set to iTAP™ () predictive text or Multi-tap () mode.
123	Numeric mode enters numbers only.

Text Input Settings

@ **Symbol** mode enters symbols only.

To set your preferred text entry mode, press  > **Control Panel** > **Text Input Settings**.

iTAP™ and Multi-tap mode tips

- Press  in a text entry view to change text case to all capital letters (**AB**), no capitals (**ab**), or next letter capital (**Ab**).
- Press  to enter a space at the cursor and move on to the next word.
- To enter numbers quickly, press and hold a number key to temporarily switch to numeric mode. Enter a space to change back to iTAP or Multi-tap mode.
- Press  to enter punctuation or other characters.


- Press  to move the cursor.
- Press  to delete the character to the left of the cursor.

iTAP™ mode tips

Press  in a text entry view to switch to iTAP **Ab** (predictive text) mode.

iTAP mode lets you enter words using one keypress per letter. The iTAP software combines your keypresses into common words and predicts each word as you enter it.

For example, if you press **7 7 6 4**,
your display shows:



If you want a different word (such as **Progress**),
continue pressing keypad keys to enter the
remaining letters.


If you want to select an alternative word
press ⬆ up or down to scroll through the
options.

Multi-tap mode

Press **#** in a text entry view to switch to
Multi-tap **Ab** mode.

To enter text in Multi-tap mode, press a
keypad key repeatedly to cycle through the
letters and number on the key. Repeat this
step to enter each letter.

For example, if you press **7** once, your
display shows:



numeric mode

Press **[#]** in a text entry view to switch to numeric **123** mode. Press the number keys to enter the numbers you want.

Shortcut: You can press and hold a number key to temporarily switch to numeric mode from iTAP™ or Multi-tap modes. Enter a space to change back to iTAP or Multi-tap mode.


symbol mode

Press **[#]** in a text entry view until your display shows a list of symbols. Scroll to the symbol you want, then press the *centre* key **[◀•▶]**.

volume

Press the volume keys to:

- turn off an incoming call alert
- change the earpiece volume during calls
- change the music volume during music playback (if you are using a A2DP headset, the volume controls are on the headset)
- change the ringer volume from the home screen.



Note: Changing the ringer volume will update your current profile.

lock and unlock keypad

To lock your keypad with the slider closed press and hold  until the power menu is displayed. Select **Lock keypad**.

To unlock your keypad open the slider or press any key and select **Yes**.

To lock your keypad with the slider open press and hold  then select **Yes**.

To unlock your keypad press any key and select **Yes**.

handsfree speaker

You can use your phone's handsfree speaker to make calls without holding the phone to your ear.

To turn the handsfree speaker on during a call, press the **Speaker** key (if available), or **Options > Audio > Speaker**.

customise

profiles

Profiles define the look and sound of your phone. Each profile uses a group of settings to define items such as ring tones, message alerts, screensavers and more. There are five standard profiles **General**, **Indoor**, **Meeting**, **Outdoor** and **Silent** that you can edit or you can define your own.

The current profile is displayed on your home screen if you have chosen to display the profiles plug-in, see page 27.

Once you have defined your profiles, you can swap between profiles to change the look and sound of your phone.

To activate a profile:

Find it:  >  **Control panel** > **Profiles**
> *profile name* > **Activate**

To edit a profile:

Find it:  >  **Control panel** > **Profiles**
> *profile name* > **Options** > **Edit**

To create a new profile:

Find it:  >  **Control panel** > **Profiles** > **Options**
> **New** > *enter profile name*

changing ring style, volume, and theme

You can change your ring style, volume, and theme from the **Basic** tab.

Find it:  >  **Control panel** > **Profiles:** *profile name* > **Options** > **Edit** > **Basic tab**

changing voice call ring tones

You can change your voice call ring tones from the **Calls** tab.

Find it:  >  **Control panel** > **Profiles:** *profile name* > **Options** > **Edit** > **Calls tab**

changing message alerts

You can change your message alerts from the **Messages** tab.

Find it:  >  **Control panel** > **Profiles:** *profile name* > **Options** > **Edit** > **Messages tab**

changing other sounds

You can change other sounds from the **Sounds** tab.

Find it:  >  **Control panel** > **Profiles:** *profile name* > **Options** > **Edit** > **Sounds tab**

changing screen saver and screen brightness

You can change your screen saver and screen brightness from the **Screen** tab.

Find it:  >  **Control panel** > **Profiles:** *profile name* > **Options** > **Edit** > **Screen tab**

home screen

You can change your home screen settings.

changing plug-ins

You can change your plug-ins from the Plug-ins tab.

Find it:  >  **Control panel** > **Home Settings**
> **Plug-ins** > *plug-in*

changing wallpaper

Set a photo or picture as a wallpaper (background) image in your home screen.

Find it:  >  **Control panel** > **Home Settings**
> **Wallpaper** > **Choose**

changing softkeys

You can change the function of your home screen's right soft key.

Find it:  >  **Control panel** > **Home Settings**
> **Soft Keys**

managing themes

A *phone theme* is a group of image and sound files that you can apply to your phone. Most themes include a wallpaper image, screen saver image, and ring tone. Your phone may come with some themes, and you can download more. 

To **apply** a theme, use your profiles, see page 57. Alternatively, press  >  **Control panel** > **Themes**, scroll to the theme, and press **Options** > **Select**.

Note: When you apply a theme, your current profile will be updated.

To **download** a theme, see page 78.

To **delete themes you downloaded**, press  >  **Control panel** > **Themes**, scroll to the theme, and press **Options** > **Delete** or **Delete All**.

To **view** a theme, press  >  **Control panel** > **Themes**, scroll to the theme, and press **Options** > **View**.

time & date

To **manually** set the time and date, press  >  **Control panel** > **Device** > **Time & date** > *date* or *time*.

answer options

You can use different ways to answer an incoming call:

Find it:  >  **Control panel** > **Call Settings**

options
Active Answer Answer by opening the slider.
Auto Answer Answer automatically when a wired headset is connected after a set duration in seconds.
Any Key Answer Answer by pressing any key.

calls

To make and answer calls, see page 25.

turn off a call alert

You can press the volume keys to turn off a call alert before answering the call.

recent calls

Your phone keeps lists of incoming and outgoing calls, even for calls that did not connect. The most recent calls are listed first. The oldest calls are deleted as new calls are added. A record of **dialled numbers**, **answered calls**, and **missed calls** can be viewed in the Recent Calls feature, and your missed calls are also shown in the calls plug-in on the home screen (see page 27).

Find it:  >  **Recent calls**, then press left or right to switch between tabs **All**, **Dialled**, **Missed**, or **Answered**.

Scroll to a call to see call details (like time and date). To call the number, press  or the *centre key* .

return a call

- 1 Press  from the home screen to see a list of recently dialled calls.
- 2 Press left or right to scroll to the missed calls tab.
- 3 Scroll to the call you want to return, then press .

redial

- 1 Press  from the home screen to see a list of recently dialled calls.
- 2 Scroll to the entry you want to call, then press .

If you hear a **busy signal**, and you see **Call Failed**, you can press  or the **Retry** key to redial the number.



caller ID

Calling line identification (caller ID) shows the phone number for an incoming call on your display.



Your phone shows the caller's name and picture when they're stored in your contacts, or **Incoming Call** when caller ID information is not available.

You can set your phone to play a different ring tone for an entry stored in your contacts (see page 68).

To show or hide **your phone number** from the next person you call, enter the phone number and press **Options > Hide my ID/Show my ID**.

emergency calls

Your service provider programs one or more emergency phone numbers, such as 999 or 112, that you can call under any circumstances, even when your phone is locked or the SIM card is not inserted.

Note: Emergency numbers vary by country. Your phone's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

- 1 Press the keypad keys to dial the emergency number.
- 2 Press  to call the emergency number.

voicemail

Your network stores the voicemail messages you receive. To listen to your messages, press and hold  from the home screen.



Note: Your service provider may include additional information about using this feature.

When you **receive** a voicemail message, your phone shows the voicemail message indicator  and **New voicemail**. Press the **Call** key to listen to the message.

To **check** voicemail messages:

Find it: Press and hold  from the home screen, or press  >  **Control panel** > **Voicemail**

Your phone may prompt you to store your voicemail phone number. If you don't know your voicemail number, contact your service provider.

Note: You cannot store a **p** (pause), **w** (wait), or **n** (number) character in this number. If you want to store a voicemail number with these characters, create a contacts entry for it. Then you can use the entry to call your voicemail.

other features

advanced calling

features

international calls



If your phone service includes international dialling, press and hold **0** to insert your local international access code (indicated by +). Then, press the keypad keys to dial the country code and phone number.

hold a call

Press **Options** > **Hold** to put all active calls on hold.

features

mute a call

Press the **Mute** key (if available) or **Options** > **Mute** to put all active calls on mute.

features

call waiting



When you are on a call, you will hear an alert if you receive a second call.

Press  to answer the new call.

- To switch between calls, press the **Answer** key.
- To connect the calls in a conference call, press **Options > Link calls**.
- To end the call on hold, press **Options > End Call On Hold**.

To turn the call waiting feature on or off, press  >  **Control panel > Call Settings > Call waiting > Voice call waiting** or **Video call waiting > Mark** or **Unmark**.

features

conference call



During a call:

Dial the next number, press , and press **Options > Link calls**.

transfer a call



During a call:

Options > Transfer, dial transfer number, press .

call divert



Set up or cancel call divert:

 >  **Control panel > Call Settings > Call diverting**

Choose **Voice**, **Video**, **Fax**, or **Data** and then select which type of calls to forward and the phone number to forward the calls to.

restrict calls and messages

features

call barring



Restrict outgoing or incoming calls:

Restrict your voice or video calls to block all calls, international calls, or all calls except ones on your home network.

 >  **Control panel** > **Call Settings**
> **Call barring**

features

block calls and text messages

You can add phone numbers and contacts to your kill filter lists. The block list blocks all calls and text messages from a number or a contact.

To activate your block list:

 >  **Control panel** > **Kill filter** > **Block list tab**
> **Enable**

To add a number or contact to your block list:

 >  **Control panel** > **Kill filter** > **Block list tab**
> **Add**

features

allow calls and text messages

You can add phone numbers and contacts to your kill filter lists. The allow list only allows calls and text messages from a number or a contact.

To activate your allow list:

 >  **Control panel** > **Kill filter** > **Allow list** tab
> **Enable**

To add a number or contact to your allow list:

 >  **Control panel** > **Kill filter** > **Allow list** tab
> **New**

contacts

To store and call contacts entries, see page 25.

features

assign a speed dial key to a contacts entry

You can assign the keys  through  to contacts entries. Then, when you press and hold a key from the home screen, you can make a voice call, video call or send a message to the contact.

Press  >  **Control panel** > **Speed Dial** and assign a key.

use the speed dial key for a contacts entry

To **use a speed dial key** that you assigned to a contacts entry, just press and hold the key from the home screen.

features

edit or delete a contacts entry

Edit a number stored in the contacts:

 >  **Contacts**, scroll to the contacts entry, and press **Options**. You can select **Edit contact**, **Delete**, or other options.

Shortcut: In the contacts, press keypad keys to enter the first letters of an entry you want.

set ring tone for a contacts entry

Assign a ring tone to an entry:

 >  **Contacts** > *entry*, then press **Options** > **Edit contact** > **Ring tone** > *ring tone name*

set image for a contacts entry

Assign a photo or picture to show when you receive a call from an entry:

 >  **Contacts** > *entry*, then press **Options** > **Edit contact** > **Image** > *image name*

features

set category for a contacts entry

 >  **Contacts** > *entry*, then press **Options** > **Edit contact** > **Category** > *category name*

set category view for contacts

 >  **Contacts**, then press **Options** > **View category** > *category name*

You can show **All phone contacts** entries in a category you create.

create group mailing list

You can put several contacts entries in a group mailing list, then send a message to the list. To create a list:

 >  **Contacts**, then press **Options** > **New group**

features

sort contacts list

Set the order in which entries are listed:

 >  **Contacts**, then press **Options**
> **Settings** > **Sort by**

copy one contacts entry

Copy an entry from the phone to the SIM card, or from the SIM card to the phone contacts:

 >  **Contacts**, scroll to the entry, press **Options** > **Add to** > **SIM** or **Options** > **Copy to Contacts**

copy multiple contacts entries

Copy multiple contacts entries between the phone and SIM card:

 >  **Contacts**, then press **Options** > **Marking** > **Mark** and then **Options** > **Add to** > **SIM** or **Options** > **Copy to Contacts**

features

send contacts entry to another device

Send a contacts entry to another phone, computer, or device:

 >  **Contacts**, scroll to the entry, press **Options** > **Send As**

For more information about sending files via Bluetooth, see page 40.

messaging

For basic messaging features, see page 28.

Your phone reads message settings from the SIM card. If you put another SIM card in your phone, your phone sends and receives

messages for the phone number on the new card.

features

send voice message



 >  **Messaging** > **Create new message**
> **MMS** or > **Email** > **Options** > **Add**
> **Record sound**

Press the *centre key*  to start and stop recording.

Your phone inserts the voice recording into the message.

save a message as a template



 >  **Messaging** > **Create new message**
> **SMS** or **MMS** or **Email** > **Options**
> **Save as template**

features

read and manage messages



 >  **Messaging** > **Messages Inbox**

To **Reply**, **Forward**, or **Delete** a message, scroll to the message and press **Options**.

To open a message, press the *centre key* . Then, you can press **Options** to use or store any phone numbers, email addresses, Web sites, or files in the message.

read and manage email



 >  **Messaging** > **Email Inbox**

To **Reply**, **Forward**, or **Delete** an email, scroll to it and press **Options**.

To open an email, press the *centre key* . Then, you can press **Options** to use or store any phone numbers, email addresses, Web sites, or files in the message.

features

store message objects



Go to a multimedia message, or scroll to an object in a message, then press **Options** > **Store**.

features

edit email settings



You can edit the settings for your email connections. To use email, you need to store your email **Account name** and details.

 >  **Messaging**, then press **Options** > **Settings** > **Email accounts**

If you have more than one email account, select an account to edit.

Your phone shows a list of email settings. Here is where you store your email **Account name** and details.

Note: To create a new account, select **Options** > **New** in the **Email accounts** list. Your display shows a folder for each email account under  >  **Messaging** > **Email Inbox**.

device settings

features

location

Set time zone location:

 >  **Control panel** > **Device** > **Location**

language

Set menu language:

 >  **Control panel** > **Device** > **Select language**

master reset

Caution: Master reset can **erase all information you have entered** (including contacts and calendar entries) **and content you have downloaded** (including applications, photos, and sounds) stored in your phone's memory. After you erase the information, you cannot recover it.

 >  **Control panel** > **Device** > **Master Reset**

features

storage wizard

View and free up memory storage.

 >  **Control panel** > **Storage Wizard**

call times & costs

Network connection time is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing . This time includes busy signals and ringing.

The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, contact your service provider.

features	
call times Show call timers:  >  Control panel > Call Settings > Call Timers	
in-call timer Show time or cost information during a call:  >  Control panel > Call Settings > In Call Timer	
call charges Show call charges trackers:  >  Control panel > Storage Wizard	

data calls

To connect your phone with a USB cable, see page 46.

features	
send data Connect your phone to the device, then place the call through the device application.	 
receive data Connect your phone to the device, then answer the call through the device application.	 

features

set up Remote Sync



You can use the Internet to synchronise your phone's contacts and calendar entries with an email account on a Microsoft® Exchange 2003 Server.



You need to know the email account's **user name** and **password**, the Microsoft® Exchange **server name**, and the **user domain name**. Confirm that the **Mobility** option is enabled on the email account, and that **data service** is activated with your phone service provider.

features

use Remote Sync



Once you set up an Remote Sync partner, you can schedule your phone to synchronise with the account automatically.



To schedule synchronization, press 
>  **Connectivity** > **Remote sync**

network

features

network settings



See network information and adjust network settings:

 >  **Control panel** > **Network settings**

features

device update



Your service provider can send updated phone software over the air to your phone. When your phone receives a software update, you can choose to download it and install it later. To install a software update you downloaded:

 >  **Control panel** > **Device**
> **Device management**

Note: You may want to copy your data to your memory card (see page 80) or computer (see page 46) to ensure no data is lost.

calendar

features

add new calendar event

Your calendar can store events (**Appointment**, **Reminder**, **All day event** and **Anniversary**).

 >  **Calendar**, scroll to the day, press , press **Options** > **New**

see calendar event

See or edit event or task details:

 >  **Calendar**, scroll to the day, press 

event reminder

When an event reminder happens:

To see reminder details, press the **View** key.

To close the reminder, press the **Back** key.

features

send calendar event to another device

Send a calendar event to another phone, computer, or device:

 >  **Calendar**, scroll to the day, press , scroll to the event, press **Options** and select **Send As**.

tools

features

set alarm

 >  **Tools** > **Time** > **Wake up!** or
> **Lunchtime** or > **Early night** and then > **Options**
> **Edit**

features

turn off alarm

When an alarm happens:

To turn off the alarm, press the **Done** key or .

To set a delay, press the **Snooze** key.

Note: The **Snooze** key is available only if the phone is already powered on when the alarm sounds.

to do

 >  **Tools** > **To do**

calculator

 >  **Tools** > **Calculator**

jotter

 >  **Tools** > **Jotter**

file manager

 >  **Tools** > **File Manager**

security

features

SIM PIN

Note: Some service providers may require you to enter a subsidy unlock code. To enter your subsidy unlock code, enter ****057***, then enter the code provided by your service provider.

Caution: If you enter an incorrect PIN code three times before the correct code, your SIM card is disabled and your display shows **SIM Blocked**.

Lock or unlock the SIM card and/or change PIN1 and PIN2 codes:

 >  **Control panel** > **Security** > **SIM PIN**

pictures, videos and games

For basic information on the camera, see page 31.

features

view, delete, or manage multi media files

Manage photos, pictures, animations, videos, ring tones, sounds and music:

 >  **Media Studio** > **Media Gallery** > *tab*

To view a file, scroll to it in the list and press the *centre key* . To **delete** a file and for other options, press **Options**.

download objects from Web page



Download a picture, sound, or other object from a Web page:

 >  **Web**, go to the page that links to the file, scroll to the link, and select it.

features

download game or application

You can download a Java™ game or application the same way you download pictures or other objects:

 >  **Web**, go to the page that links to the file, scroll to the link, and select it.

install or uninstall

To install or uninstall an application, simply scroll to the application in  **Control panel** > **Install** or **Uninstall** and press the *centre key* .

start game or application

To start a Java™ game or application, simply scroll to the game or application in the main menu or  **Games** and press the *centre key* .

flight mode

features

flight mode

You can switch your phone to flight mode to prevent it from communicating with the network. This lets you play music, games or other applications while you are on an airplane, without interfering with airplane communications.

Note: Your phone cannot make Bluetooth™ connections when **Flight Mode** is on.

Press and hold  until the power menu is displayed and select **Flight Mode**.

advanced Bluetooth features

A device is *recognised* after you connect to it once (see page 41).

features	
change your phone's name	
 >  Connectivity > Bluetooth > My phone name tab	
make phone visible to other devices	
Allow a Bluetooth device to discover your phone:	
 >  Connectivity > Bluetooth > Visible to other devices	
enable power saving	
 >  Connectivity > Bluetooth > Enable power saving	

features	
connect to recognised device	
Connect your phone to a recognised device:	
 >  Connectivity > Bluetooth > My devices tab > <i>device name</i>	
disconnect a headset or handsfree device	
 >  Connectivity > Bluetooth > Enabled audio devices tab	
Scroll to the device name and press Options > Disconnect .	
switch to headset or handsfree device during call	
During a call, press Options > Audio > <i>device name</i> , to switch to a recognised headset or car kit.	

features

copy multimedia object to device



Scroll to the object, press **Options**

> **Send As** > **Bluetooth**, select the device name. You cannot copy some copyrighted files.

memory card

For basic information on the memory card, see page 23.

features

see and change memory card information

To see the files stored on your memory card and on your phone, open a file list, such as  >  **Tools** > **File Manager** press left or right key to select the phone or memory card tab and press up or down key to select a folder.

To copy or move a file from your phone to your memory card, highlight it in the list and press **Options** > **Edit** > **Copy to** or **Move to** > **Memory card** tab > folder > **Copy** or **Move**. You cannot copy or move some copyrighted files.

features

memory card name, available memory and other information

To see your **memory card name, available memory**, and other information about the card:

 >  **Control panel > Device > Storage Wizard**

rename memory card

 **Tools > File Manager > Memory card tab
> Options > Edit > Rename**

protected content

features

store and use protected content

If you try to play a copyrighted file, it might ask you to download a license. Some licenses only let you play a file for a certain number of times or days.

For example, a license may allow you to play the content of your download five times or use the content for three days before it expires.

You cannot send, copy, or change copyrighted files.

To download a file, see page 77. To activate downloaded copyrighted files, simply open the file.

Specific Absorption Rate Data

This model meets international guidelines for exposure to radio waves.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The ICNIRP SAR limit for mobile devices used by the general public is 2 W/kg and the highest SAR value for this device when tested at the ear was 1.13 W/kg.¹ As

mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this user guide.² In this case, the highest tested SAR value is 0.68 W/kg.¹

As SAR is measured utilising the device's highest transmitting power, the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum level required to reach the network.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a “hands-free” device to keep the mobile phone away from the head and body.

Additional Information can be found on the websites of the World Health Organization (<http://www.who.int/emf>) or Motorola, Inc. (<http://www.motorola.com/rfhealth>).

-
1. The tests are carried out in accordance with international guidelines for testing. The limit incorporates a substantial margin for safety to give additional protection for the public and to account for any variations in measurements. Additional related information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.
 2. Please see the **Safety and General Information** section about body worn operation.

Information from the World Health Organisation

Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF exposure by limiting the length of calls or by using handsfree devices to keep mobile phones away from your head and body.

Source: WHO Fact Sheet 193

Further information:

<http://www.who.int/peh-emf>

index

A

- accessory connector port 2
- accessories 20
- advanced calling 64
- alarm clock 76
- alarm clock off 76
- alert
 - turn off 55, 61
- allow calls and text messages 67
- animation 77
- answer a call 25, 60
- application 78

B

- battery 21
 - extending battery life 21
- battery charging 23

- battery cover 2
- battery indicator 52
- battery installation 22
- block calls and text messages 66
- Bluetooth 41
- bluetooth
 - change your phone's name 79
 - disconnect a headset or handsfree device 79
 - enable power saving 79
 - make phone visible to other devices 79

- Bluetooth connection
 - calendar entry, sending 76
 - contacts entries 69
 - description 40
 - indicator 41, 42
- Bluetooth indicator 51

C

- cables 46
- calculator 76
- calendar 75

- call
 - answering 25, 60
 - barring 66
 - divert 65
 - end 25
 - ending 25, 50
 - making 25
 - timers 73
 - waiting 65
- caller ID 62, 68
- calls indicator 52
- camcorder 34
- camera 31
- camera flash 2
- camera key 1
- camera on indicator 2
- categories 68
- centre key 1, 49
- centre select key 20
- clear/back key 1
- close 25
- computer 46

- conference call 65
- connect to 46
- connect to another device 41
- contacts 67
 - phone's memory 30
 - SIM card 30
- copy files 42
- copyrighted files 81
- costs, tracking 73

D

- data call 73
- date, setting 60
- device settings 72
- dial a phone number 25
- dialed calls 61
- display 3
- divert calls 65
- downloaded files
 - from Web pages 77
 - in messages 71

- DRM
 - store and use protected content 81

E

- earpiece volume 55
- email
 - reading and managing 70
 - settings 71
- emergency number 62
- end a call 25, 50
- end a video call 28
- end key 1, 25, 50
- event 75
- event reminder 75

F

- fax call 73
- file manager 76
- flight mode 78

G

games 78
group mailing list 68

H

handsfree speaker 56
hold a call 64
home key 49
Home screen 3, 20, 27, 50
 customize 59

I

in-call
 timers 73
Incoming Call message 62
install 78
international access code 64
internet 44, 78
iTAP text entry mode 53

J

Java applications 78
jotter 76

K

keypad
 lock and unlock 56

L

language 72
licenses 81
linking. See Bluetooth
 connection
location 72
lock
 SIM card 77
Low Battery message 52

M

main menu 3, 50
make a call 25
master reset 72
media gallery 36
media player 37
media player key 1
media studio 31
memory card 23
 information 80
 rename 81
memory card name
 available memory
 other information 81
memory card slot 2
menu 50
menu icons 50
menu key 1
message 70
message alerts 58
message indicator 29, 52
message template 70

messaging 28
MP3 sound files 37
multimedia message 70
music router 39
mute a call 64

N

navigation key 1, 20, 32, 35, 49
network indicator 51
network settings 74
number. See phone number
numeric entry mode 55

O

object exchange 42
open 25
optional accessory 20
optional feature 20

P

pairing. See Bluetooth connection
phone number 26
phone updates 48
photo 31, 77
picture 77
picture ID 62, 68
PIN code 24, 77
play videos 39
plug-ins 27, 50, 59
power key 24
primary camera lens 2
profiles 57

R

receive 73
received calls 61
recent calls 61
redial 62
Remote Sync 74

return a call 61
ring style 58
ringer ID 62, 68
ringer volume 55
roam indicator 51

S

screen brightness 58
screen saver 58
secondary camera lens 1
send key 1, 25
signal strength indicator 51
SIM access cover 2
SIM Blocked message 24, 77
SIM card 20, 24, 77
SIM installation 21
slider 25
soft keys 1, 50, 59
software update 75
sound mode indicator 52
sounds 58

- speed dial 67
- status indicators 51
- storage wizard 72
- store your number 26
- symbol entry mode 55
- synchronising 74

T

- tab scrolling 49
- tap text entry mode 54
- task 75
- telephone number. See
 phone number
- text entry 52
- text message 70
- theme 58
- themes 59
- time, setting 60
- timers 73
- to do 76

- tools 76
- transfer a call 65
- turn on/off 24

U

- uninstall 78
- unlock
 - SIM card 77
- USB cables 46

V

- video 34
- video call
 - ending 28
- video call key 1
- voice call ring tones 58
- voice message 70
- voice recorder 40
- voicemail 63

- voicemail message indicator
 52, 63
- volume 55, 58
- volume keys 1

W

- wallpaper 59
- web 44, 78
- WHO information 84

Y

- your phone number 26

