

Discover Your Phone



Philips continuously strives to improve its products. Therefore, Philips reserves the rights to revise this user guide or withdraw it at any time without prior notice. Philips provides this user guide “as is” and does not accept, except as required by applicable law, liability for any error, omission or discrepancy between this user guide and the product described. The device is meant to be connected to GSM/GPRS networks.

How to...

Switch the phone On/Off	Long press  .
Store Numbers in Phonebook	Enter the phone number and press  to save.
Make a call	Enter the phone number on the keypad and press  to dial.
Access the Call logs	Press  in idle mode. The Call logs displays the Missed Calls , Dialed Calls and Received Calls .
Make a IP call	Enter the phone number on the keypad and long press  to dial with IP prefix.
Answer a call	Press  when your phone rings.
End a call	Press  .
Reject a call	Press  when your phone rings.
Adjust the earpiece volume	Press the up or down volume keys during the call.
Adjust ringtone volume	Press the up or down volume keys in idle mode.

Access the <i>Phone Book</i> list	Press  in idle mode.
Access the <i>Main Menu</i>	Press  <i>Menu</i> in idle mode.
Switch to silent mode	Long press  key in idle mode.
Turn on the camera	Press  in idle mode.
Take photos	Press  or  with the camera active.
Access WAP	Long press  in idle mode.
Access <i>Shortcuts</i>	Press  in idle mode.
Open <i>Audio Player</i>	Press  in idle mode.
Access <i>Write Message</i>	Press  in idle mode.
Access <i>Tone Setup</i>	Press  in idle mode.
Access <i>Multimedia</i>	Long press  in idle mode.
Go to previous menu	Press  .
Quickly return to idle	Press  .

Softkeys

The left and right soft keys  and  located at the top of the keypad allow you to select the corresponding options that appear on the screen immediately above them, including during calls. The functions associated with these keys will vary according to the current content.

Main Menu

<i>Phone Book</i>	<i>Messages</i>	<i>Call History</i>
<i>Settings</i>	<i>Multimedia</i>	<i>File Manager</i>
<i>Fun & Games</i>	<i>User Profiles</i>	<i>Organizer</i>
<i>Services</i>	<i>Extra</i>	<i>Shortcuts</i>

The *Main Menu* gives you access to all the different features of your mobile phone presented in the form of a grid. The table above summarises the arrangement of the *Main Menu*.

Press  to access the *Main Menu* when in idle mode, then use the navigation key - which directions are represented in the present guide with the , ,  or  signs-to browse the icons and lists. Within lists, press  to access the options related to the selected item, press  *Back* to go back one level.

Table of contents

1. Getting Started	4	Copy the phone book	11
Insert the SIM card and Battery	4	Copy or move a phonebook entry	12
Switch on the phone	5	Delete contacts	12
Charge the battery	5	Caller Group	12
Shortcuts function	5	Extra Number	13
2. Calling	6	Settings	13
Make a call	6	5. Messages	14
Answer and end a call	6	SMS	14
Call handsfree	6	MMS	17
Options during a call	6	Chat	20
Adjust the earpiece volume	7	Broadcast Message	20
Quickcall	7	6. Call History	21
Make an emergency call	7	Missed Calls	21
Handle multiple calls	7	Dialed Calls	21
3. Text or number Entry	9	Received Calls	21
Function keys	9	Delete Call Log	21
Multitap ABC/abc input	9	Call Time	21
Smart ABC/abc input	10	Call Cost	22
Numeric input	10	SMS Counter	22
4. Phone Book	11	GPRS Counter	22
Search for a contact in phonebook	11	7. Settings	23
Manage contacts	11	Phone Setup	23
Store a phone number with a name	11	Call Setup	25

Network Setup	26
Security Setup	27
Restore Factory Settings	29
8. Multimedia	30
Camera	30
ImageViewer	31
Video Recorder	31
Video Player	32
Audio Player	32
Sound Recorder	33
Melody Composer	34
9. File Manager	35
10. Fun & Games	36
Games	36
Themes	36
Game Setting	36
11. User Profiles	37
12. Organizer	38
Calendar	38
To Do List	38
Alarm	39
World Clock	39

13. Services	40
STK	40
WAP	40
Data Account	41
14. Extra	42
Calculator	42
Units Converter	42
Currency Converter	42
Health	42
15. Shortcuts	43
Change items in Shortcuts	43
Icons & symbols	44
Precautions	45
Troubleshooting	49
Philips Authentic Accessories	51
Specific Absorption Rate	
Information	52
Limited warranty	53

I. Getting Started

Please read the safety instructions in the “Precautions” section before use.


To use your phone, you must insert a valid SIM card supplied by a GSM operator or retailer. The SIM card contains your subscription information, your mobile telephone number, and a memory in which you can store phone numbers and messages (for more information, see “Phone Book”).

Insert the SIM card and Battery

Follow the steps below to insert your new SIM card. Remember to switch off your mobile phone before removing the back cover.


Remove the battery

To insert the SIM card, you must first remove the battery. Press the button on the back and slide the back cover downwards to remove it. Hold the latch to lift up the battery.




Insert the SIM card

Place the SIM card in the space provided, making sure that the clipped corner of the card is in correct corner and that the gold contacts are facing downwards.



Place the battery back to its slot, with the gold contacts facing downwards until it snaps into place.



Replace the back cover by sliding down into its slots until it stops.

Switch on the phone


To switch on the phone, long-press  key. Enter the PIN code if required. A PIN code is a 4- to 8-digit secret code for your SIM card. It is preconfigured and communicated to you by your operator or retailer. For more information on PIN codes, see “Security Setup” on page 27.

If you enter an incorrect PIN code three times, your SIM card will be locked. To unlock it, you must request the PUK code from your operator.

Charge the battery

Your phone is powered by a rechargeable battery. A new battery is partially charged and a sound alert will warn you when the battery reaches low.

Once the battery is back in place you can charge the phone. Plug in the connector as shown below. Then plug the other end into a main AC power socket.



The battery symbol indicates the state of charge. During charging, the charge indicators will scroll. When all the scroll bars are steady, the battery is fully charged. You can then disconnect the charger. Keeping the charger plugged to the mobile when the battery is fully charged will not damage the battery. The only way to turn off the charger is to unplug it, so use an easily accessible AC power socket.

Shortcuts function

Your phone provides ten fast ingoing function items. You can modify them according to demands. For more info see “Shortcuts” on page 43.

2. Calling

Make a call

From the idle screen

1. In idle mode, enter the phone number using the keypad. To correct an error, press .
2. Press  to dial.
3. Press  to hang up.

For an international call, shortly press  twice to enter the “+” sign for the international prefix.

Using the phonebook

1. Press  in idle mode.
2. Select a contact in the list and press , the selected number is dialled. To select a different number, press ▲ or ▼ (see “Phone Book” for more information).
3. Press  to hang up.

Answer and end a call

When receiving a call, the number of the caller may be displayed, depending on whether or not the person calling has chosen to display his or her ID. If the number is stored in the selected phonebook, then the corresponding name is displayed instead of the number.

- Answer the call: press .
- Reject the call: press  (or long press the down volume key). If you have activated [Call Divert](#), the call is diverted to a number or voice mail.
- Hang up: press .

The phone will not ring if in silent mode.

If you have selected [Any Key](#), you can accept a call by pressing any key except  and .

Call handsfree

For your own comfort and safety, ensure you move the phone away from your ear when calling handsfree, especially when increasing the volume.

Press  [H-Free](#) during a call to activate handsfree. To cancel handsfree you can press  [H-Held](#) again to deactivate it.

Options during a call

During a call, press  [Option](#) to access the following options.

Mute (On/Off)

This option allows you to mute or unmute the microphone so that your caller cannot hear you.

Sound Recorder

In most countries, recording telephone conversation is subject to legislation. We advise you to notify the caller if you intend to record your conversation and only do so if they agree.

To record a conversation during a call, select **Sound Recorder** and press . While recording you can press **Pause/Cont.** To stop recording, press , enter the name and press to save.

Other options during a call

Press **Option** to be able to perform the following tasks while a call is ongoing:

Access **Phone Book** to search entry, select **End** to hang up, send or read messages.

Adjust the earpiece volume

During a call, press the up or down volume key to increase or decrease the volume.

Quickcall

Quickcall of SIM phonebook

If you have the serial number (for example: 5) of the contact you want to dial in SIM, you can enter 5# in idle mode. The phone will show the corresponding name stored in SIM, press to call the number.

Quickcall of call logs

In idle mode, press to access **Call Logs** list. Select a number and press to dial the number.

Make an emergency call

Without SIM card

Switch on your phone, the screen shows the information to remind you to insert SIM, press **SOS** to dial emergency call.

With SIM card

In idle mode, enter 112, then press to dial.

Handle multiple calls

The ability to handle two or more calls at one time and to make conference calls is dependent on your operator and/or subscription.

Make a second call

You can make a second call during an active call or with a call on hold. While on the phone, dial a number (or select a contact in the phonebook) and press . The first call is put on hold and the second number is dialled. You can then press  to access the following options.

- **Swap** to toggle between calls.
- **Conference** to introduce the caller into a conference call.

Answer a second call

When you receive a second call while being already in communication, the phone emits a beep alert and the screen displays the info of the call. You can then:

Press  To answer the call (the first one is put on hold).

Press  or  To reject the call.

Press  **Option** To open the options list. You can select **End** to end the current call, then answer the incoming call.

To receive a second call, you must have deactivated the Call Divert and activated Call Waiting.

3. Text or number Entry

You can select the input methods to enter English letters, words, symbols and numbers. Icons appearing on the screen indicated the active text mode.

Function keys

-  To delete the characters or end the editing mode.
-  To move the cursor, select letter, monogram, word or symbol from the list, scroll down the list.
-  To return to idle mode.
-  To select the outstanding word from the list or enter option menu.
-  To enter symbols.
-  To select input method.

Multitap ABC/abc input

To select multitap input method, press  until “ABC” or “abc” appear on the screen. This method requires multiple key presses to reach the desired character: the letter “h” is the second letter on the key

, so you must press it twice to enter “h”. If the letter you enter and the one you just enter are on the same key, just wait for a few seconds for the cursor to appear.

You can press key  to insert a space in multitap ABC/abc input.

Example: how to enter the word “home”:

Press key ,  (GHI) , ,  (MNO),  (MNO), ,  (DEF).

Letters, numbers and symbols are located on each key as shown in the table below:

Key	Characters in the order displayed
	. , - ? ! , @ : # \$ / _ 1
	a b c 2
	d e f 3
	g h i 4
	j k l 5
	m n o 6
	p q r s 7
	t u v 8
	w x y z 9
	0

Smart ABC/abc input

This is an intelligent editing mode for messages including a comprehensive dictionary. It allows you to enter text more quickly. To select Smart input method, press  until “eZi ABC” or “eZi abc” appear on the screen. Press only once on the key corresponding to each letter needed to spell a word: keystrokes input are analyzed and the word suggested is displayed. If several words are available according to the keys used, you can press ▲ or ▼ to choose from those proposed by the Smart ABC/abc built-in dictionary (see example below).

Example: how to enter the word “home”:

1. Press key , , ,  in turn.
The screen displays word: *good*.
2. Press ▼ to scroll to and select *home*.
3. Press  to confirm the word *home*.

Numeric input

With this method you can press the corresponding keys to enter numbers.

4. Phone Book

Contacts are stored in one of the two available phonebooks: in your SIM card (number of entries depending on capacity) or in your phone (up to 200 names). When entering new names, they will only be added to the phonebook you have selected.

Search for a contact in phonebook

Search Entry option

1. Access [Phone Book](#) in idle mode, select [Search Entry](#).
2. Enter a name, then press  [Option](#), press .

Phone Book List

Press  in idle mode to access phone book list, press the key for the letter that you want to go to in the list (e.g. press  key three times to access the letter Y). The first record starting with this letter is selected in the list.

Manage contacts

Select a name in phone book list and press  [Option](#) to access the following options.

[IP Dial](#)
[View](#)
[Delete](#)
[Move](#)

[Send SMS](#)
[Edit](#)
[Copy](#)
[Duplicate](#)

Store a phone number with a name

1. Access [Phone Book](#) in idle mode, then select [Add New Entry](#). Select the storage and press .
2. If you select [To SIM](#), you need to enter [Name](#) and [Number](#). After you finish entering, press  and enter the number, then press .
3. If you select [To Phone](#), the operating steps is the same as above. You can enter [Name](#), [Number](#), [Home Number](#), [Company Name](#), [Email Address](#), [Office Number](#), [Fax Number](#) and select [Associate Picture](#), [Associate Sound](#) and [Caller Group](#). Press  to confirm. Your phone will inform you that the name has been saved.

Copy the phone book

You can copy all contacts in phone to SIM card and vice versa.

1. Access [Phone Book](#) in idle mode, select [Copy All](#), then press .
2. Select [From SIM](#) or [From Phone](#), press .

3. The suggestive message displays on the screen.
Select **Yes/No** to confirm/cancel the operation.

Copy or move a phonebook entry

1. Select a contact in **Phone Book List**, press  **Option**.
2. Select **Copy/ Move/ Duplicate**, then press .

Copy To copy the contact to another memory.

Move To move the contact to another memory.

Duplicate To copy the contact to the same memory.

Delete contacts

Delete contacts one by one

Method A:

1. Access **Phone Book** in idle mode, select **Delete All**.
2. Select **One By One**, then select the contacts you want to delete in phone book list and press .

Method B:

1. Access **Phone Book List** in idle mode.
2. Select the entry you want to delete and press , then select **Delete** and press .

Delete all

1. Access **Phone Book** in idle mode.
2. Select **Delete All**. You need to select **From SIM** or **From Phone**.

Caller Group

This option allows you to group the contacts in phonebook in order to be convenient for users.

1. Access **Phone Book** in idle mode, select **Caller Group**.
2. Select a group and press .
3. Select the corresponding option to modify.

You can set the following options:

Ring type To set ring tone for the call from the contacts in the group.

Alert type To set alert type for the call from the contacts in the group.

Picture To set the picture displaying on the screen when a call is coming from the contacts in the group.

Group name To set the name of the group.

Member List To add or delete members of the group.

Extra Number

Owner Number

The **Owner Number** item allows you to store your own phone number. We advise that you enter your mobile number as well as any other relevant information.

Although all its fields can be empty, the Owner Number item can not be deleted.

Service Dial Number

This is a kind of service supplied by network provider. For corresponding function, please ask network provider.

SOS Number

The SOS number will call the emergency services number in your country. In most cases, you can call this number even if you have not yet inserted a SIM card or entered your PIN.

In Europe the standard emergency number is 112, in the UK it is 999.

Settings

Memory Status

Select this menu to display the total number of contacts you have saved in each phonebook, out of the total number available.

Preferred Storage

Select this menu to set default storage to save contacts.

Fields

Select this menu to set the items displayed in phone memory.

5. Messages

SMS

This menu allows you to send text messages using the Short Messaging Service (SMS) and to manage the messages you send and receive.

Write Message

To compose and send an SMS, follow the steps detailed below:

1. Select **Write Message**, enter your text and press  to access the next options:

Done	To finish the message.
Use Template	To select a pre-configured message.
Insert Object	To add picture, animation, melody and sound to your message.
Format Text	To set Text Style , Alignment and the alignment of New Paragraph .
Input Method	To select input method.

2. Select **Done**, then press  to access the next options:

Send Only	To send the message.
Save and Send	To save the message to outbox and then send the message.

Save	To save the message to outbox.
Send To Many	To send the message to many persons.
Send By Group	To send the message to all contacts in a caller group.

3. Enter Number: press , enter a number or select a contact and press .

When you send message via SMS network, your phone possibly shows "Sent". It shows that the message has been sent to SMS center, which you have set in SIM card, but it does not show that the message has been sent to destination.

Inbox

This menu allows you to read SMS messages you have received. The messages are displayed in a list. When a message is displayed, press  to read it, then press  **Option** to access the menu options listed below.

Reply	To reply to the sender.
Forward	To forward the selected message.
Chat	To chat with the sender.
Edit	To edit, modify and resend the SMS to someone.

<i>Delete</i>	To delete the selected message.
<i>Delete All</i>	To delete all messages in inbox.
<i>Use Number</i>	To extract the number of the sender or displayed in the message, save the number in SIM card or phone, dial the number.
<i>Save Objects</i>	To store multimedia items such as images in the message into your phone.
<i>SMS Copy to Phone/ SIM</i>	To copy the selected message stored in SIM/phone to phone/SIM.
<i>SMS Move to Phone/ SIM</i>	To move the selected message stored in SIM/phone to phone/SIM.
<i>SMS Copy All</i>	To copy all messages stored in SIM/ phone to phone/SIM.
<i>SMS Move All</i>	To move all messages stored in SIM/phone to phone/SIM.

Outbox

Only when you send the message by selecting *Save and Send* or *Save* can the message be stored in outbox.

When a message is displayed, press  to read it, then press  *Option* to access the menu options listed below.

<i>Send</i>	To send the selected message.
<i>Edit</i>	To send directly or re-edit then send to other.
<i>Delete</i>	To delete the selected message.
<i>Delete All</i>	Delete all messages in outbox.
<i>Use Number</i>	To extract the number of the recipient or displayed in the message, save the number in SIM card or phone, dial the number.
<i>SMS Copy to Phone/SIM</i>	To copy the selected message stored in SIM/phone to phone/SIM.
<i>SMS Move to Phone/SIM</i>	To move the selected message stored in SIM/phone to phone/SIM.
<i>SMS Copy All</i>	To copy all messages stored in SIM/ phone to phone/SIM.
<i>SMS Move All</i>	To move all messages stored in SIM/ phone to phone/SIM.

Template

This menu allows you to predefine up to ten messages that you use most frequently. Select a message and press  to access the next options.

Edit To write a new message or edit the selected predefined message.

Erase To delete the selected predefined message.

Message Settings

This menu allows you to configure the SMS settings. The options are:

Profile Setting

SC Address To select your default SMS centre. If not available on your SIM card, you must enter your SMS centre number.

Valid Period To select the length of time your messages are to be stored in the SMS centre. This is useful when the recipient is not connected to the network (and thus cannot receive your message immediately). This feature is subscription dependent.

Message Type To select the type of the message. This option is network dependent.

Profile Name To edit the name of the profile.

Common Setting

Delivery Report When **On**, this option will inform you via SMS whether your own SMS was received or not. This feature is subscription dependent.

Reply Path When **On**, this option allows you to transmit the number of your SMS message centre together with the message. The recipient can then reply using your own SMS centre and not theirs. This speeds up the rate of transmission. This feature is subscription dependent.

Memory Status

This option is used to display the storage status of the messages saved in SIM card and phone.

Preferred Storage

This option allows you to select preferred storage to save the received messages.

Pref. Bearer

This option allows you to set the preferred transmission mode. For further detail, please contact with network provider.

MMS

Your mobile phone can also send and receive MMS (Multimedia Messaging Service) messages. With MMS you can send messages that contain pictures, sounds and text.

When sending MMS messages, your recipient must also have an MMS-enabled phone in order to be able to view your message.

Write Message

To compose and send an MMS, follow the steps detailed below:

1. Select **Write Message**, enter the following message.

To To set number or E-mail of the recipient.

Cc To set number or E-mail of the recipient to be sent the message at the same time.

Bcc To set number or E-mail of the recipient to be sent the message in secret.

Subject To set the subject of the message.

Edit content To edit the content of the message. You can add text, image, sound and attachment.

2. Press  to finish editing and access the next options.

Send Only To send the message.

Save and Send To save the message to outbox and then send the message.

Save to Drafts To save the message to drafts for sending later.

Send Options To set the sending option.

Exit To exit from editing mode. A suggestive message will be displayed to ask you whether to save the message.

Inbox

This menu allows you to read MMS messages you have received. Select a message, then press  to access the following options.

<i>View</i>	To view the message, you can press  to access option menu and can select <i>Play/Save image As/Save audio As</i> to play or save the multimedia items.
<i>Properties</i>	To view the sender, subject, date and size.
<i>Reply</i>	To reply to the sender.
<i>Reply to all</i>	To reply to sender and all in To and Cc columns.
<i>Forward</i>	To send the message to others.
<i>Delete</i>	To delete the message.
<i>Delete All</i>	To delete all messages in inbox.
<i>Use Number</i>	To extract the number in the message.

Outbox

This menu is used to save all message by selecting *Save and Send*. You can do the following operation:

<i>View</i>	To view the message.
<i>Properties</i>	To view the recipient, subject, date and size.
<i>Send to Others/ Resend</i>	To send the message to others. If the message has not been sent successfully, it will show Resend.
<i>Delete</i>	To delete the message.
<i>Delete All</i>	To delete all messages in outbox.
<i>Use Number</i>	To extract the number in the message.

Drafts

Lists all messages by selecting *Save to Drafts*. You can do the following operation:

<i>View</i>	To view the message.
<i>Properties</i>	To view the recipient, subject, date and size.
<i>Send</i>	To send the message.
<i>Edit message</i>	To edit the message.

Delete	To delete the message.
Delete All	To delete all messages in drafts.
Use Number	To extract the number in the message.

If you have not set the recipient for the message in drafts, the Send option will not display in option menu.

Templates

Lists five frequently used messages. You can use these messages when writing a new message. Select a message and press  to access the following options.

View	To view the content of the message.
Properties	To view sender, Cc, subject and size.
Write Message	To take the template as a new message. You can edit it.

Message Settings

This menu allows you to set MMS configuration for sending or receiving messages.

Sending	To set Validity period , Delivery report , Read report , Priority , Slide Timing and Delivery time options for sending an MMS.
Receiving	To set Home network , Roaming , Read Report and Delivery Report options for receiving an MMS.
Filters	To set Anonymous , Max Size and Advertisement options.
Edit Profile	To set the network configuration. You can contact with network provider.
Auto Signature	This option can be set On or Off and allows you to automatically sign your name or other content in your message.
Memory Status	To view the storage status of MMS.

Chat

This menu allows you to chat with your contact by SMS.

1. Select a chat room, then press .
2. Select *Chat Room Info*, enter *My Nickname* and *Destination Number*, then press .
3. Select *Start New*, enter the message and send it to start chatting.

Voice Mail Server

This menu is used to set mail server number and listen to voice mail. When you receive voice mail, your provider will send a message to your phone.

You can set two groups of voice mail server number. Network service provider supplies the number.

Select an item, then  to access the following options.

Edit To edit voice mail server number.

Connect to Voice To listen to voice mail.

You can quickly access voice mail server by long pressing  key in idle mode.

Broadcast Message

This is a kind of public messages broadcasted to a group of mobile users. The message are broadcasted on numbered channels. Generally speaking each broadcast channel can transmit one kind message. Please contact with the network provider, they will supply usable channel and info list.

Receive Mode

This menu is used to set the function of broadcast message. When *On*, you can receive the broadcast message. When *Off*, you can not receive messages.

Read Message

To read broadcast message after activating receive mode.

Languages

To set the language of the message that can be received.

Channel Setting

Press  to set channel, you can select *Select*, *Add*, *Edit* or *Delete*.

6. Call History

This menu provides you with the list of outgoing and incoming calls, attempts at auto redialling and call details. The different types of calls ([Dialed Calls](#), [Missed Calls](#) and [Received Calls](#)) are represented by different icons. They are displayed in chronological order with the most recent on top. If the correspondent is listed stored in your contacts, the corresponding name is displayed.

Missed Calls

This menu allows you to view the lately unanswered calls. You can view the date, time and times of each missed calls.

Select an item and press  to view date, time, times and number. Press  [Option](#) to access the following options.

- | | |
|-----------------------------------|---|
| Save to Phonebook | Save the number. |
| Delete | Delete the number. |
| Dial | Dial the number. |
| Edit | Edit the number and can save it to phonebook. |

Dialed Calls

This menu allows you to view the lately dialed calls including attempt or successful talk.

Received Calls

This menu allows you to view the calls received lately.

Delete Call Log

This menu allows you to delete [Missed Calls](#), [Dialed Calls](#), [Received Calls](#) or [Delete All](#).

Call Time

This menu allows you to view [Total Sent](#), [Total Received](#) and [Last Call Time](#) (format: hour, minute, second). You can use [Reset All Time](#) to reset all call time.

The actual time invoiced for calls and service by your service provider may vary, depending on network features, rounding-off for billing purpose, tax and so forth.

Call Cost

Last Call Cost

This menu is used to display the cost of last call.

Total Cost

To display the total cost of all calls since the cost counter was last reset. If the total cost exceeds the maximum cost set in [Max Cost](#) option, you will no longer be able to make any calls until you reset the counter.

Reset Cost

To reset the cost counter, you must enter your PIN2 code first.

Max Cost

To set maximum cost for your calls (need to enter PIN2).

Price Per Unit

Allows you to set one unit for the cost, this price per unit is used for calculating the cost of your calls (need to enter PIN2).

SMS Counter

This menu is used to display the amount of messages that have been sent and received.

GPRS Counter

This menu is used to count the amount of data sent and received via GPRS. You can also reset the counter. The unit is Byte.

7. Settings

This menu allows you to change the settings related to each available option (time and date, security, call divert, etc.) and to customise your phone.

Phone Setup

Time and Date

Allows you to set the time and date using the keypad or with the navigation keys. You can set:

Set Home City Select the city you are in.

Set Time/Date Enter the figure using keypad or navigation keys.

Set Format Include **Time Format** and **Date Format**.

Schedule Power On/Off

This menu allows you to set the time to power on or off your phone automatically. Select an item and press  to access the following options.

Status You can select **Enable** (the setting is valid) or **Disable** (the setting is invalid).

Power On/Off Select whether to power on or off.

Time Enter the figure to set the time.

Language

This menu allows you to select a language for all menu texts. Use **▲** or **▼** to browse the list and select a language by pressing .

Preferred Input Methods

This menu allows you to set the default input method.

Display Characteristic

This menu allows you to set the options displayed in idle mode.

Wallpaper

Set the background image of main screen displayed in idle mode.

System Select the predefined image.

User Define Select the downloaded image.

Screen Saver

Set the image displayed after being in idle mode for a stated time.

Setting Set **Status** (**On/Off**) and **Waiting** (set the time for the appearance of the screen saver image).

Select Select the image for screen saver.

Power On Display

Allows you to set the image displayed when power on.

System Select the predefined image.

User Define Select the downloaded image.

Power Off Display

Allows you to set the image displayed when power off.

System Select the predefined image.

User Define Select the downloaded image.

Show Date and Time

Allows you to set whether to display date and time in idle mode.

Show Owner Number

Allows you to set whether to display owner number in idle mode.

Contrast

This menu allows you to adjust the contrast of main screen.

You can press ◀ or ▶ to adjust contrast.

Sound Effect

Equalizer

This menu is used to set audio frequency in playing music.

Greeting Text

This menu allows you to set individuation greeting text and it is displayed when you switch your phone on. You need to set the following option, then press  **Done**.

Status Activate/Deactivate the display of greeting text.

Greeting Text Set the content of greeting text.

Speed Dial

This menu allows you to rapidly dial the number stored in phonebook. You can set up to eight speed dial numbers and need to set **Enable Speed Dial** and **Set Number**.

Dedicated key

In idle mode, you can quickly access preset functions by pressing the navigation keys. This menu allows you to modify the preset functions according to demands.

Auto update of date and time

This menu is used to update the time in your phone automatically.

Call Setup

Call ID

With the support of the network you can select [Set By Network](#), [Hide ID](#) or [Send ID](#) to show or hide your identity to your correspondent.

Call Waiting

This option is used to [Activate](#) or [Deactivate](#) call waiting. When this option is active, you hear a beep if someone tries to call you while already on a call. If this option is inactive, your phone will not inform you and the one tries to call you will hear the busy tone or the call will be diverted to another phone (needs to set [Divert If Busy](#)). Select [Query Status](#) to find out the status of this option.

Call Divert

To divert incoming calls to your mailbox or to a number (whether in your contacts or not).

[Divert All Voice Calls](#) Will divert all the incoming calls. If you select this option, you will not receive any calls until you deactivate it.

[Divert If Busy](#) Divert when you are on a call.

[Divert If No Answer](#) Divert when you do not answer the call.

[Divert If Unreachable](#) Divert when your phone is switched off or out of service area.

[Divert All Data Calls](#) Divert all data call.

[Cancel All Divert](#) Cancel all divert options.

Select [Activate](#) and enter the number. Select [Query Status](#) to find out the status of corresponding diverting options.

Before activating this option, you must enter your voice mailbox number. This feature is subscription dependent.

Call Barring

Allows you to limit the use of your phone to specific calls. This can be applied to [Outgoing Calls](#) ([All Calls](#), [International Calls](#) or [International Except Home](#)) and/or to [Incoming Calls](#) ([All Calls](#) or [When Roaming](#)). In both cases, the [Cancel All](#) option applies to all calls at once. [Change Barring PW](#) is used to change the call barring password. [Query Status](#) allows you to know whether a type of call is barred or not.

This feature is network dependent and requires a specific call barring password supplied by your service provider.

Line Switching

Some SIM card allow you use two subscriber numbers (network service). This function is available only when the SIM card supports it.

To switch line you can press  to select a line.

Call Time Reminder

This menu allows you to set whether to beep according to the call time. You can select **Off** (not beep), **Single** (select from 1 to 3000 seconds as the beeping time) or **Periodic** (select from 30 to 60 seconds as periodic beeping time, your phone will beep in this periodic time every minute).

Call Time Display

This menu is used to set whether to display the call time during a call.

Auto Redial

If the call you make is not answered, your phone will automatically redial this number at intervals. To end redialing you can press  or  to  cancel.

Closed User Group

This function is network dependent. Only after your phone is set by network provider can you use this option. It is mainly used to restrict your correspondent. If this option is active, you can only talk to users in the group.

IP Number

To set IP number in order to make IP calls. This function is subscription and network dependent. Contact your operator for configuration parameters.

Black List

This menu allows you to reject the incoming calls in your black list.

Mode Allows you to set this option **On** or **Off**. If you select **On**, your phone will refuse all calls from the persons in black list.

Black List Number Set the numbers to be refused.

Network Setup

Network Selection

This menu allows you to select the service network (suggest you to select **Automatic**).

Automatic You phone will automatically select and register an usable network.

Manual Provides you with a list of the network available in the area. Select the network you want to register with and press  to confirm.

You can select a network other than your home network only if it has a valid roaming agreement with your home network. If you change the network, some problems may arise during the operation of your phone.

Preferred Networks

Allows you to build a network list in order of preference. Once defined, the phone will try to register on the network, according to your preferences.

Band Selection

This menu is used to select the band of network for call.

GPRS Connection

This menu is used to set the connection mode. You can select *Always* or *When Needed*.

Security Setup

SIM Lock

When the SIM Lock is active, you must enter the PIN code (PIN code is supplied by the provider with the SIM card). If the code you enter is incorrect for three times, you need to enter PUK code (PIN unlocking code). The PUK code is used to unlock or change the

locked PIN code. If the PUK code is not offered or lost, you can contact with the network provider.

Enter PIN code, then press . If the status of *SIM Lock* is *Off*, then its status will be *On*, otherwise the status will be *Off*.

Phone Lock

This menu is used to set password for your phone and the default status is *Off*. Once you set *Phone Lock*, you must enter password each time you switch on your phone.

Enter the password, then press . If the status of *Phone Lock* is *Off*, then its status will be *On*, otherwise the status will be *Off*.

Auto Keypad Lock

This menu is used to lock your keypad automatically. Select the interval of locking the keypad, then press  to confirm.

To unlock the keypad you can press  *Unlock* in idle mode. Press  when the screen shows “*Press  to Unlock Keypad*”.

Fixed Dial

This menu is used to restrict the outgoing calls. You need to enter PIN2 code. The network provider supplies PIN2 code.

Mode

It has two modes: **On** (you can dial any number) and **Off** (you can only dial the numbers stored in **Fixed Dial List**).

To access the fixed dial list. You can press  **Add**, then enter the name and phone number, press  and enter PIN2 code, then press .

Fixed Dial List

To access the fixed dial list. You can press  **Add**, then enter the name and phone number, press  and enter PIN2 code, then press .

Not all SIM cards have a PIN2. If your SIM card has not, this option is not usable.

Barred Dial

This menu allows you to restrict different outgoing calls.

With the support of your SIM card, you can activate or deactivate this function.

Change Password

This menu is used to change **PIN** code, **PIN2** code and **Phone Lock Password**.

PIN

It is supplied with the SIM card. The service provider supplies the default value.

If you enter an incorrect PIN code three times in succession, the PIN code of SIM will lock automatically and you will be asked to enter PUK code to unlock. You can get the code from the service provider. If you enter an incorrect PUK code ten times in succession, the SIM card will be locked forever.

PIN2

It is used to access some special network functions such as charging or fixed dial etc. If you enter an incorrect PIN2 code three times in succession, the PIN2 code of SIM will be locked. To unlock PIN2 code you need to ask the service provider for PUK2 code. If you enter an incorrect PUK2 code ten times in succession, the functions related to PIN2 code can not be used anymore.

Phone Lock Password

It protects your phone against unauthorized use by other people. The password is necessary when you restore factory settings. The initial phone lock password is 1122.

Restore Factory Settings

This menu is used to reset your phone to its factory configuration.

Enter the password, then press  to confirm.

Once you enter the right password (the password is the same as Phone Lock Password, its default value is 1122), your phone will return to its factory configuration.

8. Multimedia

Camera


Your phone features a built-in digital camera. You can take pictures, store them in your phone or transfer them to your PC via cable line, use them as wallpaper or send them to your friends via MMS.

Activate the camera

Select **Camera** and press  or press left side softkey in idle mode to activate the camera.

When the camera is active, the preview screen is displayed.

The table below details the operations of the various keys in camera mode.

	Zoom in / out
	Increase / decrease exposure compensation
 or 	Take a picture
	Exit Camera mode and return to home screen
	Access the Option menu
	Return to previous screen



Set **White Balance**



Effect Setting



Set **Delay Timer**



Activate / deactivate **Cont Shot**



Set **Image Quality**



Set **Image Size**

Take a picture

1. Frame your picture and press  or  to take the picture.
2. Once the picture is taken, a view screen is displayed. Press  to save the picture, or press  to ignore the picture.

Option menu in Camera

This section describes in detail the **Option** menu in **Camera**.

To ImageViewer Access **ImageViewer**.
Set **White Balance**, **Shutter Sound**.

Camera Setting **Exposure** and **Banding**.

Image Setting Set **Image Size** and **Image Quality**.

Effect Setting Set special effect for the picture.

Add Frame	Add a frame to the picture. Some frames are usable only to some special size.
Cont Shot	Take many pictures continuously.
Delay Timer	Set delay time. When you press the function key to take a picture, the picture will be taken in the time you set.
Restore Default	Reset the camera settings to their default values.

ImageViewer

When you take a picture and save it, the file is stored in **ImageViewer** folder. When you open the menu, your photos are displayed as thumbnails. Use the ▲ and ▼ navigation keys to move through the list. Press  **Option** to access the following options.

View	Display the picture.
View Mode	Set browse style as List Mode or Matrix Mode .
Forward	Apply the picture to other options.
Rename	Rename the picture.

Delete	Delete the picture.
Delete All Files	Delete all pictures.
Sort	Allows you to sort all pictures separately by name, type, time or size.

Video Recorder

This menu is used to record a video, and the format of the video is AVI.

Activate the Video Recorder

Select **Video Recorder** and press  to activate video recorder.

The table below details the operations of the various keys in video recording mode.

▲ ▼	Zoom in / out
◀ ▶	Increase / decrease exposure compensation
 or 	Start / Stop recording
	Exit video recording mode and return to home screen
	Access the Option menu

	Return to previous screen
	Effect Setting
	Set White Balance

Recording a video

Frame your picture and press  or  to start recording. While recording you can press  [Pause/Resume](#). Press ,  or  to stop recording and save the video.

The option menu in Video Recorder

This section describes in detail the [Option](#) menu in [Video Recorder](#).

To Player	Access Video Player.
CamCoder Setting	Set White Balance , EV , Frequency and Video Quality .
Effect Setting	Set special effect for the video.
Restore Default	Reset the recorder settings to their default values.

Video Player

You can use this option to view the videos you record or prestored in your phone. Select a video, then press  [Option](#) to access the following options.

Play	Play the video.
Rename	Rename the video.
Delete	Delete the video.
Delete All Files	Delete all videos.
Sort	Allows you to sort all videos separately by name, type, time or size.

Audio Player

This menu allows you to play music. The music stored in player folder can be automatically detected and added to the play list. You can dial or answer a call during the music and the player will pause.

Activate Audio Player

Press  in idle mode or select [Audio Player](#).

The table below lists the operations of the various keys in playing music.

- ▲ Play/Pause
- ▼ Stop
- ◀ Skip to the previous music
- ▶ Skip to the next music
- Volume keys Adjust the volume of the music
-  Exit **Audio Player** and return to home screen
-  Access **Play List**, press  to access **Option** menu.
-  Return to previous screen

Option menu in Audio Player

- Play** Play the music.
- Details** Display the info of the music.
- Add To Rings** Set the music as ring tone.
- Refresh List** Refresh the play list in Audio Player.
- Settings** Include **List Auto Gen**, **Repeat** (Music repeat mode in playing), **Shuffle** (Playing order), **Background Play** (Whether to continue playing when you exit from audio player) and **Equalizer**.

Add/Delete music

1. Switch off your phone.
2. Connect your phone with computer by USB cable line. After the computer identify your phone, you can copy the music to your phone or delete music in your phone.

All music to play must be stored in root directory. This is an appointed location and you are not allowed to change.

Sound Recorder

This menu allows you to record sound. You can also play, rename and delete the memo you record. Select a memo then press  or press  directly to access **Option** menu.

- Record** Press  to start recording, press  to **Pause** or **Cont.** recording. To finish recording, press  **Stop**. Enter the name then press .
- Settings** Set the format of the memo.
- Play** Play the memo.
- Append** Append sound to the memo.
- Rename** Rename the memo.


Delete	Delete the memo.
Delete All	Delete all memos.
Forward	Apply the memo to other options.

Melody Composer

This menu allows you to edit melody you like and set it as ring tone.

If there is no melody, you can press  **Add** to create a melody and press  to access **Option** menu during composing. If you select a melody, you can press  to access **Option** menu.

The operations of keys in composing

	Insert a rest.
	Enter Do-Si.
	Insert vibra effect.
	Insert back light effect.
▲ ▼	Change pitch of the note to high, middle or low.
	Switch the status of the note to high, normal or low.
	Change the tempo.

Press the navigation keys to select the symbol of vibra or back light then press ▲ or ▼ keys to turn the effect on or off.

Option menu in composing

Play	Play the melody.
Play Speed	Select playing speed of the melody.
Select Instrument	Select a musical instrument.
Save	Save the melody.
Help	Display help information.

Option menu of a melody

Play	Play the melody.
Edit	Edit the melody.
Add	Create a new melody.
Rename	Rename the melody.
Delete	Delete the melody.
Delete All Files	Delete all melodies.
Forward	Apply the melody to other options.
Help	Display help information.

9. File Manager

This menu allows you to manage the image, sound recorder, ring tone and music in your phone.

Select **D disk**, Press  **Option** to access the following options.

- Open** Allows you to open the folder. You can select a file or folder to do the following operation.
- **Operations to file**
Play (for music file), **View** (for image file), **Forward**, **Detail**, **Rename**, **Copy**, **Move**, **Delete**, **Delete All Files** and **Sort**.
 - **Operations to folder**
Open, **Create Folder**, **Rename**, **Delete** and **Sort**.
- Create Folder** Create a new folder in the file folder.
- Format** Format the folder. (Valid for root directory only).

The top right corner of the screen in file manager shows the occupation info of the storage. If you select a folder or file in file manager, the screen will show you date and size info about it at the same corner.

I 0. Fun & Games

Games

Select a game, press . For detail about each game you can refer to the direction on the screen.

Themes

This menu allows you to set the theme of screen color. There are three kinds of themes for you to select. Select a scheme, press  *Option* to access the following options.

Activate Activate the selected theme.

Update Period Set frequency of color updating.

Set Order Set order of color updating.

No matter which options you set in Update Period or Set Order, you must select Activate after setting.

Game Setting

This menu allows you to turn audio and vibration effect of the games on or off.

Select *Game Audio* or *Game Vibration*, press the navigation keys to select *On* or *Off*, then press  to confirm.

11. User Profiles

This menu allows you to set the ring of the incoming call, new message and so on. It also allows you to set alert type, volume of the ring and answer mode and backlight etc so that your phone can fit all kinds of environments.

Select **General**, **Meeting**, **Outdoor**, **Indoor** or **Headset**, press

 **Option** to access the following options.

Activate The mode you select is in operation.

Customize Allow you to set the selected mode including **Tone Setup** (Incoming Call, Alarm, Power On, Power Off, Message Tone and Keypad Tone), **Volume** (Ring Tone and Key Tone), **Alert Type** (Ring, Vibration Only, Vibra and Ring or Vibra Then Ring), **Ring Type** (Single, Repeat or Ascending), **Extra Tone** (Warning, Error, Camp on and Connect), **Answer Mode** (Any Key) and **LCD Backlight** (5, 15, 30 or 45 Sec).

The Auto option in Answer Mode shows only in Headset Mode.

The Headset mode needs not to be activated. As long as you plug in the earphone, your phone will switch to Headset mode automatically.

I 2. Organizer

This menu contains features and options designed to help you organised and informed while on the move.

Calendar

This menu allows you to view calendar, access or edit [To Do List](#).

You can press navigation keys to view the calendar. Select the date to view and press  [Option](#) to access the following options.

[View Tasks](#) Allows you to set date, time, note and alarm of the schedule. Press  to add new tasks, edit or view the selected task. (For detail please refer to “To Do List”).

[Jump To Date](#) Allows you to view appointed date quickly. Enter a date then press .

A date with a task is displayed with red color.

To Do List

This menu helps you to manage all kinds of things in your work or life. You can set the content, detailed time and alarm of [To Do List](#).

If there is no task in your phone, it shows empty. You can press  [Add](#) to create a new task. After you edit the task you can press  [Done](#).

If you select a task, you can press  [Option](#) to access the option menu.

Create a task

[Date](#) Allows you to enter the date of the task.

[Time](#) Allows you to enter the time of the task.

The time format you enter must be 24-hour system.

[Note](#) Allows you to enter the content of the task. Press  [Edit](#), enter the content, then press  to save.

[Alarm](#) Press the navigation keys to set the status of alarm.

[Repeat](#) Allows you to set frequency: [Once](#), [Every Day](#), [Day](#), [Weekly](#), [Monthly](#).

The option menu of a task

View	View the settings of the selected task.
Add	Add a new task.
Edit Task	Edit the selected task.
Delete Task	Delete the selected task.
Delete All	Delete all tasks in To Do List.

Alarm

Your mobile phone has a built-in alarm clock. You can set up to three separate alarms.

To set an alarm, follow the steps below:

1. Select an alarm and press  **Edit**.
2. Set the status **On**.
3. Enter the time.
4. Select **Repeat**, **Once**, **Everyday** or **Days**.

After you finish the setting, press  **Done**.

To use Days mode you can select the week line then set the status of each day in the week one by one. You can switch between On and Off by pressing the left softkey.

World Clock

This menu allows you to check the time in main cities around the world.

Press the navigation keys to select cities, the local date and time will show on the bottom of the screen.

13. Services

This menu contains STK and WAP services.

STK

Function items of this menu are subscription dependent and specific to operators. If the SIM card you insert has STK function, the STK menu will display on the screen.

WAP

This option allows you to access the network. Your phone supplies you with some existent modes to access network. You can browse the network after you activate corresponding mode.

Homepage

You can store a homepage for each mode. When you access WAP, the homepage of the mode will be visited firstly.

Bookmarks

You can save the address in your phone as a bookmark.

Select a bookmark, press  *Option* to access the following options.

Goto

Access the website of the selected bookmark.

Edit

Edit the selected bookmark.

Delete

Delete the selected bookmark.

Delete all

Delete all bookmarks.

Add Bookmark

Enter *Title* and *Address* to create a new bookmark.

Recent Pages

You can view the websites you visit recently.

Enter Address

You can enter an address to connect your phone to network.

Service Inbox

The WAP messages you received are saved in *Service Inbox*, the service operator will send the WAP messages to your phone actively.

Settings

Edit Profile

This option is used to set properties of all WAP access mode. Please contact with the network operator to get the right setting.

Select a mode in profile list, then press  to access the following options.

Activate Profile Activate the selected WAP access mode.

Edit Profile Edit the properties of WAP access mode.

Browser Options

Timeout Set waiting time of the browser. If there is no response in the waiting time, the browser will terminate the connection with the website.

Show Images Set whether to show images when visiting the website.

Service Message

This menu is used to set whether to receive service message. The service message is saved in **Service Inbox**.

Clear Cache

The information and data you access is stored in cache of your phone. This option is used to clear the information in the cache.

Clear Cookies

This menu is used to clear cookies.

When you access the website, some info is saved. Suggest you clear these sensitive info termly for fear that personal data will be revealed once your phone is lost.

Trusted Certificates

Some service needs trusted certificates such as bank service. When you download the right certificate, you can save or delete it. If you select save option, the certificate will be added to trusted certificates.

Data Account

This menu is used to set the info of account, the existent account is supplied by the manufacturer.

GSM Data

You can set: **Account Name**, **Number**, **User Name**, **Password**, **Line Type**, **Speed** and **DNS**.

GPRS

You can set: **Account Name**, **APN**, **User Name**, **Password**, **Auth. Type**.

I 4. Extra

This menu contains features and options designed for your personal use.

Calculator

Your phone has a built-in calculator that you can use to perform basic calculations. Numbers are entered with the keypad and operators with the navigation keys as indicated in the table below:

▲	Add or M+
▼	Subtract or M-
◀	Multiply or MC
▶	Divide or MR
	Clear number
	Decimal point
 or 	Operation result

Units Converter

This menu allows you to use conversion function of length and weight units.

Press  key to enter decimal point.

Currency Converter

This menu allows you to convert a sum from one currency into another using the exchange rate of your choice. You can convert from *Local* to *Foreign* or vice versa. Enter a rate in the Rate field, press , select *Rate Representation* (The first line on the screen), enter an amount in either the *Local* or *Foreign* fields and press  to get the conversion value.

Rate Representation option allows you to select the Rate you enter is the ratio of Local to Foreign or Foreign to Local.

You can enter decimal point by pressing  key.

Health

This menu supplies you with the reference of Body Mass Index and females' Menstrual.

BMI

Select *Sex* and then enter *Height* and *Weight*, press  to get the result.

Menstrual

The using method is the same as "BMI". Enter the corresponding data, then press  to get the result.

15. Shortcuts

This menu allows you to quickly enter ten items by pressing ▼ in idle mode. You can also modify the default items according to the actual demand.

Change items in Shortcuts

Select an item you want to modify then press  to enter edit mode. Select the replacing item, then press  to confirm.

Icons & symbols

In idle mode, several symbols can be displayed simultaneously on the main screen.

If the network symbol isn't displayed, the network is not currently available. You may be in a bad reception area, moving to a different location may help.



Battery - The bars indicate the battery level(3 bars=full, 0 bar=low).



GSM Network - your phone is connected to a GSM network.

Reception quality-the more bars are shown the better the reception is.



Keypad lock activated.



Alarm activated.



Ring - The alert type is ring.



Vibration only - The alert type is vibration only.



Vibra and ring - The alert type is vibra and ring.



Vibra then ring - The alert type is vibra then ring.



Chat Room1 is in chatting state.



GPRS attach - Your phone is connected to the GPRS network.



Voice mail - You have received a new voice mail.



Call forward - Your phone is in calls-forward state.



Missed call - You have a missed call.



SMS message - You have received a new message.



Line - The current line.



MMS message - You have received a new MMS message.

Precautions

Radio Waves



Your cellular mobile phone is a **low power radio transmitter and receiver**. When it is operating, it sends and receives radio waves.

The radio waves carry your voice or data signal to a base station that is connected to the telephone network. The network controls the power at which the phone transmits.

- Your phone transmits/receives radio waves in the GSM frequency (900 / 1800 MHz).
- The GSM network controls transmission power (0.01 to 2 watts).
- Your phone complies with all relevant safety standards.
- The CE mark on your phone shows compliancy with European electromagnetic compatibility (Ref. 89/336/EEC) and low voltage directives (Ref. 73/23/EEC).

Your cellular mobile phone is your responsibility. To avoid damage to yourself, to others or to the phone itself, read and follow all the safety instructions and make them known to anyone borrowing your phone. Furthermore to prevent unauthorised use of your phone:



Keep your phone in a safe place and keep it out of small children's reach.

Avoid writing down your PIN code. Try to remember it instead.

Switch off the phone and remove the battery if you are going to leave it unused for a long time.

Change your PIN code after purchasing the phone and to activate call restriction options.



The design of your phone complies with all applicable laws and regulations. However your phone may cause interference with other electronic devices. Consequently you should follow all **local recommendations and regulations** when using your cellular phone both at home and when away. **Regulations on the use of cellular phones in vehicles and aircraft are particularly stringent.**

Public concern has been focused for some time on the possible health risks for users of cellular phones. The current research on radio wave technology, including the GSM technology, has been reviewed and safety standards have been drawn up to ensure protection from exposure to radio wave energy. Your cellular telephone **complies with all applicable safety standards** and the Radio Equipment and Telecommunications Terminal Equipment Directive 1999/5/EC.

Always switch off your phone...

Inadequately protected or **sensitive electronic equipment** may be affected by radio energy. This interference can lead to accidents.



Before boarding an **aircraft** and/or when packing the phone in your luggage: the use of mobile phones in an aircraft may be dangerous for the operation of the aircraft, disrupt the mobile phones network and may be illegal.



In **hospitals**, clinics, other health care centres and anywhere else where you may be in the close vicinity of **medical equipment**.



In areas with a potentially **explosive atmosphere** (e.g. petrol stations and also areas where the air contains dust particles, such as metal powders).

In a vehicle transporting flammable products (even if the vehicle is parked) or a vehicle powered by liquefied petroleum gas (LPG), check first that the vehicle complies with the applicable safety rules.

In areas where you are requested to turn off radio transmitting devices, such as quarries or other areas where blasting operations are in progress.



Check with the vehicle manufacturer that **electronic equipment** used in your vehicle will not be affected by radio energy.

Pacemakers

If you have a **pacemaker**:

- Always keep the phone more than 15 cm from your pacemaker when the phone is switched on, in order to avoid potential interference.
- Do not carry the phone in a breastpocket.
- Use the ear opposite to the pacemaker to minimise the potential interference.
- Switch off your phone if you suspect that interference is taking place.

Hearing aids

If you are a user of a **hearing aid**, consult your physician and hearing aid manufacturer to learn whether your particular device is susceptible to cellular phone interference.

Improved performance

In order to **improve the performance of your phone**, reduce radio energy emission, **reduce battery consumption and ensure safe operation** adhere to the following guidelines:



For the optimal and satisfactory operation of the phone you are recommended to use the phone in the normal operating position (when not using in hands-free mode or with a hands-free accessory).

- Do not expose your phone to extreme temperatures.
- Treat the phone with care. Any misuse will void the International Guarantee.
- Do not immerse the phone in any liquid; if your phone is damp, switch it off, remove the battery and let them dry for 24hrs before using them again.
- To clean the phone, wipe it with a soft cloth.
- Placing and receiving calls consumes the same amount of battery energy. However, the mobile consumes less energy in idle screen when kept in the same place. When in idle screen and while you are moving, your phone consumes energy to

transmit updated location information to the network. Setting the backlight for a shorter period of time as well as avoiding unnecessary navigating in the menus will also help to save the battery's energy for longer phoning and stand-by performances.

Battery information

- Your phone is powered by a rechargeable battery.
- Use specified charger only.
- Do not incinerate.
- Do not deform or open the battery.
- Do not allow metal objects (such as keys in your pocket) to short circuit the battery contacts.
- Avoid exposure to excessive heat (>60° C or 140° F), moisture or caustic environments.



You should only use Philips authentic battery and accessories, as the use of any other accessories may damage your phone and may be dangerous, and will make all guarantees for your Philips phone null and void. The use of an incorrect type of battery may also cause an explosion.

Your mobile phone and your car



Studies have shown that speaking on the telephone while driving lowers your concentration, which can be dangerous.

Adhere to the following guidelines:

- Give your full attention to driving. Pull off the road and park before using the phone.
- Respect the local regulations in countries where you drive and use your GSM phone.
- If you want to use your phone in a vehicle, install the hands-free car kit which is designed for that purpose.
- Ensure that your phone and car kit do not block any air bags or other security devices fitted in your car.

The use of an alarm system to operate a vehicle's light or horn to indicate incoming phone calls is prohibited on public roads in some countries. Check local regulations.

EN 60950 Norm

In hot weather or after prolonged exposure to the sun (e.g., behind a window or a windscreen), the temperature of your phone's casing might increase, especially when featuring a metallic finish. Be very careful in this case when picking up your phone and also avoid using it with an ambient temperature over 40° C.

Environmental care



Remember to observe the local regulations regarding the disposal of the packaging materials, exhausted batteries and old phone and please promote their recycling.

Philips has marked the battery and packaging with standard symbols designed to promote the recycling and appropriate disposal of your eventual waste.



The battery should not be disposed of with general household waste.



The labelled packaging material is recyclable.



A financial contribution has been made to the associated national packaging recovery and recycling system.



The plastic material is recyclable (also identifies the type of plastic).

Troubleshooting

The phone does not switch on

Remove/reinstall the battery. Then charge the phone until the battery icon stops scrolling. Unplug from charger and try to switch the mobile on.

Your phone doesn't return to the idle screen

Long press  or switch off the phone, check that the SIM card and the battery are installed correctly and switch it on again.

The network symbol is not displayed

The network connection is lost. Either you are in a radio shadow (in a tunnel or between tall buildings) or you are outside the network coverage area. Try from another place, try to reconnect to the network (especially when abroad), check that the antenna is in place if your mobile has an external antenna, or contact your network operator for assistance/information.

The display doesn't respond (or the display responds slowly) to key presses

The display responds more slowly at very low temperatures. This is normal and does not affect the operation of the phone. Take the phone to a warmer

place and try again. In other cases please contact your phone supplier.

Your battery seems to over heat

You might be using a charger that was not intended for your phone. Make sure you always use the Philips authentic accessory shipped with your phone.

Your phone doesn't display the phone numbers of incoming calls

This feature is network and subscription dependent. If the network doesn't send the caller's number, the phone will display *Call I* or *Withheld* instead. Contact your operator for detailed information on this subject.

You can't send text messages

Some networks don't allow message exchanges with other networks. First check that you entered the number of your SMS centre, or contact your operator for detailed information on this subject.

You have the feeling that you miss some calls

Check your call divert options.

The display shows SIM failure

Check that the SIM card has been inserted in the right position. If the problem remains, your SIM card may be damaged. Contact your operator.

When attempting to use a feature in the menu, the mobile displays NOT ALLOWED

Some features are network dependent. They are only available, therefore, if the network or your subscription supports them. Contact your operator for detailed information on this subject.

The display shows INSERT YOUR SIM CARD

Check that the SIM card has been inserted in the right position. If the problem remains, your SIM card might be damaged. Contact your operator.

Your phone is not charging

If your battery is completely flat, it might take several minutes of pre-charge (up to 5 minutes in some cases) before the charging icon is displayed on the screen.

Philips Authentic Accessories

Some accessories, such as a battery and a charger, are included as standard in the package of your mobile phone. Additional accessories may also be provided or sold separately. Package contents may therefore vary.

To maximise the performance of your Philips mobile phone and not to void the warranty, always purchase Philips Authentic Accessories that are specially designed for use with your phone. Philips Consumer Electronics cannot be held liable for any damage due to use with non authorised accessories.

Charger

Charges your battery in any AC outlet. Small enough to carry in a briefcase/handbag.

USB cable

The USB cable enables high speed communication between your phone and your computer. You can manage the information stored in your phone such as image, animation, photo, video and music. You can also use the cable to charge battery (This charging mode is fit for most PC).

Headset

Your phone will activate headset mode automatically when you plug in the earphone. And you can select **Auto** option in answer mode. If this option's status **On**, your phone will automatically answer the incoming call in 2 seconds.

USB driver CD

If the operating system of your computer is Windows 98, you can use this CD to drive your computer in order to connect your phone with PC to copy, move or delete images or music etc.

Specific Absorption Rate Information

International standards

THIS MOBILE PHONE MEETS THE INTERNATIONAL RECOMMENDATIONS FOR EXPOSURE TO RADIO WAVES

Your mobile phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the limits for exposure to radio frequency (RF) energy defined by the international standards. These recommendations have been established by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) and, the Institute of Electrical and Electronics Engineers - Standards Associations (IEEE-SA) that forecast a substantial safety margin for assuring the protection of all persons, regardless of age and health.

The exposure recommendations for mobile phones use a measurement unit known as the Specific Absorption Rate (SAR). The SAR limit recommended by the ICNIRP for the mobile phones used by the general public is 2,0 W/kg in 10g of tissue and, is 1,6W/kg in 1g of tissue by IEEE-SA (IEEE Std 1528) for the head.

Tests for SAR have been conducted using recommended operating positions with the mobile phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR levels of the mobile phone while operating are generally below the maximum SAR value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a base station antenna, the lower the power output.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the international protection standards for exposure to radio waves.

The highest SAR value for this Philips S660 model phone when tested for compliance against the standard was 0,693W/kg for ICNIRP recommendation and 1,047W/kg for IEEE Standard.

For limiting the radio waves exposure, it is recommended to reduce the mobile phone call duration or to use a headset. The purpose of those precautions is to take the mobile phone away from the head and the body.

Limited warranty

1. What Does This Limited Warranty Cover?

Philips warrants to the original retail purchaser (“Consumer” or “You”) that this Philips cellular product and all accessories originally provided by Philips in the sales package (“Product”) are free from defects in materials, design and workmanship under normal use in accordance with the operating instructions and pursuant to the following terms and conditions. This limited warranty extends only to the Consumer for Products purchased and used in the original country of purchase. The limited warranty is valid only in Philips’ intended country of sales of the product.

2. How Long is The Limited Warranty Period?

The limited warranty period for the Product extends for ONE (1) YEAR from the date of purchase of the Product, documented by valid proof of purchase. The limited warranty for original Philips rechargeable battery extends for six (6) months from the date of purchase.

3. What Will Philips Do if The Product is Not Free From Material Defects in Materials and

Workmanship During The Limited Warranty Period?

During the limited warranty period, Philips or its authorized service representative will, at its option either repair or replace, without charge for parts or labour, a materially defective Product with new or refurbished parts or Product and return such repaired or replaced Product to the Consumer in working condition. Philips will retain defective parts, modules or equipment.

Repaired or replaced Product will be covered by this limited warranty for the balance of the original limited warranty period or ninety (90) days from the date of repair or replacement whichever is longer. Repair or replacement of Product, at Philips’ option is your exclusive remedy.

4. What is Not Covered By This Limited Warranty?

This limited warranty does not cover:

- a) Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation handling, neglect, inundation, fire, water or other liquid intrusion; or

- b) Product that has been damaged due to repair, alteration, or modification by anyone not authorized by Philips; or
 - c) Product that has reception or operation problems caused by signal conditions, network reliability or cable or antenna systems; or
 - d) Product defects or problems caused by uses with non-Philips products or accessories; or
 - e) Product which warranty/quality stickers, product serial number or electronic serial number has been removed, altered or rendered illegible; or
 - f) Product purchased, used, serviced, or shipped for repair from outside the original country of purchase, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or
 - g) Product returned without valid proof of purchase or which proof of purchase has been altered or is illegible.
 - h) Normal wear and tear or Force Majeure.
5. How Do You Get Warranty Service?
- a) Return the Product to an authorized service center of Philips. You may contact the local Philips office for the location of the nearest authorized service center.

- b) The SIM card must be removed from the Product before it is given to Philips. Philips assumes no liability for damaged or loss of the SIM card or the data contained therein.
 - c) If the Product failure is not covered by this limited warranty, or this limited warranty is inapplicable, void or invalid due to any terms and conditions stated herein, the Consumer will be charged for the cost of repair or replacement of the Product and all other related cost incurred in repairing or replacing the Product.
 - d) IMPORTANT - you are required to return the Product together with a valid proof of purchase which must identify the point of purchase, date of purchase, Product model and Product serial number clearly.
6. Other Limitation: This Warranty is The Entire Agreement.

EXCEPT FOR THE EXPRESS WARRANTIES SET FORTH ABOVE AND THOSE IMPLIED BY LAW AND WHICH CANNOT BE EXCLUDED OR MODIFIED BY AGREEMENT, PHILIPS PROVIDES NO OTHER WARRANTY WHETHER EXPRESS OR IMPLIED (WHETHER BY STATUTE, UNDER THE OPERATION OF LAW OR OTHERWISE) AND SPECIALLY DISCLAIMS

ANY WARRANTY OF SATISFACTORY QUALITY MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. PHILIPS' TOTAL LIABILITY FOR DAMAGES RELATING TO OR ARISING OUT OF THE PURCHASE OR USE OF THE PRODUCT, REGARDLESS OF THE TYPE OR CAUSE OF SUCH DAMAGE OR THE FORM OR CHARACTERISATION OF THE CLAIM ASSERTED (E.G. CONTRACT OR TOPIT), SHALL NOT EXCEED THE ORIGINAL PURCHASE PRICE PAID FOR THE PRODUCT.

HOWEVER IN NO EVENT SHALL PHILIPS BE LIABLE FOR ANY PUNITIVE, SPECIAL, INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO THE LOSS OF USE, LOSS OF TIME, INCONVENIENCE, COMMERCIAL LOSS, LOST PROFITS, LOST BUSINESS OPPORTUNITIES, COST OF SUBSTITUTION OF GOODS OR SERVICES, INVESTMENTS, DAMAGE TO GOODWILL OR REPUTATION, OR LOSS OF DATA AND CLAIMS BY THIRD PARTIES) RESULTING FROM PURCHASE OR USE OF THE PRODUCT, TO THE FULLEST EXTENT ALLOWED BY LAW, WHETHER OR NOT PHILIPS HAS BEEN

ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THESE LIMITATIONS SHALL APPLY NOTWITHSTANDING THE FAILURE OF THE ESSENTIAL PURPOSE OF ANY LIMITED REMEDY.

This limited warranty represents the complete and exclusive agreement between the Consumer and Philips with respect to this cellular Product and it supercedes all prior agreements between the parties, oral or written, and all other communications between the parties relating to the subject matter of this limited warranty. No carrier, retailer, agent, dealer, employee, thereof, or employee of Philips is authorized to make modifications to this limited warranty and you should not rely on any such representation.

This limited warranty does not affect the Consumer's statutory rights under applicable national laws in force.

Declaration of conformity

We,
Philips (China) Investment Co., Ltd.
BU Wireless China
21F, Tower 1 Kerry Euerbright City
218 Tian Mu Xi Road
Shanghai, P.R.C200010

declare under our sole responsibility that the product

Philips S660
GSM/GPRS Dualband Digital Mobile Phone
TAC: 352422 01

to which this declaration relates, is in conformity with
the following Standards:

Safety: EN 60950/2001
SAR: EN 50360:2001/EN 50361:2001
R&TTE: EN301-511 V9.0.2
EMC: EN301489-1 V1.5.1 and
EN301489-7 V1.2.1

We hereby declare that all essential radio test suites have been carried out and that the above named product is in conformity to all the essential requirements of Directive 1999/5/EC.

The conformity assessment procedure referred to in Article 10 and detailed in Annex III or IV of Directive 1999/5/EC has been followed with the involvement of the following Notified Body:

BABT, Belfour House, Churchfield Road, Walton-On-Thames, Surrey, KT12 2TD, UK

Identification mark: **0168**

Aug 08th, 2006

Quality Manager

