

Mobile Phone
user manual

- Some of the contents in this manual may differ from your phone depending on the software of the phone or your service provider.
- Third party services may be terminated or interrupted at any time, and Samsung makes no representation or warranty that any content or service will remain available for any period of time.
- This product includes certain freeware source software. The exact terms of the licenses, disclaimers, acknowledgements and notices are available on the Samsung's website opensource.samsung.com.

www.samsung.com

Printed in Korea
GH68-38733A
English (EU), 03/2012, Rev. 1.0

- Do not engage in stressful or emotional conversations that may be distracting. Make people you are talking with aware you are driving and suspend conversations that have the potential to divert your attention from the road.
- Use your device to call for help. Dial a local emergency number in the case of fire, traffic accident, or medical emergencies.
- Use your device to help others in emergencies. If you see an auto accident, a crime in progress, or a serious emergency where lives are in danger, call a local emergency number.
- Call roadside assistance or a special, non-emergency assistance number when necessary. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or another special, non-emergency number.

Proper care and use of your mobile device

Keep your device dry

- Humidity and all types of liquids may damage device parts or electronic circuits.
- Do not turn on your device if it is wet. If your device is already on, turn it off and remove the battery immediately (if the device will not turn off or you cannot remove the battery, leave it as-is). Then, dry the device with a towel and take it to a service centre.
- Liquids will change the colour of the label that indicates water damage inside the device. Water damage to your device can void your manufacturer's warranty.

Do not use or store your device in dusty, dirty areas

Dust can cause your device to malfunction.

Do not store your device on slopes

If your device falls, it can be damaged.

Do not store your device in hot or cold areas. Use your device at -20 °C to 50 °C

- Your device can explode if left inside a closed vehicle, as the inside temperature can reach up to 80 °C.

Allow only qualified personnel to service your device

Allowing unqualified personnel to service your device may result in damage to your device and will void your manufacturer's warranty.

Handle SIM cards or memory cards with care

- Do not remove a card while the device is transferring or accessing information, as this could result in loss of data and/or damage to the card or device.
- Protect cards from strong shocks, static electricity, and electrical noise from other devices.
- Do not touch gold-coloured contacts or terminals with your fingers or metal objects. If dirty, wipe the card with a soft cloth.

Ensure access to emergency services

Emergency calls from your device may not be possible in some areas or circumstances. Before travelling in remote or undeveloped areas, plan an alternate method of contacting emergency services personnel.

Keep your personal and important data safe

- While using your device, be sure to back up important data. Samsung is not responsible for data loss.
- When disposing of your device, back up all data and then reset your device to prevent misuse of your personal information.
- Carefully read the permissions screen when downloading applications. Be particularly cautious with applications that have access to many functions or to a significant amount of your personal information.
- Check your accounts regularly for unauthorised or suspicious use. If you find any sign of misuse of your personal information, contact your service provider to delete or change your account information.
- In the event your device is lost or stolen, change the passwords on your accounts to protect your personal information.
- Avoid using applications from unknown sources and lock your device with a pattern, password, or PIN.

Do not distribute copyright-protected material

Do not distribute copyright-protected material that you have recorded to others without the permission of the content owners. Doing this may violate copyright laws. The manufacturer is not liable for any legal issues caused by the user's illegal use of copyrighted material.



This product meets applicable national SAR limits of 2.0 W/kg. The specific maximum SAR values can be found in the SAR information section of this manual. When carrying the product, or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 1.5 cm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.

Warning: Prevent electric shock, fire, and explosion

Do not use damaged power cords or plugs, or loose electrical sockets

Do not touch the power cord with wet hands, or disconnect the charger by pulling on the cord

Do not bend or damage the power cord

Do not use your device while charging or touch your device with wet hands

Do not short-circuit the charger or the battery

Do not drop or cause an impact to the charger or the battery

Do not charge the battery with chargers that are not approved by the manufacturer

- Do not expose your device to direct sunlight for extended periods of time (such as on the dashboard of a car).
- Store the battery at 0 °C to 40 °C.

Do not store your device with such metal objects as coins, keys and necklaces

- Your device may become deformed or malfunction.
- If the battery terminals are in contact with metal objects, it may cause a fire.

Do not store your device near magnetic fields

- Your device may malfunction or the battery may discharge from exposure to magnetic fields.
- Magnetic stripe cards, including credit cards, phone cards, passbooks, and boarding passes, may be damaged by magnetic fields.
- Do not use carrying cases or accessories with magnetic closures or allow your device to come in contact with magnetic fields for extended periods of time.

Do not store your device near or in heaters, microwaves, hot cooking equipment, or high pressure containers

- The battery may leak.
- Your device may overheat and cause a fire.

Do not drop your device or cause impacts to your device

- The screen of your device may be damaged.
- If bent or deformed, your device may be damaged or parts may malfunction.

Do not use your device or applications for a while if the device is overheated

Prolonged exposure of your skin to an overheated device may cause low temperature burn symptoms, such as red spots and pigmentation.

If your device has a camera flash or light, do not use a flash close to the eyes of people or pets

Using a flash close to the eyes may cause temporary loss of vision or damage to the eyes.

Specific Absorption Rate (SAR) certification Information

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) recommended by international guidelines. The guidelines were developed by an independent scientific organisation (ICNIRP) and include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2.0 W/kg. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The highest SAR values under the ICNIRP guidelines for this device model are:

Maximum SAR for this model and conditions under which it was recorded	
Head SAR	0.695 W/kg
Body-worn SAR	0.953 W/kg

During use, the actual SAR values for the device are usually well below the values stated above. This is because, for purposes of system efficiency and to minimize interference on the network, the operating power of your mobile device is automatically decreased when full power is not needed for the call. The lower the power output of the device, the lower its SAR value. A body-worn SAR test has been performed on this device with an approved accessory at a separation distance of 1.5 cm. To meet RF exposure guidelines during body-worn operation, the device must be used with the approved accessory or positioned at least 1.5 cm away from the body. If you use an unapproved accessory, ensure that the accessory does not contain any metal components and that it positions the device at least 1.5 cm away from the body. Organizations such as the World Health Organization and the US Food and Drug Administration have suggested that if people are concerned and want to reduce their exposure, they could use a hands-free accessory to keep the wireless device away from the body during use, or reduce the amount of time spent using the device. For more information, visit www.samsung.com/ar and search for your device with the model number.

To prevent injury to yourself and others or damage to your device, read all of the following information before using your device.

Do not use your device during a thunderstorm

Your device may malfunction and your risk of electric shock is increased.

Do not handle a damaged or leaking Lithium Ion (Li-Ion) battery

For safe disposal of your Li-Ion batteries, contact your nearest authorised service centre.

Handle and dispose of batteries and chargers with care

- Use only Samsung-approved batteries and chargers specifically designed for your device. Incompatible batteries and chargers can cause serious injuries or damage to your device.
- Never dispose of batteries or devices in a fire. Follow all local regulations when disposing of used batteries or devices.
- Never place batteries or devices on or in heating devices, such as microwave ovens, stoves, or radiators. Batteries may explode when overheated.
- Never crush or puncture the battery. Avoid exposing the battery to high external pressure, which can lead to an internal short circuit and overheating.

Protect the device, batteries, and chargers from damage

- Avoid exposing your device and batteries to very cold or very hot temperatures.
- Extreme temperatures can cause the deformation of the device and reduce the charging capacity and life of your device and batteries.
- Remove batteries from contacting metal objects, as this can create a connection between the + and - terminals of your batteries and lead to temporary or permanent battery damage.
- Never use a damaged charger or battery.

Caution: Follow all safety warnings and regulations when using your device in restricted areas

Turn off your device where prohibited

Comply with all regulations that restrict the use of a mobile device in a particular area.

Do not use your device near other electronic devices

Most electronic devices use radio frequency signals. Your device may interfere with other electronic devices.

Do not use your device near a pacemaker

- Avoid using your device within a 15 cm range of a pacemaker if possible, as your device can interfere with the pacemaker.
- If you must use your device, keep at least 15 cm away from the pacemaker.
- To minimise the possible interference with a pacemaker, use your device on the opposite side of your body from the pacemaker.

Do not use your device in a hospital or near medical equipment that can be interfered with by radio frequency

If you personally use any medical equipment, contact the manufacturer of the equipment to ensure the safety of your equipment from radio frequency.

If you are using a hearing aid, contact the manufacturer for information about radio interference


Some hearing aids may be interfered with by the radio frequency of your device. Contact the manufacturer to ensure the safety of your hearing aid.

Turn off the device in potentially explosive environments

- Turn off your device in potentially explosive environments instead of removing the battery.
- Always comply with regulations, instructions and signs in potentially explosive environments.
- Do not use your device at refuelling points (service stations), near fuels or chemicals, and at blasting areas.
- Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the device, its parts, or accessories.

When speaking on the device:

- Hold the device upright, as you would with a traditional phone.
- Speak directly into the mouthpiece.
- Do not touch the device's internal antenna. Doing so may result in reduced call quality or cause the device to emit unintended levels of radio frequency (RF) energy.



Protect your hearing and ears when using a headset

- Excessive exposure to loud sounds can cause hearing damage.
- Exposure to loud sounds while driving may distract your attention and cause an accident.
- Always turn the volume down before plugging the earphones into an audio source and use only the minimum volume setting necessary to hear your conversation or music.
- In dry environments, static electricity can build up in the headset. Avoid using headsets in dry environments or touch a metal object to discharge static electricity before connecting a headset to the device.

Use caution when using the device while walking or moving

Always be aware of your surroundings to avoid injury to yourself or others.

Do not carry your device in your back pockets or around your waist

You can be injured or damage the device if you fall.

Turn off your device when in an aircraft

Using your device in an aircraft is illegal. Your device may interfere with the electronic navigation instruments of the aircraft.

Electronic devices in a motor vehicle may malfunction due to the radio frequency of your device

Electronic devices in your car may malfunction due to radio frequency of your device. Contact the manufacturer for more information.

Comply with all safety warnings and regulations regarding mobile device usage while operating a vehicle

- While driving, safely operating the vehicle is your first responsibility. Never use your mobile device while driving. If it is prohibited by law. For your safety and the safety of others, practice good common sense and remember the following tips:
- Use a hands-free device.
- Get to know your device and its convenience features, such as speed dial and redial. These features help you reduce the time needed to place or receive calls on your mobile device.
- Position your device within easy reach. Be able to access your wireless device without removing your eyes from the road. If you receive an incoming call at an inconvenient time, let your voice mail answer it for you.
- Let the person you are speaking with know you are driving. Suspend calls in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice, and heavy traffic can be hazardous.
- Do not take notes or look up phone numbers. Jotting down a "to do" list or flipping through your address book takes attention away from your primary responsibility of driving safely.
- Dial sensibly and assess the traffic. Place calls when you are not moving or before pulling into traffic. Try to plan calls when your car will be stationary. If you need to make a call, dial only a few numbers, check the road and your mirrors, then continue.

Do not disassemble, modify, or repair your device

- Any changes or modifications to your device can void your manufacturer's warranty. For service, take your device to a Samsung Service Centre.
- Do not disassemble or puncture the battery, as this can cause explosion or fire.

Do not paint or put stickers on your device

Paint and stickers can clog moving parts and prevent proper operation. If you are allergic to paint or metal parts of the product, you may experience itching, eczema, or swelling of the skin. When this happens, stop using the product and consult your physician.

When cleaning your device:

- Wipe your device or charger with a towel or a rubber.
- Clean the terminals of the battery with a cotton ball or a towel.
- Do not use chemicals or detergents.

Do not use the device if the screen is cracked or broken

Broken glass or acrylic could cause injury to your hands and face. Take the device to a Samsung Service Centre to have it repaired.

Do not use the device for anything other than its intended use

Avoid disturbing others when using the device in public


Do not allow children to use your device

Your device is not a toy. Do not allow children to play with it as they could hurt themselves and others, damage the device, or make calls that increase your charges.

Install mobile devices and equipment with caution

- Ensure that any mobile devices or related equipment installed in your vehicle are securely mounted.
- Avoid placing your device and accessories near or in an air bag deployment area. Improperly installed wireless equipment can cause serious injury when air bags inflate rapidly.

Phone layout



1 4-way navigation key

In idle mode, access user-defined menus; In Menu mode, scroll through menu options.

Depending on your service provider, pre-defined menus may differ.

2 Dial Key

Make or answer a call; In idle mode, retrieve recently dialled, missed, or received numbers;

3 Voice mail service key

In idle mode, access voice mails (press and hold)

4 Lock key

In idle mode, lock or unlock the keypad (press and hold)

5

Softkeys

Perform actions indicated at the bottom of the display

6 Power/End key

Turn the phone on and off (press and hold); End a call; In Menu mode, cancel input and return to idle mode

7 Confirm key

In idle mode, access Menu mode; Launch the web browser (press and hold); In Menu mode, select the highlighted menu option or confirm an input. Depending on your service provider or region, the key may perform differently.

8 Silent profile key

In idle mode, activate or deactivate the silent profile (press and hold)

9 Alphanumeric keys

Your phone displays the following status indicators on the top of the screen:

Icon	Description
	No signal
	Signal strength
	Network searching
	GPRS network connected
	Call in progress
	Browsing the web
	Connecting to secured web page
	Roaming (outside of normal service area)
	Call diverting activated
	No SIM card
	Bluetooth activated
	Alarm activated
	Memory card inserted
	FM radio on
	FM radio suspended

Make a call

1. In Idle mode, enter an area code and a phone number.
2. Press [↵] to dial the number.
3. To end the call, press [✂].

Answer a call

1. When a call comes in, press [↵].
2. To end the call, press [✂].

Call a recently dialed number

1. In Idle mode, press [↵] to display a list of recent numbers.
2. Scroll left or right to select a call type.
3. Scroll up or down to select a number or name.
4. Press the Confirm key to view details of the call or [↵] to dial the number.

Adjust the volume

- To adjust the volume of the ringtone**
1. In Menu mode, select **Settings** → **Sound profiles**.
 2. Scroll to the profile you are using.
 - If you are using the silent profile, you are not allowed to adjust the volume of the ringtone.
 3. Press <Edit>.
 4. Select **Volume** → **Call alert**.
 5. Scroll left or right to adjust the volume level and press <Save>.

Send and view messages

- To send a text message or multimedia message**
1. In Menu mode, select **Messages** → **Create message**.
 2. Enter a recipient number and scroll down.
 3. Enter the message text. See "Enter text." For sending as a text message, skip to step 5. For attaching multimedia, continue with step 4.
 4. Press <Options> → **Add multimedia** and add an item.
 5. Press the Confirm key to send the message.

- To view a text or multimedia messages**
1. In Menu mode, select **Messages** → **Inbox**.
 2. Select a text or multimedia message.

Activate and send an SOS message

In an emergency, you can send SOS messages to your family or friends for help.

- To activate the SOS message**
1. In Menu mode, select **Messages** → **Settings** → **SOS messages** → **Sending options**.
 2. Press <Change> to select **On**.
 3. Select **Recipients**. You can also enter a recipient number. Skip to step 6.
 4. Press <Search> to open the contacts list. To select multiple recipients, press <Options> → **Multiple**.

Install the SIM card and battery

1. Remove the back cover and insert the SIM card.
2. Insert the battery and replace the back cover.

Charge the battery

1. Plug a travel adapter into the multifunction jack.
2. When charging is finished, unplug the travel adapter.

- To adjust the volume of voice during a call**
- While a call is in progress, press the Navigation key up or down to adjust the volume.
- In noisy environments, you may have difficulty hearing the calls while using the speakerphone feature. For better audio performance, use the normal phone mode.

Change your ringtone

1. In Menu mode, select **Settings** → **Sound profiles**.
 2. Scroll to the profile you are using.
 3. Press <Edit>.
 4. Select **Voice call ringtone**.
 5. Select a memory location (if necessary).
 6. Select a ringtone.
- To switch to another profile, select it from the list.

Use the smart home screen

The smart home screen allows you to access your favourite applications and contacts and view upcoming events or tasks. You can customise the smart home screen to fit your preferences and needs.

When you are using the smart home screen, the Navigation key does not work as shortcuts.

- Do not remove the battery from the phone before unplugging the travel adapter first. Otherwise, the phone may be damaged.
- To save energy, unplug the travel adapter when not in use. The travel adapter does not have a power switch, so you must unplug the travel adapter from the outlet when not in use to avoid wasting power. The travel adapter should remain close to the socket when in use.

Insert a memory card (optional)

- Your phone accepts microSD™ or microSDHC™ memory cards up to 32 GB (depending on memory card manufacturer and type).
- Formatting the memory card on a PC may cause incompatibility with your phone. Format the memory card only on the phone.
- Frequent writing and erasing of data will shorten the life span of memory cards.
1. Remove the back cover.
 2. Insert a memory card with the gold-coloured contacts facing down.
 3. Push the memory card in the memory card slot until it locks in place.
 4. Replace the back cover.

Instructional icons

- Note:** notes, usage tips, or additional information
- **Followed by:** the order of options or menus you must select to perform a step; for example: In Menu mode, select **Messages** → **Create message** (represents **Messages**, followed by **Create message**)
- [] **Square brackets:** phone keys; for example: [↵] (represents the Power/End key)
- < > **Angled brackets:** softkeys that control different functions at each screen; for example: <OK> (represents the OK softkey)

Turn your phone on or off

- To turn your phone on,
1. Press and hold [↵].
 2. Enter your PIN and press <Confirm> (if necessary).
- If the battery remains fully discharged or removed from the device, the time and date will be reset.
- To turn your phone off, repeat step 1 above.

Enter text

- To change the text input mode**
- Press and hold [#] to switch between T9 and ABC modes. Depending on your country, you may be able to access an input mode for your specific language.
 - Press [#] to change case or switch to Number mode.
 - Press [✖] to switch to Symbol mode.
 - Press and hold [✖] to select an input mode or change the input language.
- T9 mode**
1. Press the appropriate alphanumeric keys to enter an entire word.
 2. When the word displays correctly, press [0] to insert a space. If the correct word does not display, press the Navigation key up or down to select an alternate word.
- ABC mode**
- Press an appropriate alphanumeric key until the character you want appears on the display.
- Number mode**
- Press an appropriate alphanumeric key to enter a number.

Access menus

- To access your phone's menus,
1. In Idle mode, press <Menu> to access Menu mode.
 - You may need to press the Confirm key to access Menu mode depending on your region or service provider.
 2. Use the Navigation key to scroll to a menu or option.
 3. Press <Select> or the Confirm key to confirm the highlighted option.
 4. Press <Back> to move up one level; Press [↵] to return to Idle mode.
- When you access a menu requiring the PIN2, you must enter the PIN2 supplied by the SIM card. For details, contact your service provider.
 - Samsung is not responsible for any loss of passwords or private information or other damages caused by illegal software.

Symbol mode

- Press an appropriate alphanumeric key to enter a symbol.
- To use other features for text input**
- To move the cursor, press the Navigation key.
 - To delete characters one by one, press <Clear>.
 - To delete all of the characters, press and hold <Clear>.
 - To insert a space between characters, press [0].
 - To enter punctuation marks, press [1].

Add a new contact

- The memory location to save new contacts may be preset depending on your service provider. To change the memory location, in Menu mode, select **Contacts** → <Options> → **Settings** → **Save new contacts to** → a memory location.
1. In Idle mode, enter a phone number and press <Options>.
 2. Select **Add to Contacts** → **Create contact** → a memory location (if necessary).
 3. Select a number type (if necessary).
 4. Enter contact information.
 5. Press the Confirm key to save the contact to memory.

Send and view messages

To send a text message or multimedia message

1. In Menu mode, select **Messages** → **Create message**.
2. Enter a recipient number and scroll down.
3. Enter the message text. See "Enter text." For sending as a text message, skip to step 5. For attaching multimedia, continue with step 4.
4. Press <Options> → **Add multimedia** and add an item.
5. Press the Confirm key to send the message.

To view a text or multimedia messages

1. In Menu mode, select **Messages** → **Inbox**.
2. Select a text or multimedia message.

Activate and send an SOS message

In an emergency, you can send SOS messages to your family or friends for help.

To activate the SOS message

1. In Menu mode, select **Messages** → **Settings** → **SOS messages** → **Sending options**.
2. Press <Change> to select **On**.
3. Select **Recipients**. You can also enter a recipient number. Skip to step 6.
4. Press <Search> to open the contacts list. To select multiple recipients, press <Options> → **Multiple**.

5. Select contacts → <Add>.
 6. When you are finished setting the recipients, press the Confirm key to save the recipients.
 7. Select **Repeats**, set the number of times to repeat the SOS message.
 8. Press <Back> → <Yes>.
- To send an SOS message**
1. With the keys locked, press [↵] four times to send an SOS message to preset numbers. The phone switches to SOS mode and sends the preset SOS message.
 2. To exit SOS mode, press [✂].
- Make fake calls**
- You can simulate an incoming call when you want to get out of meetings or unwanted conversations.
- To activate the fake call feature**
- In Menu mode, select **Settings** → **Call** → **Fake call** → **Fake call hot key** → **On**.
- To make a fake call**
- In Idle mode, press and hold the Navigation key down.
 - When the keys are locked, press the Navigation key down four times.

Use the camera

- To capture photos**
1. In Menu mode, select **Camera** to turn on the camera.
 2. Rotate the phone anti-clockwise to landscape view.
 3. Aim the lens at the subject and make any adjustments.
 4. Press the Confirm key to take a photo. The photo is saved automatically.
- To view photos**
- In Menu mode, select **My files** → **Images** → a photo file.
- To capture videos**
1. In Menu mode, select **Camera** to turn on the camera.
 2. Rotate the phone anti-clockwise to landscape view.
 3. Press [1] to switch to the camcorder. Aim the lens at the subject and make any adjustments.
 4. Press the Confirm key to start recording.
 5. Press the Confirm key or <Stop> to stop recording. The video is saved automatically.
- To view videos**
- In Menu mode, select **My files** → **Videos** → a video file.

Listen to the FM radio

1. Plug a headset into the phone.
 2. In Menu mode, select **Applications** → **FM radio**.
 3. Press the Confirm key to start the FM radio.
 4. Press <Yes> to start automatic tuning. The radio scans and saves available stations automatically.
- The first time you turn on the FM radio, you will be prompted to start automatic tuning.
5. Control the FM radio using the following keys:

Key	Function
Confirm	Turn the FM radio on or off
Navigation	• Left/Right: Fine-tune the frequency; Search for an available radio station (press and hold) • Up/Down: Adjust the volume

SAMSUNG ELECTRONICS SAMSUNG

Declaration of Conformity (R&TTE)

We, **Samsung Electronics** declare under sole responsibility that the product:

GSM Bluetooth Mobile Phone : GT-E2250

to which this declaration relates, is in conformity with the following standards and/or other normative documents.

SAFETY	EN 60950-1 : 2006 + A1 : 2010
	SAR EN 50360 : 2001 / AC 2006
	EN 62206-1 : 2006
EMC	EN 62209-2 : 2010
	EN 62479 : 2010
	EN 62311 : 2008
	EN 301 489-01 V1.8.1 (04-2008)
RADIO	EN 301 489-07 V1.3.1 (11-2005)
	EN 301 489-17 V2.1 (05-2009)
	EN 301 511 V9.0.2 (03-2003)
	EN 300 328 V1.7.1 (10-2006)

We hereby declare that (a) essential radio test suites have been carried out and that (b) the above named product is in conformity to all the essential requirements of Directive 1999/5/EC.

The conformity assessment procedure referred to in Article 10 and detailed in Annex IV of Directive 1999/5/EC has been followed with the involvement of the following Notified Body(ies):

BA01: Forsyth House, Churchfield Road, Walton-on-Thames, Surrey, KT12 2TD, UK* Identification mark: 0168

The technical documentation kept at: Samsung Electronics UK Lab. (Representative in the EU)

Samsung Electronics Euro QA Lab, Blackthorn Business Park, Saxony Way, Yateley, Hampshire, GU46 6GG, UK* 2012.03.27

(Place and date of issue) (Name and signature of authorised person)

* It is not the address of Samsung Service Centre. For the address of the phone number of Samsung Service Centre, see the warranty card or contact the retailer where you purchased your product.

CE 0168