

GM200 User Guide - English

This guide will help you understand your new mobile phone. It will provide you with useful explanations of features on your phone.

Some of the contents in this manual may differ from your phone depending on the software of the phone or your service provider.



Getting to know your phone



Installing a memory card

Lift the memory card cover and insert a micro SD card with the golden contact area facing downwards. Close the memory card cover so that it clicks shut. To remove the memory card, gently push it as shown in the diagram.



Note: A memory card is an optional accessory.

Formatting the memory card

Press **Menu** and select **Settings**.

Choose **Memory status**, select **External memory** and press **Format**.

WARNING: When you format your memory card, all the content will be wiped. If you do not want to lose the data on your memory card, back it up first.

Installing the SIM Card and Charging the Battery

Installing the SIM Card

When you subscribe to a cellular network, you are provided with a plug-in SIM card loaded with your subscription details, such as your PIN, any optional services available and many others.

Important! › The plug-in SIM card and its contacts can be easily damaged by scratches or bending, so be careful when handling, inserting or removing the card. Keep all SIM cards out of the reach of small children.

Illustrations

- 1 Open battery cover
- 2 Remove the battery
- 3 Insert your SIM
- 4 Close the battery cover
- 5 Charge your battery



WARNING: Do not remove the battery when the phone is switched on, as this may damage the phone.

Menu map

 Games & Apps 1 Games 2 Applications 3 Network profile	 Call history 1 All calls 2 Missed calls 3 Dialed calls 4 Received calls 5 Call duration 6 Call costs 7 Data information	 Organiser 1 Calendar 2 Memo 3 To do	 Multimedia 1 MP3 player 2 Camera 3 Video camera 4 FM radio 5 Voice recorder 6 Ringtone creator
 Messaging 1 New message 2 Inbox 3 Email box 4 Drafts 5 Outbox 6 Sent 7 Listen to voicemail 8 Info message 9 Templates 0 Settings	 My stuff 1 Images 2 Sounds 3 Videos 4 Others 5 External memory	 Profiles 1 General 2 Silent 3 Vibrate only 4 Outdoor 5 Headset	 Contacts 1 Search 2 New contact 3 Speed dials 4 Groups 5 Copy all 6 Delete all 7 Settings 8 Information
 Tools 1 Alarm clock 2 Calculator 3 Stopwatch 4 Unit converter 5 World clock 6 SIM services	 Browser 1 Home 2 Google Search 3 NDTV Active 4 Bookmarks 5 Enter address 6 History 7 Saved pages 8 Settings 9 Information	 Connectivity 1 Bluetooth 2 Network 3 USB connection	 Settings 1 Date & Time 2 Languages 3 Display 4 Shortcut 5 Call 6 Security 7 Flight mode 8 Power save 9 Reset 0 Memory status

Calls

Making a call

1 Key in the number using the keypad.
To delete a digit press **Clear**.

2 Press  to initiate the call.

3 To end the call, press .

TIP! To enter + when making an international call, press and hold 0.

Making a call from your contacts

- 1 Select **Contacts** from the Standby screen.
- 2 Using the keypad, enter the first letter of the contact you want to call.
For example, for Office, Press 6 three times to select the first character, "O"
- 3 Select **Call** or press  to initiate the call.

Answering and rejecting a call

When your phone rings, press **Accept** or press  to answer the call.

To mute your phone while it is ringing, simply select **Silent**. This is useful if you have forgotten to change your profile to Silent for a meeting.

Press  or select **Reject** to reject the incoming call.

TIP! You can change the settings on your phone to answer your calls in different ways. Press **Menu**, select **Settings**, and choose **Call**. Select **Answer mode** and choose from **Any key**, or **Send key only**.

Speed dialling

You can assign a speed dial number to a contact you call frequently.

Viewing your Call history

You can check the record of missed, received, and dialled calls only if the network supports the Calling Line Identification (CLI) within the service area.

Changing the call settings

You can set the menu relevant to a call. Press **Menu**, select **Settings** and choose **Call**.

- **Call divert** - Choose whether to divert your calls.
- **Call barring** – Select when you would like calls to be barred.
- **Fixed dial number** – Choose a list of numbers that can be called from your phone. You'll need your PUK2 code from your operator. Only numbers included in the fixed dial list can be called from your phone.

- **Answer mode** - Choose whether to answer the phone using any key or send key only.
- **Send my number** - Choose whether your number will be displayed when you call someone. (Depends on your network provider.)
- **Call waiting** - Be alerted when you have a call waiting. (Depends on your network provider.)
- **Minute minder** - Select On to hear a tone every minute during a call.
- **Auto redial** - Choose On or Off.
- **Send DTMF tones** - Choose On or Off.

Contacts

Searching for a contact

- 1 Select **Contacts** from the standby screen, and choose **Search**.
- 2 Using the keypad enter the first letter of the contact you want to call.
- 3 To scroll through the contacts and their different numbers use the navigation arrows.

Adding a new contact

- 1 Press **Contacts** and choose **New contact**.
- 2 Choose whether to store your new contact on your **Phone** or **SIM** card.

- 3 Enter all the information you have in the fields provided and select **Save**.

Adding a contact to a group

You can save your contacts into groups, for example, keeping your work colleagues and family separate. There are a number of groups including Family, Friends, Colleague, VIP, Group1, Group2 and Group3 already set up on the phone.

Adding a picture to a contact

You can change the appearance of your contacts in your address book to include a picture.

- 1 In the standby screen, select **Contacts** and choose **Settings**.
- 2 Select View options and choose With picture.
- 3 Then return to the address book and select the contact you want to add a picture to.
- 4 Choose **Options** and select **Edit**.
- 5 Scroll down to the Picture section. Choose **Option** and choose **Save**, **No picture**, **Images** or **New image**. If you choose Image, you can choose an image that is saved in your phone memory. If you choose **New image**, your camera view finder will open

so you can take a picture of your contact.

- 6 Select **Save**.

Messaging

Your GM200 includes functions related to SMS (Short Message Service), MMS (Multimedia Message Service) and E-mail, as well as the network's service messages.

Sending a message

- 1 Press **Menu**, select **Messaging**, and choose **New message**.
- 2 Choose **Message** to send an SMS or MMS.
- 3 A new message editor will open. The message editor combines SMS and MMS into one intuitive and easy to switch between mode. The default setting of the message editor is SMS mode.
- 4 Enter your message using either the T9 predictive mode or Abc manual mode.
- 5 Select **Options** and choose **Insert** to add an **Image, Sound, Video, Symbol, Text template, Emoticon, Name & Number, New slide, Subject, or More (Contact/ My business card/Schedule/ Memo/To do)**.

- 6 Press the centre key.
- 7 Enter the phone number or press **Options** and select **Contacts** or **Recent list** to open your contacts list. You can add multiple contacts.
- 8 Select **Send**.

Setting up your email

You can stay in touch on the move using email on your GM200. It's quick and simple to set up a POP3 or IMAP4 email account.

- 1 Press **Menu**, select **Messaging**, and choose **Settings**.
- 2 Select **E-mail** then **E-mail account**.
- 3 Select **New** then set the E-mail account.

Sending an email using your new account

To send/receive an email, you should set up an email account.

- 1 Select **Menu**, select **Messaging** and choose **New message**.
- 2 Choose **E-mail** and a new email will open.
- 3 Write a subject then press **Option** and choose **Write email** and press **OK**.
- 4 Enter your message.

- 5 To add an attachment, select **Options** and select **Attachments**, then press New: **Image, Sound, Video, More(Contact, My business card, or Schedule, Memo, To do)**, Others or contents of External memory.
- 6 Press Send to and enter the recipient's address or press **Options** and select **Contacts** to open your contacts list.
- 7 Press Send and your email will be sent.

Entering text

You can enter alphanumeric characters using the phone's keypad. The following text input methods are available in the phone: T9 predictive mode, ABC manual mode and 123 mode.

Note: Some fields may allow only one text input mode (e.g. telephone number in address book fields).

T9 predictive mode

T9 predictive mode uses a built-in dictionary to recognise words you're writing based on the key sequences you press. Simply press the number key associated with the letter you want to enter, and the dictionary will

recognise the word once all the letters are entered.

ABC manual mode

This mode allows you to enter letters by pressing the key labeled with the required letter once, twice, three or four times until the letter is displayed.

123 mode

Type numbers using one keystroke per number. You can also add numbers while remaining in letter modes by pressing and holding the desired key.

Message folders

Press Menu, select Messaging. The folder structure used on your GM200 is fairly selfexplanatory.

Inbox - All the messages you receive are placed into your Inbox.

Email box - Contains all your email messages.

Drafts - If you don't have time to finish writing a message, you can save what you have done so far here.

Outbox - This is a temporary storage folder while messages are being sent.

Sent - All the messages you send are placed into your Sent folder.

Listen to voicemail - You can access your voicemail box (if provided by your network).

Info message - All info messages and updates received from your operator.

Templates - A list of useful messages, already written for a quick reply.

Multimedia

MP3 player

Your GM200 has a built-in MP3 player so you can play all your favourite music.

Playing a song

- 1 Press **Menu** and select **Multimedia**, then choose **MP3 player**.
- 2 Choose **All songs** then select the song you want to play.
- 3 Select **||** to pause the song.
- 4 Select **▶▶** to skip to the next song.
- 5 Select **◀◀** to skip to the previous song.
- 6 Select **Back** to stop the music and return to the MP3 player menu.

Creating a playlist

You can create your own playlists by choosing a selection of songs from the **All songs** folder.

- 1 Press **Menu** and select **Multimedia**.
- 2 Choose **MP3 player**, then select **My playlist**.
- 3 Press **Options** and select **New playlist**, enter the playlist name and press **Save**.
- 4 The **All songs** folder will show. Select all of the songs that you would like to include in your playlist by scrolling to them and selecting .
- 5 Select **Done** to store the playlist.

Setting Dolby effect or LG Equalizer

You can set up Dolby effect or LG Equalizer.

- 1 Press **Menu** and select **Multimedia**, then choose **MP3 player**.
- 2 Choose **Settings**, then select **Audio effect**.
- 3 Select **Dolby effect** or **LG Equalizer**.

Camera

Taking a quick photo

- 1 Select **Menu**, and select **Multimedia**. Select **Camera** to open the viewfinder.

- 2 Holding the phone and, point the lens towards the subject of the photo.
- 3 Position the phone so you can see the subject of your photo.
- 4 Press Center key to take a photo.

Video camera

Shooting a quick video

- 1 In standby screen, select **Menu** and select **Multimedia**.
- 2 Choose **Video camera**.
- 3 Point the camera lens towards the subject of the video.
- 4 Press  to start recording.
- 5 Rec will appear in the bottom left corner of the viewfinder and a timer will show the length of your video.
- 6 Select **Stop** to stop recording.

FM radio

Using the FM radio

Your LG GM200 has an FM radio feature so you can tune into your favourite stations and listen on the move.

Listening to the radio

- 1 Press **Menu** and select **Multimedia**, then choose **FM radio**.
- 2 Select the channel number of the station you would like to listen to.

Recording the Radio

- 1 Press center key during listening to the Radio.
- 2 The recording time is displayed on your phone. If you want to stop the recording, press . If recording is done, the recorded contents will be saved in My stuff as mp3 file.
- 3 When the recording is done, select **Option** and then choose from **Delete**, **Set as**, or **Album**.

Note: If you stay in an area with bad radio reception, you may find difficulty in listening to the Radio.

So, we recommend you insert Ear-mic into Handsfree connector in order to listen to the Radio and keep the good radio reception.

Voice recorder

Use your **Voice recorder** to record voice memos or other sounds.

Ringtone creator

- 1 Press **Menu** and select **Multimedia**, then choose **Ringtone creator**.
- 2 Select the music what you would like to use in music lists, and then select **OK**.
- 3 Press center key.
- 4 Select **Cut** when you want to start recoding music to use as a Ringtone while playing music.
- 5 Select **Cut** when you want to stop recording music.
- 6 Once you have finished recording, select option and choose from **Save**, **Play** or **Reset**. If you choose **Reset** the selected file is removed from your phone.

My stuff

You can store any multimedia files into your phone's memory so that you have easy access to all of your images, sounds, videos, others and games. You can also save your files to a memory card. The advantage of using a memory card is that you can free up space on your phone's memory. All your multimedia files will be saved in **My stuff**. Press **Menu** then select **My stuff** to open a list of folders.

Images

Images contains a folder of default images on your phone, images downloaded by you, and images taken on your phone's camera.

Sounds

The Sounds folder contains the Default sounds, your voice recordings, and sound files downloaded by you. From here you can manage, send, or set sounds as ringtones.

Videos

The Videos folder shows the list of downloaded videos and videos you have recorded on your phone.

Others

From the Others menu, you can view the files that are not saved in the Images, Sounds or Videos folder.

External memory

If you've inserted a memory card, it will be displayed as a folder within My stuff.

Games and Apps

Your GM200 comes with preloaded games to keep you amused when you have time to spare. If you choose to download any additional games or

applications they will be saved into this folder.

Organizer / Tools

Using the calendar

When you enter this menu, a calendar appears. A square cursor is located on the current date. You can move the cursor to another date using the navigation keys.

Adding a memo

You can register your own memos here.

Adding an item to your to do list

You can view, edit and add tasks to do.

Setting your alarm

You can set up to 5 alarm clocks to go off at a specified time.

Using your calculator

The calculator provides the basic arithmetic functions: addition, subtraction, multiplication and division.

Using the stopwatch

This option allows you to use the function of a stopwatch.

Converting a unit

This converts many measurements into a unit you want.

Adding a city to your world clock

You can add a required city to the list of world clock. You can also check the current time of Greenwich Mean Time (GMT) and major cities around the world.

SIM services

This feature depends on SIM and the network services. In case the SIM card supports SAT (i.e. SIM Application Toolkit) services, this menu will be the operator specific service name stored on the SIM card.

Browser

Accessing the browser

You can launch the wap browser and access the homepage of the activated profile on browser settings. You can also manually enter an URL address and access the associated wap page.

- 1 Press **Menu** and select **Browser**.
- 2 To access the browser homepage directly, select **Home**. Alternately, select **Enter address** and type in your desired URL.

Using Google Search

It is easy to access Google Internet Service using this function.

NDTV Active

GM200 supports NDTV Active URL:
Access this to get information about news & current affairs etc.

Connectivity

Changing your connectivity settings

Your connectivity settings have already been set up by your network operator, so you can enjoy your new phone from switch on. If you want to change any settings, use this menu.

You can configure the network setting and data access profiles in this menu.

- **Bluetooth** - Setup your GM200 for Bluetooth® use. You can adapt your visibility to other devices or search through devices your phone is paired with.
- **Network** - Your GM200 connects automatically to your preferred network. To change these settings use this menu. You can also add new access points using this menu.

- **USB connection** - Choose **Data service** and synchronise your GM200 using the LG PC Suite software to copy files from your phone. If you have a memory card inserted, select **Mass storage** to use your phone in the same way as you would use a USB stick. Connect to your computer and drag and drop files to the GM200 removable device folder.

Note: To use the USB mass storage function, you will need to insert an external memory card in your phone.

Changing your Bluetooth settings

- 1 Press **Menu** and select **Connectivity**. Choose **Bluetooth**.
- 2 Choose **Bluetooth settings**. Make changes to your :
 - **My visibility** - Choose whether to Show or Hide your device to others.
 - **My name** - Enter a name for your LG GM200.
 - **My address** - View your Bluetooth address.
 - **Primary storage** - Choose the default location you prefer items to be saved to.

Pairing with another Bluetooth device

By pairing your GM200 and another device, you can set up a passcode protected connection. This means your pairing is more secure.

- 1 Check your Bluetooth is **On** and **Visible**. You can change your visibility in the **Bluetooth settings** menu, by selecting **My visibility**, then **Show**.
- 2 Select **Device list** from the **Bluetooth** menu and choose **New**.
- 3 Your GM200 will search for devices. When the search is completed **Pair** and **Refresh** will appear on screen.
- 4 Choose the device you want to pair with, select **Pair** and enter the passcode then choose OK key.
- 5 Your phone will then connect to the other device, on which you should enter the same passcode.
- 6 Your passcode protected Bluetooth connection is now ready.

Profiles

Personalising your profiles

You can personalise each profile setting.

- 1 Press **Menu** and select **Profiles**.

- 2 Choose the profile you want and select **Personalize**.

- 3 For the Silent and Vibrate only profiles, you can activate only.

Smart - profiling your profiles.

You can select suitable volume level considering present surrounding circumstances.

- 1 Press **Menu** and select **Profiles**.
- 2 Choose **General** or **Outdoor**. You can use only this function with General and Outdoor.
- 3 Select **smart-profiling**.
- 4 Your phone recommends the suitable volume level to you.

Settings

Changing your date & time

You can set functions relating to the date and time.

Changing the language

You can change the language for the display texts in your phone. This change will also affect the language input mode.

Changing your display settings

You can change the settings for the phone display.

Changing your shortcuts settings

You can change the shortcuts of 4 navigation keys.

Changing your security settings

Change your security settings to keep your GM200 and the important information it holds protected.

- **PIN code request** - Choose a PIN code to be requested when you turn your phone on.
- **Auto key lock** - Lock the keypad automatically in standby screen without allowing the action of key.
- **Phone lock** - Choose a security code to lock your phone **When power on**, **When SIM changed** or **Immediately**.
- **Application lock** - lock the application: Image, Calendar, Memo, To do.
- **Anti Theft Mobile Tracker** - When the handset is stolen, handset sends the SMS to the numbers configured by real owner. To activate the ATMT feature, you will need to set ATMT on, and configure the ATMT settings with name, primary number and secondary number. Default ATMT code is "0000."

ATMT SMS will contain information about the stolen phone IMEI, current location (captured as per Cell Broadcast message) & number of the person who is using that handset.

- **Change codes** - Change your Security code, PIN2 code, or ATMT code.

Using flight mode

Use this function to switch the flight mode On or Off. You will not be able to make calls, connect to the internet, send messages when Flight mode is switched On.

Power save

Choose to switch the power saving settings On or Off.

Resetting your phone

Use Reset to reset all the settings to their factory definitions. You need the security code to activate this function.

Viewing memory status

You can use the memory manager to determine how each memory is used and see how much space is available: Common, Reserved, SIM card, and External memory.

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information

This mobile phone model GM200 has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all users, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardised methods with the phone transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.

- The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2W/kg averaged over 10g of tissue.
- The highest SAR value for this model phone tested by DASY4 for use close to the ear is 0.473 W/kg(10g) and when worn on the body is 0.224 W/kg(10g).
- SAR data information for residents in countries/regions that have adopted the SAR limit recommended by the Institute of Electrical and Electronics Engineers (IEEE), which is 1.6 W/kg averaged over 1g of tissue.

Product care and maintenance

WARNING

Only use batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone, and may be dangerous.

- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.

Guidelines for safe and efficient use (Continued)

- Keep away from electrical appliances such as TVs, radios, and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the phone in any area where you are required by special regulations. For example, do not use your phone in hospitals as it may affect sensitive medical equipment.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock and can seriously damage your phone.
- Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.
- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the phone when it is on soft furnishings.
- The phone should be charged in a well ventilated area.
- Do not subject this unit to excessive smoke or dust.
- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the phone.
- Do not expose the phone to liquid or moisture.
- Use the accessories like earphones cautiously. Do not touch the antenna unnecessarily.

Efficient phone operation

Electronics devices

- Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over pacemakers, i.e. in your breast pocket.
- Some hearing aids might be disturbed by mobile phones.
- Minor interference may affect TVs, radios, PCs, etc.

Guidelines for safe and efficient use (Continued)

Road safety

Check the laws and regulations on the use of mobile phones in the area when you drive.

- Do not use a hand-held phone while driving.
- Give full attention to driving.
- Use a hands-free kit, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is particularly imperative when near roads.

Avoid damage to your hearing

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions, and follow the rules and regulations.

Potentially explosive atmospheres

- Do not use the phone at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid, or explosives in the same compartment of your vehicle as your mobile phone and accessories.

Guidelines for safe and efficient use (Continued)

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your mobile phone off before boarding any aircraft.
- Do not use it on the ground without permission from the crew.

Children

Keep the phone in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available under all mobile networks. Therefore, you should never depend solely on the phone for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.

- Use only LG batteries and chargers. LG chargers are designed to maximize the battery life.
- Do not disassemble or short-circuit the battery pack.
- Keep the metal contacts of the battery pack clean.
- Replace the battery when it no longer provides acceptable performance. The battery pack maybe recharged hundreds of times until it needs replacing.
- Recharge the battery if it has not been used for a long time to maximize usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.
- Do not leave the battery in hot or cold places, this may deteriorate the battery performance.
- There is risk of explosion if the battery is replaced by an incorrect type.
- Dispose off used batteries according to the manufacturer's instructions. Please recycle when possible. Do not dispose as household waste.


Guidelines for safe and efficient use (Continued)

- If you need to replace the battery, take it to the nearest authorized LG Electronics service point or dealer for assistance.
- Always unplug the charger from the wall socket after the phone is fully charged to save unnecessary power consumption of the charger.

Accessories


There are various accessories for your mobile phone. These are detailed below.

Charger



Data cable and CD

Connect and synchronise your GM200 and PC.




Battery



User Guide

Learn more about your GM200.

Stereo headset



Note

- Always use genuine LG accessories. Failure to do this may invalidate your warranty.
- Accessories may be different in different regions. Please check with our regional service company or agent for further inquiries.

Technical data

General

Product name : GM200

System : GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900

Ambient Temperatures

Max : +55°C (discharging)
+45°C (charging)

Min : -10°C

Bluetooth QD ID B015111

Declaration of Conformity



Suppliers Details

Name

LG Electronics Inc

Address

LG Electronics Inc. LG Twin Towers 20,
Yeouido-dong, Yeongdeungpo-gu, Seoul, Korea 150-721

Product Details

Product Name

GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900 Quad band Terminal Equipment

Model Name

GM200

Trade Name

LG

CE 0168

Applicable Standards Details

R&TTE Directive 1999/5/EC

EN 301 489-01 V1.6.1, EN 301 489-07 V1.3.1, EN 301 489-17 V1.2.1
EN 301 511 V9.0.2
EN 50360/EN 50361:2001
EN 60950-1:2001
EN300328 V1.7.1

Supplementary Information

The conformity to above standards is verified by the following Notified Body(BABT)

BABT, Balfour House, Churchfield Road, Walton-on-Thames, Surrey, KT12 2TD, United Kingdom
Notified Body Identification Number : 0168

Declaration

I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates complies with the above mentioned standards and Directives

European Standard Center
LG Electronics Logistics and Services B.V.
Veluwezoom 15, 1327 AE Almere, The Netherlands
Tel : +31 - 36- 547 - 8940, Fax : +31 - 36 - 547 - 8794
e-mail : jacob @ lge.com

Name

Issued Date

Seung Hyoun, Ji / Director

23, FEB, 2009

Signature of representative

Memo

GM200 उपयोगकर्ता मार्गदर्शिका – HINDI

यह मार्गदर्शिका आपके नए मोबाइल को समझने में आपकी मदद करेगी. यह आपको आपके फोन में दी गई सुविधाओं के बारे में उपयोगी जानकारी देगी.

इस मार्गदर्शिका की कुछ सामग्री आपके फोन के सॉफ्टवेयर या आपके सेवा प्रदाता के अनुसार आपके फोन से अलग हो सकती है.



अपने फोन को जानें



मेमोरी कार्ड लगाना

मेमोरी कार्ड कवर उठाएं और गोल्डन संपर्क क्षेत्र को नीचे की तरफ रख कर माइक्रो एसडी कार्ड डालें. मेमोरी कार्ड कवर इस तरह बंद करें कि वह क्लिक की आवाज के साथ बंद हो जाए. मेमोरी कार्ड निकालने के लिए, चित्र में दिखाए अनुसार उसे धीमे से धकेलें.



नोट: मेमोरी कार्ड एक वैकल्पिक सहायक उपकरण है.

मेमोरी कार्ड स्वरूपित करना

मेनू दबाएँ और सेटिंग चुनें.

मेमोरी स्थिति चुनें, बाह्य मेमोरी चुनें और स्वरूप दबाएँ.

चेतावनी: आपके द्वारा अपना मेमोरी कार्ड स्वरूपित करने पर सभी सामग्री हट जाएगी. यदि आप अपने मेमोरी कार्ड का डेटा खोना नहीं चाहते हैं तो पहले उसका बैकअप ले लें.

सिम कार्ड लगाना और बैटरी चार्ज करना


सिम कार्ड लगाना

किसी सेल्युलर नेटवर्क की सदस्यता लेने पर, आपको आपके सदस्यता विवरण जैसे आपका पिन, उपलब्ध वैकल्पिक सेवाएँ और अन्य जानकारी वाला प्लग-इन सिम कार्ड दिया जाता है।

महत्वपूर्ण ! > प्लग-इन सिम कार्ड और उसके संपर्क खरोंचों या मुड़ने से बहुत जल्दी खराब हो सकते हैं, इसलिए कार्ड रखते, डालते, और निकालते समय सावधानी रखें। सभी सिम कार्ड छोटे बच्चों की पहुँच से दूर रखें।

सिम कैसे डालें

- 1 बैटरी कवर खोलें
- 2 बैटरी निकालें
- 3 अपनी सिम डालें
- 4 बैटरी कवर बंद करें
- 5 अपने फोनकी बैटरी चार्ज करें



चेतावनी: जब फोन चालू हो तो बैटरी न निकालें, इससे फोन को नुकसान हो सकता है।

मेनू मैप



खेल एवं अनुप्रयोग

- 1 गेम्स
- 2 सुविधायें
- 3 नेटवर्क की रुपरेखा



कॉल इतिहास

- 1 सभी कॉल
- 2 छोटे कॉल
- 3 डायलड कॉल्स
- 4 प्राप्त कॉल
- 5 कॉल अवधि
- 6 कॉल लागत
- 7 डेटा जानकारी



ऑर्गेनाइजर

- 1 कैलेंडर
- 2 मेमो
- 3 करने के लिए



मल्टीमीडिया

- 1 MP3 प्लेयर
- 2 कैमरा
- 3 वीडियो कैमरा
- 4 FM रेडियो
- 5 वॉइस रिकॉर्डर
- 6 रिंगटोन बनाने वाला



संदेश

- 1 नया संदेश
- 2 इनबॉक्स
- 3 ई-मेल बॉक्स
- 4 प्रारूप
- 5 आउटबॉक्स
- 6 प्रेषित
- 7 वॉइज़ मेल सुनें
- 8 जानकारी संदेश
- 9 टेम्पलेट्स
- 0 सेटिंग्स



मेरी चीज़ें

- 1 चित्र
- 2 ध्वनि
- 3 वीडियो
- 4 अन्य
- 5 बाहरी मेमोरी



प्रोफाइल्स

- 1 सामान्य
- 2 मौन
- 3 सिर्फ कंपन
- 4 आउटडोर
- 5 हेडसेट



फ़ोन पुस्तिका

- 1 खोजें
- 2 नया संपर्क
- 3 स्पीड डायल
- 4 समूह
- 5 सभी की प्रतिलिपि बनाएँ
- 6 सभी हटाएँ
- 7 सेटिंग
- 8 जानकारी



उपकरण

- 1 अलार्म घड़ी
- 2 कैलकुलेटर
- 3 स्टॉपवॉच
- 4 इकाई परिवर्तक
- 5 विश्व घड़ी
- 6 सिम सेवाएँ



WAP

- 1 होम
- 2 Google खोज
- 3 सक्रिय NDTV
- 4 बुकमार्क
- 5 पता दर्ज करें
- 6 इतिहास
- 7 सुरक्षित पृष्ठ
- 8 सेटिंग
- 9 जानकारी



संयोजकता

- 1 ब्लूटूथ
- 2 नेटवर्क
- 3 USB संयोग मोड



सेटिंग्स

- 1 दिनांक और समय
- 2 भाषाएँ
- 3 प्रदर्शित करें
- 4 शॉर्टकट
- 5 कॉल
- 6 सुरक्षा
- 7 फ्लाइट मोड
- 8 ऊर्जा बचत
- 9 रीसेट करें
- 0 मेमोरी स्थिति

कॉल्स

कॉल करना

- 1 कीपैड से नंबर लिखें. कोई अंक हटाने के लिए **साफ करें** दबाएँ.
- 2 कॉल शुरू करने के लिए  दबाएँ.
- 3 कॉल समाप्त करने के लिए,  दबाएँ.

युक्ति! कोई अंतर्राष्ट्रीय कॉल करते समय + दर्ज करने के लिए 0 दबाकर रखें.

अपने संपर्कों से कॉल करना

- 1 स्टैंडबाय स्क्रीन से संपर्क चुनें.
- 2 कीपैड का उपयोग करके उस संपर्क का पहला अक्षर लिखें, जिसे आप कॉल करना चाहते हैं. उदाहरण के लिए, Office के लिए, पहला वर्ण "O" चुनने के लिए तीन बार 6 दबाएँ
- 3 कॉल प्रारंभ करने के लिए **कॉल करें** चुनें या  दबाएँ.

कॉल का उत्तर देना और निरस्त करना

जब आपके फोन की घंटी बजे, तो **स्वीकारें** दबाएँ या कॉल का उत्तर देने के लिए  दबाएँ. आपका फोन बजने पर उसे म्यूट करने के लिए, केवल **मौन** चुनें. यदि आप किसी मीटिंग के लिए अपनी प्रोफाइल को मौन पर बदलना भूल गए हैं तो ऐसा करना उपयोगी होगा.

आवक कॉल अस्वीकार करने के लिए  दबाएँ या निरस्त करें दबाएँ.

युक्ति! अपने कॉल्स का विभिन्न तरीकों से उत्तर देने के लिए आप अपने फोन की सेटिंग्स बदल सकते हैं. इसके लिए **मेनू** दबाएँ, सेटिंग्स चुनें और कॉलें का चयन करें. इसके लिए **उत्तर मोड** चुनें और **किसी भी कुंजी** या **केवल भेजें कुंजी** चुनें.

शीघ्र डायलिंग

आप ऐसे संपर्क को स्पीड डायल नंबर असाइन कर सकते हैं, जिसे आप बार-बार कॉल करते हैं.

अपना कॉल इतिहास देखना

आप छूटी, प्राप्त, और डायल की गई कॉल्स के रिकॉर्ड केवल तभी देख सकते हैं, जब नेटवर्क, उस सेवा क्षेत्र में कॉलिंग लाइन आइडेंटिफिकेशन (CLI) का समर्थन करता है.

कॉल सेटिंग्स बदलना

आप किसी कॉल के संगत मेनू सेट कर सकते हैं. इसके लिए **मेनू** दबाएँ, **सेटिंग्स** चुनें और कॉल का चयन करें.

- **कॉल अंतरण** – अपने कॉल्स को डायवर्ट करना या न करना चुनें.
- **कॉल रोधन** – चुनें कि आप कब कॉल अवरोधित करना चाहेंगे.
- **निर्धारित डायल नंबर** – उन नंबरों की सूची चुनें, जिन्हें आपके फोन से कॉल किया जा सके. आपको आपके ऑपरेटर से आपका PUK2 कोड लेना होगा. केवल फिक्स्ड डायल सूची में शामिल नंबरों को ही आपके फोन से कॉल किया जा सकता है.

- **उत्तर मोड** – चुनें कि किसी भी कुंजी से फोन का उत्तर देना है या केवल भेजें कुंजी से.
- **मेरा नंबर भेजें** – चुनें कि किसी व्यक्ति को कॉल करने पर आपका नंबर प्रदर्शित हो या नहीं. (आपके नेटवर्क प्रदाता पर निर्भर करता है.)
- **कॉल प्रतीक्षा** – कोई कॉल प्रतीक्षा में होने पर सचेत रहें. (आपके नेटवर्क प्रदाता पर निर्भर करता है.)
- **मिनट माइंडर** – किसी कॉल के दौरान प्रत्येक मिनट पर टोन सुनने के लिए चालू को चुनें.
- **स्वतः रिडायल** – चालू या बंद चुनें.
- **DTMF टोन्स भेजें** – चालू या बंद चुनें.

फोन पुस्तिका

कोई संपर्क खोजना

- 1 स्टैंडबाय स्क्रीन से **फोन पुस्तिका** चुनें और **खोजें** का चयन करें.
- 2 जिस संपर्क को आप कॉल करना चाहते हैं, उसका पहला अक्षर लिखने के लिए कीपैड का उपयोग करें.
- 3 संपर्क और उनके अलग-अलग नंबरों में स्क्रॉल करने के लिए नेविगेशन कुंजियों का उपयोग करें.

नया संपर्क जोड़ना

- 1 **फोन पुस्तिका** दबाएँ और **नए संपर्क** का चयन करें.
- 2 चुनें कि आपके नए संपर्क को आपके **फोन** पर संग्रहीत करना है या **सिम** कार्ड पर.

- 3 उपलब्ध कराई गई फील्ड में अपनी सभी जानकारीयों दर्ज करें और **सहेजें** चुनें.

किसी समूह में संपर्क जोड़ना

आप अपने संपर्कों को समूहों में सहेज सकते हैं, उदाहरण के लिए, अपने सहकर्मियों और परिजनों को अलग-अलग समूह में रख सकते हैं. परिवार, दोस्त, सहकर्मी, वीआईपी समूह¹, समूह² और समूह³ सहित कई समूह हैं, जो पहले से फोन में सेट हैं.

किसी संपर्क में चित्र जोड़ना

कोई चित्र शामिल करके आप अपनी पता पुस्तिका में अपने संपर्कों का प्रकटन बदल सकते हैं.

- 1 स्टैंडबाय स्क्रीन में, **फोन पुस्तिका** चुनें और फिर **सेटिंग्स** चुनें.
- 2 विकल्प देखें चुनें और चित्र सहित का चयन करें.
- 3 फिर पता पुस्तिका पर वापस आएँ और वह संपर्क चुनें, जिसमें आप चित्र जोड़ना चाहते हैं.
- 4 **विकल्प** चुनें और फिर संपादन चुनें.
- 5 चित्र अनुभाग में नीचे स्क्रॉल करें. **विकल्प** का चयन करें और सहेजें, कोई चित्र नहीं, छवियाँ या नई छवि का चयन करें. यदि आप छवि को चुनते हैं, तो आप किसी ऐसी छवि को भी चुन सकते हैं, जो आपकी फोन मेमोरी में सहेजी हुई है. यदि आप नई छवि का चयन करते हैं, तो आपके कैमरे का व्यू फाइंडर खुल जाएगा, ताकि आप अपने संपर्क का चित्र ले सकें.
- 6 सहेजें चुनें.

संदेश

आपके GM200 में एसएमएस (शॉर्ट मैसेज सर्विस) एवं एमएमएस (मल्टीमीडिया मैसेज सर्विस) और ई-मेल, सहित नेटवर्क के सेवा संदेशों से संबंधित सुविधाएँ हैं।

संदेश भेजना

- 1 मेनू दबाएँ, **संदेश** चुनें और **नया संदेश** चुनें.
- 2 एसएमएस या एमएमएस भेजने के लिए संदेश चुनें.
- 3 नया संदेश संपादक खुलेगा. संदेश संपादक एक सहज और आपस में आसानी से बदलें जाने वाले मोड में एसएमएस और एमएमएस को जोड़ता है. संदेश संपादक की डिफॉल्ट सेटिंग एसएमएस मोड है.
- 4 T9 प्रिडिक्टिव मोड या एबीसी मैन्युअल मोड का उपयोग करते हुए अपना संदेश लिखें.
- 5 अब **विकल्प** चुनें और कोई **चित्र**, **ध्वनि**, **वीडियो**, **प्रतीक**, **पाठ्य टेम्पलेट**, **भावनाएं**, **नाम एवं नंबर**, **नया स्लाइड**, **विषय** या **अन्य (संपर्क/मेरा व्यवसाय कार्ड/सूची/मेमो/करने के लिये)** जोड़ने के लिये सम्मिलित करें का चयन करें.
- 6 मध्य कुंजी दबाएँ.
- 7 फोन नंबर दर्ज करें या **विकल्प** दबाएँ और अपनी **फ़ोन पुस्तिका** सूची खोलने के लिए संपर्क या नवीनतम सूची चुनें. आप एक से अधिक संपर्क जोड़ सकते हैं.
- 8 भेजें चुनें.

अपनी ईमेल सेट करना

आप अपने GM200 पर ईमेल का उपयोग करते हुए यात्रा के दौरान भी संपर्क में रह सकते हैं. POP3 या IMAP4 ईमेल खाता सेट करना तेज़ और आसान है.

- 1 मेनू दबाएँ, **संदेश** सेवा चुनें और **सेटिंग्स** का चयन करें.
- 2 **ई-मेल** और फिर **ई-मेल लेखा** चुनें.
- 3 **नया** चुनें और फिर **ई-मेल** खाता सेट करें.

अपने नए खाते का उपयोग करके ईमेल भेजना
ईमेल भेजने/प्राप्त करने के लिए, आपको ईमेल खाता सेट करना होगा.

- 1 मेनू चुनें, **संदेश** सेवा चुनें और **नया संदेश** का चयन करें.
- 2 अब **ई-मेल** चुनें और एक नया ईमेल खुल जाएगा.
- 3 कोई विषय लिखें, फिर **विकल्प** दबाएँ और ईमेल लिखें का चयन करें और **ठीक** दबाएँ.
- 4 अपना संदेश लिखें.
- 5 कोई संलग्नक जोड़ने के लिए, **विकल्प** चुनें और **संलग्नक** चुनें, फिर नया दबाएँ: **छवि**, **ध्वनि**, **वीडियो**, **अन्य (संपर्क, मेरे व्यवसाय कार्ड, सूची, मेमो, करने के लिये)** या बाहरी मेमोरी की सामग्रियाँ.
- 6 भेजें दबाएँ और प्राप्तकर्ता का पता लिखें या **विकल्प** दबाएँ और अपनी संपर्क सूची खोलने के लिए **संपर्क** चुनें.
- 7 भेजें दबाएँ और आपका ईमेल भेज दिया जाएगा.

पाठ लिखना

आप फोन के कीपैड का उपयोग करते हुए अल्फान्यूमेरिक वर्ण लिख सकते हैं। फोन में निम्न पाठ इनपुट पद्धतियाँ उपलब्ध हैं: T9 प्रिडिक्टिव मोड, ABC मैन्युअल मोड और 123 मोड।

नोट: कुछ फील्ड में केवल एक पाठ इनपुट पद्धति की ही अनुमति होती है (जैसे पता पुस्तिका फील्ड्स में टेलीफोन नंबर)।

T9 प्रिडिक्टिव मोड

T9 प्रिडिक्टिव मोड आपके द्वारा लिखे जा रहे शब्दों को पहचानने के लिए आपके द्वारा दबाई जा रही कुंजियों के क्रम के आधार अंतर्निहित शब्दकोश का उपयोग करता है। जिस अक्षर को आप डालना चाहते हैं उससे संबंधित कुंजी दबाएँ, और शब्दकोश सभी अक्षरों के लिखते ही शब्द को पहचान लेगा।

ABC मैन्युअल मोड

इस मोड में आप अपने इच्छित अक्षर वाली कुंजी को दबाकर अक्षर डाल सकते हैं, इसके लिए अक्षर दिखाई देने तक आपको एक, दो, तीन या चार बार कुंजी दबाना पड़ सकता है।

123 मोड

प्रत्येक अंक के लिए एक बार कुंजी दबाने से वह अंक लिखा जाता है। आप अक्षर मोड में रहते हुए भी इच्छित कुंजी को दबाए रखकर अंक डाल सकते हैं।

संदेश फोल्डर्स

मेनू दबाएँ, संदेश सेवा चुनें। आपके GM200 पर प्रयुक्त फोल्डर संरचना बिल्कुल सरल और स्पष्ट है।

इनबॉक्स – आपको प्राप्त सभी संदेश आपके इनबॉक्स में रखे जाते हैं।

ई-मेल बॉक्स – इसमें आपके सभी ईमेल संदेश होते हैं।

प्रारूप – यदि आपके पास संदेश पूरा लिखने का समय नहीं है, तो आप लिखे हुए संदेश को यहाँ सहेज सकते हैं।

आउटबॉक्स – यह संदेश भेजे जाने के समय के लिए अस्थायी संग्रहण फोल्डर होता है।

प्रेषित – आपके द्वारा भेजे गए सभी संदेश आपके प्रेषित फोल्डर में रखे जाते हैं।

वॉइज़ मेल सुनें – आप अपने वॉइसमेल बॉक्स तक पहुँच सकते हैं (यदि वह आपके नेटवर्क द्वारा प्रदान किया गया हो)।

जानकारी संदेश – आपके ऑपरेटर से प्राप्त सभी जानकारी संदेश और अपडेट यहाँ होते हैं।

टेम्पलेट्स – त्वरित उत्तर के लिए पहले से लिखे उपयोगी संदेशों की सूची।

मल्टीमीडिया

MP3 प्लेयर

आपके GM200 में एक अंतर्निहित MP3 प्लेयर है, इसलिए आप अपना सभी पसंदीदा संगीत बजा सकते हैं।

कोई गीत चलाना

- 1 मेनू दबाएँ और **मल्टीमीडिया** चुनें, और फिर MP3 प्लेयर चुनें.
- 2 सभी गाने चुनें और फिर इच्छित गाना चुनें.
- 3 गीत को रोकने के लिए  चुनें.
- 4 अगले गाने पर जाने के लिए  चुनें.
- 5 पिछले गाने पर जाने के लिए  चुनें.
- 6 संगीत रोकने और MP3 प्लेयर मेनू पर वापस आने के लिए वापस चुनें.

सूची बनाना

आप सभी गाने फोल्डर से गीत चुनकर अपनी स्वयं की सूची बना सकते हैं.

- 1 मेनू दबाएँ और **मल्टीमीडिया** चुनें.
- 2 अब MP3 प्लेयर का चयन करें, और फिर मेरी सूची चुनें.
- 3 विकल्प दबाएँ और नई नई सूची, प्लेलिस्ट का नाम लिखें और सहेजें दबाएँ.
- 4 सभी गीत फोल्डर दिखाई देगा. स्कॉल करके और  चुनकर वे सभी गीत चुनें जिन्हें आप अपनी सूची में सम्मिलित करना चाहते हैं.
- 5 सूची संग्रहीत करने के लिए पूर्ण चुनें.

डॉल्बी प्रभाव या LG इक्वेलाइज़र सेट करना

आप डॉल्बी प्रभाव और LG इक्वेलाइज़र सेट कर सकते हैं.

- 1 मेनू दबाएँ और **मल्टीमीडिया** चुनें, और फिर MP3 प्लेयर का चयन करें.
- 2 सेटिंग का चयन करें, फिर ऑडियो प्रभाव चुनें.
- 3 डॉल्बी प्रभाव या LG इक्वेलाइज़र चुनें.

कैमरा

तुरंत फोटो लेना

- 1 मेनू चुनें, और **मल्टीमीडिया** चुनें. व्यूफाइंडर खोलने के लिए **कैमरा** चुनें.
- 2 फोन को थामें और लेंस को फोटो के सब्जेक्ट पर केंद्रित करें.
- 3 फोन इस तरह रखें कि आप अपने फोटो के सब्जेक्ट को देख सकें.
- 4 फोटो लेने के लिए मध्य कुंजी दबाएँ.

वीडियो कैमरा

तुरंत वीडियो शूट करना

- 1 स्टैंडबाय स्क्रीन में, मेनू और **मल्टीमीडिया** चुनें.
- 2 वीडियो कैमरा चुनें.
- 3 कैमरा लेंस को वीडियो के सब्जेक्ट पर केंद्रित करें.
- 4 रिकॉर्डिंग प्रारंभ करने के लिए  दबाएँ.
- 5 व्यूफाइंडर के निचले बाएँ कोने में Rec दिखाई देगा और टाइमर आपके वीडियो की लंबाई दिखाएगा.
- 6 रिकॉर्डिंग रोकने के लिए **रोकें** दबाएँ.

FM रेडियो

एफएम रेडियो चलाना

आपके LG GM200 में एफएम रेडियो सुविधा है, जिससे आप यात्रा के दौरान भी अपने पसंदीदा रेडियो स्टेशन को सुनने के लिए ट्यून कर सकते हैं.

रेडियो सुनना

- 1 **मेनू** दबाएँ और **मल्टीमीडिया** चुनें, और फिर **FM रेडियो** का चयन करें.
- 2 उस स्टेशन का चैनल नंबर चुनें, जिसे आप सुनना चाहते हैं.

रेडियो से रिकॉर्ड करना

- 1 रेडियो सुनते समय मध्य कुंजी दबाएँ.
- 2 रिकॉर्डिंग समय आपके फोन पर दिखाई देता है. यदि आप रिकॉर्डिंग रोकना चाहते हैं, तो  दबाएँ. रिकॉर्डिंग पूरी होने पर रिकॉर्ड की गई सामग्री मेरी चीजें में mp3 फाइल के रूप में सहेज ली जाएँगी.
- 3 रिकॉर्डिंग पूरी होने पर, **विकल्प** चुनें और फिर **हटाएँ, ऐसे सेट करें, या अल्बम** में से चयन करें.

नोट: यदि आप खराब रेडियो रेसेप्शन क्षेत्र में हैं तो, आपको रेडियो सुनने में दिक्कत हो सकती है. अच्छे रेडियो रेसेप्शन और रेडियो सुनने के लिए हेड सेट को हैंड्सफ्री कनेक्टर में लगाए

वॉइज़ रिकॉर्डर

वॉइस मेमो या अन्य ध्वनियाँ रिकॉर्ड करने के लिए अपने वॉइज़ रिकॉर्डर का उपयोग करें.

रिंगटोन बनाने वाला

- 1 **मेनू** दबाएँ और **मल्टीमीडिया** चुनें, और फिर **रिंगटोन बनाने वाला** का चयन करें.
- 2 वह संगीत चुनें, जिसका उपयोग आप संगीत सूचियों में करना चाहेंगे, और फिर **ठीक** चुनें.
- 3 मध्य कुंजी दबाएँ.

- 4 जब आप कोई संगीत चला रहे हों और उसे रिंगटोन की तरह उपयोग करना चाहें तो संगीत रिकॉर्डिंग शुरू करने के लिए कट करें चुनें.
- 5 जब आप संगीत रिकॉर्डिंग रोकना चाहें, तो कट करें चुनें.
- 6 रिकॉर्डिंग समाप्त कर लेने के बाद, विकल्प चुनें और **रक्षित करें, चलाएँ** या **रीसेट करें** में से चयन करें. यदि आप **रीसेट करें** का चयन करते हैं, तो चयनित फाइल आपके फोन से निकाल दी जाती है.

मेरी चीजें

आप अपने फोन की मेमोरी में कोई भी मल्टीमीडिया फाइल संग्रहीत कर सकते हैं, जिससे आप अपनी सभी छवियों, ध्वनियों, वीडियो, अन्य चीजों और गेम्स पर आसानी से पहुँच सकें. आप अपनी फाइलों को मेमोरी कार्ड में भी सहेज सकते हैं. मेमोरी कार्ड के उपयोग का यह लाभ है कि इससे आप अपने फोन की मेमोरी का स्थान खाली कर सकते हैं. आपकी सभी मल्टीमीडिया फाइलें **मेरी चीजें** में सहेजी जाएँगी. फोल्डरों की सूची खोलने के लिए **मेनू** दबाएँ और फिर **मेरी चीजें** चुनें.

चित्र

चित्र में आपके फोन की डिफॉल्ट छवियाँ, फोल्डर, आपके द्वारा डाउनलोड की गई छवियाँ, और आपके फोन के कैमरे से ली गई छवियाँ शामिल होती हैं.

ध्वनि

ध्वनि में डिफ़ॉल्ट ध्वनियाँ, आपकी वॉइस रिकॉर्डिंग और आपके द्वारा डाउनलोड की गई ध्वनि फाइलें होती हैं। यहाँ से आप ध्वनियों को प्रबंधित कर सकते हैं, भेज सकते हैं या रिंगटोन के रूप में सेट कर सकते हैं।

वीडियो

वीडियो फोल्डर डाउनलोड किए गए वीडियो और आपके द्वारा अपने फोन पर रिकॉर्ड किए गए वीडियो की सूची दिखाता है।

अन्य

अन्य मेनू से, आप वे फाइलें देख सकते हैं, जो चित्र, ध्वनि या वीडियो फोल्डर में नहीं सहेजी गई हैं।

बाहरी मेमोरी

यदि आपने मेमोरी कार्ड लगाया है, तो यह मेरी चीजों में फोल्डर के रूप में दिखाई देगा।

खेल एवं अनुप्रयोग

आपके GM200 में पहले से लोड किए गए गेम्स होते हैं, ताकि आप खाली समय में भी मनोरंजन कर सकें। यदि आप कोई भी अतिरिक्त गेम या अनुप्रयोग डाउनलोड करते हैं तो वे इस फोल्डर में सहेजे जाएँगे। इसमें जाने के लिए **मेनू** दबाएँ और **खेल एवं अनुप्रयोग** चुनें।

आयोजक / उपकरण

कैलेंडर का उपयोग करना

जब आप इस मेनू में आते हैं, तो एक कैलेंडर दिखाई देता है। वर्तमान दिनांक पर वर्गाकार कर्सर स्थित होता है। आप नेविगेशन कुंजियों का उपयोग करके कर्सर को दूसरे दिनांक पर ले जा सकते हैं।

मेमो जोड़ना

आप अपने स्वयं के मेमो यहाँ पंजीकृत कर सकते हैं।

करने के लिए में आइटम जोड़ना

आप करने के कार्यों को देख सकते हैं, संपादित कर सकते हैं, और जोड़ सकते हैं।

अपना अलार्म सेट करना

किसी निर्दिष्ट समय को याद रखने के लिए आप अधिकतम 5 अलार्म घड़ियाँ सेट कर सकते हैं।

अपने कैल्कुलेटर का उपयोग करना

कैल्कुलेटर आपको मूलभूत गणितीय फंक्शन योग, अंतर, गुणा और भाग प्रदान करता है।

स्टॉपवॉच का उपयोग करना

इस विकल्प के द्वारा आप विराम घड़ी फंक्शन का उपयोग कर सकते हैं।

इकाई परिवर्तक

यह कई मापों को आपकी इच्छित इकाई में कनवर्ट करता है।

अपनी विश्व घड़ी में कोई शहर जोड़ना

आप विश्व घड़ी की सूची में वह शहर जोड़ सकते हैं जिसकी आपको आवश्यकता है। आप ग्रीनविच

मीन टाइम (GMT) और पूरे विश्व के प्रमुख शहरों का वर्तमान समय भी जाँच सकते हैं।

सिम सेवाएँ

यह सुविधा सिम और नेटवर्क सेवाओं पर निर्भर करती है। यदि सिम कार्ड SAT (अर्थात् सिम एप्लिकेशन टूलकिट) सेवाओं का समर्थन करता है, तो यह मेनू सिम कार्ड पर संग्रहीत ऑपरेटर विशिष्ट सेवा के रूप में होगा।

WAP

ब्राउजर तक पहुँच

आप वैप ब्राउजर लॉन्च कर सकते हैं और ब्राउजर सेटिंग्स पर सक्रिय प्रोफाइल के होमपेज पर पहुँच सकते हैं। आप मैनुअल रूप से भी URL पता दर्ज कर सकते हैं और संबंधित वेब पेज तक पहुँच सकते हैं।

- 1 मेनू दबाएँ और WAP चुनें।
- 2 ब्राउजर के होमपेज पर सीधे पहुँचने के लिए, होमपेज चुनें। वैकल्पिक रूप से, पता दर्ज करें चुनें और अपना इच्छित URL लिखें।

Google खोज का उपयोग करना

इस फंक्शन के उपयोग से Google इंटरनेट सेवा पर आसानी से पहुँचा जा सकता है।

सक्रिय NDTV

GM200, सक्रिय NDTV का समर्थन करता है: समाचार और समसामयिक घटनाक्रमों इत्यादि की जानकारी प्राप्त करने के लिए इस पर पहुँचें।

संयोजकता

अपनी संयोजकता सेटिंग्स बदलना

आपकी संयोजकता सेटिंग्स आपके नेटवर्क ऑपरेटर द्वारा पहले ही सेट कर दी गई हैं, इसलिए आप सीधे ही अपने नए फोन का उपयोग शुरू कर सकते हैं। यदि आप कोई सेटिंग्स बदलना चाहते हैं, तो इस मेनू का उपयोग करें। इस मेनू में आप नेटवर्क सेटिंग और डेटा एक्सेस प्रोफाइल्स कॉन्फिगर कर सकते हैं।

- **ब्लूटूथ** – अपने GM200 को ब्लूटूथ उपयोग के लिए सेट करें। आप अन्य डिवाइसों के लिए अपनी दर्शनीयता अपना सकते हैं या उन डिवाइसों से खोज कर सकते हैं, जिनसे आपका फोन जुड़ा है।
- **नेटवर्क** – आपका GM200 अपने आप आपके अनुशंसित नेटवर्क से कनेक्ट हो जाता है। ये सेटिंग्स बदलने के लिए इस मेनू का उपयोग करें। इस मेनू का उपयोग करते हुए आप नए एक्सेस पॉइंट भी जोड़ सकते हैं।
- **USB संयोग मोड** – डेटा सेवा चुनें और अपने फोन की फाइलों की प्रतिलिपि बनाने के लिए LG PC Suite सॉफ्टवेयर का उपयोग करते हुए अपना GM200 सिंक्रनाइज करें। यदि मेमोरी कार्ड लगा हुआ है तो अपने फोन का ठीक यूएसबी स्टिक की तरह उपयोग करने के लिए **मास स्टोरेज** चुनें। अपने कंप्यूटर से कनेक्ट करें और GM200 निकाले जाने योग्य डिवाइस फोल्डर में फाइलें ड्रैग और ड्रॉप करें।

नोट: यूएसबी मास स्टोरेज फंक्शन का उपयोग करने के लिए, आपको अपने फोन में बाहरी मेमोरी कार्ड डालना होगा।

अपनी ब्लूटूथ सेटिंग्स बदलना

1 मेनू दबाएँ और **संयोजकता** चुनें. **ब्लूटूथ** चुनें.

2 **ब्लूटूथ सेटिंग्स** चुनें.

अब निम्न में परिवर्तन करें :

- **मेरी दृश्यता** – चुनें कि दूसरों को अपनी डिवाइस दिखाएँ या छुपाएँ.
- **मेरा नाम** – अपने LG GM200 के लिए कोई नाम लिखें.
- **मेरा पता** – अपना ब्लूटूथ पता देखें.
- **प्राथमिक संग्रहण** – वह डिफॉल्ट स्थान चुनें, जिस पर आइटम सहेजे जाने को आप प्राथमिकता देते हैं.

दूसरी ब्लूटूथ डिवाइस से जुड़ना

अपने GM200 और अन्य डिवाइस को जोड़कर आप कोई पासकोड सुरक्षित कनेक्शन सेट कर सकते हैं. इसका अर्थ है कि आप अधिक सुरक्षित तरीके से जुड़े हैं.

- 1 जाँचें कि आपका ब्लूटूथ **चालू** और **दृश्यमान** है. आप **ब्लूटूथ सेटिंग्स** और फिर **मेरी दृश्यता** चुनकर **दिखाएँ** मेनू में अपनी दृश्यता बदल सकते हैं.
- 2 **ब्लूटूथ** मेनू से **डिवाइस सूची** चुनें और नया का चयन करें.
- 3 आपका GM200 डिवाइसों की खोज करेगा. खोज पूरी होने पर स्क्रीन पर **पेयर और पुनश्चर्या** दिखाई देंगे.
- 4 जिस डिवाइस को आप जोड़ना चाहते हैं, उसे चुनें, **जोड़ें** चुनें और पासकोड डालने के बाद **ठीक** कुंजी का चयन करें.

5 इसके बाद आपका फोन दूसरे डिवाइस से कनेक्ट हो जाएगा, जिसमें आपको वही पासकोड लिखना होगा.

6 अब आपका पासकोड रक्षित ब्लूटूथ कनेक्शन तैयार है.

प्रोफाइल्स

अपनी प्रोफाइल को व्यक्तिगत रूप देना

आप प्रत्येक प्रोफाइल सेटिंग को व्यक्तिगत रूप दे सकते हैं.

- 1 **मेनू** दबाएँ और **प्रोफाइल्स** चुनें.
- 2 इच्छित प्रोफाइल चुनें और **वैयक्तिकृत** चुनें.
- 3 मौन और सिर्फ कंपन प्रोफाइलों को, आप केवल सक्रिय कर सकते हैं.

अपनी प्रोफाइलों की स्मार्ट – प्रोफाइलिंग.

आस पास के वर्तमान वातावरण पर विचार करते हुए आप उपयुक्त वॉल्यूम स्तर चुन सकते हैं.

- 1 **मेनू** दबाएँ और **प्रोफाइल्स** चुनें.
- 2 **सामान्य** या **आउटडोर** का चयन करें. आप इस फंक्शन का उपयोग केवल सामान्य और आउटडोर के साथ कर सकते हैं.
- 3 **स्मार्ट-प्रोफाइलिंग** चुनें.
- 4 आपका फोन आपके लिए उपयुक्त वॉल्यूम स्तर की अनुशंसा करता है.

सेटिंग्स

अपना दिनांक और समय बदलना

आप दिनांक और समय से संबंधित फंक्शन सेट कर सकते हैं.

भाषा बदलना

आप अपने फोन में डिस्प्ले पाठ की भाषा बदल सकते हैं। इस बदलाव से भाषा इनपुट मोड भी प्रभावित होगा।

अपनी प्रदर्शन सेटिंग्स बदलना

आप फोन डिस्प्ले की सेटिंग्स बदल सकते हैं।

अपनी शॉर्टकट्स सेटिंग्स बदलना

आप 4 नेविगेशन कुंजियों के शॉर्टकट्स बदल सकते हैं।

अपनी सुरक्षा सेटिंग्स बदलना

अपने GM200 और उसके द्वारा सुरक्षित की जाने वाली महत्वपूर्ण जानकारीयाँ बनाए रखने के लिए अपनी सुरक्षा सेटिंग्स बदलें।

- **PIN कोड अनुरोध** – आपके द्वारा अपना फोन चालू करने पर डाला जाने वाला पिन कोड चुनें।
- **स्वतः की लॉक** – स्टैंडबाय स्क्रीन में कुंजी की गतिविधि के बिना अपने आप कीपैड लॉक करें।
- **फोन लॉक** – अपने फोन के लिए ये सुरक्षा कोड चुने जब पॉवर चालू हो, जब सिम बदली जाए या तुरंत।
- **अनुप्रयोग लॉक** – अनुप्रयोग लॉक करें: छवि, कैलेंडर, मेमो, करने के लिये।
- **एंटी थेफ्ट मोबाइल ट्रैकर** – हैंडसेट चोरी हो जाने पर, हैंडसेट वास्तविक स्वामी द्वारा कॉन्फिगर किए गए नंबरों पर एसएमएस भेजता है। ATMT सुविधा सक्रिय करने के लिए, आपको ATMT को चालू पर सेट करना होगा, और नाम, प्राथमिक नंबर और द्वितीयक नंबर के साथ

ATMT सेटिंग्स कॉन्फिगर करना होगी। डिफॉल्ट ATMT कोड "0000" है।

ATMT एसएमएस में चोरी हुए फोन IMEI के बारे में जानकारी, वर्तमान स्थान (जो प्रति सेल ब्रॉडकास्ट संदेश के अनुसार कैप्चर किया गया है) और उस व्यक्ति का नंबर होगा, जो उस हैंडसेट का उपयोग कर रहा है।

- **कोड्स बदलें** – अपना सुरक्षा कोड, PIN2 कोड, या ATMT कोड बदलें।

फ्लाइट मोड का उपयोग करना

फ्लाइट मोड चालू या बंद करने के लिए इस फंक्शन का उपयोग करें। फ्लाइट मोड चालू होने पर आप कॉल नहीं कर सकेंगे, इंटरनेट से कनेक्ट नहीं हो सकेंगे, संदेश नहीं भेज सकेंगे।

कोड बदलें

ऊर्जा बचत सेटिंग्स चालू या बंद करना चुनें।

आपके फोन को रीसेट करना

सभी सेटिंग्स को उनके फैक्ट्री निर्धारण पर रीसेट करने के लिए रीसेट करें का उपयोग करें। यह फंक्शन सक्रिय करने के लिए आपको सुरक्षा कोड की आवश्यकता होगी।

मेमोरी की स्थिति देखना

आप मेमोरी प्रबंधक का उपयोग कर निर्धारित कर सकते हैं कि कितनी मेमोरी का उपयोग हुआ है और देख सकते हैं कि कितना स्थान उपलब्ध है: साँझा, आरक्षित, सिम कार्ड, और बाहरी मेमोरी।

सुरक्षित और प्रभावी उपयोग के दिशानिर्देश

कृपया ये सरल दिशानिर्देश पढ़ें. इन दिशानिर्देशों का पालन न करना खतरनाक या गैरकानूनी हो सकता है.

रेडियो फ्रीक्वेंसी ऊर्जा के संपर्क में आना

रेडियो तरंगों से संपर्क और विशिष्ट अवशोषण दर (स्पेसिफिक एब्जॉर्शन रेट) (SAR) की जानकारी

यह मोबाइल फोन मॉडल GM200 रेडियो तरंगों के एक्सपोजर के लिए लागू सुरक्षा आवश्यकताओं के अनुरूप बनाया गया है. ये आवश्यकताएँ वैज्ञानिक निर्देशों पर आधारित हैं, जिनमें सभी आयु वर्ग और हर प्रकार के स्वास्थ्य वाले लोगों की सुरक्षा तय करने के लिए बनाए गए सुरक्षा उपाय शामिल हैं.

- रेडियो तरंग संपर्क एक्सपोजर दिशानिर्देश मापन की एक इकाई का उपयोग करते हैं जिसे विशिष्ट अवशोषण दर, या SAR के रूप में जाना जाता है. फोन पर SAR के परीक्षण मानकीकृत पद्धतियों का उपयोग करके किए जाते हैं, इसके लिए उपयोग होने वाले सभी फ्रीक्वेंसी बैंड्स में फोन के उच्चतम प्रमाणित पावर स्तर पर संप्रेषण किया जाता है.
- हालाँकि विभिन्न LG फोन मॉडल के SAR स्तर में भिन्नता हो सकती है, फिर भी उनको इस तरह बनाया गया है कि वे सभी रेडियो तरंगों से संपर्क के संबंधित दिशानिर्देशों को पूरा करें.

- नॉन-आयोनाइजिंग रेडिएशन प्रोटेक्शन (ICNIRP) के लिए अंतरराष्ट्रीय आयोग द्वारा अनुशंसित SAR सीमा 10g टिशू पर औसतन 2W/kg होती है.
- इस मॉडल फोन का सबसे उच्च SAR मान कान पर उपयोग के लिए 0.473 W/kg(10g) है और शरीर के संपर्क में होने पर 0.224 W/kg(10g) है, जिसका परीक्षण DASY4 द्वारा किया गया है.
- जिन देशों/क्षेत्रों ने इंस्टीट्यूट ऑफ इलेक्ट्रिकल एंड इलेक्ट्रॉनिक्स इंजीनियर्स (IEEE) द्वारा अनुशंसित SAR सीमा को स्वीकार किया है, वहाँ के निवासियों के लिए SAR डेटा जानकारी 1g टिशू पर औसतन 1.6 W/kg है.

उत्पाद की देखभाल और रखरखाव

चेतावनी

इस विशेष फोन मॉडल के साथ केवल बताई गई बैटरियाँ, चार्जर्स और सहायक उपकरणों का ही उपयोग करें. किसी भी दूसरे प्रकार का उपयोग करने पर फोन पर लागू होने वाले अनुमोदन या वॉरंटी अमान्य हो सकते हैं और यह खतरनाक हो सकता है.

- इस यूनिट को डिसअसेंबल न करें. सुधारने की आवश्यकता होने पर इसे योग्य सेवा तकनीशियन के पास ले जाएँ.
- बिजली के उपकरणों जैसे टीवी, रेडियो और पर्सनल कंप्यूटर से दूर रखें.

सुरक्षित और प्रभावी उपयोग के दिशानिर्देश (जारी)

- यूनिट को गर्मी के स्रोतों जैसे रेडिएटर्स या कुकर से दूर रखना चाहिए.
- इसे गिराएँ नहीं.
- इसे मैकेनिकल कंपन या झटकों से बचाएँ.
- जिस स्थान पर विशेष 1 नियम हों वहाँ फ़ोन स्विच ऑफ़ करें. उदाहरण के लिए, अपना फ़ोन अस्पतालों में उपयोग न करें क्योंकि यह संवेदनशील मेडिकल उपकरणों को प्रभावित कर सकता है.
- चार्ज होते समय फ़ोन को गीले हाथों से न पकड़ें. इससे इलेक्ट्रिक शॉक लग सकता है और आपके फ़ोन को गंभीर रूप से क्षति हो सकती है.
- हैंडसेट को ज्वलनशील सामग्री के पास चार्ज नहीं करना चाहिए क्योंकि हैंडसेट गर्म होकर आग का कारण बन सकता है.
- इसे बाहर से साफ़ करने के लिए सूखे कपड़े का उपयोग करें (रसायन जैसे बेंजीन, थिनर, या एल्कोहल का उपयोग न करें).
- फ़ोन को सॉफ़्ट फ़र्नीचर पर चार्ज न करें.
- फ़ोन को अच्छे हवादार क्षेत्र में चार्ज करना चाहिए.
- फ़ोन को अत्यधिक धुएँ या धूल में न रखें.
- फ़ोन को क्रेडिट कार्ड्स या ट्रांसपोर्ट टिकट्स के पास न रखें; यह चुंबकीय पट्टियों की जानकारी को प्रभावित कर सकता है.
- स्क्रीन को नुकीली वस्तु से न ठकठकाएँ क्योंकि इससे फ़ोन को नुकसान हो सकता है.

- फ़ोन को तरल पदार्थ या नमी में न रखें.
- सहायक उपकरण जैसे ईयरफ़ोन का सावधानीपूर्वक उपयोग करें. एंटीना को अनावश्यक रूप से न छुएँ.

प्रभावी ढंग से फ़ोन का उपयोग

इलेक्ट्रॉनिक्स डिवाइस

- बिना अनुमति के अपने मोबाइल फ़ोन का उपयोग मेडिकल उपकरण के पास न करें. फ़ोन को पेसमेकर के पास अर्थात अपने शर्ट के ऊपरी जेब में न रखें.
- मोबाइल फ़ोन द्वारा कुछ श्रवण सुविधाएँ बाधित हो सकती हैं. छोटा-सा व्यवधान भी टीवी, रेडियो, पीसी इत्यादि को प्रभावित कर सकते हैं.

सड़क सुरक्षा

- जिस क्षेत्रों में आप वाहन चलाते हैं, वहाँ मोबाइल फ़ोन के उपयोग से संबंधित कानूनों और नियमों की जानकारी ले लें.
- वाहन चलाते समय हैंड-हेल्ड फ़ोन का उपयोग न करें.
 - वाहन चलाने पर पूरा ध्यान दें.
 - यदि उपलब्ध हो, तो हैंड्स-फ्री किट का उपयोग करें.
 - यदि वाहन चलाते समय आवश्यक हो, तो कॉल करने या उत्तर देने से पहले वाहन को सड़क के किनारे लगाएँ.

सुरक्षित और प्रभावी उपयोग के दिशानिर्देश (जारी)

- RF ऊर्जा आपके वाहन के कुछ इलेक्ट्रॉनिक सिस्टम्स जैसे कार स्टीरियो और सुरक्षा उपकरण को प्रभावित कर सकती है.
- जब आपके वाहन में एयर बैग की सुविधा हो, तो लगे हुए या पोर्टेबल वायरलेस उपकरण से व्यवधान न डालें. इससे एयर बैग विफल हो सकता है या अनुपयुक्त कार्य के चलते उसे बहुत अधिक नुकसान भी पहुँच सकता है.
- यदि आप यात्रा के समय संगीत सुन रहे हैं, तो कृपया सुनिश्चित करें कि वॉल्यूम उचित स्तर पर रहे जिससे आप अपने चारों ओर के वातावरण के प्रति सचेत रहें. यह तब विशेष रूप से जरूरी है जब आप रास्ते में हों.

अपने सुनने की क्षमता को नुकसान न पहुँचाएँ

यदि आप लंबे समय तक तेज ध्वनि सुनते हैं तो आपकी सुनने की क्षमता को क्षति पहुँच सकती है. इसलिए हम सलाह देते हैं कि आप अपना हैंडसेट कान के पास चालू या बंद न करें. हम इसकी भी सलाह देते हैं कि संगीत और कॉल वॉल्यूम उचित स्तर पर सेट हों.

विस्फोटक क्षेत्र

फोन का उपयोग ऐसे स्थान पर न करें जहाँ विस्फोट हो रहे हों. प्रतिबंधों का अवलोकन करें, और नियम-कायदों का पालन करें.

संभावित रूप से विस्फोट वाले वातावरण

- फोन का उपयोग ईंधन भरने के स्थान पर न करें.
- ईंधन या रसायनों के पास उपयोग न करें.
- मोबाइल फोन और सहायक उपकरणों को ज्वलनशील गैस, तरल या विस्फोटकों के साथ अपने वाहन में न ले जाएँ या न ही रखें.

एयरक्रॉफ्ट में

वायरलेस डिवाइस से एयरक्रॉफ्ट में बाधा उत्पन्न हो सकती है.

- किसी भी एयरक्रॉफ्ट में चढ़ते समय अपना मोबाइल फोन बंद कर दें.
- क्रू की अनुमति के बिना विमानतल पर इसका उपयोग न करें.

बच्चे

फोन को छोटे बच्चों की पहुँच से दूर एक सुरक्षित स्थान पर रखें. इसमें छोटे-छोटे भाग होते हैं जो यदि अलग हो जाएँ तो गले में फँस सकते हैं.

आपातकालीन कॉल्स

आपातकालीन कॉल्स सभी मोबाइल नेटवर्क्स के तहत उपलब्ध नहीं हो सकते. इसलिए, आपको आपातकालीन कॉल्स के लिए केवल फोन पर ही निर्भर नहीं रहना चाहिए. अपने स्थानीय सेवा प्रदाता से इसकी जानकारी लें.

सुरक्षित और प्रभावी उपयोग के दिशानिर्देश (जारी)


बैटरी जानकारी और देखभाल

- बैटरी रिचार्ज करने के पहले आपको उसे पूरी तरह डिस्चार्ज करने की आवश्यकता नहीं है। अन्य बैटरी सिस्टम्स के विपरीत, ऐसा कोई मेमोरी प्रभाव नहीं है जिससे बैटरी के प्रदर्शन पर असर पड़ता है।
- केवल LG बैटरीज और चार्जर्स का उपयोग करें। LG के चार्जर्स बैटरी का जीवन बढ़ाने के लिए बने होते हैं।
- बैटरी पैक को अलग-अलग न करें या उसे शॉर्ट-सर्किट से बचाएँ।
- बैटरी पैक के धातु वाले हिस्सों को साफ रखें।
- बैटरी का प्रदर्शन अपेक्षानुसार न रहने पर उसे बदल दें। बैटरी पैक को सैकड़ों बार रीचार्ज किया जा सकता है, जब तक कि उसे बदलने की आवश्यकता न हो।
- यदि बैटरी को लंबे समय से उपयोग नहीं किया गया है तो उसकी क्षमता बढ़ाने के लिए उसे रीचार्ज करें।
- बैटरी चार्जर को सीधे धूप में न रखें या बाथरूम जैसी अधिक नमी वाली जगहों पर इसका उपयोग न करें।
- बैटरी को गर्म या ठंडे स्थानों पर न रखें, इससे बैटरी के प्रदर्शन पर बुरा असर हो सकता है।
- यदि बैटरी को किसी गलत प्रकार की बैटरी से बदला जाता है तो विस्फोट का खतरा होता है।
- उपयोग की गई बैटरियों का निपटान, निर्माता के निर्देशों के अनुसार ही करें। जब भी संभव हो इसे रीसायकल करें। इसे घरेलू कचरे की तरह न फेंकें।
- यदि आप बैटरी बदलना चाहते हैं तो सहायता के लिए इसे नजदीक के अधिकृत LG इलेक्ट्रॉनिक्स सेवा केन्द्र या डीलर के पास ले जाएँ।
- फोन पूरी तरह चार्ज हो जाने पर चार्जर को वाल सॉकेट से निकाल दें ताकि चार्जर की अनावश्यक ऊर्जा खपत को बचाया जा सके।

सहायक सामग्री


आपके मोबाइल फोन के लिए विभिन्न सहायक उपकरण हैं। इनका नीचे वर्णन किया गया है।

चार्जर



डेटा केबल और सीडी

आपका GM200 और PC कनेक्ट और सिंक्रनाइज करें।




बैटरी



उपयोगकर्ता मार्गदर्शिका

अपने KM380T के बारे में और जानें।

स्टीरियो हेडसेट



नोट

- हमेशा प्रामाणिक LG सहायक उपकरणों का उपयोग करें। ऐसा नहीं करने पर आपकी वॉरंटी अमान्य हो जाएगी।
- अलग-अलग क्षेत्रों में सहायक उपकरण अलग हो सकते हैं। कृपया अधिक जानकारी के लिए हमारे क्षेत्रीय सेवा कंपनी या एजेंट से संपर्क करें।

तकनीकी डेटा

सामान्य

उत्पाद नाम : GM200

सिस्टम : GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900

परिवेश का तापमान

अधिकतम : +55°C (डिस्चार्जिंग)
+45°C (चार्जिंग)

न्यूनतम : -10°C

Bluetooth QD ID B015111

Declaration of Conformity		 LG Electronics	
Suppliers Details			
Name LG Electronics Inc			
Address LG Electronics Inc, LG Twin Towers 20, Yeouido-dong, Yeongdeungpo-gu, Seoul, Korea 150-721			
Product Details			
Product Name GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900 Quad band Terminal Equipment			
Model Name GM200			
Trade Name LG			
CE 0168			
Applicable Standards Details			
R&TTE Directive 1999/5/EC EN 301 489-01 V1.6.1, EN 301 489-07 V1.3.1, EN 301 489-17 V1.2.1 EN 301 511 V9.0.2 EN 50360/EN 50361:2001 EN 60950-1:2001 EN300328 V1.7.1			
Supplementary Information			
The conformity to above standards is verified by the following Notified Body(BABT) BABT, Balfour House, Churchfield Road, Walton-on-Thames, Surrey, KT12 2TD, United Kingdom Notified Body Identification Number : 0168			
Declaration			
I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates complies with the above mentioned standards and Directives		Name Seung Hyoun, Ji / Director	
European Standard Center LG Electronics Logistics and Services B.V. Veluwezoom 15, 1327 AE Almere, The Netherlands Tel : +31 - 36- 547 - 8940, Fax : +31 - 36 - 547 - 8794 e-mail : jacob @ lge.com		Issued Date 23, FEB, 2009	
		 Signature of representative	

LG Mobile



WARRANTY CARD

This LG handset and charger comes with a 12-month warranty from date of purchase or 15 months from manufacturing date of corresponding IMEI No. Of the unit whichever is earlier, against defect in material or workmanship. In case of a defect, LG Electronics India Pvt. Ltd. undertakes to get the set repaired free of charge through its authorised service centre (ASC) or service dealer subject to following conditions:

Terms and Conditions

1. This warranty is applicable to the first purchase and in no case it can be transferred or extended.
2. Repair of this product will be carried out on a carry in basis to the nearest ASC.
3. While the company will make every effort to carry out repairs at the earliest, it however is made explicitly clear that the company is under no obligation to do so in a specified period of time.
4. The company or its authorised ASC/ service dealer reserves the right to retain any parts of the component/s replaced at its discretion. In the event of a defect being noticed in the equipment during the warranty period.
5. This warranty entitles the purchaser to free of cost repairs of the unit within warranty period and does not entitle for replacement or refund of entire unit. Claims, if any, to this warranty shall in no case exceed the purchase price of the unit.
6. In case of any software upgradation of the phone, no warranty is provided on phone memory or phone book.
7. The warranty is void in case the serial no./ IMEI no. is tampered / disfigured or details in the warranty card are not properly filled up at the time of purchase.
8. This warranty is not valid for damages resulting due to negligence, mishandling, improper use, tampering, breakage, soaking, fire, unauthorised repair and failure due to network upgrades.
9. Batteries are covered under warranty for a period of 6 months from date of purchase or 9 months from date of corresponding IMEI no. of the unit whichever is earlier
10. Warranty does not cover accessories external to the equipment supplied by the dealer.
11. The Delhi / New Delhi courts shall have the jurisdiction to try any dispute and /or suits related to or arising out of this agreement.

Customer Information Center/ Call Center Number

For any query related to the after sales service and customer support please contact us at the numbers listed below.

 LG	SERVICE
	1800-180-9999*
*MTNL / BSNL	39-01-0909**
**Prefix STD Code	

BRANCH ADDRESSES

S. No.	Branch	Branch Office Address	STD Code	Phone No.
1	Ahmedabad	LGEIL, 233-234, Platinum Plaza, Judges Bungalow Road, Bodakdev Road, Ahmedabad - 51	079	40040013 / 14
2	Asansol	LGEIL, Block-E, 1st Floor, P C Chattarjee Market, Rambandhu Tala, GT Road (E) Asansol - 713303	0341	3292009 / 3292010
3	Aurangabad	LGEIL, 302 CIDCO No 3, Opp Hotel Ramgiri, Jalna Road, Aurangabad - 431003	0240	2474055 / 32095436 / 32095437 / 32095438
4	Bangalore	LGEIL, No. 914, 2nd Floor, Shri Venkateshwara Complex, Opp. IBP Petrol Bunk, 80ft Road, 6th Block, Koramangala - Bangalore - 560095	080	41145145 / 41144750 / 41144751 / 30910754 / 30910753
5	Bhopal	13 A Vignes Warehousing Corporation, Sector-G Govindpura Industrial Area J K Road Bhopal	0755	4062900 / 3092938 / 3959804
6	Bhubaneshwar	LGEIL, Plot No.02, 1st Flr., Bapuji Nagar, Bhubaneshwar - 751009	0674	2531430 / 2534280 / 3966525 / 3966526
7	Chandigarh	LGEIL, SCO No. 142-143, 3rd Floor, Sector-34A Chandigarh. - 160002	0172	5087389 / 90 / 5089107 / 3256001 / 3256003
8	Chennai	LGEIL, AA11, 2nd Avenue, Fatima Tower, Anna Nagar West, Chennai - 600040	044	65510501 ~ 04
9	Cochin	LGEIL, 40/1270, Vasudeva Buildings, T.D. Road, Emakulam Cochin - 682011	0484	2369743 / 2370744 / 2370484 / 4027444 / 4027555
10	Coimbatore	LGEIL, 250a, Sanganur Main Road, Kannappa Nagar, Coimbatore - 641027	0422	2332197 / 2332195 / 2332506 / 3094613 / 3094573
11	Dehradun	LGEIL, M - 22, Mobbewala, Tata Commercial Compound, Dehradun Saharanpur Road, Dehradun	0135	2644213 / 283
12	Delhi	LGEIL, A-27, Mohan Co-operative, Industrial Estate, New Delhi	011	26991411 / 12 / 13
13	Ghaziabad	LGEIL, J-10, RDC Rajnagar Ghaziabad - 201001	0120	9811354152 / 3 / 64 / 65
14	Goa	LGEIL, Plot No-D-3&D-4, Rego Baug, Alto Santacruz, Bambolim, Goa - 403	0832	3294955 / 3294956 / 3294759
15	Gurgaon	LGEIL, II nd Flr, A Block, Centre Point Bldg, Sushant Lok , PH-I, Gurgaon - 122001	0124	4047461 / 62 / 63 / 4272867 / 4047460
16	Guwahati	LGEIL, Shantineer Bhawan, C K Aggarwal Path, Chenikurthi, Guwahati - 781003	0361	2663895 / 2666958 / 2665983 / 2668984
17	Hubli	LGEIL, 603/1B, Ravi Nagar Road, Behind Renuka Petrol Pump, Gokul Road, Hubli - 580030	0836	4250251 / 52 / 2337251 / 52
18	Hyderabad	LGEIL, 1st Floor, Survey No.54, Pulla Reddy Building, Vikaramपुरi Main Road Kharkhana, Secunderabad - 500004	040	27811732 / 33 / 34
19	Indore	LGEIL, 3rd flr., 304 Bansi Trade Centre, 581/5 M.G.Road, Indore - 452003	0731	4065523 / 24 / 40822157
20	Jaipur	LGEIL, B-71, Sahakar Marg, Lal Kothi Scheme, Jaipur - 302015	0141	5111118 / 5113028 / 5105392
21	Jalandhar	LGEIL, Village Khajurla, Near Hawali Restaurant Jalandhar, Phagwara Highway, G T Road, Jalandhar	01824	502667 / 508025 / 502668
22	Jammu	LGEIL, Plot No.-52, Yard No. 6, Transport Nagar, Narwal, Jammu - 180006	0191	2477420 / 2477419 / 2474396 / 2474384
23	Jodhpur	LGEIL, 22(1-A)/21(2-B)/2, RIICO Heavy Industrial area, Jodhpur - 342003	0291	2742384 / 392
24	Kolkata	LGEIL, 1, Ho-Chi-Min-Sarani, 6th Floor, Metro Towers, Kolkata - 700071	033	22883250 / 51 / 52
25	Kundli	LGEIL, Sunshine Enterprises, Sunder Cold Storage, Gt Karnal Road, Kundli - Sonipat	0130	2219201 / 02 / 03
26	Lucknow	LGEIL, B-537, Hari Kunj, Keshav Nagar, Sitapur Road Lucknow - 226020	0522	2757538 / 39 / 2759121
27	Ludhiana	LGEIL, Village Jhande, Near Badowal Railway Station, Opp ferozpur Road Ludhiana.	0161	2804413 / 19
28	Mumbai	LGEIL, Trade Star, 4th Floor, A Wing, J.B Nagar, Andheri Kurla Road, Andheri (E) Mumbai - 400059	022	28352882 - 2887
29	Nagpur	LGEIL, 5a, Road No.13, Behind Msrtc Workshop, MIDC Hinga, Nagpur - 440016	07104	235120 / 235122
30	Patna	LGEIL, 2nd Floor, Ankit Chandra Deep Complex, Bander Bageecha, Near Samrat Hotel, Patna - 800001.	0612	3299156
31	Pune	LGEIL, 105/106, Premium Point, GM Road, Opp Modern High School, IIrd Floor, Shivaji Marg. Pune - 411005	020	66030100 / 732
32	Raipur	LGEIL, Nathani Compound, Shyam Nagar, Katora Talab, Raipur (C.G)	0771	4053171 / 4037470 / 4048745
33	Ranchi	LGEIL, 402, Commerce Tower, Opp. Gel Church Complex, Main Road, Ranchi	0651	3294026 / 2331815 / 3090426
34	Surat	LGEIL 1001-1004, Ascon Plaza, II nd Flr, Anand Mahal Road, Behind Bhulka Bhavan School, Adajan, Surat - 395009	0261	2730982 / 83 / 84
35	Thane	LGEIL, Gall Shop No - 206, 207, 2nd Floor, Sai Plaza , Above Vijay Sales Opp. Cine Wonder Mall, Ghodbunder Road, Thane(West) - 400607	022	25472633 / 2637
36	Varanasi	LGEIL, Pama Complex, DLW, Lahartara Road, Shivdaspur, Manduadih, Varanasi UP - 221002	0542	2373432 / 36 / 37
37	Vijaywada	LGEIL, Door No 32-2/1-7, Ratnamamba Street, Prajasakti Nagar, Vijaywada - 520010, Andhra Pradesh	0866	2497283 / 87
38	Warangal	LGEIL, HOUSE NO. 1-8-598/1 FIRST FLOOR, BESIDE HDFC BANK NAKKALGUTTA, HANAMAKONDA-506001 (WARANGAL)	0870	2551453

Dealer name with Stamp **Dealer address**
IMEI No. **Date of sale** **Serial no.**

LG Electronics India Pvt. Ltd., Plot No. 51, Udyog Vihar Surajpur Kasma Road, Greater Noida, U.P.

Memo