



MANTA

MOBILE PHONE SENIOR TOWER

TEL1704



Instrukcja obsługi
User's Manual

Przyciski

1. Lewy klawisz funkcyjny / Prawy przycisk: Funkcje pokazane w lewym/prawym dolnym rogu ekranu.

2. Zadzwoń / Odbierz (zielony),

Naciśnij po wybraniu numeru do połączenia.

Naciśnij aby odebrać połączenie przychodzące.

Naciśnij w trybie gotowości, aby przejść do historii połączeń.

3. Koniec / Przycisk zasilania: Naciśnij długo, aby włączyć / wyłączyć telefon; Naciśnij aby odrzucić połączenie lub wyjść z menu.

4. Klawisze nawigacji: Wciśnij góra / dół w menu do przewijania, przeglądania lub edycji.

6. 0-9 klawisze alfanumeryczne: Naciśnij odpowiednie klawisze do wprowadzania cyfr podczas wybierania numerów lub cyfr i znaków podczas edycji.

Naciśnij przycisk "+", aby wprowadzić znak "+" dla wybierania numeru międzynarodowego.

7. * (gwiazdka): Naciśnij w trybie czuwania, aby wprowadzić symbol "*". Długie naciśnięcie w trybie gotowości odblokowuje klawiaturę.

8. # (krzyżyk): Naciśnij w trybie gotowości do wprowadzania znaku "#". Długie naciśnięcie w trybie gotowości, aby włączyć lub wyłączyć tryb cichy.

Przygotowanie telefonu

1 Instalacja karty SIM

Należy przechowywać kartę SIM z dala od dzieci.

Należy bardzo uważać podczas instalowania, usuwania, przenoszenia lub przechowywania karty SIM.

Przed zainstalowaniem lub wyjęciem karty SIM, upewnij się, że telefon jest wyłączony. Należy zdjąć tylną obudowę i wyjąć baterię.

Uwaga: Podczas montażu należy upewnić się, że styki karty SIM są skierowane w dół oraz zwrócić uwagę na oznaczenia kierunku gniazda.

2 Instalacja karty pamięci

Ten telefon obsługuje funkcję karty pamięci. Prosimy upewnić się, że karta pamięci jest prawidłowo włożona przed użyciem.

Podczas montażu karty microSD należy zwracać uwagę na kierunek gniazda, należy odchylić osłonę gniazda karty pamięci, wsunąć kartę pamięci aż zostanie całkowicie włożona do gniazda i zamknąć osłonę. Telefon obsługuje karty microSD

3 Instalacja baterii

1. Włóż baterię zgodnie z oznaczeniami, stykami baterii w kierunku stuków w telefonie i naciśnij górną część baterii w dół aż zostanie włożona do gniazda baterii.

4 Wyjmowanie baterii

Najpierw należy wyłączyć telefon, położyć go ekranem w dół i przesunąć pokrywę baterii, zdjąć pokrywę i wyjąć baterię.

5 Ładowanie baterii

Włóż jeden koniec ładowarki do gniazda, a drugi koniec do gniazdka ładowania. Jeśli telefon jest włączony ikona baterii wyświetlana jest w prawym górnym rogu ekranu. Jeśli wskaźnik jest pełni i przestanie zmieniać się, bateria jest w pełni naładowana. Jeśli telefon jest wyłączony w czasie ładowania, duża ikona ładowania wyświetla się na ekranie. Po zakończeniu ładowania, odłącz wtyczkę.

UWAGA: Przed pierwszym użyciem należy ładować akumulator przez co najmniej 4 godziny. Będzie on osiągnąć maksymalną wydajność dopiero po kilku cyklach ładowania i rozładowania.

Korzystanie z telefonu

1 Włączanie / wyłączanie

Wciśnij i **przytrzymaj klawisz End / zasilania**, aby przełączyć lub wyłączyć telefon.

2 Wykonywanie połączeń

W trybie gotowości, naciśnij odpowiednie przyciski numeryczne, aby wprowadzić numer telefonu, naciśnij **przycisk końca rozmowy**, aby usunąć błędne wpisy; **naciśnij zielony przycisk**, aby nawiązać połączenie.

3 Odbieranie połączenia

Gdy jest połączenie przychodzące, jeśli sieć obsługuje ID dzwoniącego, na ekranie zostanie wyświetlona nazwa lub numer rozmówcy (w zależności od tego, czy znajdują się informacje na temat rozmówcy w książce telefonicznej).

1. Naciśnij przycisk **połączenia** aby odebrać połączenie przychodzące.

2. Jeśli nie chcesz, aby odebrać połączenie przychodzące, **naciśnij klawisz End / zasilania**, aby ją odrzucić. Możesz także nacisnąć **klawisz End / zasilania**, aby zakończyć połączenie.

3. W trakcie rozmowy można nacisnąć **w górę / w dół**, aby dostosować głośność.

4. Możesz skontaktować się ze służbami ratunkowymi bez karty SIM. Różne sieci wykorzystuje różne numery alarmowe, należy skontaktować się z operatorem sieci, aby uzyskać szczegółowe informacje.

Funkcje menu

1 Wiadomości

Napisz wiadomość

Funkcja: Tworzenie nowej wiadomości, zapisywanie i / lub wysłać go do odbiorcy.

Uwaga: aby wysłać SMS, trzeba ustawić poprawny numer centrum usługi SMS, które można uzyskać od operatora sieci.

Podczas pisania, naciśnij klawisz #, aby zmienić metodę wprowadzania, wiadomości tekstowe mogą być do 160 znaków.

Naciśnij klawisz lewy [Opcje], aby wybrać opcje podczas edycji:

- **Wyślij:** Wyślij skomponowaną wiadomość, wejście numer odbiorcy za pomocą klawiatury lub wybrać kontakt z książki telefonicznej.

- **Szablon SMS:** Wybierz zaprogramowaną wiadomość SMS.

2 Skrzynka odbiorcza

Otrzymane wiadomości SMS mogą być przechowywane w telefonie lub na karcie SIM, a są dostępne tutaj.

Po otrzymaniu wiadomości, dźwięki, aby ostrzegać i znak wiadomość zostanie pokazany również na ekranie. **Naciśnij lewy klawisz funkcyjny** [Czytaj] lub **przycisk OK**, aby przeczytać nową wiadomość, naciśnij **Prawy przycisk** [Wstecz], aby powrócić, i można uzyskać dostęp do skrzynki odbiorczej, aby przeczytać nową wiadomość.

Na liście wiadomości, **naciśnij klawisz OK** lub **lewy klawisz funkcyjny** [Opcje], aby następujące menu:

- **Odpowiedz:** Odpowiedz nadawcy SMS bezpośrednio.

- **Nadawcę Zadzwoń:** Zadzwoń do nadawcy wiadomości bezpośrednio.

- **Prześlij:** przekazanie wiadomości do kogoś innego.

- **Usuń:** Usuwanie wiadomości.

- **Zaawansowane:** można wybrać skopiować do telefonu i Przenieś do funkcji telefonu itp.

- **Zapisz w książce telefonicznej:** Zapisz numery do książki telefonicznej

3 Kopie robocze

Niekompletnie złożony i zapisane wiadomości mogą być zorganizowane i dostępne tutaj.

4 Nadawcza

Jeśli [Zapisz i wyślij], gdy wybrana jest opcja wysyłania wiadomości, wysłane SMS zostanie zapisany w skrzynce nadawczej.

W wysłanym liście wiadomości, **naciśnij klawisz OK** lub **lewy klawisz**, aby przeczytać wybraną wiadomość.

5 Wysłane wiadomości

Jeśli wiadomość zostanie wysłana pomyślnie wysłany SMS zostanie zapisany w skrzynce nadawczej.

6 Ustawienia SMS

Zestawy i zapisz parametry usługi SMS z karty SIM.

Spis telefonów

Przechowuje i zarządza kontakty, które często korzystają.

Istnieją dwa miejsca, w których można przechowywać nazwy i numery, które regularnie korzystają, w pamięci karty SIM oraz w pamięci telefonu. Objętość kontaktów można zapisać na karcie SIM, zależy od pojemności karty SIM.

Po wyszukaniu nazwy, **naciśnij klawisz połączenia / Odbierz**, aby wybrać numer z rejestru, a następnie **naciśnij klawisz zasilania / Zakończ**, aby zakończyć wybieranie. **Naciśnij przycisk OK**, aby wyświetlić informacje o płycie, naciśnij **lewy klawisz funkcyjny** [Opcje], aby uzyskać dostęp do opcji menu:

• Dodaj nowy kontakt

To menu pozwala na dodanie nowego rekordu do pamięci karty SIM lub telefonu. Wprowadź numer telefonu bezpośrednio w trybie czuwania, a następnie naciśnij **przycisk OK**, aby zapisać numer telefonu, na karcie SIM lub w telefonie.

Najpierw musisz wybrać przechowywanie: do SIM lub do telefonu.

• **Do SIM:** Wybierz tę opcję, naciśnij przycisk **OK**, lub **naciśnij lewy klawisz funkcyjny** [Edytuj], aby wejść do interfejsu wprowadzania nazwy i wprowadź odpowiednią nazwę, a następnie **naciśnij klawisz OK** lub **naciśnij lewy klawisz funkcyjny** [Opcje], aby wybrać "Gotowe" i potwierdź.

Naciśnij klawisz Navigator, aby przejść do kolumny liczb, wpisz bezpośrednio numer telefonu i potwierdzić, w końcu **naciśnij klawisz OK** lub **lewy klawisz** [OK] i potwierdź, aby zapisać, dodając rekordy na karcie SIM zostaną wykonane.

• **Wyślij wiadomość SMS:** Wyślij SMS na aktualnie zarejestrowane.

• **Zadzwoń:** Wybierz aktualnie wybrany numer telefonu.

• **Edycja:** Zmiana aktualnie wybrany rekord stycznego.

• **Usuń:** Usuń aktualnie wybrany rekord.

• **Kopiuj:** Skopiuj ten zapis do karty SIM, jeśli jest zapisany w telefonie i odwrotnie.

• **Ustawienia książki telefonicznej**

Preferowane przechowywania: Wybierz miejsce zapisu kontaktu.

Dodatkowe numery: Modyfikacja numery właściciel i ustawić funkcję wybierania ustalonego.

Status pamięci: Zobacz stan usług karty SIM i telefonu książki telefonicznej. Pojemność karty SIM zależy od innej karty SIM.

Kopiowanie kontaktów: Kopiuj rekord do karty SIM, jeśli jest zapisany w telefonie i odwrotnie.

Przenieś kontakty: Przesuń rekord do karty SIM, jeśli jest zapisany w telefonie i odwrotnie.

Usuń wszystkie kontakty: Usuń aktualnie wybrany rekord.

Spis połączeń

Ten telefon może rejestrować wszystkie odebrane połączenia, nawiązywanych, nieodebrane połączenia i odrzucone, jak również ich czas połączenia. Tylko wtedy, gdy funkcja związana jest obsługiwana przez sieć, a telefon jest włączony i ma zasięgu sieci, może nagrywać odebranych i nieodebranych.

Spis połączeń można uzyskać wybierając opcję **Spis połączeń** w menu. Istnieją różne ikony przed różnych rekordów.

- **Nieodebrane / wybieranych / odebranych / Wszystkie połączenia**

Wyświetlanie listy wszystkich / nieodebranych / wybieranych / odebranych.

- **Usuń dzienniki połączeń**

Multimedia

1. Audio

Umożliwia odtwarzanie plików audio zapisanych w pamięci telefonu lub na karcie pamięci.

2 Obrazy

Umożliwia przeglądanie obrazów zapisanych w pamięci telefonu lub na karcie pamięci.

4 Nagr. audio

Telefon może nagrywać dźwięki.

5 Wideo

To menu pozwala na odtwarzanie filmów zapisanych w telefonie lub na karcie pamięci.

Przycisk SOS

Można ustawić do 3 numerów SOS. Po naciśnięciu przycisku SOS przycisk telefon zadzwoni numer alarmowy i odtworzy dźwięk SOS.

Ustawienia

1 Godzina i data

- **Ustaw czas / data:** użyj lewego lub prawego przycisku nawigatora, aby przesunąć kursor do pozycji i używać klawiszy numerycznych, aby wprowadzić wartość i klawisz nawigacji w górę lub w dół, aby wybrać ustawienie czasu między pola i ustawienie daty, naciśnij **przycisk OK** po zakończeniu zapisać.

- **Format:** Ustaw format daty i czasu.

- Język

Możesz wybrać język obsługi telefonu.

2 Profile

Możesz wybrać profil dzwonienia.

3 Ustawienia zabezpieczeń

Możesz ustawić opcje zabezpieczeń w telefonie w ramach tego menu tak, że telefon lub karta SIM nie może być nielegalnie wykorzystywane.

4 Ustawienia Dual SIM

Możesz wybrać, aby ustawić inną kartę SIM

5 Przywróć ustawienia

Aby powrócić ustawień telefonu do ich oryginalnych wartości, jak, kiedy wyszedł z fabryki, wprowadź hasło telefonu, wybierz opcję [Tak], aby zresetować i restart (wyłącz i włącz ponownie telefon). Kod domyślnym jest "1122".

Uwaga!

Konstrukcja produktu i parametry techniczne mogą ulec zmianie bez wcześniejszego powiadomienia. Dotyczy to przede wszystkim parametrów technicznych, oprogramowania oraz podręcznika użytkownika. Niniejszy podręcznik użytkownika służy ogólnej orientacji dotyczącej obsługi produktu. Producent i dystrybutor nie ponoszą żadnej odpowiedzialności tytułem odszkodowania za jakiegokolwiek nieścisłości wynikające z błędów w opisach występujących w niniejszej instrukcji użytkownika.

Uwagi dotyczące utylizacji:



Starsze urządzenia, na których znajduje się symbol jak pokazano na rysunku, nie można wyrzucić z odpadami domowymi. Należy oddać je do konkretnego składowiska (skontaktować się z lokalnymi władzami) lub do sprzedawcy. Te strony zapewnią bezpieczną utylizację bez szkody dla środowiska

**INFOLINIA SERWISOWA**

tel: +48 22 332 34 63 lub e-mail: serwis@manta.com.pl
od poniedziałku do piątku w godz. 9.00-17.00

Producent zastrzega sobie możliwość wprowadzenia zmian w specyfikację produktu bez uprzedzenia.

Strona główna www.manta.com.pl
Strona wsparcia technicznego www.manta.info.pl



Made in P.R.C.
FOR MAN TA EUROPE

Knowing the Keys

1. Left soft key/Right soft key: Implement the functions shown in the lower left /right hand corner.

2. Call/Answer (Green) Key

Press after dialing to connect.

Press if there is an incoming call to answer.

Press from standby to go to call records list.

3. End/Power key: Long press to switch phone on/off; Press to end, reject call; or to exit a menu.

4. Navigator keys: Press the up/down direction in menu to scroll, browse or in edit page to move cursor.

5. 0-9 alphanumeric keys: Press corresponding keys to input numbers when dialing or numbers and characters when editing.

Press “+” to input “+” symbol for international access in the dialing interface.

Press “p” to input “p” symbol for the fixed extension number.

7. ★ (Star) Key: Press in standby to input “*” symbol. . Long press from standby to unlock keypad.

8. # (Pound) Key: Press in standby to input “#” character. Long press from standby to activate or deactivate silent mode.

Preparing Your Phone

1 Installing SIM Card

Please keep your SIM card away from reach of children.

Scratches and bends can easily damage the SIM card. Please be extra careful when installing, removing, handling or storing your SIM card.

Before installing or removing the SIM card, make sure the phone is switched off, and remove the back cover and battery.

Note: Find SIM card's groove in the back of phone and slide it completely there. During installation, please make sure that the chip is facing downwards and pay attention to slot direction.

2 Installing Memory Card

This phone supports the memory card function. Please ensure the memory card is inserted correctly before using.

Find memory card's groove in the back of phone, make the chip face to back of the phone and pay attention to the slot direction, slide the memory card as shown in the figure until it is entirely inserted into its groove.

3 Installing Battery

1. Align the battery chip with the metallic salient point in battery jar, insert the battery and press top of the battery downwards as per the arrow direction until it is inserted into the battery jar.
2. Slide battery cover into back of the phone until it is locked.

4 Removing Battery

First switch off the phone and make it face downwards, push the battery cover to top of the phone, get its top and remove it.

5 Charging Battery

Insert one end of the charger into charging slot and the other end into electrical outlet. If the phone is switched on and the battery power icon stripes in right hand of the screen are rolling, then it is charging; if the stripes are full and have stopped rolling, it is fully charged. If the phone is switched off when charging, a large charging sign will display in screen. After charging is finished, just pull out the plug.

Note: Before you first use, please charge the battery for at least 4 hours. It will achieve maximum efficiency after several charge and discharge cycles.

Using Your Phone

1 Powering on/off

Press and hold **the End/Power key** to switch your phone on or off.

2 Making a Call

In standby mode, press the corresponding numeric keys to enter the phone number, press **the Green key** to make a call when done to connect.

3 Receiving a Call

When there is an incoming call, the phone will give corresponding alert, if your network supports caller ID, the screen will display caller's name or number (depending on whether there is information about the caller in your phonebook).

1. Press **the Call/Answer key** to answer the incoming call.
2. If you do not want to answer an incoming call, press **the End/Power key** to reject it.

You can also press **the End/Power key** to end a call.

3. During a call, you can press **the up/down navigator keys** to adjust receiver volume.

4. You can contact emergency service numbers without the need of SIM card. Different networks use different emergency numbers, please contact your network operator for details.

4 Emergency Service

You can directly dial the emergency service number without SIM card. Different networks use different urgency service numbers, so for details please inquire the network operation company.

Menu functions

1 Write message

- Text message

Function: Compose a new message, save and/or send it to the recipient.

Note: to send SMS, you need to set the correct SMS service center number which can be obtained from network provider.

While composing, press the # key to change input method, a text message can be up to 160 characters.

Press **the Left Soft key** [Options] to select options when editing:

•**Send to:** Send the composed message, input the recipient's number using the keypad or select a contact from Phonebook.

•**Insert template:** Choose preset SMS.

•**Advanced:** Select the option want to insert number, name, contact and expressing symbol.

•**Save:** Save the message to drafts.

2 Inbox

Received SMS messages can be stored either in phone or in SIM memory, and are accessed here.

In message list, press **Left soft key** [Options] to make the following menu:

•**Reply:** Reply to the SMS sender directly.

•**Call sender:** Call the message sender directly.

•**Forward:** Forward the message to someone else.

•**Delete:** Delete the messages.

•**Advanced:** you can choose copy to phone and Move to phone etc function.

•**Save to Phonebook:** Save the numbers to phonebook

3 Drafts

Incompletely composed and saved messages can be organized and accessed here.

4 Outbox

If [Save and send] option is selected when sending the message, the sent SMS will be saved to Outbox.

In sent message list, press **the OK key** or **the left key** to read the selected message.

5 Sent messages

If message is sent successfully, the sent SMS will be saved to Outbox.

6 SMS Settings

Sets and save SMS service parameters of SIM card.

Phonebook

Stores and manages contacts that you often use.

There are two locations where you can store the names and numbers that you regularly use, in the SIM memory and in the phone memory. The volume of contacts can be saved in SIM card depends on SIM capacity.

After searching for the name, press **the Call/Answer key** to dial the number of record, and press **the End/Power key** to end dialing. Press **the OK key** to view details of the record, press **the Left soft key** [Options] to access the menu options:

•Add new contact

This menu allows you to add the new record to the SIM card or the Phone. Enter the phone number directly in standby mode, then press **the OK key** to save the phone number in the SIM card or the Phone.

First you need to select storage: To SIM or To Phone.

•**To SIM:** Select this option, press **the OK key** to enter name input interface and input the corresponding name, then press **the OK key** or press **the Left soft key** [Options] to select 'Done' and confirm.

Press the Navigator key to switch to number column, enter the phone number directly and confirm, finally press **the OK key** and confirm to save, adding records to the SIM card will be done.

•**View:** Display details of the currently recorded.

•**Send text message:** Send a text message to the currently recorded.

•**Call:** Dial the currently selected phone number.

•**Edit:** Modify the currently selected contactor record.

•**Delete:** Delete the currently selected record.

•**Copy:** Copy this record to SIM card if it is saved in phone and vice versa.

•**Phonebook settings**

Preferred storage: Select a contact storage location.

Extra numbers: Modify the owner numbers and set the function of fixed dial.

Memory status: View the service condition of the SIM card and phone's phone book. The capacity of SIM card depends on different SIM card.

Copy contacts: Copy the record to SIM card if it is saved in phone and vice versa.

Move contacts: Move the record to SIM card if it is saved in phone and vice versa.

Delete all contacts: Delete the currently selected record.

Call history

This phone can record all answered calls, dialed calls, missed calls and rejected calls as well as their call time. Only when related function is supported by network and phone is switched on and in network service area, it can record the answered and missed calls.

Call records may be accessed by pressing **the Call/Answer (Green) Key** from standby or accessing through the menu. There are different icons before different records.

- Missed/Dialed/ Received/All calls

Display list of all/missed/dialed/received calls.

- Delete call logs

Delete dialed / missed / received / all calls

Once on the call records list, press **the Call/Answer (Green) Key** to make a call; press **the OK key** to view the details, press **the Left soft key** [Options] to make the following options:

- View:** View the details of the call.
- Call:** Dial the number of the other party.
- Forward Connect people:** Forward call recor to someone else.
- Send text message:** Compose and send a SMS to the other party.
- Save to phonebook:** Save the call records to phonebook.
- Delete:** Delete the current call record.

Call settings

- SIM1/SIM2 call settings

You can select SIM1 or SIM2 to set the call settings options as below.

•**Call waiting (supported by the network):** You can switch on and off or checking for the call waiting function.

Switch on call waiting, and you will hear warning alert tone if there is a new incoming call during a call, with a phone number of another call on the screen.

•**Call divert (supported by the network):** Divert your incoming calls to voicemail or other numbers. There are three diverting ways, each of which can be set to divert to voice Mail or to the other number, off or check status.

•**Call barring(supported by the network):**You can switch on and off or checking for the call barring.

- **Advanced settings**

•**Answer mode:** use **the OK key** or **the Left soft key** to turn any key on or off, if activated, you can answer incoming calls just by any key except the Red key and the Right soft key.

Multimedia

1 Audio Player

Play the audio files saved in the phone or memory card.

In playing interface, press **ok keys** to select ►/|| ‘play/pause’, ■ ‘stop’, press **4/6 keys** to select ◀/▶ ‘previous/next’ ; press the Up softkey and the Down softkey to adjust player volume.

Press **the Left soft key** [List] to enter playing list interface, press **the Left soft key** [Options] to access the operation menu of MP3 player.

2 Image viewer

Entering this option, you can conveniently view photo list saved in album, press **the OK key** to view the selected photo, press **the Left soft key** [Options] to make the following operations:

- View:** View the currently selected photo.
- Send:** Send the photo via the Bluetooth.
- Use as:** Be used as Wallpaper/Screen saver/power on display/power off display
- Rename:** Change the name of the photo.
- Delete:** Delete the current photo.
- Storage:** Select [Phone] or [Memory card] as photos’ saving position.
- Image information:** Display the information of the selected photo.

3 Sound recorder

Your phone can record sounds.

Select ‘Record’ option, use **the Left Green key** to start or pause recording, use **the Right Red key** to stop recording.

4 Video player

This menu allows you to playback videos stored in your phone or memory card.

Enter video preview interface, press **the OK key** to make the following operations:

- Play:** play this video. You need to repress **the OK key** to start playing when screen displays start interface.
- Rename:** change the name of the video.

- Delete:** delete this video.
- Storage:** select [Phone] or [Memory card] as videos' saving position.

SOS Button

You can set 3 SOS phone numbers. When you long press SOS button phone will call SOS number and play SOS sound.

Settings

1 Time and date

•**Set time/date:** use the left or right navigator key to move the cursor to position and use numeric key pad to enter value and the up or down navigator key to select between setting time and setting date fields, press **the OK key** when done to save.

•**Set format:** Set the format of the time and date.

- Language

You can select the operation language of the phone.

2 Profiles

You can select your ring profile.

3 Security settings

You can set security options of the phone under this menu so that the phone or the SIM card cannot be illegally used.

4 Dual SIM settings

You can choose to set different SIM card

5 Restore settings

To return your phone's settings to their original values as when it came out of the factory, enter the phone password, select [Yes] to reset and reboot (power off and on again the phone). The factory default code is "1122".

Note!

Product design and Technical parameters may be change without notice. This mainly concerns parameters technical, software and user manual present. User's Manual is a general orientation on service product. Manufacturer and distributor do not assume any responsibility as compensation for any inaccuracies errors in the descriptions appearing in this user manual.

Note about disposal

Older appliances, which display the symbol as shown in the picture, may not be discarded in household waste. You must take them to a specific disposal site (check with your local authority) or to your retailer. These sites will guarantee disposal without harming the environment

**MANTA****CUSTOMER SERVICE**

tel: +48 22 332 34 63 lub e-mail: serwis@manta.com.pl

FROM MONDAY TO FRIDAY, IN HOURS: 9.00-17.00

The manufacturer reserves the right to make changes to product specifications without notice.

Main page: www.manta.com.pl

Technical support page: www.manta.info.pl



Made in P.R.C.

FOR MANTA EUROPE