

1 Your cellphone.....



OT-600A
ALCATEL
mobile phones

1.1 Keys

- Navigation key
Confirm an option (press the middle of the key)
Access slide show and music player (long keypress)
- Answer
Send a call
Access call memory (Redial) (short keypress)
Access events (long keypress)
- Switch on/Switch off the telephone (long keypress)
End call
Return to the main screen
- Left softkey
- Right softkey
- Access your voicemail (long keypress)
- In Edit mode:
 - Short keypress: change input methods
 - Switch from T9 predictive mode to Normal mode
 - Long keypress: access the Symbols table
- In Edit mode:
 - Short keypress: access the language list
 - Long keypress: enter zero
- From main screen
 - Short keypress: #
 - Long keypress: activate/deactivate the vibrator
- In edit mode:
 - Short keypress: (space)
 - Long keypress: add a word

⁽¹⁾ The key mentioned on the following chapters stands for Send Call key only.

1.2 Main screen icons

- Battery charge level
- Vibrate alert: your phone vibrates, but neither rings nor beeps except for the alarms.
- Bluetooth status (Blue - Activated).
- Headset connected.
- Keypad locked.
- Call forwarding activated: your calls are forwarded.
- Alarm clock programmed.
- Level of network reception.
- Voicemail message arrived.
- Unanswered calls.
- WAP alerts ⁽¹⁾.
- Roaming
- Memory card scanning in progress.
- Memory card scanning completed.
- Line switching ⁽¹⁾: indicates the selected line.
- GPRS connection status (Blue - Activated).
Shown only in no ciphering mode while calling, sending/receiving SMS.
- Multimedia player active.
- USB cable connected.
- Reception of a message in progress.
- Sending a message.
- Silence mode: your phone neither rings, beeps nor vibrates except for the alarms.
- Message unread
- Message list is full: your terminal cannot accept any new messages. You must access the message list and delete at least one message on your SIM card.
- Preferred tariff areas ⁽¹⁾.
- Antenna off mode.
- A2DP connected.

⁽¹⁾ Contact your network operator to check service availability.

2 Getting started

2.1 Set-up

Removing the back cover



Installing the battery



Inserting and removing the SIM Card



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the SIM card, lift the bottom up a bit and slide it out in the directions of the arrows. Please power off your phone before you remove the SIM card.

2.2 Power on your phone

Hold down the key until the telephone powers on.

2.3 Power off your phone

Hold down the key from the main screen.

3 Calls

3.1 Making a call

Dial the desired number then press the key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the right softkey.

To hang up the call, press the key.

Making an emergency call

If your phone is covered by the network, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

3.2 Calling your voicemail ⁽¹⁾

To access your voicemail, hold down the key.

3.3 Receiving a call

When you receive an incoming call, press the key to talk and then hang up using the key.

3.4 Available functions during the call

During a call, you can use your directory, your diary, short messages, etc. without losing your correspondent by pressing the key.

⁽¹⁾ Contact your network operator to check service availability.

4 Call register

4.1 Call memory

You can access your call memory by pressing the key from the main screen.

4.2 Events

By holding down the key from main screen or accessing from main menu, it allows you to view a list of your all latest 20 events (SMS, MMS, WAP Alerts, Voicemail and unanswered calls).

4.3 Billing

You can access different items with this option: Amount, Duration, GPRS counter, Beep duration.

4.4 Call settings

You can access a number of items with this option: Call waiting, Call forwarding, Call barring, Caller ID, Line switching, Auto redial.

5 Directory

5.1 Consulting your directory

To access the **directory** from the main screen, press the key or press the key and select the icon from the menu.

5.2 Creating a file

Select the directory in which you wish to create a file, press the "Options" softkey, select "Create file" then .

6 Messages

6.1 Create message

From the main menu select "Messages" to create text/multimedia message. You can type a message but you can also modify a predefined message in **Templates** or customize your message by adding pictures, photos, sounds, titles, etc. (only available while editing a MMS). While writing a message, select "Options" to access all the messaging options. You can save your messages that you send often to **Drafts** or **Templates**.

6.2 Inbox

All received messages (read and unread) are stored in the same Inbox.

7 My settings.....

From the main screen, select the icon menu and select the function of your choice in order to customize your telephone: Color, Theme, Equalizer, Display, Clock, Keys, More settings...

8 Tools

8.1 Bluetooth

Access this feature by selecting "Tools" from the main menu, then "Bluetooth".

8.2 Organizer

Once you enter this menu from "Tools", there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked in color.

8.3 Alarm

Your cellphone has a built-in alarm clock with a snooze feature.

8.4 Calculator

Hold down the key to get the decimal point. Confirm with the key or the left softkey.

8.5 Converter

Unit converter and Currency converter.

8.6 Voice memo

This feature enables you to record a call by selecting "Voice memo" while communicating. To record a sound, select "Voice memo"; then "New record".

8.7 Memory status

It will indicate how much space is used and how much is currently free on your phone and memory card (if any).

8.8 Directory backup

It maintains copy of contacts between Phone Directory and memory card, in case of phone errors, theft or disasters.

8.9 My shortcuts

Access the shortcuts already programmed. To program new shortcuts: select "My shortcuts" if you want to create a quick access to a function, Directory, or WAP Bookmarks, etc.

9 WAP

Access Wap options: Homepage, Bookmarks, Recent pages, Go to URL and Profiles.

10 File manager

You will have an access to all audio and visual files stored in phone or memory card in File manager.

10.1 My audios

Choose an audio for the ON/OFF screen, for an incoming call, a message alert, power on/off ringtone or an alarm and scheduler.

10.2 My images

You can select an image or a photo as wallpaper, ON/OFF screen, or assign it to a contact in the directory.

10.3 My videos

The "My videos" album contains all video clips embedded and downloaded in phone or memory card.

10.4 My creations

This feature stores all the photos captured by your cellphone.

10.5 Unknown files

Store files of unsupported format.

10.6 Memory card

You will have access to all files stored in memory card here.

Insert and remove the memory card



Unclip the back cover and insert the MicroSD card into the slot.

Unclip the back cover and gently push the memory card until unlocked. Take out your MicroSD card and clip the back cover.

10.7 Formats and compatibility

- Sounds: mp3, m4a, aac, midi, wav, amr
- Images: jpg, gif, bmp
- Videos: 3gp, mjpg

11 Camera

Your cellphone is fitted with a camera for taking photos and shooting videos that you can use in different ways:

- store them in your "File manager".
- send them in a multimedia message (MMS) to a cellphone or an email address.
- customize your main screen.
- select them as incoming call image to a contact in your directory.
- transfer them by data cable or microSD card to your computer.
- modify your photos through adding frames.

12 Multimedia player

Access this feature from the main menu by selecting "Multimedia player" or directly by holding down the key. You will have full access to "Music player", "Video player" and "Image viewer".

13 Games

Your Alcatel phone may include some games.

13.1 Game settings

It allows you to manage game settings, in which you may set "Background music", "Sound effect" and "Vibration".

14 Profiles

With this menu, you may personalise ringtones for different events and environments.

15 Making the most of your cellphone.....

PC suite is provided on our website. You can download software upgrade for free from the website.

16 Latin input mode

To write messages, there are two writing methods:

- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key.
- Predictive with the T9 mode: this mode speeds up the writing of your text.
- - key in edit mode
- Short keypress: access the language list
- Long keypress: enter zero

ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.

All rights reserved © Copyright 2009 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

