

htc Inspire™ 4G

Quickstart



Welcome to AT&T

Please use this Quickstart to get a brief overview of the major features and services available with your new HTC Inspire 4G.

OR

Use our interactive web tutorial available at:

att.com/Tutorials

for the most complete and up-to-date information available to set up your HTC Inspire 4G and services. The online tutorials include step-by-step instructions and screen shots to assist your learning as well as providing an easy search function.

You can also visit www.htc.com/support to view and download the User Guide for your HTC Inspire 4G.

Your device controls are
shown on this foldout.




htc

Before you turn on your HTC Inspire 4G

Insert your SIM card and microSD card

1. Push the bottom cover out to remove it.



2. Insert your SIM card into the right slot (with its gold contacts facing down and cut-off corner facing out).



3. Insert your microSD card into the left slot (with its gold contacts facing down).




4. Push the microSD card in until it clicks into place.
5. To replace the bottom cover, slide it onto the exposed area at the bottom of the device and push it in.

Before you turn on your HTC Inspire 4G (continued)

Insert the battery

Your HTC Inspire 4G uses a rechargeable lithium-ion battery.

1. Remove the thin film that is wrapped around the battery.
2. Insert the battery (with its copper contacts first) back into the battery compartment.



3. Put back the battery compartment cover, pushing the battery all the way in.



4. Close the battery compartment with the battery compartment cover, pushing the battery all the way in.


Note: You can find the battery compartment cover in a separate bag inside the box.

Tip: If you need to remove the battery, take the battery compartment cover off, and then shake the device a little to let the battery slide out. Then pull the battery out.

Charge the battery

The battery is only partially charged. Before you turn on and start using your HTC Inspire 4G, please fully charge the battery.

1. Connect the device to the power adapter using the USB sync cable.



2. Plug in the power adapter to an electrical outlet to start charging.

Note: Only the power adapter and USB sync cable provided with your HTC Inspire 4G must be used to charge the battery.

When the battery is charging, the Notification LED lights up in solid amber. When the battery is fully charged, the Notification LED lights up in solid green.

Warning! Do not remove the battery from the device while charging.

HTC Inspire 4G basics

Turn on your HTC Inspire 4G

Press the power button on the top panel to turn your HTC Inspire 4G on.


Power button



Unlock the screen

When your device is idle, it automatically goes into sleep mode to save battery power. Press the power button to wake up the device.

You'll then see the lock screen. Press and hold the bar on the lock screen and then slide your finger down to unlock.




htc

Set up your HTC Inspire 4G

The first time you turn on HTC Inspire 4G, you will be guided to select the language, connect to Wi-Fi® (if available), transfer contacts, set up your email and social network accounts, and more.

Follow screen instructions until you see the Home screen.



Customize your Home screen

The Home screen is highly customizable, giving you lots of room to add tools or applications so you can access the information that matters most to you and makes your life easier. Apart from the main Home screen, there are six additional screens that extend to the left and right sides of the Home screen.

Navigate the Home screens


On any Home screen, slide your finger horizontally across the screen to go to the left or right screens.



To jump straight to a screen that you want, press Home or pinch the screen to see all seven Home screens as thumbnails, and then tap a screen thumbnail to go directly to that screen.

Change the Home screen wallpaper


1. From the Home screen, tap  > **Wallpaper**.
2. Tap **Wallpapers** (HTC or Live) or **Gallery**.
3. Tap the wallpaper you want to use, and then tap **Save** (if you selected Gallery), or **Preview** > **Apply** (if you selected Wallpapers).



Check status and notifications

Status bar indicators

The status bar displays important icons that tell you the current status of your wireless signal, connection type and signal strength, remaining battery power, as well as any notifications.



Check out the Important icons and indicators section on the foldout. You can also refer to the Getting started chapter of the User Guide.

Notifications panel

Press and hold the status bar and then slide your finger down the screen to open the Notifications panel.



On the Notifications panel, you will see:

- New email or text messages, upcoming appointments, USB connection status, and more. Tap a notification to open the related application.
- Recently-used applications. Slide left or right across these applications and then tap one to open it.

To close the Notifications panel, press Back.

Make calls and check your voicemail

Make a call

1. On the Home screen, tap **Phone** to open the Phone screen.
2. On the Phone screen, tap the desired phone number using the dial pad.
Tip: Matched contacts will appear as you type the phone number. Tap a matched contact's photo or name to select it.
3. Tap **Call** to make the call.



4. To open the in-call options, press **Menu** while on a call. To adjust the in-call volume, press the Volume Control buttons at the left panel of the device.
5. To end the call, tap **End Call**.

Check your voicemail

From your HTC Inspire 4G

1. Press and hold the number **1** key.
2. Follow the voice prompts.

From other phones

1. Dial your 10-digit wireless number.
2. Tap the ***** key when you hear your personal greeting.
3. Enter your password.
4. Follow the voice prompts.

Set the ringer and ringtone

Set the ringer to vibrate or silent

1. To make your HTC Inspire 4G vibrate instead of ring when you receive a call, press the **Volume down** button until you see the vibrate icon (🔇).
2. To set your device to silent mode, press the **Volume down** button again until you see the silent icon (🔇).

Choose a ringtone

1. From the **Home** screen, tap  > **Ringtone**.
2. Scroll through the preset ringtones and tap the one you want to use.

Or tap **New ringtone**, choose a sound file from your storage card, and then tap **OK** to add it to the Ringtones list.




3. Tap **Apply**.

Manage contacts

Add a new contact



1. From the Home screen, tap  > People.
2. Tap **Add contact**.
3. Select a **Contact type** to determine which account the contact will sync with.
4. Tap the **Name** field and enter the contact name.
If the contact type is Google, Exchange or Phone contact, tap **OK** after entering the name.
5. Enter the contact details.
6. Tap **Save**.

Scroll up or down your contacts list by sliding your finger on the screen.



Add a new contact from Call history

1. From the Home screen, tap **Phone** and then tap  to display the Call History.
Tip: From the Home screen, you can also tap  > **Call History**.
2. Press and hold the unknown call entry, and tap **Save to People**.



3. Tap **Create new contact**, enter the contact details, and then tap **Save**.

Send and receive text messages

Send a text message

1. From the Home screen, tap  > **Messages** > **Compose message**.
2. To specify a recipient:
 - Enter phone numbers in the **To** field. Separate multiple numbers with a comma. Matching numbers from your contacts are displayed. Tap a number to select it.
 - Tap  to select contacts. After selecting all recipients, tap **OK**.

Tip: You can also select contact groups.
3. Select the **Tap to add text** box, and enter your message.
4. Tap the **Attachments** icon to add a picture, video, or other attachment to your message.
5. Tap **Send**.

Please don't text and drive.


View message conversations

You can find all text and multimedia messages you exchanged with a contact in the Messages tab of the Contact details screen.

1. From the Home screen, tap  > **People**.
2. Tap a contact, and then tap the Messages () tab.

All messages you exchanged with the contact are displayed as conversations.

3. To reply, select the **Tap to reply** box, enter your reply, and then tap **Send**.



Connect to the Internet and browse the Web


Use the data connection

It's simple. When you turn on HTC Inspire 4G, you'll be connected to AT&T's data network.

Turn the connection off when not in use

Turning the data connection off when not in use helps save battery life and minimize data charges.

1. From the Home screen, press **Menu**, and then tap **Settings > Wireless & networks**.
2. Clear the **Mobile network** check box to turn off the data connection.



To turn it back on, select the **Mobile network** check box.

Use Wi-Fi

Wi-Fi provides a fast, seamless connection at home, in the office, and in thousands of hotspots. Using Wi-Fi is convenient and helps you save on your mobile data usages. To help you take advantage of the speed and flexibility of Wi-Fi, HTC Inspire 4G arrives with Wi-Fi on.

1. From the Home screen, press **Menu**, and then tap **Settings > Wireless & networks**.
2. Tap **Wi-Fi settings**.
3. Tap a Wi-Fi network to connect to. If you selected an open network, you will be automatically connected to the network.

Note: You may need the network name (SSID) and password to log in to home or office Wi-Fi networks.

When your device is connected to a wireless network, the Wi-Fi icon  appears in the status bar and tells you the approximate signal strength (number of bands that light up).

If **Network notification** in Wi-Fi settings is enabled, this icon  appears in the status bar whenever the device detects an available wireless network within range.

Connect to the Internet and browse the Web (continued)

Turn Wi-Fi off when not in use

Turning Wi-Fi off when not in use helps save battery life.

1. From the Home screen, press **Menu**, and then tap **Settings > Wireless & networks**.
2. Clear the **Wi-Fi** check box.


Open a web page

1. From the Home screen, tap  > **Internet**.
2. Scroll and tap the content you want to browse.
3. To visit another website, tap the address bar on the top of the screen.
4. Enter the website address (URL) in the address bar and then tap  on the onscreen keyboard.



Navigate on the web page

1. Drag your finger to pan on the web page.



2. Tap the screen twice to zoom in or out. You can also pinch the screen using two fingers to zoom in or out.



Link to your social networks

Log into Facebook® and Twitter™ for HTC Sense


If you haven't set up your Facebook® and Twitter™ accounts, follow these steps.

1. From the Home screen, press **Menu**, and then tap **Settings > Accounts & sync**.
2. Tap **Add account > Facebook for HTC Sense**, enter your log in credentials, and then tap **Sign in**.
3. Tap **Add account > Twitter for HTC Sense**, enter your log in credentials, and then tap **Sign in**.

Catch up with friends using FriendStream™

With FriendStream™, share and get updates from your Facebook® and Twitter™ friends in a single feed. Easily track status updates, photo uploads, notifications, and more.

1. From the Home screen, tap  > **FriendStream**.
2. On the **All updates** tab (), scroll the screen to view recent feeds.
3. Scroll back to the top of the screen and then tap the **What's on your mind?** box.
4. Enter your status update and then tap **Share**.



Use the camera

Take a photo

1. From the Home screen, tap  > Camera.
2. To zoom in or out, slide your finger up or down the zoom bar.



3. Frame your subject on the screen. Let Camera auto focus at the center, or tap the area where you want to focus.
4. Tap  to take the photo.

All photos and videos you captured are saved on the storage card. Tap **Gallery** to view, send, or upload them.

Record video

1. From the Home screen, tap  > Camcorder.
If you've already opened Camera, tap  to switch to video mode.
2. Frame your subject on the screen.
3. Tap  to start recording.
4. While recording, you can freely zoom in or out or change focus.
You can also tap the flash button () to switch the camera light on or off during recording.
5. To stop recording, tap  again.

Set up and use email

Gmail

Gmail is Google's web-based email service and is automatically configured the first time you turn on your HTC Inspire 4G.

Mail

Use the Mail application to set up Internet-based (like Yahoo!, AOL, or Hotmail) and corporate email accounts (Microsoft Exchange ActiveSync Server) on your device:

Send email

1. From the Home screen, tap  > **Mail**.
2. If you have several email accounts, choose the account you want to use.
3. Tap **Compose mail**.
4. In the **To** field:
 - Enter email addresses, separating them with a comma. As you type, matching contacts are displayed. Tap a contact to select it.
 - Tap  to choose contacts or groups. Tap **OK**.
5. Enter the email subject, and then compose your message.
6. To add an attachment, press **Menu** and tap **Add attachment**.
7. Tap **Send**.

Connect a Bluetooth® headset

You can listen to music over a *Bluetooth* stereo headset or have hands-free conversations using a compatible *Bluetooth* headset.

1. Turn on the *Bluetooth* headset that you want to connect with. Set it to discoverable mode. Refer to the headset documentation to learn how to turn discoverable mode on.
2. On your device, press **Home** > **Menu**, and then tap **Settings** > **Wireless & networks**.
3. Select the *Bluetooth* check box.
4. Tap *Bluetooth* settings > **Scan for devices**.
5. Tap the name of the stereo or hands-free headset in the *Bluetooth* devices section. Your device then automatically attempts to pair with the headset.
6. If automatic pairing fails, enter the passcode supplied in your headset documentation.

When the *Bluetooth* headset is connected to your device, you'll see  in the status bar. You can now start using the headset to listen to music and/or make and receive phone calls.

Mobile Hotspots

You can use your HTC Inspire 4G to allow mobile broadband for up to 5 devices. Stay connected to the people, places and information that are important to you so you never miss a thing. Tether your HTC Inspire 4G or create a mobile hotspot and share your connection with multiple users/ devices.

Note: Requires a DataPro 4 GB Plan. Devices connected to your Mobile Hotspot use data from your DataPro 4 GB Plan. If you do not use a password, others will be able to use your Mobile Hotspot connection.

Create a Mobile Hotspot

1. From the Home screen, tap  > **Wi-Fi Hotspot**.

The first time you open Wi-Fi hotspot, you'll see a short introduction about the application. Tap **OK**.

2. In the **Router name (SSID)** box, use the default name or enter another name for your Mobile Hotspot.
3. Choose the type of security and set a password for your Mobile Hotspot.


Note: Users who want to connect to your Mobile Hotspot need to enter your password on their device.

4. Tap **Manage users**.
5. Tap the box below **Max. connection** and choose the number of users/ devices you want to allow to connect to your Mobile Hotspot, and then tap **Done**.

Tip: If you want to be able to accept or reject a connection when someone tries to connect to your Mobile Hotspot, select the **Allowed users only** check box.

6. Select the **Portable Wi-Fi Hotspot** check box to start up your Mobile Hotspot.

Your Mobile Hotspot is ready when you see  on the status bar.



Featured services

The following services are available for your HTC Inspire 4G.



Asphalt5: Take a ride in over 30 of the fastest, most prestigious cars you've ever dreamed of, from manufacturers like Ferrari, Lamborghini, Audi and Ducati. The world is your racetrack.



AT&T FamilyMap: Use this subscription service to easily locate a family member's wireless phone on a map from your device. To sign up for this service, visit att.com/familymap.



AT&T Code Scanner: Use this application to scan 2D (QR and datamatrix codes) and 1D (UPC and EAN) barcodes.



AT&T myWireless: Manage your AT&T account from your device.



AT&T NavigatorSM: Get traffic updates, GPS navigation, and turn-by-turn voice directions.



Blockbuster: Download and watch movies on your device. Browse through a list of movies to rent or buy.



Market: Choose from thousands of free and paid apps in Android Market. Download and install the apps that you want to your device. You'll get notifications whenever there are new updates to your installed apps.



Reader: Search, add and read Internet ePubs and eBooks on your device.



YPmobile: Use text or voice search to find businesses and events near your location.

Note: Some services may require a separate subscription.

© 2011 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T affiliated companies. All other marks contained herein are the property of their respective owners.

HTC Inspire 4G January 2011 Quickstart

htc

Find more information

On the Web

- Interactive web tutorials are available at att.com/Tutorials. Select Manufacturer: **HTC** and Model: **Inspire 4G** from the drop down menus.
- Detailed support information including device specifications, user guide, troubleshooting, user forums and knowledgebase articles are available at att.com/DeviceSupport.
- For information about your wireless account, service plan or network, visit att.com/Wireless.
- To view the User Guide for your device, visit www.htc.com/support.

On the device

Call AT&T Customer Care at **1-800-331-0500** or dial **611** from any AT&T mobile phone for assistance with your service or device.

Find Accessories

Accessories for your smartphone are available at att.com/WirelessAccessories or visit your local AT&T store.



91H00795-40M Rev.A



HTC Inspire 4G key functions



Important icons and indicators

Notification LED

Tells you when the battery is fully charged, low in power, is being charged, or when you have a pending notification, such as a missed call.

-  New Gmail message
-  New Exchange ActiveSync or POP3/IMAP email
-  New SMS/MMS
-  New voicemail
-  Upcoming event
-  Song is playing
-  FM Radio in use
-  Call in progress
-  Missed call
-  Call on hold
-  Call forwarding on
-  Uploading data
-  Downloading data
-  Data synchronizing
-  Matched contacts suggestion
-  App update available on Android Market



-  HSPA+ available
-  Connected to HSPA+
-  Signal strength
-  No signal
-  Roaming
-  Connected via Wi-Fi
-  Connected via Bluetooth
-  Airplane mode
-  Alarm is set
-  Speakerphone on
-  Vibrate mode
-  Phone speaker is muted
-  Battery is very low
-  Battery is full
-  Battery is charging

