

What's in the Box

1

Your phone box contains the following items:

- Mobile Phone
- Battery
- Charger
- USB cable
- Headset (with the 3.5 mm jack)
- microSD card
- Quick start guide

For more information about how to use your phone, please refer to the User Manual that stored on the microSD card.


Safety Precautions

Please read the safety precautions carefully to ensure the correct use of your mobile phone. For detailed information, refer to the section “For Your Safety”.

	Read the Safety Information section of this user guide on this page		Do not use while re-fuelling
	Do not use hand-held while driving		This device may produce a bright or flashing light
	For body-worn operation maintain a separation of 15 mm		Do not dispose of it in a fire
	Small parts may cause a choking hazard		Avoid contact with magnetic media
	This device may produce a loud sound		Avoid Extreme Temperatures
	Keep away from pacemakers and other personal medical devices		Avoid any contact with liquid, keep it dry
	Switch off when instructed in hospitals and medical facilities		Do not attempt to disassemble
	Switch off when instructed in aircrafts and airports		Do not rely on this device for emergency communications
	Switch off in explosive environments		Only use approved accessories

Getting to Know Your Phone

2



<Power>: Press to turn on your mobile phone. You can also use this key to lock or unlock the display of your phone and put it into sleep mode or wake it up.

<Home Key>: Press to return to the home screen.

<Menu Key>: Press to open the menu on an active screen.

<Back Key>: Press to return to the previous screen.


<Search Key>: Press to open the Quick Search Box.

<Camera Key>: Hold to open the camera and press to take the shot.

Before Getting Started


3

Removing the Back Cover




Before removing the back cover, make sure that the charger is removed.

Installing the SIM/microSD Card



Do not remove the microSD card frequently. Otherwise, the data on the card will be probably lost.


Installing the Battery



Charging the Battery

4

Before charging the battery, make sure that the battery has been properly inserted into your mobile phone.



- 1 Connect your USB cable to your mobile phone, as shown in **b**.
- 2 Connect the other end of the cable to the charger, as shown in **a**.
- 3 Plug the charger into a power socket.

The phone starts charging, with the charging icon displayed in animation on the screen.

Powering On/Off Your Phone

5


Before you power on your phone, make sure that your SIM card is installed and the battery is charged.

- Press **Power Key** to power on your phone.
- To power off your phone, hold **Power Key** to get the phone options. Select **Power off**, and then tap **OK**.
- To switch your phone to sleep mode, press **Power Key**.

Waking Up Your Phone from Sleep Mode

Sleep Mode suspends your phone to a low power consumption state by turning off the display to save battery power. Your phone also goes into Sleep Mode automatically when you leave it idle after a certain period of time.


1. Press **Power Key** to activate your screen display.
2. Drag  icon to the right.



While the device is in sleep mode, it is able to receive incoming calls, emails and messages.

Your Home Screen

6



<Notifications bar>:
Displays the reminders and status icons of your phone. Flick down to open the notifications panel.

<Display area>:
Shows the operation and display areas of your phone.

<Shortcuts>: Tap these shortcuts to start related applications.

<Interface switching buttons>: Include the Main Menu, Messages, Email, and Dialer.

Getting to Know the Canvas

7

The Canvas is a desktop which you can freely define. You can do the following things on the Canvas desktop:

- Navigate your screen display.
- Customize the Home Screen.
- Create and arrange shortcuts.
- Create and arrange widgets.
- Create and arrange folders.
- Define and switch between wallpapers.



Widgets and Google Services

8

Widgets

A widget works as a shortcut to let you preview or use an application.


You can stick widgets on your desktop as icons or preview windows.

Besides the default widgets installed on your phone, you can also download more from Android Market.



Google Services

Google provides you various excellent services, such as Talk, Google Mail, Market, and Maps.



Calling

9

You can place a phone call by dialing a phone number.

1. Tap , then tap **Dialer** to display the dialing panel.
2. Tap the keys to enter the phone number.
3. Tap  to dial.

When there is an incoming call, drag  icon to the right to answer the call or drag  icon to the left to reject the call. When you receive a call, you can press a Volume control key to mute the speaker.

Dialer



Your mobile phone supports the Dialer function, that is, when you touch numbers on the dialer, the phone automatically searches among your contacts and lists the matching results based on the accuracy. If no contact is matched with your entered information, the phone will not display any result.

Entering Text

10


Did you know you can type on your touchscreen? It's easy. When you enter a field that needs text or numbers, a virtual keyboard will appear automatically.

On the text input screen, tap and hold the space where you usually write your text. An **Edit text** menu pops up, where you can switch input method, select text you've entered, or do cut/copy and paste.


XT9

XT9 is a predictive text input mode which displays a word candidate list as you enter the first few characters so you just select the word that you want.

Tap to enter



Trace to enter



Entering Text


10

Touch pal

There are three keyboard layouts you can choose. To switch the keyboard layout, tap and hold one side of the keyboard panel, and then flick the panel to the edge of the screen.




Full QWERTY



Entering Text


10

12-Key PhonePad



Tap a key repeatedly until the desired letter appears.

CooTek T+




Tap to enter the left letter on the key; tap and flick right to enter the right letter/symbol on the key.

Entering Text

10

Android




Personalizing Your Phone

11


Changing the Wallpaper

- On the Home screen, tap Menu Key > Wallpaper.
- In the options menu, select a picture application.
- Select the wallpaper you want to use.




Changing the Ringtone

- On the Home screen, tap Menu Key > Settings > Sound & display > Phone ringtone.
- Select the ringtone in the list and then tap OK.



Adding items to Home screen

- On the Home screen, long press the blank area to get the Add to Home screen shortcut menu.
- Select the category and the item you want.



For Your Safety

RF Exposure

General Statement on RF Energy

Your phone contains a transmitter and a receiver. When it is ON, it receives and transmits RF energy. When you communicate with your phone, the system handling your call controls the power level at which your phone transmits.

Specific Absorption Rate (SAR)

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2 W/kg and the highest SAR value for this device when tested at the ear was 1.180 W/kg*. As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this user guide**.

* The tests are carried out in accordance with EN50360:2001, ICNIRP Guidelines, EN 62209-1:2006, IEC 62209-2 Edition 1.0 (2010-03).

** Please see next page about body-worn operation.

As SAR is measured utilizing the device's highest transmitting power, the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum power required to communicate with the network.

Body-worn Operation

Important safety information regarding radio frequency radiation (RF) exposure:

To ensure compliance with RF exposure guidelines the phone must be used with a minimum of 15 mm separation from the body. Failure to observe these instructions could result in your RF exposure exceeding the relevant guideline limits.

Limiting Exposure to Radio Frequency (RF) Fields

For individuals concerned about limiting their exposure to RF fields, the World Health Organization (WHO) provides the following advice:

Precautionary measures: Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If individuals are concerned, they might choose to limit their own or their children's RF exposure by limiting the length of calls, or using 'hands-free' devices to keep mobile phones away from the head and body.

Further information on this subject can be obtained from the WHO home page <http://www.who.int/peh-emf> WHO Fact sheet 193: June 2000.

Distraction

Driving

Full attention must be given to driving at all times in order to reduce the risk of an accident. Using a phone while driving (even with a hands free kit) causes distraction and can lead to an accident. You must comply with local laws and regulations restricting the use of wireless devices while driving.

Operating Machinery

Full attention must be given to operating the machinery in order to reduce the risk of an accident.

Product Handling

General Statement on Handling and Use

You alone are responsible for how you use your phone and any consequences of its use.

You must always switch off your phone wherever the use of a phone is prohibited. Use of your phone is subject to safety measures designed to protect users and their environment.

- Always treat your phone and its accessories with care and keep it in a clean and dust-free place.
- Do not expose your phone or its accessories to open flames or lit tobacco products.

- Do not expose your phone or its accessories to liquid, moisture or high humidity.
- Do not drop, throw or try to bend your phone or its accessories.
- Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.
- Do not paint your phone or its accessories.
- Do not attempt to disassemble your phone or its accessories, only authorized personnel must do so.
- Do not expose your phone or its accessories to extreme temperatures, minimum - [5] and maximum + [50] degrees Celsius.
- Please check local regulations for disposal of electronic products.
- Do not carry your phone in your back pocket as it could break when you sit down.

Small Children

Do not leave your phone and its accessories within the reach of small children or allow them to play with it.

They could hurt themselves or others, or could accidentally damage the phone.

Your phone contains small parts with sharp edges that may cause an injury or may become detached and create a choking hazard.

Demagnetization

To avoid the risk of demagnetization, do not allow electronic devices or magnetic media close to your phone for a long time.


Electrostatic Discharge (ESD)

Do not touch the SIM card's metal connectors.

Power Supply

Do not connect your device to the power supply or switch it on until instructed to do so in the installation instructions.


Antenna



Do not touch the antenna unnecessarily.

Normal Use Position

When placing or receiving a phone call, hold your phone to your ear, with the bottom towards your mouth.



Air Bags

Do not place a phone in the area over an air bag or in the air bag deployment area.

Store the phone safely before driving your vehicle.

Seizures/ Blackouts

This phone is capable of producing bright flashing lights.

Repetitive Motion Injuries

To minimize the risk of RSI when texting or playing games with your phone:

- Do not grip the phone too tightly.
- Press the buttons lightly.
- Use the special features which minimize the number of buttons being pressed, such as Message Templates and Predictive Text.
- Take lots of breaks to stretch and relax.

Emergency Calls

This phone, like any wireless phone, operates using radio signals, which cannot guarantee connection in all conditions. Therefore, you must never rely solely on any wireless phone for emergency communications.

Loud Noise

This phone is capable of producing loud noises, which may damage your hearing. Turn down the volume before using headphones, Bluetooth stereo headsets or other audio devices.

MP3 and Video Player Function

When listening to pre-recorded music or watching videos on your device, with headphones or earphones at high volumes, you run the risk of permanent damage to your hearing. Even if you are used to listening to music at a high volume and it seems acceptable to you, you still risk damaging your hearing. Reduce the sound volume to a reasonable level and avoid using headphones for an excessive period of time to avoid hearing damage.

Different headphones, earphones or ear buds may deliver a higher or lower volume, at the same volume setting on your device.

Always start at a low volume setting.

Do not listen to music or video with headphones while driving.

Bright Light

This phone is capable of producing flash of light or use as a torch, do not use it too close to the eyes.

Phone Heating

Your phone may become warm during charging and during normal use.

Electrical Safety

Accessories

Use only approved accessories.

Do not connect with incompatible products or accessories.

Take care not to touch or allow metal objects, such as coins or key rings, to contact or short-circuit in the battery terminals.

Connection to a Car

Seek professional advice when connecting a phone interface to the vehicle electrical system.

Faulty and Damaged Products

Do not attempt to disassemble the phone or its accessory.

Only qualified personnel is permitted to service or repair the phone or its accessory.

If your phone or its accessory has been submerged in water, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorized service centre.

Battery Handling & Safety

Always switch the device off and disconnect the charger before removing the battery.

Only use the battery and charger supplied, or manufacturer approved replacements intended for use with your phone. Using other batteries and chargers could be dangerous.

Do not disassemble or short-circuit the battery. Accidental short-circuiting can occur if a metallic object such as a key, paper clip, or pen touches the terminals of the battery.

Improper battery use may result in a fire, explosion, or other hazard. If you believe the battery has been damaged, do not use it, take it to a service centre for testing.

Interference

Care must be taken when using the phone in close proximity to personal medical devices, such as pacemakers and hearing aids.

General Statement on Interface

Power off your device if using the device is prohibited. Do not use the device when using the device causes danger or interference with electronic devices.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15 cm be maintained between a mobile phone and a pacemaker to avoid potential interference with the pacemaker. To achieve this, use the phone on the opposite ear to your pacemaker and do not carry it in a breast pocket.

Hearing Aids

People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby.

The level of interference will depend on the type of hearing device and the distance from the interference source, increasing the separation between them may reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

Medical Devices

Please consult your doctor and the device manufacturer to determine if operation of your phone may interfere with the operation of your medical device.

Hospitals

Switch off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

Aircraft

Switch off your wireless device whenever you are instructed to do so by airport or airline staff.

Consult the airline staff about the use of wireless devices on board the aircraft, if your device offers a 'flight mode' this must be enabled prior to boarding an aircraft.

Interference in Cars

Please note that because of possible interference to electronic equipment, some vehicle manufacturers forbid the use of mobile phones in their vehicles unless a hands-free kit with an external antenna is included in the installation.

Explosive Environments

Petrol Stations and Explosive Atmospheres

In locations with potentially explosive atmospheres, obey all posted signs to turn off wireless devices such as your phone or other radio equipment.

Areas with potentially explosive atmospheres include fuelling areas, below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

Blasting Caps and Areas

Power off your mobile phone or wireless device when in a blasting area or in areas posted turn off “two-way radios” or “electronic devices” to avoid interfering with blasting operations.