

ALCATEL 30-20G ALCATEL 30-20D

Quick Start Guide


For more information about how to use the phone, please go to www.alcateloneouch.com to download complete user manual. Also on our website you can find helpful FAQs, realize software upgrade, etc.



When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 10 mm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.



Your mobile.....



- Navigation key: To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.
- Switch on/ Switch off End call
- Left softkey
- Right softkey
- Facebook key
- Wi-Fi key
- Answer/Send call
- Call log (idle screen)

1.1 Keys

- Navigation key (press the middle of the key)
- Answer/Send a call
Press: Enter Call log
Press and hold: Enter Fake call
- Press: End a call
Return to the Home screen
Press and hold: Power on/off
- Left softkey
- Right softkey
- Press to enter Facebook main menu
- Enter Wi-Fi list and refresh
- Access your voicemail (press and hold)
- In idle screen:
Press and hold: Lock the keypad
In edit mode:
Press: input space
Press and hold: switch language

1.2 Status bar icons (1)

- Battery charge level.
- Vibrate alert: your phone vibrates, but does not ring or beep with the exception of the alarm.
- Bluetooth status (Activated).
- Bluetooth status (Connected to an audio device).
- Keypad locked.
- Headset connected.
- Alarm or appointments programmed.
- Voicemail message arrived.
- Missed calls.
- Radio is on.
- Roaming.
- SD card scanning completed.
- MMS receipt in progress.
- Sending a MMS.
- In edit screen:
Press: Switch the uppercase and lowercase

2 Getting started.....

- Removing or installing the back cover
- Removing and inserting the SIM card
- Power on your phone
- Power off your phone

- Home screen
- Widget bar
- Change wallpaper

- Removing and installing the battery
- Charging the battery

- 3 Calls.....
- 3.1 Making a call
- 3.2 Calling your voicemail(1)
- 3.3 Receiving a call
- 3.4 Available functions during the call

- 4 Messages.....
- 5 Contacts.....
- 7 Music.....
- 11 Wap.....
- 15 My files.....
- 18 Calendar.....
- 23 Alarm.....
- 27 Fake call.....
- 31 Facebook(1).....
- 32 Twitter(2).....
- 28 Call filter.....
- 29 Games(1).....
- 26 Settings.....
- 33 Mobile TV(3).....

4 Messages.....

- 4.1 Access
You may access this menu using the following options:
• Access from the main menu by selecting "Messages".
• Select [] from widget bar, and then enter the sub-menu you require.
- 4.2 Write message
You can select "Message/Write new SMS/MMS" from the main menu or access from widget [] to write text/multimedia message. For dual SIM model, you can type a message and select to send it to a recipient in either the SIM1 or SIM2 directory. One or more recipients may be added from contact list and you can remove a recipient by pressing Delete key. Press "Contexts" through [] key to multi-select recipients from Contacts.
An SMS will be converted to MMS automatically when images, videos are inserted.

5 Contacts.....

- 5.1 Consulting your contacts
You can access to this function by selecting "Contacts" from the main menu.
For dual SIM model, the complete contacts of both SIM1 and SIM2 are available in this menu(1).
- 5.2 Adding a contact
You can add a new contact to phone or SIM card by selecting "Add contact".

7 Music.....

- You can access this feature from the main menu by selecting "Music". You will have full flexibility of managing music both on your mobile and SD card.
- 8 Images.....
A library links to the images (stored in "My Images") in phone or SD card, set as Wallpaper, Power on/off display, and Incoming call image, or sent by MMS, Bluetooth.
- 9 Videos.....
Contains all video clips (stored in "My Videos") in phone or SD card and enables you to play, send, set as power-on/off display, delete, rename, etc.

11 Wap.....

- Access Wap options: Homepage, Bookmarks, Go to URL, Last wap address, Recent pages, Offline pages, Service Inbox, Settings.
- 12 Apps(1).....
Apps store is an online software store, where you can download and install applications and games to your phone.
- 13 Camera.....
Your mobile phone is fitted with a camera for taking photos and shooting videos that you can use in different ways:
• store them as your creations in SD card or phone.
• send them in a multimedia message (MMS) to a mobile phone.
• send them directly by MMS, Bluetooth.
• customize your Home screen.
• select them as incoming call image to a contact in your Contacts.

15 My files.....

- You will have an access to all audio and visual files stored in phone or SD card in "My files".
- Inserting and removing the memory card:
To release the MicroSD card holder, slide it in the direction of the arrow and lift it. Then insert the MicroSD card with the golden contact downward. Finally, turn down the MicroSD holder and slide it in the opposite direction to lock it.

18 Calendar.....

- Once you enter this menu from main menu, there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked in color.
- 19 Calculator.....
Access this feature by selecting "Calculator" from the main menu. Enter a number, select the type of operation to be performed using the navigation keys, and enter the second number, then select [=] to display the result.

23 Alarm.....

- Your mobile phone has a built-in alarm clock with a snooze feature.
- 24 Voice alarm.....
With this menu, you may create the voice file and set it as the alarm.
- 25 World clock.....
The World clock shows current local time and the time zone in different cities.

27 Fake call.....

- This program enables you to call yourself by simulating a caller number/name, ringtone at a scheduled time. It helps you to politely escape from social situations at any time you wish. This call can be rejected by key []. Activate a fake call by "Fake call model Enable".
- 28 Call filter.....
Enable blacklist, all callers in the list will be automatically blocked. Enable whitelist, all callers in the list can be connected.

31 Facebook(1).....

- Facebook is a social utility that connects people with friends and others who work, study and live around them. It provides a number of features with which users interact, such as Walls, Photos, etc. To open an account online, please go to: <http://m.facebook.com/>.
- 32 Twitter(2).....
Twitter is a social networking and microblogging service that has gained notability and popularity worldwide. This feature enables phone users to exchange news updates and ideas with a community in the form of messages or posts. Posts are displayed on the author's profile page and delivered to the author's subscribers or followers. To open an account online, please go to: <http://m.twitter.com/>.

(1) 3020D only
English - CJB271AALAN

(1) 3020D only

(1) The quality of the radio depends on the coverage of the radio station in this particular area.
(2) Depending on your network operator and market.

(1) Depending on your network operator.

(1) The icons and illustrations in this guide are provided for informational purposes only.

(1) You can use the Weight and Length conversion by selecting the unit you wish to convert, then press to input the digits. Finally confirm with "OK".

(1) 3020D only.

(1) You need to download the application to your phone for the first time. May cause additional network charges for data flow to download this application.

(1) Depending on your network operator.
(2) You need to download the application to your phone for the first time. May cause additional network charges for data flow to download this application.
(3) 3020G only.

