


1 Your mobile



OT-V570
ALCATEL
mobile phones

1.1 Keys

- Navigation key
 - Confirm an option (press the middle of the key)
- Pick up
 - Send a call
 - Access call memory (Redial) (short keypress)
- End call
 - Return to the main screen
- Left softkey
 - Right softkey
- Access your voicemail (long keypress)
- In Edit mode:
 - Short keypress: change input methods
 - Switch from TP predictive mode to Normal mode
 - Long keypress: access the Symbols table
- In edit mode:
 - Short keypress: access the language list
 - Long keypress: Enter zero
- From main screen:
 - Short keypress: #
 - Long keypress: activate/deactivate the vibrator
- In edit mode:
 - Short keypress: _ (space)
 - Long keypress: add a word
- Access camera
- LED key
 - Call: Flashing while incoming calls/missed calls

1

1.2 Main screen icons

- Battery charge level
 - Vibrate alert: your phone vibrates, but neither rings nor beeps except for the alarm.
- Headset connected
 - Call forwarding activated: your calls are forwarded.
- Alarm clock programmed
 - Level of network reception
- Voicemail message arrived
 - Unanswered calls
- WAP alerts⁽¹⁾
 - Roaming
- Double line⁽¹⁾: indicates the selected line.
- GPRS connection status (Blue - Activated)
 - Shown only in no tethering mode while calling, sending/receiving SMS.
- USB cable connected
 - Reception of a message in progress
- Sending a message
 - Silence mode: your phone neither rings, beeps nor vibrates except for the alarms.
- Message unread
 - Message list is full: your terminal cannot accept any new messages. You must access the message list and delete at least one message on your SIM card.
- Preferred tariff areas⁽¹⁾
 - Antenna off mode

⁽¹⁾ Contact your network operator to check service availability. 2

2 Getting started

2.1 Set-up

Removing the back cover



Installing the battery



Inserting the SIM Card

Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press it and slide it out.

2.2 Power on your phone

Hold down the key until the telephone powers on.

2.3 Power off your phone

Hold down the key from the main screen.

3 Calls

3.1 Making a call

Dial the desired number then press the key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the right softkey.

Making an emergency call

If your phone is covered by the network, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

3.2 Calling your voicemail⁽¹⁾

To access your voicemail, hold down the key.

3.3 Receiving a call

When you receive an incoming call, press the key to talk and then hang up using the key.

3.4 Available functions during the call

During a call, you can use your directory, your organizer, short messages, etc. without losing your correspondent by pressing the key.

⁽¹⁾ Contact your network operator to check service availability. 4

4 Call register

4.1 Call memory

You can access your call memory by pressing the key from the main screen.

4.2 Billing

You can access different items with this option: Amount, Duration, GPRS counter, Beep duration.

4.3 Call settings

You can access a number of items with this option: Call waiting, Call forwarding, Call barring, Caller ID, Conceal ID, Line switching, Auto redial.

5 Directory

5.1 Consulting your directory

To access the directory from the main screen, press the key or press the key and select the icon from the menu.

5.2 Creating a file

Select the directory in which you wish to create a file, press the "Options" softkey, select "Create file" then .

6 Messages

6.1 Create message

From the main menu select "Messages" to create text/multimedia message. You can type a message but you can also modify a predefined message in Templates or customise your message by adding pictures, photos, sounds, titles, etc. (only available while editing a MMS). While writing a message, select "Options" to access all the messaging options. You can save your messages that you send often to Drafts or Templates.

6.2 Inbox

All received messages (read and unread) are stored in the same inbox.

7 My settings

From the main screen, select the icon menu and select the function of your choice in order to customise your telephone: Color, Chimebell, Theme, Antenna off mode, Display, Clock, Keys, More settings...

8 Tools

8.1 Organizer

Once you enter this menu from "Tools", there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked in color.

8.2 Alarm

Your mobile phone has a built-in alarm clock with a snooze feature.

9 My shortcuts

9.1 Calculator

Hold down the key to get the decimal point. Confirm with the key or the left softkey.

9.2 Converter

Unit converter and Currency converter.

9.3 Voice memo

This feature enables you to record a call by selecting "Voice memo" while communicating.

9.4 Memory status

It will indicate how much space is used and how much is currently free on your phone.

10 WAP

Access WAP options: Homepage, Bookmarks, Recent pages, Go to URL and Profiles.

7

11 Media album

You will have an access to all audio and visual files stored in phone in Media album.

11.1 My audios

Choose an audio for the ON/OFF screen, for an incoming call, a message alert, power on/off ringtone or an alarm and scheduler.

11.2 My images

You can select an image or a photo as main screen or the ON/OFF screen.

11.3 My creations

This feature stores all the photos captured by your mobile phone.

11.4 Unknown files

Store files of unsupported format.

11.5 Formats and compatibility

- Sounds: mp3, midi, wav, amr
- Images: jpg, gif

2

12 Camera

Your mobile phone is fitted with a camera for taking photos that you can use in different ways:

- store them in your "Media album";
- send them in a multimedia message (MMS) to a mobile phone or an email address;
- customise your main screen;
- select them as incoming call image to a contact in your directory;
- transfer them by data cable to your computer;
- modify your photos through adding frames.

13 Games & Apps

Your Alcatel phone may include ⁽¹⁾ some Java™ applications and games. You can also download new applications and games to your phone.

14 Making the most of your mobile

PC suite is provided on our website. You can download software upgrade for free from the website.

⁽¹⁾ Depending on your country or your operator. 9

15 Profiles

From the main screen, select the icon menu and select the function of your choice in order to customise your telephone:

16 Latin input mode

To write messages, there are two writing methods:

- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key. Press the key several times until the highlight character is inserted into the text.
- Predictive with the TP mode: This mode speeds up the writing of your text. Write the word by pressing a key between and . Press the key once and the word will be modified each time you press a key. As you go on, the word will keep changing. Example: For "Tomorrow", press on the following keys: = Too -> = tomorrow

key in edit mode
Short keypress: access the language list
Long keypress: Enter zero

ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.
All rights reserved © Copyright 2008 TCT Mobile Limited.
TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only headphones recommended by TCT Mobile Limited and its affiliates.

11

English - CJB3060A1AAB 12

