

P51

1 KNOW YOUR PHONE	2
2 SIM/SD CARD INSTALLATION	3
3 MAKE CALLS	4
4 MESSAGES	5
5 CAMERA	6
6 GALLERY	7
7 WI-FI	8
8 MUSIC	9
9 SAR	10
10 TAKING CARE OF YOUR DEVICE	12
11 WARRANTY CONDITIONS	15
12 BATTERY RECOMMENDATIONS	19
13 DISCLAIMERS	20
14 COPYRIGHTS	21

1 KNOW YOUR PHONE



1. Earphone plug

2. Front flash

3. USB port

4. Receiver

5. Front Camera

6. Microphone

7. Rear camera

8. Flash


9. Volume button

10. Power button

11. Speaker



2 SIM/SD CARD INSTALLATION

1. Power off mobile.
2. Refer to the following picture for SIM / SD card installation.




3 MAKE CALLS

On dial interface and enter a complete phone number to make a call.




4 MESSAGES

You can use Messages to exchange text and multimedia messages with your friends. You can select SIM 1 or SIM 2 to send messages.



5 CAMERA


Your camera pictures and videos can be stored in SD card, so you must insert one to use the Camera. You can copy pictures and videos from the SD card to a PC and vice versa.



6 GALLERY

You use gallery to view pictures that you have taken with Camera, downloaded, or copied onto your SD card or USB storage, you can also view pictures in a Picasa web album. You can also share your pictures with friends, via email or messaging, or by uploading them to the Picasa and YouTube web sites.



In the gallery, you can choose to do the makeup or beautification to make yourself more charming.



7 WI-FI



To browse the web, you need switch on Data connection.

If there is Wi-Fi around, you can switch on Wi-Fi to use it browse the web. Some may need password.



8 MUSIC

When you copy music to your SD card, the Music player searches the card for music files and builds a catalog of your music, based on information about each file that is stored in the file itself.



9 SAR

Specific Absorption Rate (SAR) Certification THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) recommended by international guidelines. The guidelines were developed by an independent scientific organization (ICNIRP) and include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2.0 W/kg. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The highest SAR values under the ICNIRP guidelines for this device model are: Maximum SAR for this model and conditions under which it was recorded

Head	0.388 W/Kg
Body	1.597W/Kg

During use, the actual SAR values for this device are usually well below the values stated above. This is because, for purposes of system efficiency and to minimize interference on the network, the operating power of your mobile device is automatically decreased when full power is not needed for the call. The lower the power output of the device, the lower its SAR value.

A body-worn SAR test has been performed on this device at a separation distance of 5 mm. To meet RF exposure guidelines during body-worn operation, the device must be positioned at least 5 mm away from the body.

Organizations such as the World Health Organization and the US Food and Drug Administration have suggested that if people are concerned and want to reduce their exposure, they could use a hands-free accessory to keep the wireless device away from the head and body during use, or reduce the amount of time spent using the device.

10 TAKING CARE OF YOUR DEVICE

Your device is a product of superior design and artisanship and should be handled with care: The following suggestions will help you protect your phone :

- Keep the device dry. Precipitation, humidity, and all types of liquid or moisture can contain minerals that will rust electronic circuits.
- Do not store the device in high or cold temperature. High temperature can shorten the life of electronic devices and damage batteries.
- Do not use or store the device in dusty or dirty areas. Its moving parts and electronic components may be damaged.
- Do not attempt to open the device other than as instructed in this guide. Repairing of phone by yourself and others than our authorized service agent/center is against the warranty

- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Use a soft, clean and dry cloth to clean the surface of the device.

Battery& Chargers Safety:

- Do not place the battery in fire; follow local laws and ordinances in disposing used battery.
- Check the model number of the charger before using it to charge the mobile.
- Only use original battery, charger and accessories applicable to the specific mobile model. Using other types of battery, charger and accessories may violate the certification or warranty terms of the equipment and may result in danger.
- Stop charging when battery is higher than 55 °C, and restore charging when below 50 °C.

- Return waste and used batteries to the supplier or specified recovery site.

CAUTION!

- There are risks of explosion if battery is replaced by a non-original one.
- Dispose of used batteries according to the instructions.

*Notes:

- The socket-outlet shall be installed near the equipment and shall be easily accessible.
- Keep pressing the power button for 10 seconds to restart the phone.

If you want to know more:

www.itel-mobile.com

www.facebook.com/itelmobile

[Twitter.com/itel_mobile](https://twitter.com/itel_mobile)

11 WARRANTY CONDITIONS

The warranty period starts at the time of product's original purchase by the first end-user. The product may consist of several different parts and different parts may be covered by a different warranty.

What is not covered?

1. This Limited Warranty does not cover user manuals or any third party software, settings, content, data or links included or downloaded in the product, whether included during installment, assembly, shipping or any other time in the delivery chain or otherwise and in any way acquired by you. Itel does not warrant that any Itel software will meet your requirements, will work in combination with any hardware or software provided by a third party, that the operation of any software will be uninterrupted or error free or that any defects in the software are correctable or will be corrected.

2. This Limited Warranty does not cover
- (a) Normal wear and tear (including, without limitation, wear and tear of camera lenses, batteries, or displays)
 - (b) Defects caused by rough handling (including, without limitation, defects caused by sharp objects, by bending, compressing or dropping, etc.)
 - (c) Defects or damage caused by misuse of the Product, including use that is contrary to the instructions provided by itel (e.g. as set out in the Product's user guide).
 - (d) Transport costs.
 - (e) Other acts beyond the reasonable control of itel.
3. The Limited Warranty does not cover defects or alleged defects caused by the fact that the product was used with, or connected to, any product, accessory, software and/or service not manufactured, or supplied, by itel or was used otherwise than for its intended use. Defects can be caused by viruses from your or a third party's unauthorized access to services, other accounts,

computer systems or networks. This unauthorized access can take place through hacking, password mining or through a variety of other means.

4. This Limited Warranty does not cover defects caused by the fact that the battery has been short-circuited or by the fact that the seals of the battery enclosure or the cells are broken or show evidence of tampering or by the fact that the battery has been used in equipment other than those for which it has been specified.
5. This Limited Warranty is not enforceable if the Product is opened, modified or repaired by anyone other than an authorized service centre, if it is repaired using unauthorized spare parts or if the Product's serial number, the mobile accessory date code or the IMEI number has been removed, erased, defaced, altered or are illegible in any way and this shall be determined in the sole discretion of itel.

6. This Limited Warranty is not enforceable if the Product has been exposed to moisture, to dampness or to extreme thermal or environmental conditions or to rapid changes in such conditions, to corrosion, to oxidation, to spillage of food or liquid or to influence from chemical products.

12 BATTERY RECOMMENDATIONS

- Please put the battery in a well-ventilated place out of direct sunlight. Charge the battery at room temperature range.
- If the time span of the battery after charging becomes much shorter than usual, the battery life is at an end. Replace the battery with a new battery of the same make and specification.
- Do not discard the battery with household trash. Please dispose of used battery according to your local environmental laws and guidelines.
- Use manufacturer approved batteries, chargers, accessories and supplies. We will not be responsible for user's safety when using unapproved batteries or accessories.

13 DISCLAIMERS

- The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.
- The content of this manual may vary from the actual content displayed in the mobile phone. In such a case, the later shall govern.
- We keep the right to make modifications to any of the content in this user guide without public announcement or prior notification.
- For devices with external power supplies, plug socket should be placed in short distance and easily accessible.
- Using the wrong type battery replacement there is a danger of explosion, be sure to follow the instructions disposal of used batteries.

14 COPYRIGHTS

All rights reserved. Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of is strictly prohibited.



To prevent possible hearing damage, do not listen at high volume levels of long periods.

To use the device only with the earphones included, never change the earphones included for another one.

Android is a trademark of Google Inc.



www.itel-mobile.com | www.facebook.com/itelmobile