



Turning Your Phone On and Off

1. Press and hold the [END] key until the phone switches on.
2. To switch the phone off, hold down the [END] key until the power-off image displays.

Making a call

1. Enter a phone number including the area code.
2. Press the [SEND] key to call the number.
3. When finished, press the [END] key.

Answering a call

1. When the phone rings and the phone icon flashes on the screen, press the [SEND] key or the left soft key to answer.
2. If the Any Key menu option (Menu 5.5.2.1), has been set, any key press will answer a call except for the [END] key or the right soft key.
3. End the call by pressing the [END] key.

Note: After the call ends, the phone will go back to standby mode.

Making an international call

1. Press and hold the [+] key for the international prefix. The '+' character automatically selects the international access code.
2. Enter the country code, area code, and the phone number.
3. Press [SEND] key to call the number.

Lost Mobile Track (LMT)

1. The LMT feature of this phone provides you with the ability to have a tracking system in place for your Mobile in case you lose or misplace it.
2. The moment an un-authorized user uses your phone, a SMS is triggered from your phone and the Message is sent to your pre-defined number.
3. Setting the LMT ON [Menu - Settings - security]
 - › Select "Lost Mobile Track"
 - › Enter Default LMT code.
 - › Select Set LMT
 - › Select ON, press OK
 - › Change the default LMT code
 - › Input the "Number for LMT" details

Note

- › In case you want to use your phone with some other SIM card, make sure to set the LMT feature OFF.
- › It is recommended to enter the Number for LMT with the country code (e.g. for INDIA +91 followed By mobile number)
- › Default LMT code is "0000".


Installing the SIM Card and Charging the Battery

Installing the SIM Card

When you subscribe to a cellular network, you are provided with a SIM card loaded with your subscription details, such as your PIN, any optional services available and many others.

Important!

- › The SIM card and its contacts can be easily damaged by scratches or bending, so be careful when handling, inserting or removing the card. Keep all SIM cards out of the reach of small children.
- › USIM is not supported in this phone.
- › If the battery is removed for about 1 minute, the clock returns to its default setting. You will then need to reset the time.




Illustrations

1. Open battery cover
2. Insert your SIM
3. Close battery cover
4. Charge your battery

Menu and Options

Your phone offers a set of functions that allow you to customize it. These functions are arranged in menus and sub-menus, accessed via the left and right soft keys. The label on the bottom of the display screen immediately above the soft keys indicates their current function.



How to set the tone

Ringtone

1. Press the left soft key [Menu] and select [Settings - Profiles] using the up/down navigation keys.
2. Select [General - Personalise] and choose Ringtones menu.
3. Press the left soft key [OK] and then you can set the desired ringtone.

Tip

- › If you want to change your ringer to vibrate, select Vibrate mode or press and hold the [SEND] key.


Call alert type, Ring tones, Ring volume, Message alert type, Message tones, Message volume, Keypad tones, Keypad volume, Effect sound volume, Power on/off volume

You can select Call alert type, Ring tones, Ring volume, Message alert type, Message tones, Message volume, Keypad tones, Keypad volume, Effect sound volume, Power on/off volume.

You can change the sound that will occur when a key is pressed, or volume level.

[Menu - Settings - Profiles - General - Personalise]

Phone Components



Entering Text

You can enter alphanumeric characters by using the phone's keypad. To change modes, press the [TEXT] key.

T9 Mode

This mode allows you to enter words with only one keystroke per letter. Each key on the keypad has more than one letter. The T9 mode automatically compares your keystrokes with an internal linguistic dictionary to determine the correct word, thus requiring far fewer keystrokes than the traditional ABC mode.

ABC Mode

This mode allows you to enter letters by pressing the key labeled with the required letter once, twice, three or four times until the letter is displayed.


123 Mode (Numbers Mode)

Type numbers using one keystroke per number.

Symbol Mode

This mode allows you to enter special characters by short pressing [SYM] key.

Display Information



On-Screen Icons

The table below describes various display indicators or icons that appear on the phone's display screen.

[Signal strength icon]	Tells you the strength of the network signal.
[Call icon]	Call is connected.
[Roaming icon]	Shows that you are using a roaming service.
[Alarm icon]	The alarm has been set and is on.
[Battery icon]	Tells you the status of the battery.
[Text message icon]	You have received a text message.
[Voice message icon]	You have received a voice message.
[Vibrate icon]	Vibrate only menu in profile.
[General menu icon]	General menu in profile.
[Outdoor menu icon]	Outdoor menu in profile.
[Silent menu icon]	Silent menu in profile.
[Headset menu icon]	Headset menu in profile.
[Schedule icon]	You can view your schedule.

FM Radio

(This function may be different in different regions.)

1. Press the corresponding number key of a channel to store the selected radio station.
2. After presetting radio channels, you can listen to another channel by pressing the corresponding number key.
3. You can access the following option menus by pressing the left soft key [Options].
 - › **Edit channel:** You can adjust frequency and channel 0.1 MHz at a time using the Left/Right navigation keys and number keys.
 - › **Auto scan:** If you turn "Auto Scan Now?" on, this automatically sets the radio channel. When "Save this Station?" message pops up and you select Yes, the selected frequency will be stored.
 - › **Reset channels:** You can delete all channels you saved.
 - › **Listen via speaker:** You can listen to the FM radio via built-in speaker. When you select [Options - Listen via wired headset] and connect the ear-mic then you can listen via headset.

Note (GB106)

Intenna FM (Wireless FM antenna): In weak FM radio signal area the sensitivity can degrade with wireless antenna mode. So it is advisable to insert the ear-mic for better & enhanced FM quality.

Menu tree

1. Contacts

- 1.1 Search
- 1.2 New contact
- 1.3 Speed dials
- 1.4 Copy all
- 1.5 Delete all
- 1.6 Memory status
- 1.7 Information

2. Messaging

- 2.1 New message
- 2.2 Inbox
- 2.3 Drafts
- 2.4 Outbox
- 2.5 Sent
- 2.6 Listen voice mail
- 2.7 Info messages
- 2.8 Templates
- 2.9 Settings

3. Call history

- 3.1 All calls
- 3.2 Missed calls
- 3.3 Dialed calls
- 3.4 Received calls
- 3.5 Call duration

4. Tools

- 4.1 Games
- 4.2 FM radio
- 4.3 Calculator
- 4.4 Stopwatch
- 4.5 Unit Converter
- 4.6 World clock

5. Settings

- 5.1 Profiles
- 5.2 Date & Time
- 5.3 Language
- 5.4 Display
- 5.5 Call
- 5.6 Auto lockout
- 5.7 Security
- 5.8 Power save
- 5.9 Network selection
- 5.0 Reset settings
- 5.* Memory status

6. Organizer (SIM Services) **

- 6.1 Alarm
- 6.2 Calendar
- 6.3 Memo

** In case SIM Services are also provided by the service provider then Menu 6 will be SIM Services and Organizer will be under Menu 4. Tools.

Quick feature reference

This section provides brief explanations of features on your phone.

Contacts	Menu 1
Search	You can Search for contacts in Phonebook. Note: Instant searching is available by inputting the initial letter of the name you want to search.
New contact	You can add phonebook entries by using this menu.
Speed dials	Assign contacts to any of keys between [2-9].
Copy all	You can copy all entries from SIM card memory to Phone memory and also from Phone memory to SIM card memory.
Delete all	You can delete all entries from SIM card memory or Phone memory.
Memory status	You can check free space and memory usage.
Information	› Service dial numbers: Access the list of service numbers assigned by service provider safely. › Own numbers: You can save and check your own numbers in SIM card. › Business card: This option allows you to create your own business card featuring your name, mobile phone number and so on.

