

# X330 User Manual

### **INTRODUCTION**

Thank you for purchasing this mobile phone. To obtain the best performance of your phone, please read this user manual carefully.

# ***User manual***

---

## **Table of Contents**

|          |                                                |           |
|----------|------------------------------------------------|-----------|
| <b>1</b> | <b>Safety .....</b>                            | <b>5</b>  |
| 1.1      | Safety Precautions .....                       | 5         |
| <b>2</b> | <b>Introduction .....</b>                      | <b>6</b>  |
| 2.1      | Phone and Accessories .....                    | 6         |
| 2.2      | Phone.....                                     | 6         |
| 2.3      | About SIM Card and the Battery .....           | 7         |
| 2.4      | To switch ON and OFF .....                     | 7         |
| <b>3</b> | <b>Phonebook.....</b>                          | <b>7</b>  |
| 3.1      | To add a Contact.....                          | 8         |
| 3.2      | Multi Operation .....                          | 8         |
| 3.3      | Copy All.....                                  | 8         |
| 3.4      | Move All.....                                  | 8         |
| 3.5      | To delete a Contact.....                       | 8         |
| 3.6      | Caller groups .....                            | 8         |
| 3.7      | Extra Numbers .....                            | 9         |
| 3.8      | Phonebook Settings .....                       | 9         |
| 3.9      | Caller Picture.....                            | 9         |
| 3.10     | Caller Ringtone.....                           | 9         |
| 3.11     | Caller Video .....                             | 9         |
| 3.12     | Add to Blacklist.....                          | 9         |
| 3.13     | Speed dial .....                               | 9         |
| <b>4</b> | <b>Calling .....</b>                           | <b>10</b> |
| 4.1      | To activate 'mute' during a call .....         | 10        |
| 4.2      | To view contacts during a call .....           | 10        |
| 4.3      | DTMF (Dual Tone MultiFrequency) tone .....     | 10        |
| 4.4      | Caller ID .....                                | 10        |
| 4.5      | Call waiting.....                              | 10        |
| 4.6      | Call divert.....                               | 10        |
| 4.7      | Call Barring.....                              | 11        |
| 4.8      | Conference Call .....                          | 11        |
| <b>5</b> | <b>Call history .....</b>                      | <b>12</b> |
| 5.1      | Missed calls/dialed calls/received calls ..... | 12        |
| 5.2      | Delete call logs .....                         | 12        |
| 5.3      | Call Timer.....                                | 12        |
| 5.4      | Call Cost .....                                | 12        |
| <b>6</b> | <b>Messages.....</b>                           | <b>12</b> |
| 6.1      | Write SMS .....                                | 12        |
| 6.2      | SMS Inbox .....                                | 13        |
| 6.3      | SMS Draftbox .....                             | 13        |
| 6.4      | Sent Items.....                                | 13        |
| 6.5      | Templates.....                                 | 13        |

## ***User manual***

---

|           |                                                     |           |
|-----------|-----------------------------------------------------|-----------|
| 6.6       | SMS Settings .....                                  | 14        |
| 6.7       | SMS Black List .....                                | 14        |
| 6.8       | Send MMS.....                                       | 14        |
| 6.9       | MMS Inbox.....                                      | 14        |
| 6.10      | MMS Outbox.....                                     | 15        |
| 6.11      | MMS Draftbox.....                                   | 15        |
| 6.12      | Templates.....                                      | 15        |
| 6.13      | MMS Settings.....                                   | 15        |
| 6.14      | Voicemail Server .....                              | 15        |
| 6.15      | Broadcast Message.....                              | 16        |
| <b>7</b>  | <b>Settings .....</b>                               | <b>17</b> |
| 7.1       | Customized Phone Settings .....                     | 17        |
| 7.2       | Profile Setup .....                                 | 18        |
| 7.3       | Safety.....                                         | 18        |
| <b>8</b>  | <b>Multimedia and Entertainment .....</b>           | <b>19</b> |
| 8.1       | Camera .....                                        | 19        |
| 8.2       | Image Viewer .....                                  | 19        |
| 8.3       | Video Recorder .....                                | 19        |
| 8.4       | Video Player.....                                   | 20        |
| 8.5       | Audio Player.....                                   | 20        |
| 8.6       | Sound Recorder.....                                 | 20        |
| 8.7       | FM Radio.....                                       | 21        |
| <b>9</b>  | <b>Fun &amp; Games.....</b>                         | <b>21</b> |
| 9.1       | Games.....                                          | 21        |
| <b>10</b> | <b>Bluetooth .....</b>                              | <b>21</b> |
| 10.1      | To Activate/deactivate Bluetooth Connectivity ..... | 22        |
| 10.2      | To Search/Inquire Audio Device.....                 | 22        |
| 10.3      | To Search My (new) device .....                     | 22        |
| <b>11</b> | <b>Organizer.....</b>                               | <b>23</b> |
| <b>12</b> | <b>File Manager .....</b>                           | <b>24</b> |
| <b>13</b> | <b>WAP Services .....</b>                           | <b>25</b> |
| 13.1      | WAP Browser .....                                   | 25        |
| 13.2      | WAP Setup .....                                     | 25        |
| <b>14</b> | <b>STK .....</b>                                    | <b>26</b> |
| 14.1      | STK Services .....                                  | 26        |
| <b>15</b> | <b>Maintenance .....</b>                            | <b>27</b> |
| <b>16</b> | <b>Taking Care of your Device .....</b>             | <b>28</b> |
| <b>17</b> | <b>After Services .....</b>                         | <b>29</b> |
| <b>18</b> | <b>Inputting Text.....</b>                          | <b>30</b> |

### 1.1 Safety Precautions

-  Please read through the following briefings carefully, and act in accordance with these rules, so as to prevent causing any danger or violating any law.
-  **Safe driving**
- 1) Do not use the phone while driving. When you have to use the phone, please use the personal hands-free kit.
  - 2) Please put the phone safely in the phone stand. Do not put it onto any passenger seat or any place from which it may fall down in case of vehicular collision or emergency braking.
-  **Turn off during a flight:** Flight is influenced by interference caused by the phone. It is illegal to use a phone on the airplane. Please turn off your phone during a flight.
-  **Turn off the phone when within an area where blasting takes place:** Be sure to strictly observe the related laws and statutes by turning off the phone when you are within, or in the vicinity of, an area where blasting takes place.
-  **Turn off the phone when any dangerous goods are in vicinity:** Please turn off your phone when you are close to a gas station or in the vicinity of any place where fuel and chemical preparations, or any other dangerous goods are stored.
-  **In hospital:** Please obey the related rules or bylaws of the hospital when using your phone in a hospital. Be sure to turn off your phone when near any medical equipment. Your use of any wireless transmission equipment, inclusive of the phone, will interfere with any medical equipment that is not protected fully, and other electronic equipment items, too. Should you have any question in this regard, please consult a related physician or medical equipment supplier.
-  **Interference:** Each and every phone's performance may be affected due to radio interference.
-  **Professional service:** The phone must be installed or repaired by no other personnel than professionals. You are likely to suffer a huge risk when you install or repair this phone by yourself, which also goes against the warranty rules.
-  **Fittings and battery:** You shall use the fittings and battery acknowledged by the phone manufacturer only. Using unauthorized accessories may tamper the warranty of the device.
-  **Proper use:** Please use the phone in the normal way. Do not touch the antenna unnecessarily after the phone is turned on.
-  **Emergency call:** You may enter a telephone number (112, etc.) to ask for emergency help after making sure that the phone has been turned on and is in the service status. Press the Send Key to call out.

**Disclaimer:** Micromax will not bear any responsibility for any incompliance with the above mentioned guidelines or improper usage of the mobile phone. Our company keeps the right to make modifications to any of the content here in this user guide without public announcement in advance. The content of this manual may vary from the actual content displayed in the mobile phone. In such case, the latter shall govern.

### **2.1 Phone and Accessories**

Open the packing box of the phone and check that you have the phone, charger, battery, USB cable, earphone and user manual.

### **2.2 Phone**



### **2.3 About SIM Card and the Battery**

Please store the cards out of childrens reach.

The card and the contacts are vulnerable to damages due to scratching or bending. Therefore, be careful when using, inserting or removing the cards.

Be sure to switch off the phone before you insert or remove the battery or the card, otherwise, the phone may be damaged.

1. Insert the plug of the charger into the interface of the phone, and insert the charger into the power socket carefully. The battery icon will blink.
2. The red light is lit during charging. When the battery icon stops blinking or the green light is lit, it indicates that charging is finished.
3. After the charging, unplug the charger from the socket, and press and hold the left and right buttons on the plug of the charger to pull out the plug from the phone.

Tips:

The battery icon  displayed on the screen indicates that the battery power is low. Please charge the battery following the steps above.

Please charge the battery before you use the newly purchased phone. We suggest you charge the battery for 4 hours continuously for the first time.

Charging when the phone is in the ON mode will not influence the normal dialing and answering, but this needs to consume power, thus the time of charging will increase.

We suggest you recharge the battery when the power is used up so as to prolong the life of the battery.

### **2.4 To switch ON and OFF**

**To switch on:** Long press **End key** when the phone is in the OFF mode.

If the phone lock has been activated, you need to enter the 4-digit password to unlock. (The preset unlock code is 0000.)

If the SIM card has been inserted in the phone, and the related PIN code protection is activated, you need to enter the 4-8 digit password to unlock.

**Warning:** If you enter three wrong PIN codes in a row, the SIM card will be locked and you need to enter the PUK code to unlock. Both the PIN code and PUK code are provided by the network operator.

**To switch off:** In the standby mode, long press **End key**.

## **3 Phonebook**

You can store names and phone numbers in the memory of the phone or SIM card. The phone memory stores up to 500 entries, each of which contains name, 4 phone numbers (mobile, home, office and fax), company name, e-mail address and birthday. You can set photo caller ID, ringtone and groups for each.

**Menu > Phonebook**

### 3.1 To add a Contact

In idle, enter phone numbers.

**Options > Save > Select the location for saving**

Or: **Menu > Phonebook > Add new contact > Select the location for saving**

You can edit the name, mobile phone number, home phone number, company name, e-mail address, office phone number, fax number. (The number of columns may be set by you in the **[Fields]** in the **[Settings]**).

### 3.2 Multi Operation

**Menu > Phonebook > Multi Operation**

Allows you to mark a single or mark all entries from the phonebook and perform functions like: send text message, delete selected and add to blacklist/whitelist

### 3.3 Copy All

**Menu > Phonebook > Copy All**

Copy all the messages stored in SIM to the phone memory, or copy all the messages stored in the phone memory to SIM.

### 3.4 Move All

**Menu > Phonebook > Move All**

Move all the messages stored in SIM to the phone memory, or move all the messages stored in the phone memory to SIM.

### 3.5 To delete a Contact

In Contacts list, select the entry you want to delete: **Options > Delete**

You can delete all entries from SIM card or Phone by:

**Menu > Phonebook > Delete > From SIM/from phone.**

And, you can also delete the name one by one:

**Menu > Phonebook > Delete > One by one.**

### 3.6 Caller groups

**Menu > Phonebook > Caller groups**

Select the group to be set:

**To edit the name:** Highlight the name and select **Edit**.

**To select a ringtone:** Press **Navigation key (Left/Right)** to select a ringtone for this group. If you select **none**, when a call from the number of a group comes in, the default ringtone designated by system will be played.

**To select a picture:** Press **Navigation key (Left/Right)** to select a picture for this group. If you select **none**, when a call from the number of a group comes in, the default picture designated by system will be displayed.

**To select a group member:** Enter the list of group members, and select **Options > Ok**.

**Tip:** You can select group members from the entries stored in the phone only.

### **3.7 Extra Numbers**

#### **Menu >Phonebook> Extra Numbers**

Under this option you can view the following:

- SIM 1/2 owner number
- SIM 1/2 service dialing number
- SIM 1/2 Emergency number

### **3.8 Phonebook Settings**

#### **Menu >Phonebook> Phonebook Settings**

Under this feature you can view the following options:

- Memory Status
- Preferred Storage
- Fields
- Myvcard

### **3.9 Caller Picture**

#### **Menu >Phonebook> Caller Picture**

Allows you to add a picture (stored in your phone) to a specified number stored in your phonebook. Each time the caller (who you have set a picture to) calls you would be able to see the picture flash on your screen.

### **3.10 Caller Ringtone**

#### **Menu >Phonebook> Caller Ringtone**

Allows you to set a specific ringtone to a chosen contact from your phonebook.

### **3.11 Caller Video**

#### **Menu >Phonebook> Caller Video**

Allows you to set a specific video to a chosen contact from your phonebook.

### **3.12 Add to Blacklist**

#### **Menu >Settings > Advace Settings> Blacklist**

Allows you to ignore calls by adding a desired number to the blacklist.

### **3.13 Speed dial**

#### **Menu> Settings> Call Settings > Advance Settings> Speed Dial**

You can specify speed dial numbers to frequently used phone numbers.

Long press the number keys **2-9** on the dial plate to display a corresponding phone number on the screen, and press **Send key** to dial the phone number. (The **1 key** correspond with Voice Mailbox.)

**Tip:** You must have set a speed dial number for that number key, and the Speed Dial function has been activated.

### **4.1 To activate 'mute' during a call**

During a call, you can prevent the other party from hearing you:

**While on call> Press the Righ Soft Key (RSK)**

### **4.2 To view contacts during a call**

You can search a phone number from the Phonebook during a call:

**Options > Phonebook**

### **4.3 DTMF (Dual Tone MultiFrequency) tone**

During a call, you can select to turn ON or turn OFF the DTMF tone. When the DTMF tone is turned off, the digits entered will not be regarded as a DTMF signal response.

During a call:

### **4.4 Caller ID**

**Menu > Settings > Call settings > SIM 1/2 call settings>Calller ID**

Choose from the below options to use the caller ID feature in your phone

- Set by network
- Hide ID
- Send ID

### **4.5 Call waiting**

**Menu > Settings > Call settings > SIM 1/2 call settings>Call Waiting**

This function allows you to put the current call on hold and then answer a second one.

If, during a call, a new call comes in, you will hear a special alert sound and the screen will display the number of the new incoming call, which indicates that a third-party call is coming in and waiting for to answer.

- To answer the new call: Press Send key or select Options > Answer
- To reject the new call: Press Reject or press End key
- To end the current call: Select Options > End active
- If you answer the new call, the first call will be held and you will hear the hold alert sound.
- To switch between calls: Press Send key or select Options > Swap
- To end the select call : Select Options > End Single call
- To end the current call: Press End key

### **4.6 Call divert**

**Menu > Settings > Call settings > SIM 1/2 call settings>Call divert**

With the Call Divert function (needs network support), you may divert incoming calls to another mobile phone or a direct line telephone, but not to any extensions of a fixed telephone.

The function needs the support from the local network. In some districts, you can use the

function only after you apply to the local network operator.

### **4.7 Call Barring**

**Menu > Settings > Call settings > SIM 1/2 call settings>Call Barring**

The function is a GSM network service and can restrict outgoing and incoming calls selectively. If you need to change the settings of Restrict Calls, please contact your network operator to obtain the password for opening this service.

### **4.8 Conference Call**

The phone supports Three-party Calling. A Three-party Calling, also called a multiparty call or a conference call, is a service based on call waiting. It is applicable to dual standby with GSM network.

The function needs the support from the local network. In some districts, you can use the function only after you apply with the local network operator.

During a call, you may dial other numbers without hanging up the current call, and use the functions provided during the call to connect to new parties and make a three-way calling.

You may conduct a three-way calling containing up to five parties.

Ask the other party of the current call not to disconnect, and select Options > Pause to hold the current call.

Select Options > **New call** to enter and dial a new number, then talk with him/her after he/she answers your call.

Select Options > Conference to connect all the parties and form a conference.

1. Continue to dial new numbers, and repeat the steps above to add more parties to the conference.

**Tip:** After a conference is formed, if you press End key, you will end all the calls.

### *5 Call history*

#### **5.1 Missed calls/dialed calls/received calls**

##### **Menu>Call History**

You may select the number from missed/dialed or received calls and choose options to view the following:

**View:** View the desired entry

**Call:** Call the desired entry

**Save to Phonebook:** to save the number to the Phonebook

**Edit:** to edit the number to dial or save to the phonebook.

**Send SMS:** to write SMS to send to the number.

**Send MMS:** to write MMS to send to the number.

**Send to blacklist:** send a desired number to the blacklist

**Delete:** to delete the entry.

**Delete All:** delete all the registered entry in one go.

#### **5.2 Delete call logs**

##### **Menu>Call Logs**

You may select to delete **Missed**, **Dialed**, **Received** or **All** calls.

#### **5.3 Call Timer**

Allows you to view the call timers.

#### **5.4 Call Cost**

Allows you to view the call timers.

### *6 Messages*

#### **6.1 Write SMS**

##### **Menu > Messages > Text Message**

Write the content of the SMS, **Options >**

**Input Method:** select Multitap abc/Numeric/Insert Symbol/Smart HINDI/Multitap HINDI

**Insert Object:** Allows you to insert an object (picture/ animation/ melody/predefined sound etc)

**Text style:** Choose a text style/Alignment/New paragraph

**Insert template:** select a phrase from the list and insert it into the SMS.

**Insert name:** Insert the name of a desired contact stored in the phonebook

**Insert bookmark:** Insert a desired bookmark

**Insert Number:** Insert a desired number

### 6.2 SMS Inbox

**Menu > Messages > SMS > Inbox**

To read a message, move to the entry and press **OK**

When reading a SMS, you can select **Options >**

**View:** Allows you to view the SMS received.

**Reply:** Allows you to reply to the SMS received.

**Forward:** forward the entry to others.

**Copy to phone/SIM:** copy the SMS stored in SIM/phone to the phone/SIM.

**Move to phone/SIM:** move the SMS stored in SIM/phone to the phone/SIM.

**Delete all:** delete all the messages from the Inbox.

**Copy all:** copy all the messages stored in SIM to the phone memory, or copy all the messages stored in the phone memory to SIM.

**Move all:** move all the messages stored in SIM to the phone memory, or move all the messages stored in the phone memory to SIM.

**Use number:** Use the number from which SMS was received and: Call/Save to phonebook/Send text message

**Use URL**

**Use USSD**

### 6.3 SMS Draftbox

**Menu > Messages > SMS > Drafts**

This allows you to read the Messages that failed to send and those saved during editing.

### 6.4 Sent Items

SMS that have been sent and saved are stored in Outbox.

**Menu > Messages > SMS > Outbox**

To read a message, move to the entry and press **OK**

When reading an SMS, you can select **Options >**

**Send:** select how to send.

**Edit:** edit the message.

**Delete:** delete the message.

**Copy to phone/SIM:** copy the SMS stored in SIM/phone to the phone/SIM.

**Move to phone/SIM:** move the SMS stored in SIM/phone to the phone/SIM.

**Delete all:** delete all the messages from the Outbox.

**Copy all:** copy all the messages stored in SIM to the phone memory, or copy all the messages stored in the phone memory to SIM.

**Move all:** move all the messages stored in SIM to the phone memory, or move all the messages stored in the phone memory to SIM.

**Use number:** extract the number of the receiver and the number(s) contained in the SMS into a list (up to 6 numbers), and select to dial or save it/them in the Phonebook.

### 6.5 Templates

The phone has preset frequently used phrases which may be selected and added to the text when you are editing SMS. Preset phrases may be modified.

Menu > Messages > SMS > Templates

### 6.6 SMS Settings

**Menu > Messages > SMS > SMS settings**

**Sim 1/ 2 Settings:**

- Profile settings:
- Common settings
- Preferred storage

**Save sent messages:** Click Yes/No to save the sent messages.

**Memory Status:** Check the available and uses memory.

**Text message counter**

### 6.7 SMS Black List

**Menu > SMS >SMS Settings> SMS Black List**

Select the ON/OFF status to activate or deactivate the Black List.

Black List numbers: check the numbers stored under this list

### 6.8 Send MMS

MMS, which contains text, picture, video and ringtone, is sent through the MMS center to another mobile phone or an e-mail account.

The phone supports sending and receiving MMS by EDGE, and multiple-sending.

**Menu > Messages > MMS > Write MMS**

Select **Option:**

**Add Text:** write text.

**Add Audio:** select an Audio from **File Manager** and add to the MMS.

**Add Image:** select an image from **File Manager** and add to the MMS.

**Add Video:** select a Video from **File Manager** and add to the MMS.

**Edit Number:** enter the number edit screen.

**Send:** send the MMS.

### 6.9 MMS Inbox

**Menu > Messages > MMS > Inbox > Option**

**View:** read the highlighted MMS.

**Reply:** reply to the MMS

**Reply by SMS:** Choose to reply to the MMS via SMS

**Reply all:** Reply to all MMS

**Forward:** Forward the MMS to another number

**Delete:** select MMS to delete.

**Delete All:** delete all the MMS from the Inbox.

**Save as template:** Save the MMS as a template

**Properties:** Allows you to check the details of the MMS

Use details: Use the number from which you received the MMS

### **6.10 MMS Outbox**

MMS which have been sent or can't be sent are stored in the Outbox.

**View:** read the highlighted MMS.

**Forward:** Forward the MMS to another number

**Edit:** edit the MMS

**Delete:** select MMS to delete.

**Delete All:** delete all the MMS from the Inbox.

**Save as template:** Save the MMS as a template

**Properties:** Allows you to check the details of the MMS

**Use details:** Use the number from which you received the MMS

### **6.11 MMS Draftbox**

MMS saved during editing are stored in the Draft.

**Menu > Messages > MMS > MMS Draftbox > Option**

**View:** read the highlighted MMS.

**Send:** send the MMS

**Edit:** edit the MMS

**Delete:** select MMS to delete.

**Delete All:** delete all the MMS from the Inbox.

**Save as template:** Save the MMS as a template

**Properties:** Allows you to check the details of the MMS

**Use details:** Use the number from which you received the MMS

### **6.12 Templates**

**Menu > Messages > MMS > Templates**

The phone has preset set of MMS which may be selected and added to the text when you are editing SMS. Preset phrases may be modified.

### **6.13 MMS Settings**

**Menu > Messages > MMS > MMS Setting**

1. Compose
2. Send
3. Retrieve
4. Filter
5. Sever Profile
6. Memory status

### **6.14 Voicemail Server**

The phone supports Voice Mail.

**Menu > Messages > Voice mail server**

Set the voice mail numbers. When connecting, you can call and listen to the voice mail.

**Tip:** If you have set the voice mail number, press and hold **1 key** on idle screen to dial the

corresponding number.

### **6.15 Broadcast Message**

#### **Menu > Messages > Broadcast Message**

The phone supports Broadcast Message. It is supported by GSM network. Broadcast messages are single-way messages sent to the users of the network operators by the message service center. For the contents and channel setup of broadcast messages, consult your network operator.

You need to set Receive Broadcast Message to **On** before you can use Broadcast Message.

**Tip:** If you have opened and turned on Broadcast Message, you can select **Read Message** to browse the broadcast messages received. The phone will display 5 broadcast messages at most, since old messages will be replaced by the messages newly received.

### 7.1 Customized Phone Settings

| Functions                                    | Description                                                                                                                                                                                                                                                                                                                                                               |
|----------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Set time and date                            | Menu > Settings > Phone settings > Time and date                                                                                                                                                                                                                                                                                                                          |
| Schedule power on/off                        | Menu > Settings > Phone settings > Schedule power on/off<br>To disable and enable status; to activate/deactivate, switch on/off, and time in turn.                                                                                                                                                                                                                        |
| Select language                              | Menu > Settings > Phone settings> Language                                                                                                                                                                                                                                                                                                                                |
| Select preferred input methods               | Menu > Settings > Phone settings> Preferred Input methods (Smart abc/Hindi , Multitap abc/Hindi/ Numeric                                                                                                                                                                                                                                                                  |
| Set Display Settings                         | Menu > Settings > Phone settings > Display Setup > Wallpaper/Screen saver/Show date and time/ Show owner number                                                                                                                                                                                                                                                           |
| Set greeting text                            | Menu > Settings > Phone settings > Greeting Text                                                                                                                                                                                                                                                                                                                          |
| Shortcuts                                    | Menu > Settings > Phone settings> Shortcuts                                                                                                                                                                                                                                                                                                                               |
| Specify the dedicated key                    | Menu > Settings > Phone setup > Dedicated key<br>By default:<br>Up > Audio player<br>Down > Write SMS<br>Left & Right: Change wallpaper                                                                                                                                                                                                                                   |
| Auto update of date and time On/Off          | Menu > Settings > Phone settings > Auto update of date and time                                                                                                                                                                                                                                                                                                           |
| Set LCD Backlight                            | Menu > Settings > Phone settings > LCD backlight                                                                                                                                                                                                                                                                                                                          |
| Caller ID- Set by Network                    | Menu > Settings > Call settings > SIM 1 / 2 call settings>Caller ID                                                                                                                                                                                                                                                                                                       |
| Activate / deactivate the Call times display | Menu > Settings > Call settings > Advance settings > On / Off                                                                                                                                                                                                                                                                                                             |
| Activate / deactivate the Call time reminder | Menu > Settings > Call settings > Advance settings> Call time reminder > ON/OFF<br>You can select <b>Single</b> or <b>Periodic</b> .                                                                                                                                                                                                                                      |
| Auto calls disconnect                        | Menu > Settings > Call settings > Advance settings> Auto call dsconnect > ON/OFF                                                                                                                                                                                                                                                                                          |
| Select network                               | Menu > Settings > Network Setup > SIM 1/2 network setup> Network selection<br><b>Select Network:</b> The phone will search and display the list of known networks for you to select the desired one, after which, the phone will try to log in the selected network. If the selected network is registered successfully, it will prompt so.<br><b>Preferred networks:</b> |
| Select preferred network                     | Menu > Settings > Network setup > Preferred networks                                                                                                                                                                                                                                                                                                                      |

## User manual

|                                    |                                                                                                                                                                                                                                                                                                                     |
|------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Set information of GPRS Connection | Menu > Connectivity> Data account>GPRS/GSM Data                                                                                                                                                                                                                                                                     |
| Restore factory default            | <b>Menu &gt; Settings &gt; Restore factory settings</b><br><b>Tip:</b> You need to enter the phone password when you want to restore factory default. The preset phone password is <b>0000</b> . Please bear your password in mind. Incase you forget it, contact the local dealer or an authorized service center. |

### 7.2 Profile Setup

| Functions                                   | Description                                                                                        |
|---------------------------------------------|----------------------------------------------------------------------------------------------------|
| Activate the profile mode                   | <b>Menu &gt; Settings&gt; User profiles &gt; Options &gt; Activate</b>                             |
| Activate 'vibration mode' in idle condition | <b>Long press the # key on your keypad to activate the vibration mode</b>                          |
| Set the ringtone for incoming calls         | <b>Menu &gt; Settings &gt; User profiles &gt; Options&gt; Customize&gt; SIM1 / 2 incoming call</b> |
| Set the ringtone for messages               | <b>Menu &gt; User profiles &gt; Options&gt; Customize&gt;Tone setup &gt;SIM1 / 2 message tone</b>  |
| Set the ringtone for keypad tone            | <b>Menu &gt; User profiles &gt; Options&gt; Customize tone setup &gt; Keypad tone</b>              |
| Adjust the volume of Ring Tone / Key Tone   | <b>Menu &gt; User profiles &gt; Options &gt; Customize &gt; Volume &gt; Key tone</b>               |
| Set Alert Type of ringing                   | <b>Menu&gt;User profiles&gt; Options&gt; Customize &gt;Alert type</b>                              |
| Set the ringtone type                       | <b>Menu &gt; User profiles &gt; Options &gt; Customize &gt; Tone setup</b>                         |
| Set the Extra Tone                          | <b>Menu &gt; User profiles &gt; Options &gt; Customize &gt; Extra tone</b>                         |
| Set the answer mode                         | <b>Menu &gt; User profiles &gt; Options &gt; Customize &gt; Answer mode</b>                        |

### 7.3 Safety

| Functions               | Description                                                                                                                                                                                                                                                       |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>PIN code request</b> | <b>Menu &gt; Settings &gt; Security settings &gt;SIM 1/2 security settings&gt; SIM lock</b><br><b>Warning:</b> If you enter three wrong PIN codes in a row, you need to enter the PUK code to unlock. PIN code and PUK code are provided by the network operator. |
| <b>Data security</b>    | <b>Menu &gt; Settings &gt; Security settings &gt; Data Security</b><br>Protect folders (Phonebook, Messages, Call history, MMS, File manager) with a password. The default password is 0000.                                                                      |
| <b>Phone lock</b>       | <b>Menu &gt; Settings&gt; Security settings &gt; Phone lock</b><br>The preset password is <b>0000</b>                                                                                                                                                             |
| <b>Auto keypad lock</b> | <b>Menu &gt; Settings &gt; Security settings&gt;Auto keypad lock &gt; Select the time for the auto keylock.</b><br>Note: Press the LSK and * to lock/unlock the keypad.                                                                                           |
| <b>Change password</b>  | <b>Menu &gt; Settings &gt; Security settings&gt; Change password</b>                                                                                                                                                                                              |

## 8 Multimedia and Entertainment

### 8.1 Camera

**Menu > Multimedia > Camera:**

When the camera is activated, the phone enters the view finding status.

On the view finding screen, press **Ok Key** to capture.

**Tip:** If in weak light, such as night or indoor scene, the ISO Sensitivity may increase, which will cause noise or mottle.

Switch to Videorecorder:

Before shooting, you can set the following as needed. Select **Options >**

**Photos:** enter the photos.

**Camera settings:** set EV, Banding, delay timer, shutter sound, contrast and cont. shot,

**Image settings:** set the size and quality of photos.

**White balance:** set White Balance.

**Scene mode:** set scene mode.

**Effect settings:** set the special effects of photos, such as Grayscale, Sepia, Sepia Green, Sepia blue and Colour Invert.

**Storage:** select phone or memory card.

**Restore default:** restore default settings.

### 8.2 Image Viewer

**Menu > Multimedia > Image viewer**

Or on the view finding screen, select **Options > Photos**

The phone will automatically read the entries with the format supported by the phone under the folder **Photos** of **File manager** and display a list of entries. If there is no entry, the list is blank.

On the Image viewer list screen, select **Options>**

**View:** view the highlighted photo.

**Browse style:** select the style of viewing.

**Use:** set the highlighted photo as wallpaper, screen saver, or the photo caller ID of a Phonebook entry.

**Send:** send the photo by MMS or Bluetooth.

**Rename:** rename the highlighted file.

**Delete:** delete the highlighted file.

**Delete all files:** delete all the files from the list.

**Sort by:** sort the files in the list.

**Storage:** select phone or memory card.

### 8.3 Video Recorder

**Menu > Multimedia > Video recorder**

- Press **Ok Key** to record. When recording, press **Ok Key** to pause the recording, and press **Ok Key** again to resume recording.

**Tip:** If in weak light, such as night or indoor scene, the ISO Sensitivity may increase, which will cause noise or mottle.

Before recording, you can set the following as needed. Select **Options >**

**To player:** enter video player.

**Camcorder settings:** set White Balance, EV, Night Mode and Banding.

**Video settings:** set the Video Quality, File size limit, Rec time limit, and record audio.

**Effect settings:** set the special effects, such as Grayscale, Sepia, and Sepia Green etc.

**Restore default:** restore default settings.

### 8.4 Video Player

**Menu > Multimedia > Video player**

Or, on the view finding screen, select **Options > To player**

The phone will automatically read the entries with the format supported by the phone under the folder **Videos** of the **File manager** and display a list of entries. If there is no entry, the list is blank.

On the video player list screen, select **Options >**

**Play:** enter the play screen of the highlighted file. Select **Ok Key** to begin/pause playing; press **Navigation key (Up/Down)** to adjust the speed, press **Navigation key (Left/Right)** to adjust the progress.

**Send:** send the video by MMS or Bluetooth.

**Rename:** rename the highlighted file.

**Delete:** delete the highlighted file.

**Delete all files:** delete all the files from the list.

**Sort by:** sort the files in the list.

**Storage:** select phone or memory card.

### 8.5 Audio Player

The music player supports these formats: MP3, Midi, WAV, AWB, AMR and IMY.

**Menu > Multimedia > Audio player**

Create Play list

Before you start to enjoy the music for the first time, you need to create a play list.

You can create a play list automatically.

1. In Settings, activate List Auto Gen.

2. On the play list screen, select **Options > Refresh List**.

3. The phone will add the tracks with the format supported by the phone under the folder **My music** of the **File Manager** to the play list automatically.

Add to Rings

Rings are the list of ringtones selectable in the profile mode setup. You can select a single track and add it to the Rings.

On the 'play list' screen, select a track and select **Options > Add to ringtones**

### 8.6 Sound Recorder

**Menu > Multimedia > Sound recorder**

On the Sound Recorder list screen, you can select:

**New Record:** begin recording. The recordings will be saved in the folder **Audio** under the **File Manager** automatically.

**Play:** play the highlighted recording.

**Append:** continue to record the highlighted recording. (The format must be AMR or AWB).

**Rename:** rename the highlighted recording.

**Delete:** delete the highlighted recording.

**Delete all files:** delete all the recordings from the list.

**Settings:** set the format of the recording.

**Use as:** send the highlighted record to the ringtone list for profiles.

**Send:** send the highlighted record by MMS, Bluetooth.

### **8.7 FM Radio**

Menu > Multimedia > FM radio

**Edit the channel list manually:**

Options > Channel list

Options > Edit

**Edit the channel list automatically:**

Options > Auto search

**Play on the background play**

Options > Settings

Set the function **On** or **Off**.

**Listen in by Loud Speaker:**

Options > Settings

Set the speaker to **On** or **Off**.

**To Increase/Decrease the volume:**

To increase the volume press the # key and to decrease the volume press the \* key.

## ***9 Fun & Games***

### **9.1 Games**

Menu > Applications > Games

## ***10 Bluetooth***

**Tip:**

1. You can connect wirelessly to other compatible device with Bluetooth technology. Compatible devices may include computers, mobile phones. You can use Bluetooth connectivity to send images, music and sound clips, video clips, and notes.
2. Since devices with Bluetooth wireless technology communicate using radio waves, your devices and the other devices only need to be within 10 meters of each other, but the connection may be subject to interference or could face obstruction from stuff such as wall or from other electronic devices. Use the wireless technology of blue-tooth to be able to consume battery quantity of electric charge. If you are restricted by something

when using blue-tooth technology, Consult local authorities please.

### **10.1 To Activate/deactivate Bluetooth Connectivity**

**Menu > Connectivity > Bluetooth > Power ( On/Off )**

### **10.2 To Search/Inquire Audio Device**

**Menu > Connectivity> Bluetooth > Inquiry audio device**

**Tip:** Please activate the Bluetooth first.

### **10.3 To Search My (new) device**

**Menu > Connectivity> Bluetooth > My device > Inquiry new device**

**Tip:** Please activate the Bluetooth first.

### 11 Organizer

| Functions                    | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| View the calendar            | <b>Menu &gt; Organizer &gt; Calendar</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Add to do                    | Menu > Organizer > To do<br><b>Options &gt; Add</b><br><b>Or: Menu &gt; Organizer &gt; Calendar</b><br><b>Options &gt; Add task</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| View the events in the to do | Menu > Organizer > To do<br><b>Options &gt; View</b><br><b>Or: Menu &gt; Organizer &gt; Calendar</b><br><b>Options &gt; View tasks</b>                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Set the alarm                | <b>Menu &gt; Organizer &gt; Alarm &gt; Edit</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| World clock                  | <b>Menu &gt; Organizer &gt; World clock</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Stopwatch                    | <b>Menu &gt; Applications &gt; Stopwatch &gt; Typical stopwatch &gt; Split timing/Lap timing / View record</b><br>Press <b>Start</b> to start timing, and press <b>Split / Lap</b> continuously to record more than one time. Press <b>Done</b> to save the time.<br>Menu > Extra > Stopwatch > nWay stopwatch<br>Press <b>Start</b> to start timing, and press the corresponding <b>Navigation key</b> to activate the sub-timing. The main timing will continue to add. Select <b>Stop</b> to stop the main timing and the sub-timing. Press <b>Reset</b> to clear all the time. |
| Calculator                   | <b>Menu &gt; Applications &gt; Calculator</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Answer machine               | <b>Menu &gt; Applications &gt; Answer machine</b><br>Select ON/OFF to activate or deactivate 'auto answer' on your phone.                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

### ***12 File Manager***

When an USB cable is connected, you can use the phone as a USB mass storage.

| <b>Functions</b>                 | <b>Description</b>                                                                                                                                                                               |
|----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>View folders</b>              | <b>Menu &gt; File manager&gt; Options &gt; Open</b>                                                                                                                                              |
| <b>Create folders</b>            | <b>Menu &gt; File manager &gt; Options &gt; New folder</b>                                                                                                                                       |
| <b>View detailed information</b> | <b>Menu &gt; File manager &gt; Options &gt; Open<br/>Options &gt; Detail</b>                                                                                                                     |
| <b>Format</b>                    | <b>Menu &gt; File manager &gt; Options &gt; Format</b><br><b>Tip:</b> The Format function will delete the data you have created and saved. Please back up important data and keep them properly. |

### 13.1 WAP Browser

#### **Menu > Connectivity > WAP**

You need to make the relevant settings in WAP Setup before you use the WAP browser to surf the web.

When the WAP browser is activated, if a homepage is set in WAP Setup, the phone will link the website indicated by the homepage; otherwise, you may enter a website and the phone will connect to it.

When surfing the web, select **Options >**

**Refresh:** To refresh the web page.

**Homepage:** To link the homepage.

**Input URL:** input a website address.

**Add Bookmark:** Add to bookmark.

**Set Homepage:** set the URL as homepage.

**Forward/Backward:** To turn to the next /previous page.

**Advance:** Show URL info, Bookmark, Save item.

**Exit:** To exit the browser.

### 13.2 WAP Setup

WAP settings are required for surfing the web with WAP. Follow the steps below to set up a WAP account:

- Connectivity > Data Account > GPRS > Add account > Add account name/ APN/ Username & password > Save.

Then go to:

- Menu >Connectivity > WAP >Settings > Profiles > Add new > Account Name/ Homepage/ Data Account (select the previously created data account) > Select connection type (HTTP/WAP- Indise HTTP & WAP enter the correct proxy address & port > Done > Save the account >Go to the created account & activate.

#### **Menu > Connectivity> WAP> Settings>Profile**

You can set the following:

**Account:** To select from the GPRS connection list.

**Connection type:** To set WAP or HTTP connection mode.

**Home page:** To set the address of the homepage. The phone has a default and you can modify it.

### **14.1 STK Services**

If your SIM card supports STK, you may use the corresponding value-added services.

**Menu > Connectivity**

### ***15 Maintenance***

Use a dry soft cloth to wipe general dirt.

Do not use a hard cloth, benzene or thinner to wipe the phone, otherwise, the surface of the phone will be scratched or could even result in the fading of colour.

### *16 Taking Care of your Device*

- Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone:
- Always keep the small parts of the phone away from children.
- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will rust electronic circuits. If your device does get wet, remove the battery, and allow the device to dry completely before replacing it.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices and damage batteries.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Use chargers indoors

For details, see the After Service Guide supplied with the phone.

### ***18 Inputting Text***

You can enter text in English and digit.