

1. Packing List

- | | | |
|-----------------------------|----------------------|------------------|
| 1. Prestigio MultiPhone | 2. AC Adapter | 3. Earphone |
| 4. USB Cable | 5. Quick Start Guide | 6. Warranty Card |
| 7. Legal and Safety Notices | 8. Battery | |


2. Device Overview

- | | | |
|----------|-----------------------------|--|
| 1 | Earphone Jack | Earphone connection |
| 2 | Menu | Display menu options |
| 3 | Home | Back to the Home screen |
| 4 | Back | Back to the previous page |
| 5 | USB/Charge port | Micro USB cable/charge connection |
| 6 | Power | Turn on/off the device;
Suspend/Activate the device |
| 7 | Vol + \ Vol - Button | Adjust the volume level |
| 8 | Camera | Take photos |
| 9 | Speaker | Listen to phone calls or music |



3. Uninstalling the back cover and battery

- Uninstalling the back cover: hold the side of device tightly with one hand and lift up the back cover at its buckle with the other hand.



- Taking out the battery: hold the side of device tightly with one hand and pull up the battery handle with the other hand.

Notice: Your device must be powered off before exchanging or uninstalling the battery.

4. Installing the SIM cards and Micro SD card



a. Insert SIM cards

- The slot at the bottom is card 1 slot and for 3G WCDMA card (compatible with 2G card), another is card 2 slot and for GSM card.
- Please make sure the gold contact area on the card is facing downwards.

b. Insert Micro SD card

- Insert Micro SD card into the Micro SD card slot with the metallic pins facing downwards. Push the card until it locks into place.
- To remove the micro SD card, pull the card out of the slot.

5. Charging

- Insert one end of USB cable into the USB port on the device and plug the power adapter to the electrical socket.
- Normally it takes approximately 3~4 hours to fully charge the device. Operating the device while charging with the AC adapter may extend the time of full charging.



Notice: If you don't use your phone for a long time, it will gradually discharge. Please charge it first before your next use or charge the phone every 3 months even you don't use it.

6. Power on/Sleep Mode/Power off

- Press and hold the **Power Button** for a few seconds. It will automatically enter the **Home** screen after start-up screen.

- Press the **Power Button** once to enter sleep mode and press it again to awake the device.
- Press and hold the **Power Button**, and then tap on **Power off** to power off the device.

Technical Specifications

Processor	MSM7227A-AA @ 1 GHz
Memory	512MB RAM + 512MB ROM, Micro SD slot supports up to 32GB
OS	Android 2.3.5 (Gingerbread)
Display	4.0-inch LCD, Capacitive multi-touch
Resolution	480x800 pixels
Net Mode	WCDMA + GSM (UMTS:2100MHz; GSM:900/1800MHz)
Interfaces	USB 2.0, Micro SD
Communications	WiFi (802.11b/g/n), 3G
Battery	1400mAH Lithium-ion battery
Dimensions	125*64*11.7 mm (H * W * D)
Weight	107g

Disclaimer



As the Prestigio products are constantly updated and improved, your device's software and hardware may have a slightly different appearance or modified functionality than presented in this Quick Start Guide.

Prestigio hereby states that this Smartphone complies to basic requirements and another relevant regulations given by the EU directive 1999/5/ES. Full version of the declaration of conformity is available on <http://www.prestigio.com/compliance>.