



Introduction

Thanks for choosing the T-Mobile Vivacity.

This quick guide is designed to help you familiarise yourself with the mobile phone's basic functions.

Please note the pictures we use in this guide are only used to demonstrate the mobile phone's functions, so they might be a bit different from what you see on your mobile phone.

Powering On/Off Your Phone

Make sure the SIM card is in your phone and the battery is charged.

- Hold the **Power Key** to switch on your phone.
- To switch it off, hold **Power Key** to get the phone options. Select **Power off**, and then tap **OK**.

Switching to Sleep Mode

To save battery power, Sleep Mode suspends your phone to a low-power-consumption state while the display is off. Your phone also goes into Sleep Mode by itself when the display is automatically turned off after a certain period of time, which you can set in **Settings > Display > Screen timeout**.

Press the **Power Key** to switch to Sleep Mode.


Waking Up Your Phone

1. Press the **Power Key** to activate your screen display.
2. Drag the  icon to the right.

NOTE: If you have set an unlock pattern, PIN or password for your phone, you'll need to draw the pattern or enter the PIN/password to unlock your screen.

2

Your Home Screen



Taking Pictures

1. Tap **Home Key** >  > **Camera** to open the camera.
2. Aim the camera at the subject and then tap  to take the shot.

Camera Settings

From the Camera Screen tap  to set up focus mode, exposure, picture size/quality, colour effect, ISO, anti-banding, saturation, contrast, sharpness, and restore camera settings.

Tap  or  to choose whether to save photo's geographic location.

3

Tap  to change white balance setting.

Tap  or  to turn on or off flash.

Tap **1x** to zoom in or out.

Tap  or  to use the back or front camera.

TIPS: To change quickly from camera to camcorder or vice versa, use the switch  icon. Use the  bar to adjust the brightness.

Shooting Videos

1. Tap Home Key >  > Camcorder to open the video camera.
2. Tap  to start shooting, and tap  to stop.

Camcorder Settings

From the Camcorder Screen, tap  to adjust colour effect, video quality, video/audio encoder, video duration, and restore camera settings.

Tap  to change white balance setting.

Tap  to change video quality, video/audio encoder, and video duration together, including **High**, **Low**, **MMS**, **YouTube**, and **custom** mode.


Tap  or  to use the back or front camera.

Playing Music

Before you use the music player, please copy the music files to the microSD card and insert the card into your phone.

4

1. Tap **Home Key** >  > **Music** to open the Music Screen.
2. Tap **Artists/Albums/Songs/Playlists** tabs to get the songs you want to play.
3. Tap a song from the list to start playing.




Playing Videos

Before you use the video player, please copy the video files to the microSD card and insert the card into your phone.

1. Tap **Home Key** >  > **Videos**. Your phone will display all video files saved on your microSD card.

5

2. Tap the video file you want to play.
3. Tap on the screen to show or hide the control bar.



Turning On/Off USB Mass Storage

You can use the USB mass storage feature to transfer data between the microSD card and PC.

To turn on USB mass storage:

1. Insert the microSD card into your phone and connect the phone to the PC with a USB cable.
2. Flick down the notification panel and tap **USB connected** > **Turn on USB storage**.

6

To turn off USB mass storage:

Just flick down the notification panel and tap **Turn off USB storage** > **Turn off USB storage**.

Bluetooth®

Turning Bluetooth On/Off

Tap **Home Key** >  > **Settings** > **Wireless & networks** and tick the **Bluetooth** check box. When Bluetooth is on, the  icon will appear in the status bar.

If you want to turn Bluetooth off, just clear the **Bluetooth** check box.

Pairing With Another Bluetooth Device

To pair with another Bluetooth device, you need to turn the Bluetooth function of both devices on and make the other Bluetooth device 'visible'.

1. Tap **Home Key** >  > **Settings** > **Wireless & networks** > **Bluetooth settings**.
2. Tap **Scan for devices**. Your phone will show all visible Bluetooth devices (in range) in its **Bluetooth devices** list.
3. Select the device you want to pair with.
4. If required, enter your PIN and tap **OK**.

If a PIN is required, the same PIN should be entered on the other device.

7

Connecting to the Internet Using Wi-Fi

1. Tap **Home Key** >  > **Settings** > **Wireless & networks**.

2. Tick the **Wi-Fi** check box to turn Wi-Fi on.
3. Tap **Wi-Fi settings**.
The Wi-Fi access points, or "hotspots", that your phone has detected are displayed with their names and security settings.
4. Tap an access point to connect to it.
If security features are implemented, you'll need to enter a password.

Using GPRS/EDGE/3G Connection

To get connected via GPRS/EDGE/3G you need a data plan with your service provider. Also if the GPRS/EDGE/3G settings are not pre-configured on your phone, please contact your provider to get the necessary information.

1. Tap **Home Key** >  > **Settings** > **Wireless & networks** > **Mobile networks** > **Access Point Names**.
2. Tap **Menu Key** > **New APN**.
3. Tap each item to enter the information you get from your service provider.
4. Tap **Menu Key** > **Save** to complete.

TIPS: To set the APN to default settings, tap **Menu Key** > **Reset to default**.

C € 1588 !

8