



EN

MOTOROLA XOOM™ 2

MEDIA EDITION

LIFE. POWERED.

YOUR TABLET

When you're up and running, be sure to explore what your tablet can do:

- **Customize:** Start up, then "**PERSONALIZE**".
- **Create:** Check and send your "**EMAIL**", and even create and edit documents and calendar events for "**WORK**".
- **Enjoy:** "**LOAD UP**" your tablet's apps and games, or "**PLAY & RECORD**" media.

TIPS & TRICKS

- **Power/Sleep:** To turn your tablet on or off, press and hold Power/Sleep on the back. To make the screen sleep or wake up, press but don't hold.

Note: Wi-Fi-only devices don't have a SIM card. Certain apps and features may not be available in all countries.



START

Let's get you up and running.

Caution: Before assembling, charging, or using your tablet for the first time, please read the important safety, regulatory and legal information provided with your product.


TIPS & TRICKS

- In the unlikely event that your tablet becomes unresponsive, try a forced reboot—press and hold both Power/Sleep and the down volume key for more than 12 seconds.

Note: This product uses a non-removable battery.

Note: Wi-Fi-only devices don't have a SIM card.

Note: This device supports apps and services that use a lot of data, so make sure your data plan meets your needs. Contact your service provider for details.




TOUCH

It's all in the touch:

- **Touch:** Choose an icon or option.
- **Touch & hold:** Move items on the home screen, or open options for items in lists.
- **Drag or flick:** Scroll slowly (drag) or quickly (flick).
- **Pinch or double-tap:** Zoom in and out on websites, photos, and maps.

TIPS & TRICKS

- **Flick & stop:** When you flick a long list, touch the screen to stop it from scrolling.
- **Maps:** Twist a map with two fingers to rotate it, and pull two fingers down to tilt it.




NAVIGATE

Find your way around:

- **Search:** Search with text or voice.
- **App menu:** See all your apps (if you have a lot, flick left and right to see them all).
- **Back:** Go back one screen.
- **Home:** Return to the home screen at any point.
- **Recent apps:** Show thumbnails of your recent apps (touch a thumbnail to open the app).

TIPS & TRICKS

- **Panels:** Flick left or right to show the five home screen panels. To return to the center panel, touch Home .
- **Menu:** When you see in the top right, or in the bottom left, you can touch them to open a menu for the screen you're on.



WANT MORE?

You can get more information, more help, more free stuff. We're here to help.

- **Answers:** Check out the help center on your tablet—touch **Apps** > **Help Center**. If your device doesn't have **Help Center**, you can download it from www.motorola.com/myroom?media=dlc.
- **Support:** Go to www.motorola.com/support, where you can select from a number of customer care options. You can also contact the Motorola Customer Support Center at 0800 666 8676 (Argentina), 800 201-442 (Chile), 01-800-100-1504 (Colombia), 01 800 021 0000 (Mexico), 0800-100-4289 (Venezuela), or 0 800 52 470 (Peru).
- **Updates:** To keep your tablet current, software updates may be available. Touch **Apps** > **Settings** > **About tablet** > **System updates** to see if your tablet is up to date. If it isn't, touch **Update**.
- **Join us:** Get the latest news, apps, tips & tricks, videos and so much more—join us on:
 - YouTube™ www.youtube.com/motorola
 - Facebook™ www.facebook.com/motorola
 - Twitter www.twitter.com/motomobile


You can find accessories for your tablet at www.motorola.com/accessories

Copyright & Trademarks

SAR This product meets the applicable SAR limits of 1.6 W/kg FIC and 2.0 W/kg CMRP. The limits and guidelines include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The highest SAR values measured for this device are listed in the regulatory information packaged with your product. Certain features, services and applications are network dependent and may not be available in all areas; additional terms, conditions and/or charges may apply. Contact your service provider for details. All features, functionality, and other product specifications, as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation. **Note:** The images in this guide are examples only. MOTOROLA and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. Google, the Google logo, Google Maps, Google Earth, Gmail, YouTube, Google Books, Google Docs, Google Photos, Google Maps Navigation Beta, Google Calendar, Android, Android Market, and other marks are trademarks of Google, Inc. All other product or service names are the property of their respective owners. © 2011 Motorola Mobility Inc. All rights reserved. Product ID: MOTOROLA XOOM™ 2 Media Edition with 3G-FIC/CMRP Model M20012 Manual Number: 890160101-A


PERSONALIZE

- Change your widgets, wallpaper, and more—make it yours.
- **Home screen:** To move widgets or shortcuts, touch and hold them. To add them or change wallpaper, touch in the top right.
 - **Sound & display:** Touch the clock in the bottom right, then touch and **Settings** to choose **Screen**, **Sound**, and more.
- TIPS & TRICKS**
- **Add to your home screen:** Just touch and hold an empty spot on the home screen.
 - **Remove from your home screen:** Touch and hold a widget or shortcut, then drag it to the trash can in the top right.
 - **Settings app:** To open settings from the app menu, touch **Apps** > **Settings**.




LOAD UP

- Your tablet comes with fun games and apps—explore them, and download even more from Android Market™!
- Find it:** **Apps** > **Market**
- **Find:** To find a game or app, touch at the top.
 - **Review:** To show the apps you've downloaded from **Market**, touch **My apps**.
- TIPS & TRICKS**
- **Help:** To get help and more, touch **Menu** in the top right corner.
 - **On a computer:** You can find and manage apps from any computer. Just go to market.android.com and log in with the email and password for your Google™ account.
 - **Uninstall:** To uninstall your apps from **Market**, touch **My apps**. Touch an app to show the **Uninstall** button.




SURF

- You're surfing on the big screen.
- Find it:** **Apps** > **Browser**
- **Tabs:** Touch to open a new tab, then touch tabs to go to them or touch to close them.
 - **Bookmarks:** If you love that website, touch to bookmark it. Touch to open your bookmarks.
- TIPS & TRICKS**
- **Touch & hold:** Touch and hold a link or text field for options.
 - **Zoom:** To zoom in or out, pinch your fingers together or move them apart on the screen.
 - **Search:** To search from the home screen, touch in the top left for a **text** search, or touch for a **voice** search.
 - **Share:** To send a website link to a friend, just touch **Menu** > **Share** page.




PLAY & RECORD

- See it, capture it, share it!
- Find it:** **Apps** > **Camera** or **Music**
- **Photos & videos:** In the camera, touch to take a photo or touch to switch to videos.
To open photos & videos, touch **Apps** > **Gallery**.
 - **Stream and transfer computer files:** Open **Apps** > **MotoCast** and install it on your computer (from www.mymotocast.com), then log in to stream or download files right to your tablet.
- TIPS & TRICKS**
- **Zoom:** To zoom in or out on photos, pinch your fingers together or move them apart on the screen.
 - **Camera settings:** In the photo viewfinder, touch to open **Camera settings**.



EMAIL

- Keep in touch with friends and colleagues.
- Find it:** **Apps** > **Email** or **Gmail**
- **Add accounts:** Touch **Apps** > **Settings** > **Accounts & sync**; then touch **Add account** in the top right. For Microsoft® Exchange work accounts, choose **Corporate** and enter settings from your IT department.
- TIPS & TRICKS**
- **Keypad:** Touch a text field to open the touchscreen keypad.
 - **Drag or flick:** When you flick a long list of contacts or emails, touch the screen to stop it from scrolling.
 - **Social networking:** Get Facebook™, Twitter, and lots more. Visit Android Market™ to grab the latest official apps and widgets, and see what everyone is up to. Touch **Apps** > **Market**.



WORK

- You can use Quickoffice™ to view and edit files online, or download them to your tablet to work on them anytime.
- Find it:** **Apps** > **Quickoffice HD**
- **Open files:** Touch a file or folder to open it, or touch and hold a file for options. You can edit most text or spreadsheet files.
 - **Select text:** Double-touch text to select it.
- TIPS & TRICKS**
- **Options:** To open a keyboard, choose formatting, save the file, or choose other options touch **Menu** .
 - **Accelerate:** Use a dock or Bluetooth™ keyboard and mouse when you want to make your tablet more like a laptop computer. Turn them on and touch **Apps** > **Settings** > **Wireless & networks** > **Bluetooth settings** > **Find nearby devices**. To disconnect the mouse, turn it off. To disconnect the keyboard, touch the keyboard icon in the bottom right of your screen, then drag the touch switch to **Off**.

