

User Guide



Restore™

www.sprint.com

*©2010 Sprint. SPRINT and the logo are trademarks of Sprint.
Other marks are the property of their respective owners.*

6/10/10



Consejo: Para encontrar esta guía para usuarios en español, por favor visita a www.sprint.com y haz clic en **Support > Devices**.

To find this user guide in Spanish, please visit www.sprint.com and click **Support > Devices**.

Important Privacy Message – Sprint's policies often do not apply to third-party applications. Third-party applications may access your personal information or require Sprint to disclose your customer information to the third-party application provider. To find out how a third-party application will collect, access, use, or disclose your personal information, check the application provider's policies, which can usually be found on their website. If you aren't comfortable with the third-party application's policies, don't use the application.

Open Source Software – Some software components of this product incorporate source code covered under GNU General Public License (GPL), GNU Lesser General Public License (LGPL), OpenSSL License, BSD License and other open source licenses. To obtain the source code covered under the open source licenses, please visit:
<http://opensource.samsungmobile.com/index.jsp>.

Table of Contents

Tip: Looking for something? If you don't see it in the headings listed here, try the Index on page 191.

Introduction	i
Your Phone's Menu	i
Section 1: Getting Started	1
1A. Setting Up Service	2
Setting Up Your Phone	2
Activating Your Phone	3
Setting Up Your Voicemail	4
Sprint Account Passwords	4
Getting Help	5
Section 2: Your Phone	7
2A. Phone Basics	8
Your Phone	8
Viewing the Display Screen	11
Turning Your Phone On and Off	16
Battery and Charger	16
Navigating Through the Menus	19

Displaying Your Phone Number	21
Making and Answering Calls	22
Entering Text in Portrait Mode	31
Entering Text in Landscape Mode	35
2B. Navigating the Main Screen	42
Getting to Know Sprint One Click	42
Personalizing the Carousel	44
2C. Settings	48
Sound Settings	48
Display Settings	50
Location Settings	52
Messaging Settings	53
Airplane Mode	54
TTY Use With Sprint Service	55
Phone Setup Options	56
Security Settings	57
2D. History	62
Viewing History	62
History Options	63
Making a Call From History	64
Saving a Number From History	64

Erasing History	65
2E. Contacts	66
Adding a New Contacts Entry	66
Adding a New Group	67
Saving a Phone Number	67
Contacts Entry Options	68
Editing a Contacts Entry	68
Adding a Number to a Contacts Entry	69
Editing a Contacts Entry's Numbers	69
Deleting a Contact	70
Assigning Speed Dial Numbers	70
Selecting a Ringer Type for an Entry	71
Assigning a Picture to an Entry	72
Finding Contacts Entries	72
Secret Contacts Entries	73
Dialing Sprint Services	73
Wireless Backup	74
2F. Calendar & Tools	76
Calendar	76
File Manager	80
Alarm Clock	81

Memo Pad	82
Calculator	83
Tip Calculator	83
Eco Calculator	83
World Clock	84
Updating Your Phone	84
Updating the PRL	84
2G. Voice Services	85
Automatic Speech Recognition (ASR)	85
Managing Voice Memos	88
2H. microSD Card	91
Your Phone's microSD Card and Adapter	91
microSD Card Settings	93
microSD Card Folders	94
Connecting Your Phone to Your Computer ...	95
2I. Camera	97
Taking Pictures	97
Recording Videos	101
Storing Pictures and Videos	102
Sending Pictures and Videos	104
Printing Pictures From Your Phone	107

Settings	107
2J. Bluetooth	109
Turning Bluetooth On and Off	109
Using the Bluetooth Settings Menu	110
Pairing Bluetooth Devices	110
Sending Items via Bluetooth	111
Section 3: Sprint Service.....	115
3A. Sprint Service: The Basics	116
Voicemail	116
Messaging (SMS/MMS)	119
Caller ID	121
Call Waiting	122
Making a 3-Way Call	122
Call Forwarding	123
Roaming	123
3B. Web and Data Services	127
Getting Started With Data Services	127
Browser Menu	131
Accessing Messages	135
Downloading Games, Ringers, and More	138
Applications	141

Data Services FAQs	149
3C. Entertainment: TV and Music	151
TV	151
Music – Sprint Music Store	154
Streaming Music	160
3D. GPS Navigation	162
GPS Services	162
Sprint Navigation	162
Sprint Family Locator	164
Getting Driving Directions	164
Configuring Your Navigation Preferences	170
Launching the Product Tour	172
Section 4: Safety and Warranty	
Information	173
4A. Important Safety Information	174
General Precautions	174
Maintaining Safe Use of and Access to Your Phone	175
Using Your Phone With a Hearing Aid Device	176
Caring for the Battery	178
Radio Frequency (RF) Energy	179

Owner's Record	181
User Guide Proprietary Notice	181
4B. Manufacturer's Warranty	182
Manufacturer's Warranty	182
Index.	191

Introduction

This **User Guide** introduces you to Sprint® service and all the features of your new phone. It's divided into four sections:

- ◆ Section 1: Getting Started
- ◆ Section 2: Your Phone
- ◆ Section 3: Sprint Service Features
- ◆ Section 4: Safety and Warranty Information

Note: Because of updates in phone software, this printed guide may not be the most current version for your phone. Visit www.sprint.com and sign on to **My Sprint** to access the most recent version of the user guide.

WARNING: Please refer to the **Important Safety Information** section on page 174 to learn about information that will help you safely use your phone. Failure to read and follow the Important Safety Information in this phone guide may result in serious bodily injury, death, or property damage.

Your Phone's Menu

The following table outlines your phone's main menu structure. For more information about using your phone's menus and the carousel main screen, see "Navigating Through the Menus" on page 19 and section 2B "Navigating the Main Screen" on page 42.

OPTIONS (Left Softkey)
1: Main Menu
2: Personalize Carousel
3: Tutorial
4: Software Updates
5: Minimize Carousel
6: Reset One Click
7: About Sprint One Click
CONTACTS (Right Softkey)
Web

Maps	
1: Sprint Navigation	
2: Sprint Family Locator	
Entertainment	
1: Music	
2: Sprint TV	
3: Games	
1: Get New Games	2: My Stuff Manager Games
3: Bejeweled Demo	4: Diner Dash Flo on the Go
5: Texas HoldEm Poker Demo	
History	
Missed Alerts	
My Stuff	
1: Application Manager	
2: Games	
1: Get New Games	2: My Stuff Manager Games
3: Bejeweled Demo	4: Diner Dash Flo on the Go
5: Texas HoldEm Poker Demo	

3: Ringers	
1: Get New Ringers	2: My Stuff Manager Ringers
4: Screen Savers	
1: Get New Screen Savers	
2: My Stuff Manager Screen Savers	
5: Applications	
1: Get New Applications	
2: My Stuff Manager Applications	
3: NASCAR Sprint Cup Mobile	
4: Scan Life	5: Social Zone
6: Sprint Football Live	
6: Call Tones	
<i>Photos & Videos</i>	
1: Camera	
Press right softkey to view the following options:	
1: Mode	
1: Camera	2: Camcorder
2: Shooting Mode	
1: Single Shot	2: Continuous
3: Mosaic	4: Panorama
5: Night Shot	

3: Resolution	
1: 2M	2: 1.3M
3: High	4: Med
5: Low	
4: White Balance	
1: Auto	2: Daylight
3: Cloudy	4: Incandescent
5: Flourescent	6: Manual
5: Brightness	
1: Brightness	
6: Self Timer	
1: Off	2: 5 Sec
3: 10 Sec	
7: Effect	
1: None (default)	2: MONOCHROME
3: SEPIA	4: NEGATIVE
5: AQUA	6: GREEN
8: Quality	
1: Fine	2: Normal
3: Economy	
9: Shutter Sound	
1: Off	2: Shutter 1
3: Shutter 2	4: Shutter 3

10: Auto-Send	
1: On	2: Off
11: Storage	
1: Phone	2: Card
2: Camcorder (Video Mail/Long Video)	
Press the right softkey to view the following options:	
1: Mode	
1: Camera	2: Camcorder
2: White Balance	
1: Auto	2: Daylight
3: Cloudy	4: Incandescent
5: Flourescent	6: Manual
3: Brightness	
1: Brightness	
4: Self Timer	
1: Off	2: 5 Sec
3: 10 Sec	
5: Effect	
1: None (default)	2: MONOCHROME
3: SEPIA	4: NEGATIVE
5: AQUA	6: GREEN

6: Quality	
1: Fine 3: Economy	2: Normal
7: Auto-Send	
1: On	2: Off
8: Storage	
1: Phone	2: Card
3: My Photos & Videos	
1: In Phone	2: Memory Card
4: My Places	
1: Add New Place..	
5: Auto-Send	
1: Add-Send Places	
6: Settings	
1: Auto Save to	2: Status Bar
Messages	
1: Voicemail	
1: Call Voicemail	2: Clear Envelope
2: Send Message	

3: Messages	
4: Email	
5: Settings	
1: Notification	
1: Message & Icon	2: Icon Only
2: Callback Number	
1: None 3: Other	2: [your phone]
3: Prest Messages	
4: Signature	
1: On	2: Off
5: Reset Envelope	
Contacts	
Settings	
1: Display	
1: Screen Saver	
1: No Image 3: My Albums 5: Preloaded	2: Take New Picture 4: Downloaded

2: Picture ID	
1: Contacts	2: Unsaved Numbers
3: Private/Unknown	
3: Backlight Control	
1: Backlight Dim	2: Backlight Off
3: Java Backlight	
4: Brightness	
5: PowerSave Mode	
1: On	2: Off
2: Volume	
1: Incoming Ringer Volume	
2: Playback Volume	
1: Use Ringer Volume	
2: Seperate Volume	
3: Key Beeps	
1: Tone Type	2: Tone Volume
3: Ringers	
1: Incoming Calls	2: Voicemail
3: Text Message	4: Alarm/Calendar
5: PowerUp/Down	6: Battery Alert

4: Auto Keyguard	
1: On	2: Off
5: Text Entry	
1: Word Complete	2: Next Word Complete
6: Phone Information	
1: Phone Number/User ID	
2: Memory Status	3: Icon Glossary
4: Version	5: Advanced
6: My Account	
7: Lock Phone	
1: Change Lock Code	
2: Keep Existing Lock Code	
3: Cancel	
8: Location	
1: On	2: Off
9: Parental Controls	
1: On/Off	
2: Change Parental Control Code	
3: Restrictions	
0: Reset/Delete	

*: Others	
1: Abbreviated Dialing	2: Accessibility
3: Airplane Mode	4: Data
5: Contact Match	6: Roaming
7: Language	8: Contacts
9: Wireless Backup	10: TTY Options
Tools	
1: Alarm	
2: Calendar	
1: Personal Calendar	2: Add Calendar
3: Bluetooth	
1: On/Off	2: Visibility
3: Add new	4: Trusted Devices
5: My Bluetooth Info	
4: Update Phone	
1: Update Firmware	2: Update PRL
5: Mass Storage	
1: Connect to PC	2: File Manager
3: Format Memory Card	4: Memory Info
6: Voice Service	

7: Calculator	
1: Calculator	2: Tip Calculator
3: Eco Calculator	
8: Device Self Service	
9: World Time	
0: Memo Pad	
*: Voice Memo	
1: Record	2: Review
Shopping	
In Use Menu	
Press MUTE/UNMUTE (left softkey). Press OPTIONS (right softkey) to display the following options:	
1: Save/Contact Details	
2: 3-way call	3: Contacts
4: Voice Memo	5: Phone Info
6: Key Mute/Unmute	7: Messaging
8: Recent History	9: Tools

Section 1
Getting Started



1A. Setting Up Service

- ◆ Setting Up Your Phone (page 2)
- ◆ Activating Your Phone (page 3)
- ◆ Setting Up Your Voicemail (page 4)
- ◆ Sprint Account Passwords (page 4)
- ◆ Getting Help (page 5)

Setting Up Your Phone

1. Install the battery.
 - Remove the battery from its packaging.
 - Place your fingernail into the Release Latch indentation (adjacent to the microphone) and carefully lift (1) the case off the rear of the phone (2).

- This is similar to popping the top off a soda can.



- Insert the battery into the opening in the back of the phone (3), making sure the connectors align. Gently press down to secure the battery (4).



- Position the battery cover over the battery compartment and press down until you hear a click.
2. Press  to turn the phone on.
 - If your phone is activated, it will turn on, search for Sprint service, and enter standby mode.

- If your phone is not yet activated, see “Activating Your Phone” on page 3 for more information.

3. Make your first call.

- Use your keypad to enter a phone number.
- Press .

Note: Your phone's battery should have enough charge for your phone to turn on and find a signal, set up your voicemail, and make a call. You should fully charge your battery as soon as possible. See “Charging the Battery” on page 18 for details.

Activating Your Phone

- **If you purchased your phone at a Sprint Store**, it is probably activated and ready to use.
- **If you received your phone in the mail and it is for a new Sprint account or a new line of service**, it is designed to activate automatically. To confirm your activation, make a phone call.
- **If you received your phone in the mail and you are activating a new phone for an existing number on your account**, you will need to go online to activate your new phone.

- From your computer's Web browser, go to www.sprint.com/activate and complete the onscreen instructions to activate your phone.

When you have finished, make a phone call to confirm your activation. If your phone is still not activated or you do not have access to the Internet, contact Sprint Customer Service at **1-888-211-4727** for assistance.

Tip: Do not press  while the phone is being activated. Pressing  cancels the activation process.

Note: If you are having difficulty with activation, contact Sprint Customer Service by dialing **1-888-211-4727** from any other phone.

Setting Up Your Voicemail

Your phone automatically transfers all unanswered calls to your voicemail, even if your phone is in use or turned off. You should set up your Sprint Voicemail and personal greeting as soon as your phone is activated. Always use a passcode to protect against unauthorized access.

1. From standby mode, press and hold .
2. Follow the system prompts to:
 - Create your passcode.
 - Record your name announcement.
 - Record your greeting.

Note: Voicemail Passcode

Sprint strongly recommends that you create a passcode when setting up your voicemail to protect against unauthorized access. Without a passcode, anyone who has access to your phone is able to access your voicemail messages.

For more information about using your voicemail, see “Voicemail” on page 116.

Sprint Account Passwords

As a Sprint customer, you enjoy unlimited access to your personal account information, your voicemail account, and your data services account. To ensure that no one else has access to your information, you will need to create passwords to protect your privacy.

Account Username and Password

If you are the account owner, you will create an account username and password when you sign on to www.sprint.com. (Click **Need to register for access?** to get started.) If you are not the account owner (if someone else receives the bill for your Sprint service), you can get a sub-account password at www.sprint.com.

Voicemail Password

You'll create your voicemail password (or passcode) when you set up your voicemail. See "Setting Up Your Voicemail" on page 4 for more information on your voicemail password.

Data Services Password

With your Sprint phone, you may elect to set up an optional data services password to control access and authorize Premium Service purchases.

For more information, or to change your passwords, sign on to www.sprint.com or call Sprint Customer Service at **1-888-211-4727**.

Getting Help

Managing Your Account

Online: www.sprint.com

- Access your account information.
- Check your minutes used (depending on your Sprint service plan).
- View and pay your bill.
- Enroll in Sprint online billing and automatic payment.
- Purchase accessories.
- Shop for the latest Sprint phones.
- View available Sprint service plans and options.
- Learn more about data services and other products like Sprint Picture Mail, games, ringers, screen savers, and more.

From Your Sprint Phone

- Press  to check minute usage and account balance.
- Press  to make a payment.

- Press    to access a summary of your Sprint service plan or get answers to other questions.
- Press    to add a new line of service, upgrade your phone, purchase accessories, or access other account services.

From Any Other Phone

- Sprint Customer Service: **1-888-211-4727**.
- Business Customer Service: **1-800-927-2199**.

Sprint 411

Sprint 411 gives you access to a variety of services and information, including residential, business, and government listings; movie listings or showtimes; driving directions, restaurant reservations, and major local event information. You can get up to three pieces of information per call, and the operator can automatically connect your call at no additional charge.

There is a per-call charge to use Sprint 411, and you will be billed for airtime.

► Press    .

Sprint Operator Services

Sprint Operator Services provides assistance when you place collect calls or when you place calls billed to a local telephone calling card or third party.

► Press  .

For more information or to see the latest in products and services, visit us online at www.sprint.com.

Section 2
Your Phone



2A. Phone Basics

- ◆ Your Phone (page 8)
- ◆ Viewing the Display Screen (page 11)
- ◆ Turning Your Phone On and Off (page 16)
- ◆ Battery and Charger (page 16)
- ◆ Navigating Through the Menus (page 19)
- ◆ Displaying Your Phone Number (page 21)
- ◆ Making and Answering Calls (page 22)
- ◆ Entering Text in Portrait Mode (page 31)
- ◆ Entering Text in Landscape Mode (page 35)

Tip: Phone Software Upgrades – Updates to your phone's software may become available from time to time. Sprint will automatically upload critical updates to your phone. You can also use the menu to check for and download updates.

- Highlight  and press  > **Tools** > **Update Phone** to search for and download available updates.

Your Phone



Key Functions

1. **Front Indicator Light (LED)** shows your phone's connection status at a glance.
2. **Status Bar Icons** provide information about your phone's status and options, such as signal strength, roaming, ringer setting, messaging, and battery charge.
3. **Display Screen** displays all the information needed to operate your phone, such as the call status, the Contacts list, the date and time, and the signal and battery strength.
4. **Navigation Key** (similar to an optical joystick) uses touch to scroll through the phone's menu options. Pressing it accepts an onscreen selection.
5. **Softkeys Portrait Mode** let you select left and right softkey actions or menu items corresponding to the bottom left and bottom right lines on the Display Screen when the phone is in portrait mode.
6. **SPEAKER Key** lets you place or receive calls in speakerphone mode.
7. **TALK Key** () allows you to place or receive calls, answer Call Waiting, use 3-Way Calling, or activate Voice Dial.
8. **Keypad** lets you enter numbers, letters, and characters, and navigate within menus. Press and hold keys for speed dialing.
9. **Microphone** allows other callers to hear you clearly when you are speaking to them.
10. **END/POWER Key** () lets you turn the phone on or off, end a call, or return to standby mode. While in the main menu, it returns the phone to standby mode and cancels your input. When you receive an incoming call, press to enter silent mode and mute the ringer.
11. **BACK/Clear Key** deletes characters from the display in text entry mode. When in a menu, pressing the Back key () returns you to the previous menu. This key also allows you to return to the previous screen in a data session.
12. **MENU/OK** lets you access the phone's menus and selects the highlighted choice when navigating through a menu.

13. **Earpiece** lets you hear the caller and automated prompts.
14. **Charger/Accessory Jack** allows you to connect the phone charger or an optional USB cable.
CAUTION! Inserting an accessory into the incorrect jack may damage the phone.
15. **Volume Button** allows you to adjust the ringer volume in standby mode (with the phone open) or adjust the voice volume during a call. The volume button can also be used to scroll up or down to navigate through the different menu options.
16. **microSD Card (internal)** lets you use a microSD card to expand the memory of your phone. To gain access to this slot, you must first remove the battery cover.
17. **Cover Release Latch** lets you remove the battery cover and expose both the internal battery compartment and internal microSD card slot.
18. **Camera Button** lets you activate the camera and camcorder and take pictures and videos.

19. **Headset Jack** allows you to plug in either a stereo headset or an optional headset for convenient, hands-free conversations.
CAUTION! Inserting an accessory into the incorrect jack may damage the phone.
20. **Camera Lens**, as part of the built-in camera, lets you take pictures and videos.

Landscape Phone Features



21. **Softkeys Landscape Mode** let you select left and right softkey actions or menu items corresponding to the bottom left and bottom right lines on the Display Screen when the phone is in landscape mode.
22. **QWERTY Keyboard** provides an alphanumeric character keyboard layout.
23. **Shift Key** lets you toggle alphabet characters between mixed case, uppercase and lowercase. Character case remains as selected until the Shift key is pressed again.
24. **FN Key** (Function) key, toggles to access the white numbers/symbols on the QWERTY keyboard.
25. **Text Key** launches the New Text Message menu from where you can initiate a new outgoing text message.
26. **Space Key** lets you add spaces between words and characters.
27. **Enter/OK Key** lets you perform the function highlighted in the current menu. Press to enter additional lines of text.
28. **Back Key** deletes characters from the display in text entry mode. When in a menu, pressing  returns you to the previous menu. This key also allows you to return to the previous screen in a data session.

Viewing the Display Screen

Your phone's display screen provides information about your phone's status and options. This list identifies the symbols you'll see on your phone's display screen:

Tip: To view a list of your phone's icons and descriptions, from the main menu select **Settings > Phone Information > Icon Glossary**.

Note: For information about using your phone's main screen carousel, see section 2B "Navigating the Main Screen" on page 42.

<i>Status Bar – Service Icons</i>	
	Signal Strength – Your current signal strength. (More bars = stronger signal.)
	No Service – Your phone cannot find a usable signal.
	Roaming – Your phone is “roaming” off the Nationwide Sprint Network.
	Data Status – Sprint 1xRTT data service is available. When active, the icon is animated.
	Data Sending – Sprint 1xRTT data service is transmitting data.
	Data Receiving – Sprint 1xRTT data service is receiving data.
	Data Dormant – Data service is currently dormant.
	EVDO Data Service Available – Sprint mobile broadband data service (EVDO) is available. When active and communicating, the icon is animated.
	EVDO Data Service Status – Current status of the Sprint mobile broadband data service.

<i>Status Bar – Service Icons</i>	
	EVDO Data Service Active – Sprint mobile broadband data service (EVDO) is active.
	EVDO Data Service Dormant – Sprint mobile broadband data service (EVDO) is dormant.

<i>Status Bar – Status Icons</i>	
	Battery Strength – Your current battery charge level. (Icon shown is fully charged.)
	Low battery – Your current battery charge level is low.
	Location On – Your phone’s location feature is on and available for location-based services such as GPS Navigation.
	Location Off – Your phone’s location feature is off. Your location is available only for 911 (see page 52).
	TTY – Your phone is operating in TTY mode.
	Keytones Muted – Your phone’s key tones are muted.

<i>Status Bar – Status Icons</i>	
	Speakerphone Enabled – Your phone's speakerphone feature is enabled.
	Silence All – All incoming sounds are turned off.
	Vibrate Only – The ringer is set to vibrate only.
	Ring and Vibrate – Your phone has the ringer volume set and the vibrate option checked (enabled).
	Ringer – The phone is set to ring only.
	Ringer Off – The ringer is turned off and vibrate mode is disabled.
	Ringer Off and Vibrate – Your phone has the ringer deactivated and the vibrate option checked (enabled).
	1 Beep – Your phone is set to beep when an incoming call is received.
	1 Beep and Vibrate – Your phone is set to beep and vibrate when an incoming call is received.


<i>Status Bar – Status Icons</i>	
	Alarm – An alarm has been set on your phone.

<i>Status Bar – Messaging Icons</i>	
	Text Message – You have new text messages.
	Urgent Message – You have new messages marked as Urgent.
	Picture Mail Message – You have new picture mail messages.
	Voicemail – You have new voicemail messages. Press and hold   to call your voicemail box.
	Email Message – You have new email messages.
	Missed Picture Mail Message – You have a new Picture mail message.
	Missed Text/Email Message – You have new unread text or email messages.
	Missed Voicemail Message – You have new unheard voicemail messages.

<i>Status Bar – Messaging Icons</i>	
	Locked Message – You have new text messages.

<i>Status Bar – Other Icons</i>	
	Missed Scheduler – You have missed a scheduled event.
	Missed Alarm – You have missed an alarm event.
	Missed Call – You have missed an incoming call.
	Missed Call Alert – You have missed a call alert.
	Multiple Alerts – You have multiple alert messages.
	Calendar Event – You have a pending event scheduled.
	Camera Mode – The camera is enabled and you are in Camera Mode.
	Camcorder Mode – The camcorder is enabled and you are in Camcorder Mode.

<i>Status Bar – Other Icons</i>	
	Self Timer – The self-timer function is enabled.
	White Balance (Auto) – The white balance has been set to Automatic. This is used for taking pictures indoors or outdoors using automatic white balance settings.
	White Balance (Daylight) – The white balance has been set to Sunny. This is used for taking pictures or movies outdoors on bright sunny days.
	White Balance (Cloudy) – The white balance has been set to Cloudy. This is used for taking pictures or movies outdoors under cloudy conditions.
	White Balance (Incandescent) – The white balance has been set to Tungsten. This is used for taking pictures or movies indoors under normal lighting conditions.
	White Balance (Fluorescent) – The white balance has been set to Fluorescent. This is used for taking pictures or movies indoors under fluorescent lighting conditions.

<i>Status Bar – Other Icons</i>	
	White Balance (Manual) – The white balance has been set to Manual. This is used for taking pictures indoors or outdoors using your own custom settings.
	Recording – A video or voice memo is currently being recorded.
	Paused – A voice memo or video has been paused.
	Play – A voice memo or video is playing.
	Media Upload – Files have been uploaded to an online album or folder.
	Voice Caption – Voice captioning is enabled and that audio is currently being recorded.
	Bluetooth (Enabled/Active) – The Bluetooth technology is active and enabled.
	Bluetooth (Connected) – The Bluetooth device is connected.
	Bluetooth (Headset Connected) – The Bluetooth Headset is connected and visible.

<i>Status Bar – Other Icons</i>	
	Bluetooth (Stereo Connected) – The Bluetooth stereo device is connected and visible.
	Bluetooth (Hidden) – The device is hidden to other Bluetooth devices and not transmitting its information.
	Background Application +1 – Indicates that more than one application is currently running and one has been minimized and placed in the background.
	Wireless Backup – A current wireless backup session is in progress.

Turning Your Phone On and Off

Turning Your Phone On

- ▶ Press and hold  for two seconds.

Once your phone is on, it may display “Searching for Service.” When your phone finds a signal, it enters standby mode – the phone’s idle state. At this point, you are ready to begin making and receiving calls.

If your phone is unable to find a signal after 15 minutes of searching, a Power Save feature is automatically activated. When a signal is found, your phone automatically returns to standby mode.

In Power Save mode, your phone searches for a signal periodically without your intervention. You can also initiate a search for Sprint service by pressing any key (when your phone is turned on).

Tip: The Power Save feature conserves your battery power when you are in an area where there is no signal.

Turning Your Phone Off

- ▶ Press and hold  for two seconds until you see the powering-down animation on the display screen.

Your screen remains blank while your phone is off (unless the battery is charging).

Battery and Charger

WARNING: Use only Sprint-approved or Samsung-approved batteries and chargers with your phone. The failure to use a Sprint-approved or Samsung-approved battery and charger may increase the risk that your phone will overheat, catch fire, or explode, resulting in serious bodily injury, death, or property damage.

Sprint-approved or Samsung-approved batteries and accessories can be found at Sprint Stores or through Samsung; or call 1-866-866-7509 to order. They’re also available at www.sprint.com.

Battery Capacity

Your phone is equipped with a Lithium Ion (Li-Ion) battery. It allows you to recharge your battery before it is fully drained. The battery provides up to 6.0 hours of continuous digital talk time.

When the battery reaches 5% of its capacity, the battery icon blinks (). When there are approximately two minutes of talk time left, the phone sounds an audible alert and then turns off.

Note: Long backlight settings, searching for service, vibrate mode, browser use, and other variables may reduce the battery's talk and standby times.

Tip: Watch your phone's battery level indicator and charge the battery before it runs out of power.

Installing the Battery

- See "Setting Up Your Phone" on page 2.

Removing the Battery

1. Make sure the power is off so that you don't lose any stored numbers or messages.

2. Place your fingernail into the Release Latch indentation (adjacent to the microphone) and carefully lift the case off the rear of the phone.
3. Lift the battery up (1) and remove the battery from the phone (2).

WARNING: Do not handle a damaged or leaking Li-Ion battery as you can be burned.



4. Position the battery cover over the battery compartment. Align the case over the Battery Latch, then in a single motion, press down and snap the entire case over the compartment until you hear a click.



- Press along the entire edge of the cover to verify it is securely in place.

WARNING: Do not handle a damaged or leaking Li-Ion battery as you can be burned.

Charging the Battery

Keeping track of your battery's charge is important. If your battery level becomes too low, your phone automatically turns off, and you will lose any information you were just working on.

Always use a Sprint-approved or Samsung-approved desktop charger, travel charger, or vehicle power adapter to charge your battery.

Tip: It is recommended that you completely charge your battery first before using your phone. This guarantees you begin using your phone with a fully charged battery.

- Plug the flat end of the charger into the phone's charger jack and the other end into an electrical outlet.



- A **red indicator light** means the battery is charging.
- A **green indicator** light means the battery is at least 90 percent charged.
- A **battery icon** () indicates the current charge level of the internal battery.

With the Sprint-approved Li-Ion battery, you can recharge the battery before it becomes completely run down.

Navigating Through the Menus


Note: Your phone's Sprint One Click main screen gives you instant access to your favorite features. See section 2B "Navigating the Main Screen" on page 42 for complete information.

Menu navigation can be accomplished via either the touch-sensitive navigation key or via the directional keys on the QWERTY keyboard.

The navigation key on your phone lets you scroll through and select onscreen items. Many menus feature a scroll bar on the right to help you keep track of your position in the menu.

For a diagram of your phone's menu, please see "Your Phone's Menu" on page i.

Selecting Menu Items Using the Navigation Key



The navigation key acts as a dual touch-sensitive mouse and OK/Enter key. As you navigate through a menu, options are highlighted. Select any option by highlighting it and pressing .

- If the option is numbered, you can also select it by pressing the corresponding number on the phone's keypad.

For example, to view your text messages:

1. From standby mode, scroll left or right to highlight  and then press  to access the main menu.
2. Scroll across the navigation key until **Messages** is highlighted and press .
3. Select **Messages** by highlighting it and then pressing . (If you have any text messages, they are displayed.)

For the purposes of this guide, the above steps condense into:

- Highlight  and press  > **Messages** > **Messages**.

Selecting Menu Items Using the Arrow Keys

As you navigate through a menu, options are highlighted. Select any option by pressing a directional arrow from the QWERTY keyboard and moving the onscreen selection, highlighting it and pressing .

- If the option is numbered, you can select it by pressing the corresponding number on the phone's keypad.

For example, to view your text messages:

1. From standby mode, press the left or right directional keys to highlight  and then press  to access the main menu.
2. Press these keys and select **Messages** by highlighting it and pressing .
3. Select **Messages** by highlighting it and pressing . (If you have any text messages, they are displayed.)

Backing Up Within a Menu

To go to the previous menu:

- ▶ Press .

To return to standby mode:

- ▶ Press .

Displaying Your Phone Number

- ▶ Highlight  and press  > **Settings** > **Phone Information** > **Phone Number/User ID**. (Your phone number and other information about your phone and account will be displayed.)

Making and Answering Calls

Making Calls

1. Enter a phone number from standby mode. (If you make a mistake while dialing, press  to erase the numbers.)
2. Press . (To make a call when you are roaming and Call Guard is enabled, press  and press . See “Call Guard” on page 125.)
3. Press  when you are finished.

Tip: To redial your last outgoing call, press  twice.

To redial other recent numbers, press , highlight a number, and press  again.

When making calls off the Nationwide Sprint Network, always dial using 11 digits (1 + area code + phone number).

You can also place calls from your phone by speed dialing numbers from your Contacts (page 30) and using your History listings (page 64).

Dialing Options

When you enter numbers in standby mode, you will see a variety of dialing options displayed as softkeys on the phone's screen.

To send a message to the number, press **SEND MESSAGE** (left softkey).

– or –

To initiate an option, press **OPTIONS** (right softkey), then press the corresponding softkey.

- **Contact Details:** Displays the details for a Contact if the entered number matches a previously created entry.

Tip: To speed dial a phone number from standby mode, press and hold the speed dial number. If the speed dial number is two digits, enter the first digit, and then press and hold the second digit. (For information on setting up speed dial numbers, see “Assigning Speed Dial Numbers” on page 70.) (This feature will not work when you are roaming off the Nationwide Sprint Network; when roaming you must dial using eleven digits [1 + the area code + the seven-digit phone number].)

- **Save Contact:** Allows you to save the phone number in your Contacts. (See “Saving a Phone Number” on page 27.)
- **Hard Pause:** Enter digits and then use this feature to enter a hard pause within a number string (the phone waits for your input). To continue dialing, you must press . (See “Dialing and Saving Phone Numbers With Pauses” on page 28.)
- **2-Sec Pause:** Enter digits and then use this feature to enter a 2 second delay within a number string (the phone continues dialing after 2 seconds without any additional keys being pressed). (See “Dialing and Saving Phone Numbers With Pauses” on page 28.)

Answering Calls

1. Make sure your phone is on. (If your phone is off, incoming calls go to voicemail.)
2. Press  to answer an incoming call. (Depending on your settings, you may also answer incoming calls by opening the phone or by pressing any number key.)

Your phone notifies you of incoming calls in the following ways:

- The phone rings or vibrates.
- The indicator light flashes.
- The backlight illuminates.
- The screen displays an incoming call message.

If the incoming call is from a number stored in your Contacts, the entry’s name is displayed. You may also see the caller’s phone number, if available.

Answering a Roam Call With Call Guard Enabled

Call Guard is an option that helps you manage your roaming charges when making or receiving calls while outside the Nationwide Sprint Network. Please see “Roaming” on page 123 for more information about roaming.

- ▶ Select **ANSWER** to answer the call. (See “Call Guard” on page 125 for additional information.)

Note: When your phone is off, calls go directly to voicemail

Ending a Call

- ▶ Press .

Missed Call Notification

When you do not answer an incoming call, your screen displays the Missed Alerts Call log.

To display the Missed Call entry from the notification screen:

- ▶ Highlight the entry and press . (To dial the phone number, press .)

To display a Missed Call entry from standby mode:

1. Highlight  and press  > **History**.
2. Highlight an entry and press .

Calling Emergency Numbers

You can place calls to 911 by dialing    , even if your phone is locked or your account is restricted.

Note: When you place an emergency call, your phone automatically enters Emergency mode.

During an emergency call, press **OPTIONS** (right softkey) to display your options. Highlight an option and press .

- **Speaker On** to activate speakerphone mode. (If you are in speakerphone mode, the option is displayed as **Speaker Off** to deactivate.)
- **Unlock Phone** to unlock your phone (appears only if the phone is locked).
- **Close Menu** to close the pop-up menu (appears only if the phone is unlocked).

Tip: Press **My Phone** (left softkey) to display your phone number during an emergency call.

To exit Emergency mode:

1. Press   until Emergency mode is exited.

Note: When you are in Emergency mode, you can exit by pressing  then pressing .

To deactivate the Emergency call in standby mode:

- ▶ Press   until Emergency mode is exited.

Enhanced 911 (E911) Information

This phone features an embedded Global Positioning System (GPS) chip necessary for utilizing E911 emergency location services where available.

When you place an emergency 911 call, the GPS feature of your phone seeks information to calculate your approximate location. Depending on several variables, including availability and access to satellite signals, it may take up to 30 seconds or more to determine and report your approximate location.

Important: Always report your location to the 911 operator when placing an emergency call. Some designated emergency call takers, known as Public Safety Answering Points (PSAPs) may not be equipped to receive GPS location information from your phone.

In-Call Options

Pressing **OPTIONS** (right softkey) during a call displays a list of available in-call features. To select an option, press the corresponding keypad number or highlight the option and press . The following options may be available through the Options menu:

- **Contact Details** to display Contact information if the number is saved in your Contacts.
- **Save** to add the new number to your Contacts list.
- **3-way Call** to initiate a three-way call. (For more information, see “Making a 3-Way Call” on page 122)
- **Contacts** to display your Contacts list.
- **Voice Memo** allows you to record incoming audio from your conversation. (For more information, see “Managing Voice Memos” on page 88.)
- **Phone Info** displays the following menu options:
 - **Phone Number** - your phone number
 - **Icon Glossary** - a list of currently available icons
 - **Version** - phone software version
 - **Advanced** - additional technical information
- **Key Mute/Unmute** allows you to mute the key tones from being heard by the caller.
- **Messaging** accesses the Message menu options.
- **Recent History** checks your call log for Recent calls. You can also erase the logs from this menu.
- **Tools** accesses the Tools menu options.
 - **Calendar** - your calendar entries

- **Bluetooth** - a list of current Bluetooth devices
- **Memo Pad** - onscreen memo pad
- **Alarm** - your Alarm events and menu
- **Calculator** - onscreen calculator

Press **MUTE** (left softkey) during a call to mute the microphone. Press **UNMUTE** (left softkey) to unmute the microphone.

Using the Speakerphone

To use your phone handsfree or to share a call with other people:

1. Place your phone in Speaker Mode by pressing the Speaker key () until “Entering speaker mode” appears in the display.

WARNING: Because of higher volume levels, do not place the phone near your ear during speakerphone use.

2. To disable Speaker Mode, press  until “Exit speaker mode” appears in the display.

End-of-Call Options

After you receive a call from or make a call to a phone number that is not in your Contacts, the phone displays the phone number and the duration of the call.

- Press **OPTIONS** (right softkey) > **Save** to add the new number to your Contacts. (See “Saving a Phone Number” on page 27.)

After you receive a call from or make a call to a phone number that is already in your Contacts, the phone displays the entry name, phone number, and the duration of the call. Press **OPTIONS** (right softkey) > **Contact Details** to view the Contacts listing for the number.

Note: The End-of-Call options are not displayed for calls identified as No ID or Restricted.

Saving a Phone Number

You can store up to 1000 contact entries in total, with each contact entry containing a maximum of seven phone numbers for a total phone book capacity of 7000 numbers. Each entry's name can contain 64 characters. Your phone automatically sorts the Contacts entries alphabetically. (For more information, see "2E. Contacts" on page 66.)

To save a number from standby mode:

1. Enter a phone number and press **OPTIONS** (left softkey) > **Save Contact**.
2. Highlight **New Entry** or **Existing Entry** and press .
3. Highlight a label (**Mobile**, **Home**, **Work**, **Pager**, **Fax**, or **Other**) and press .
4. Enter the new contact name.
– or –
Search for an existing contact name.

5. Press **DONE** (left softkey) to save the entry. You are then notified if the number was successfully added.

Finding a Phone Number


You can search Contacts for entries by name.

1. Press **CONTACTS** (right softkey) and enter the first letter or letters of an entry. (The more letters you enter, the more specific the search.)
2. To display an entry, highlight it and press .
To dial a number, highlight it and press .

You can also search Contacts by using a specific string of numbers.

1. Enter four or more of the last digits in standby mode. (The more numbers you enter, the more specific the search becomes.)

- Matching Contacts entries are displayed within an onscreen list.



2. To display the Contacts entry that contains the phone number you entered, highlight the entry and press **OPTIONS** (right softkey) > **Contact Details**.

– or –

To dial the number, highlight the entry from the list and press .

Dialing and Saving Phone Numbers With Pauses

You can dial or save phone numbers with pauses for use with automated systems, such as voicemail or credit card billing numbers.

There are two types of pauses available on your phone:

- **Hard Pause** sends the next set of numbers when you press . (This is indicated with a **p** within the number sequence.)
- **2-Second Pause** automatically sends the next set of numbers after two seconds. (This is indicated with a **t** within the number sequence.)

Note: You can have multiple pauses in a phone number and combine two-second and hard pauses.

To dial or save phone numbers with pauses:

1. Enter the phone number.
2. Press **OPTIONS** (right softkey) > **Hard Pause** or **2-Sec Pause**.
3. Enter additional numbers.

4. Press  to dial the number.

– or –

Press **OPTIONS** (right softkey) > **Save Contact** to save the number in your Contacts.

Note: When dialing a number with a hard pause, press **SEND TONES** (left softkey) to send the next set of numbers.

Abbreviated Dialing

Abbreviated Dialing is similar to speed dialing. You can use either of the following abbreviated dialing features.

- **Contacts Match** – Retrieve any number saved in your Contacts by entering the last four digits of the number. Press  to dial the retrieved number. (See “To activate the Contacts Match feature:” on page 57.)
- **Prepend/Abbreviated Dialing** – Prepend the first five or six digits (for example, the area code and prefix) to any four or five digits you enter. Press  to dial the resulting number. (See page 57 to register a prepend number and activate the Prepend feature.)

To place a call using Contacts Match Abbreviated Dialing:

1. Enter the last four to six digits of a Contacts entry's phone number.
2. Press  to call the displayed number. (If there is more than one matched number in your Contacts, your phone displays the Abbrev. Dial list. Highlight a name and then press  to place a call.) (See “Finding a Phone Number” on page 27.)

To place a call using Prepend Abbreviated Dialing:

1. Enter the last four or five digits of the number.
2. Press .

Dialing From the Contacts List

1. Highlight  and press  > **Contacts**.

Shortcut: From standby mode, press **CONTACTS** (right softkey) to list entries.

2. Highlight the entry you want to call and press  to dial the entry's default phone number.

– or –

To dial another number from the entry, highlight the name and press , and then highlight a number and press .

Speed Dialing

You can store up to 99 numbers in your phone's speed dial memory. Dial speed dial entries using one keypress for locations 2–9 or two keypresses for locations 10–99.

To use One-Touch Dialing for speed dial locations 2–9:

- ▶ Press and hold the appropriate key for approximately two seconds. The display confirms that you have dialed the number when it shows “Calling...”.

To use Two-Touch Dialing for speed dial locations 10–99:

1. Press the first digit.

2. Press and hold the second digit for approximately two seconds. The display confirms that you have dialed the number when it shows “Connecting...”.

Plus (+) Code Dialing

When placing international calls, Plus Code Dialing automatically enters the international access code for your location (for example, 011 for international calls made from the U.S.).

1. Press and hold  until you see a “+” on the display screen.
2. Dial the country code and phone number, and then press . (The phone automatically prepends the access code for international dialing, followed by the country code and phone number.)

Entering Text in Portrait Mode

Your phone provides convenient ways to enter letters, numbers, and symbols whenever you are prompted to enter text (for example, when adding a Contacts entry or when using Sprint Mail and Text Messaging).

In this section we'll cover the steps necessary to enter text while the phone is in portrait mode where the keypad is the primary method of both text and character entry.

Selecting a Text Input Mode

1. From a screen where you can enter text, press **OPTIONS** (right softkey) > **Text Mode** to change the text input mode.
2. Select one of the following options:
 - **Predictive Text** to enter text using a predictive text system that reduces the number of keypresses required while entering a word. (See page 32.)
 - **Smiley's** to enter "emoticons." (See page 33.)
 - **Symbols** to enter symbols. (See page 33.)

- **Text Settings** to configure these options: **Auto-Capital**, **Auto-Space**, **Dual Language**, **Word Choice List**, **Word Prediction**, **Word Completion**, **Use My Words** (See "Entering Numbers, Symbols, Smileys and Preset Messages" on page 33.)

Tip: When entering text, press  to change letter capitalization (**ABC** > **Abc** > **abc**).

Selecting a Text Message Option

1. From a screen where you can enter text, press **OPTIONS** (right softkey).
2. Select one of the following options:
 - **Add Preset Message** to enter preprogrammed messages. (See page 34.)
 - **Add/Change Recipients** to return to the Send to page and either add or change any previously chosen recipients.
 - **Add/Change Attachments** to return to the Send to page and either add or change any current attached files. See "Composing Text/Picture Messages" on page 119.

- **Add/Change Subject Line** to return to the Send to page and either add or change the message subject text.
- **Save as Draft** to store the current message as a draft for later modification and delivery.
- **Mark as Urgent** to set a priority level of Urgent to the outgoing message. This notifies any recipient of the urgent read status for the outgoing message.
- **Set Callback #** to set the callback number seen by text message recipients.

For complete information on text messaging, see “Messaging (SMS/MMS)” on page 119.

Entering Text Using Predictive Text

Predictive Text lets you enter text by pressing keys just once per letter. (To select this mode when entering text, see “Selecting a Text Input Mode” on page 31.) This input method uses an intuitive word database to analyze the letters you enter and create a suitable word. (The word may change as you type.)

1. From a screen where you can enter text, press **OPTIONS** (right softkey) > **Text Mode** > **Predictive Text** > **On** to activate this input mode.
2. Press the corresponding keys once per letter to enter a word. (For example, to enter the word “Bill,” press) (If you make a mistake, press to erase a single character. Press and hold to erase all previously entered text.)

ABC Mode

In its default mode, also known as ABC or multi-tap entry, you press keys one, two, three, or four times to enter the letters you see on the keypad. For example, press  once for “a,” twice for “b,” or three times for “c”; or press  once for “p,” twice for “q,” three times for “r,” or four times for “s.”

1. Press the corresponding keys repeatedly until the correct letter appears. (For example, to enter the word “Bill,” press  twice,  three times,  three times, and  three times again.) (If you make a mistake, press  to erase a single character. Press and hold  to erase an entire word.)

By default, the first letter of an entry is capitalized and the following letters are lowercased. After a character is entered, the cursor automatically advances to the next space after two seconds or when you enter a character on a different key.

Characters scroll in the following order:

Key	English Sequence	
	Upper Case	Lower Case
	. ? ! , - ' @ : / 1	
	A B C 2	a b c 2
	D E F 3	d e f 3
	G H I 4	g h i 4
	J K L 5	j k l 5
	M N O 6	m n o 6
	P Q R S 7	p q r s 7
	T U V 8	t u v 8
	W X Y Z 9	w x y z 9
	Shift	Caps Lock Unshift
	0	
	Space	

Entering Numbers, Symbols, Smileys and Preset Messages

To enter numbers:

- Press the corresponding keys repeatedly until the correct number appears. Pressing a key multiple times cycles the characters through its available set. Pressing four times displays the number two. (See “Selecting a Text Input Mode” on page 31.)

To enter symbols:

1. From a screen where you can enter text, press **OPTIONS** (right softkey) > **Text Mode** > **Symbols** to activate this input mode.
2. To enter a symbol, press the appropriate key indicated on the display.

To enter “emoticons” (smileys):

1. From a screen where you can enter text, press **OPTIONS** (right softkey) > **Text Mode** > **Smiley’s** to activate this input mode.
2. To enter a smiley/emoticon, press the appropriate key indicated on the display.

To enter preset messages:

1. From a screen where you can enter text, press **OPTIONS** (right softkey) > **Add Preset Message** to activate this input mode. (See “Selecting a Text Input Mode” on page 31.)
2. Highlight a message and press .

Note: Preset messages make composing text messages easier by allowing you to enter quick messages, such as “Meet me at,” “Let’s get lunch,” or a customized message of your own. (For more information on preset messages, please see “Managing Preset Messages” on page 53.)

Setting Text Options

The Text Options menu allows you to specify more automated features during the text entry process. These options can help streamline the text entry process by correcting for capitalization, spelling, spacing, and completing the most commonly entered words for you.

1. From a screen where you can enter text, press **OPTIONS** (right softkey) > **Text Mode** > **Text Settings** and then use your navigation key to scroll down the list and activate the desired text entry option:
 - **Auto-Capital**: allows you to turn on or off the capitalization of the next character after a full stop punctuation is followed by a space.
 - **Auto-Space** allows you to turn on or off the ability to insert a space automatically after a word is selected from the candidate list.
 - **Dual Language** allows you to select word candidates to display in English only (**None**) or in Spanish (**Spanish**).
 - **Word Choice List** allows you to display an onscreen list of available word choices.
 - **Word Prediction** allows you to configure the phone to display possible word candidates after a preset number of characters have been entered.
 - **Word Completion** allows you to turn on or off the ability to insert predictive words into the text.
 - **Use My Words** allows you to turn on or off the ability to use words from your own custom dictionary.

Note: You can also access Text Entry options from the Settings menu. Press **Menu > Settings > Text Entry**.

Entering Characters In Dual Language

By enabling the Dual Language text option, you can use the keys for both English and Spanish text entry. If the Word Prediction and Word Completion text options are enabled, the available word choices presented are from both language sets (English/Spanish).

To enter characters in dual language mode:

1. From a screen where you can enter text, press **OPTIONS** (right softkey) > **Text Mode** > **Text Settings** > **Dual Language**.
2. Select **Spanish** and press . (See “Selecting a Text Input Mode” on page 31.)

To disable dual language mode:

1. From a screen where you can enter text, press **OPTIONS** (right softkey) > **Text Mode** > **Text Settings** > **Dual Language**.
2. Select **None** and press .

Entering Text in Landscape Mode

Accessing the QWERTY Keyboard

The Samsung Restore™ has a built-in, keyboard-style keypad, referred to as a full QWERTY keyboard. The keyboard is located beneath the display screen and is accessed by sliding it open. This orients the phone's display to landscape (widescreen) mode.

Using the QWERTY keyboard, you can type letters, numbers, punctuation, and other special characters into text entry fields or other applications simpler and faster than using the telephone keypad.


To open the phone and access the keyboard:

1. Rotate the phone 90 degrees counter-clockwise.
2. Slide the top section of the phone up to open, as shown in the following illustration. When you slide the phone open, the display rotates from a vertical viewing mode (portrait) to a horizontal viewing mode (landscape).



Navigation Key in Landscape Mode

Just as the screen orientation is changed, so is the functionality of both the softkeys and the navigation key. The Up/Down/Left/Right options of the navigation key are also adjusted when the phone changes from portrait to landscape modes.



Entering Text Using the Keyboard

Your phone's keyboard provides a convenient way to enter letters, numbers, and symbols whenever you are prompted to enter text. Using your phone's keyboard is just like using any standard computer keyboard, except that here each key has a primary character in white on the bottom (usually letters) and a secondary character in red on the top (numbers and punctuation).

Secondary characters are accessed by first pressing the Function key (Fn).



The following keys perform special functions when entering text:

Keyboard Functions	
	Sym – Launches the Symbols page. Press  and  to choose from onscreen symbols by using their associated numbers.
	Shift – Changes the text input mode among Upper/Lower/Mixed case modes. (Press twice to turn Shift lock on.)

Keyboard Functions	
	Function – Allows you to enter the numbers or characters displayed in blue at the top of the QWERTY keys. Examples: 1, \$, %, #, ! (Press twice to turn Fn lock on.)
	Web – Launches an Internet connection.
	Text – Launches a new text message.
	WWW – Inserts either a question mark into your text or when used in conjunction with  it inserts www..
	Space – Inserts an empty space.
	COM – Inserts either a period into your text or when used in conjunction with  it inserts a .com .
	OK/Enter – Accepts a change or option. While entering text, moves the insertion point to the next line in a message, like the Enter key on a computer keyboard.

<i>Keyboard Functions</i>	
	Back – Deletes the previous character, similar to the backspace key on a computer keyboard.
	Smiley's – Launches the Smiley's page. Choose from an extensive list of smiley's (emoticons). Use the left and right navigation keys to scroll to the different pages.

Using the Keyboard

Setting Text Options

The Text Mode menu allows you to specify more automated features during the text entry process. These options can help streamline the text entry process by correcting for capitalization, spelling, spacing, and completing the most commonly entered words for you.

1. From a screen where you can enter text, press **OPTIONS** (right softkey)

Note: When in Landscape mode, use the left and right softkeys located below the LCD.

2. Use the navigation keys on the keyboard and press  or **Enter** to select the desired text entry option:
 - **Text Mode** provides access to Predictive text Smiley's, Symbols, and Text Settings.
 - **Predictive Text** allows you to configure the phone to display possible word candidates as characters are entered.
 - **Add Preset Message** to enter preprogrammed messages. (See page 41.)
 - **Add/Change Recipients** to return to the Send to page and either add or change any previously chosen recipients.
 - **Add/Change Attachments** to return to the Send to page and either add or change any current attached files.
 - **Add/Change Subject Line** to return to the Send to page and either add or change the message subject text.
 - **Save as Draft** to store the current message as a draft for later modification and delivery.

- **Mark as Urgent** to set a priority level of Urgent to the outgoing message. This notifies any recipient of the urgent read status for the outgoing message.
 - **Set Callback #** to set the callback number seen by text message recipients.
3. Press  or  to store the new settings and return to the message screen.

Entering Letters

- Press the desired letter keys to enter words.
 - Press  once to capitalize the next letter.
 - Press  twice to turn on Shift (Caps) lock.
 - Press  or  to erase the previous letter.
 - Press and hold  or  to erase all previous text.

Note: During text entry, a list of possible word choices is displayed. If your desired word is listed, select the entry from the list and press  to insert the selected word into your message.

Example: To enter the name "Bill," press the following keys:




Entering Numbers and Punctuation

- Press  and then press the key with the desired character displayed on top.
 - For example, to enter 9, press  and then press .


To enter only the top row of characters, double press  to fix all consecutive characters.

Example: To enter "9:30," you would use the keyboard sequence shown below.



Note: In some applications, certain fields may default to entering numbers (such as the phone number fields in Contacts). In others, you will need to use  to enter numbers.

Example: Here's an example showing how to enter a combination of letters and numbers.



Entering Symbols and Smiley's

Symbols and Smiley's (emoticons) are entered by accessing onscreen menus and touching the desired item.

To enter symbols:

1. With the cursor in the desired location, press  > .
2. Press the numeric key corresponding to the desired symbol.

Note: You can exit from the Symbols page by pressing any keyboard key or .

To enter smiley's:

1. With the cursor in the desired location, press .
2. Press the numeric key corresponding to the desired smiley or emoticon.

To edit specific text using the onscreen navigation keys:

- Use the navigation keys to place your cursor in the desired location.
 - If you make a mistake, press  to reveal the keyboard and press  to erase a single character.
 - Press and hold  to erase an entire word or all entered characters.

To enter preset messages:

1. From a screen where you can enter text, press **OPTIONS** (right softkey) > **Add Preset Message** to activate this input mode. (See “Selecting a Text Input Mode” on page 31.)
2. Highlight a message and press  or .

Returning to Portrait Mode

When you close the QWERTY keyboard, the display screen will revert back to Portrait mode until you slide the keyboard back open.

2B. Navigating the Main Screen


- ◆ Getting to Know Sprint One Click (page 42)
- ◆ Personalizing the Carousel (page 44)

Getting to Know Sprint One Click

Sprint One Click brings all your favorite features to your fingertips. Instead of navigating through the levels of a traditional phone menu, this design puts the things you need the most – features like text messaging, Internet access, and GPS navigation – right up front. Not only can you access what you need right away, you get to choose what and where it all goes.

Using the Sprint One Click main screen is easy once you've learned a few basics.

The Sprint One Click Main Screen



The illustration above shows the basic layout of your phone's main screen, also known as the standby screen. The callouts highlight what you'll need to know to get started with Sprint One Click.

- **Carousel** – The carousel is the bottom row of **tiles**, or icons, on your main screen. Using the **navigation key** (Optical Joystick) left or right moves the carousel. The tile in the center is the selected tile, and its menu

is displayed. In the illustration, the **Home** tile () is in the center, so the Home screen is displayed.

- **Tiles** – The tiles are the individual icons on the carousel. Each tile displays a specific menu, such as Messaging and Internet. The carousel can hold up to 15 tiles, which you can add, remove, and rearrange to suit your needs. The **Home** tile () provides access to the phone's full menu, and it is the only one that cannot be moved or removed.
- **Function Keys** – The keys you'll use to navigate through the main screen are:
 - **Navigation key (Menu/OK)**: The navigation key doubles as a touch-sensitive optical joystick and OK Key.
 - Use the Optical Joystick to move the carousel and select tiles. Selected tiles occupy the center position. Scroll across the Optical Joystick up or down to highlight bubbles (Home screen only) or menu items.
 - Press to select highlighted menu items. From the Home () screen, press  to display the phone's full menu.

- **Softkeys**: Press the left or right softkey (while in Portrait or Landscape modes) to perform the action or access the menu indicated by the text directly above it on the display.
- **End/Power key** (): Press from any menu or tile to return to the Home () screen.

Take the Tutorial

Your phone has a built-in menu of tutorials to teach you all you need to know about Sprint One Click.

1. Highlight  and press **OPTIONS** (left softkey) > **Tutorial**.
– or –
Select  (**Personalize My Phone**) > **Tutorial**.
2. Highlight a topic and press  to display the tutorial.
 - Topics include: **Getting Started, Changing the Carousel, Adding a Tile, Removing a Tile, Alerts and Notifications, Dismissing, and Finding Dismissed**.

Tip: To see a full menu of tutorials when viewing another topic in the tutorial, press **INDEX** (left softkey).

Personalizing the Carousel

Now that you know what the carousel is, it's time to make it work for you by adding, removing, or rearranging tiles to match how you want to use your phone.

Adding a Tile to the Carousel

1. Highlight  and press **OPTIONS** (left softkey) > **Personalize Carousel**.
2. Press **Add Tile** (left softkey), select a tile category (**New**, **All**, **News & Sports**, **Communicate & Tools**, **Web & Communities**, **Social Networks**, **Entertainment & Games**, **Money & Weather**, or **Green**) and then highlight a tile.
3. To add the tile, press **ADD** (left softkey) or press . (To view a preview, press **PREVIEW** [right softkey].)

Note: Tile categories and available tiles are continually being updated, and there are dozens of tiles to choose from. The following table shows a sampling of the default tiles that may be preloaded on your phone.

Sprint One Click Tiles	
	Home – View Home screen and bubbles. Press  to access the phone's full menu.
	Messaging – Access Voicemail, Send Message, Text Message, Picture Mail, and Email. See “3A. Sprint Service: The Basics” on page 116.
	My Account – Access links to Account Details Web page, Hear Minutes, and Hear Balance.
	Sprint Zone – Access links to Sprint Zone services like Games & Apps, My Stuff, and other Promotional Content. See “Downloading Games, Ringers, and More” on page 138.
	Personalize My Phone – Access Change Screen Saver, Change Ringer, Personalize Carousel, and Tutorial.
	Shortcuts – Add and access up to five shortcuts from My Stuff, My Album, Web Bookmarks, and Menu Items.
	MySpace – Access to your MySpace page. See “MySpace” on page 146.

<i>Sprint One Click Tiles</i>	
	Best of Green – Access a collection of green, earth-friendly information including access to: Five Simple Things, Green Guides, Green Glossary, and All Things Green. See “Best of Green” on page 148.
	Yahoo – Access links to Yahoo services such as Mail, Mobile Homepage, News and Address Book.
	Twitter – Access your Twitter page and chat online with friends via “tweets”. See “Twitter” on page 148.
	Facebook – Access your Facebook page and all your friends. See “Facebook” on page 147.
	Sprint Navigation – Access Sprint Navigation, including Drive To, Search, Maps & Traffic, and Share & More. See “3D. GPS Navigation” on page 162.
	Google – Get easy access to all your favorite Google services such as Google search, online Maps, Gmail™, and YouTube™. See “Google” on page 142.

<i>Sprint One Click Tiles</i>	
	Internet – Access data services, including the Sprint home page, Favorites, Recent Pages, the Enter Web Address menu, and Google search. See “Launching a Web Connection” on page 128.

Removing a Tile From the Carousel

1. Highlight  and press **OPTIONS** (left softkey) > **Personalize Carousel**.
2. Scroll the navigation key left or right to select a tile, and then highlight **Remove Tile** and press .

Shortcut: From the main screen, highlight a tile and press **OPTIONS** (left softkey) > **Remove Tile**. Remember that you cannot remove, move, or replace the **Home** tile.

Rearranging Tiles on the Carousel

1. Highlight  and press **OPTIONS** (left softkey) > **Personalize Carousel**.
2. Scroll the navigation key left or right to select a tile, and then highlight **Move Tile** and press .
3. Scroll the navigation key left or right to select a location, and then press **INSERT** (left softkey) or  to place the tile.

Shortcut: From the main screen, highlight a tile, press **OPTIONS** (left softkey) > **Move Tile**, and then complete step 3.

Replacing Tiles on the Carousel

If your carousel is full or if you just want to swap out one tile for another, you can replace an existing tile with another.

1. Highlight  and press **OPTIONS** (left softkey) > **Personalize Carousel**.
2. Scroll the navigation key left or right to select a tile, and then highlight **Replace Tile** and press .
3. Select a tile category and then highlight a tile.

4. To replace the previous tile, press **REPLACE** (left softkey) or press  to place the tile.

Shortcut: From the main screen, highlight a tile, press **OPTIONS** (left softkey) > **Replace Tile**, and then complete steps 3 and 4.

Editing Tiles

Certain tiles, such as Shortcuts, contain editable content. You can use the Personalize Carousel menu to edit these tiles.

1. Highlight  and press **OPTIONS** (left softkey) > **Personalize Carousel**.
2. Scroll the navigation key left or right to select a tile, and then highlight **Edit Tile** and press .
3. Use your navigation key and function keys to edit the tile.

Shortcut: From the main screen, highlight a tile, press **OPTIONS** (left softkey) > **Edit Tile**, and then complete step 3.

Resetting One Click

To reset the one click carousel to the original default settings:

1. Highlight  and press **OPTIONS** (left softkey) > **Reset One Click**.
2. Highlight **Yes** and press .

2C. Settings

- ◆ Sound Settings (page 48)
- ◆ Display Settings (page 50)
- ◆ Location Settings (page 52)
- ◆ Messaging Settings (page 53)
- ◆ Airplane Mode (page 54)
- ◆ TTY Use With Sprint Service (page 55)
- ◆ Phone Setup Options (page 56)
- ◆ Security Settings (page 57)

Sound Settings

Ringer Types

Ringer types help you identify incoming calls and messages. You can assign ringer types to individual Contacts entries, types of calls, and types of messages.

Selecting Ringer Types

Your phone provides a variety of ringer options that allow you to customize your ring and volume settings. These options allow you to identify incoming calls by the ring.

1. Highlight  and press  > **Settings > Ringers**.
2. Select the entry for which you want to add a ringer type (**Incoming Calls [Contact Entries, Unsaved Numbers, Private/Unknown], Voicemail, Messages, Alarm/Calendar, Power Up/Down, and Battery Alert**).
3. Highlight a ringer type (**Downloaded, Preloaded, or No Ringer**).
4. Highlight the file and press  to assign a ringer.

Getting New Ringers

A wide variety of new ringers is available from the Sprint Digital Lounge, and you can access them right from your phone. (Additional charges may apply, but some are free.)

1. Highlight  and press  > **My Stuff** > **Ringers** > **Get New Ringers**.
2. Use your navigation key to search through available ringers. When you find one you want, highlight it and press .
3. To make a purchase, highlight **Buy** and press .
4. When the download is finished, select an option to continue:
 - **Listen** to listen to the ringer.
 - **Set As** to assign the ringer to a call or message type or to a specific contact.
 - **Shop** to browse for other items to download.

Adjusting the Phone's Volume Settings

Adjust your phone's volume settings to suit your needs and your environment.

1. Highlight  and press  > **Settings** > **Volume**.
2. Select **Incoming Ringer Volume**, **Playback Volume**, or **Key Beeps**.

3. Using the navigation or volume keys, choose a volume level and press .

Tip: You can adjust the ringer volume in standby mode (or the earpiece volume during a call) by using the volume button on the left side of your phone.

- Select **Always Vibrate** (or **VIB ON** [left softkey]) if you wish the phone to vibrate in addition to ringing at the selected volume setting.

Vibrate

To set your phone to vibrate instead of making any sounds:

- With the phone open, press the volume button down in standby mode until you see "Vibrate All" on the screen.

To set your phone always to vibrate in addition to any ringer settings:

1. With the phone open, press the volume button up or down in standby mode until a volume setting appears on the screen.

2. Press **VIB ON** (left softkey) to check the **Always Vibrate** option. (If you have already checked the option, pressing **VIB OFF** (left softkey) deselects the option.)

Silence All

The Silence All option allows you to mute all sounds without turning your phone off.

To activate Silence All:

- ▶ With the phone open, press and hold the volume button down in standby mode. (You will see “Silence All.”)

To deactivate Silence All:

- ▶ Press the volume button up repeatedly to select a volume level.

Selecting a Key Tone

Your phone offers a number of options for selecting the audible tones accompanying a keypress.

1. Highlight  and press  > **Settings > Volume > Key Beeps**.

2. Highlight an option and press .
 - **Tone Type** to select the sound of a keypress (**Lucid**, **DTMF**, or **Voice**).
 - **Tone Volume** to select a keypress volume level.
3. Highlight an available option from one of the above menus and press .

Display Settings

Changing the Backlight Time Length

Select how long the display screen remains backlit or when the backlight turns off after you press any key.

To adjust the Backlight dimming feature:

1. Highlight  and press  > **Settings > Display > Backlight Control > Backlight Dim**.
2. Select a time setting and press .
 - Select **Slide Open**, **8 seconds**, **15 seconds**, **30 seconds**, or **Always Dim**.

Note: Long backlight settings reduce the battery's talk and standby times.

To adjust the Backlight Off feature:

1. Highlight  and press  > **Settings** > **Display** > **Backlight Control** > **Backlight Off**.
2. Select a time setting and press .
 - Select **1 minute**, **30 seconds**, or **15 seconds**.

To adjust the Java Backlight feature:

Select how long the display screen remains backlit while in a Java application.

1. Highlight  and press  > **Settings** > **Display** > **Backlight Control** > **Java Backlight**.
2. Select a time setting and press .
 - Select **Default** or **Continuous**.

Changing the Display Screen

Choose what you see on the display screen while powering on or off and when in standby mode (screen saver).

1. Highlight  and press  > **Settings** > **Display** > **Screen Saver**.

2. Choose where to obtain the image from (**No Image**, **Take New Picture**, **My Albums**, **Downloaded**, or **Preloaded**) and press  to view it. (Once you see an image, use your navigation key to scroll through and view other available images.)

3. Highlight an image and press  to assign it.
 - or –

To make an online image purchase, highlight Buy and press . (Your phone automatically downloads the image). For more information on downloading images, see “Downloading Games, Ringers, and More” on page 138.)

4. Press **ASSIGN** (left softkey) to assign an image.

Changing the Brightness

Adjust your screen’s brightness (contrast) to suit your surroundings.

1. Highlight  and press  > **Settings** > **Display** > **Brightness**.
2. Scroll your navigation key left or right to adjust the screen contrast and press  or press **DONE** (left softkey).

Activating the PowerSave Mode

1. Highlight  and press  > **Settings** > **Display** > **PowerSave Mode**.
2. Highlight either **On** or **Off** and press .

Changing the Phone's Menu Style

Choose the layout of your phone's menu.

1. Highlight  and press .
2. Press the left softkey to toggle between these options.
 - **GRID VIEW** to view the menu as a grid.
 - **LIST VIEW** to display the menu as a list.

Display Language

You can choose to display your phone's onscreen menus in English or in Spanish.

1. Highlight  and press  > **Settings** > **Others** > **Language**.
2. Highlight **English** or **Español** and press .

Location Settings

Your phone is equipped with a Location feature for use in connection with location-based services.

The Location feature allows the network to detect your position. Turning Location off will hide your location from everyone except 911.

Note: Turning Location on will allow the network to detect your position using GPS technology, making some Sprint applications and services easier to use. Turning Location off will disable the GPS location function for all purposes except 911, but will not hide your general location based on the cell site serving your call. No application or service may use your location without your request or permission. GPS-enhanced 911 is not available in all areas.

To enable your phone's Location feature:

1. Highlight  and press  > **Settings** > **Location**. (You will see the Location disclaimer.)
2. Read the disclaimer and press **OK** (left softkey).
3. Highlight **On** or **Off** and press  > **DONE** (left softkey).

When you turn the Location feature on, the phone displays the  icon. When you turn Location off, the phone displays the  icon.

Messaging Settings

Your phone's advanced messaging capabilities let you send and receive many different kinds of text messages without placing a voice call. (For more information, see "Accessing Messages" on page 135.)

Messaging settings allow you to decide how you would like to be notified of new messages, create a signature with each sent message, and create your own preset messages.

Setting Message Notification

When you receive a message, your phone notifies you by displaying an icon on your display screen. You can also choose to be notified with a message notification on your display screen.

1. Highlight  and press  > **Messages** > **Settings** > **Notification**.
2. Select **Message & Icon** or **Icon Only**.

Adding a Customized Signature

Add a customized signature to each message you send.

1. Highlight  and press  > **Messages** > **Settings** > **Signature** > **On**. (If you do not wish to attach a signature, select **Off**.)
2. Enter a signature and press . (See "Entering Text in Portrait Mode" on page 31 or See "Entering Text in Landscape Mode" on page 35.)

Managing Preset Messages

Your phone is loaded with 20 preset messages to help make sending text messages easier. Customize or delete these messages, such as "Where are you?," "Let's get lunch," and "Meet me at" to suit your needs, or add your own messages to the list.

To edit or delete a preset message:

1. Highlight  and press  > **Messages** > **Settings** > **Preset Messages**. (You will see the list of preset messages.)

2. Select **EDIT** (left softkey) to edit the message (see “Entering Text in Portrait Mode” on page 31 or see “Entering Text in Landscape Mode” on page 35), and press .

3. To delete a single message, highlight it and press **OPTIONS** (right softkey) > **Delete**.

– or –

To delete all current preset messages, select **OPTIONS** (right softkey) > **Delete All** to delete the messages. (Select **CLOSE** (right softkey) to cancel the deletion.)

To add a new preset message:

1. Highlight  and press  > **Messages** > **Settings** > **Preset Messages**. (You will see the list of preset messages.)

2. To add a new message, select **OPTIONS** (right softkey) > **Add New**.

3. Enter your message and press . (Your new message will be added to the beginning of the list.)

Other Text Message Settings

These settings allow you to configure the options associated with a text message sent from your phone. These options include:

- **Callback Number** - allows you to set the callback number for the recipient to view when receiving a text message.

To activate a callback number:

4. Highlight  and press  > **Messages** > **Settings** > **Callback Number**.

5. Select **None**, <your phone number>, or **Other**.

Airplane Mode

Airplane Mode allows you to use many of your phone's features, such as Games, Notepad, and Voice Memos, when you are in an airplane or in any other area where making or receiving calls or data is prohibited. When you set your phone to Airplane Mode, it cannot send or receive any calls or access online information.

1. Highlight  and press  > **Settings** > **Others** > **Airplane Mode**.
2. Read the disclaimer and press **OK** (left softkey).
3. Highlight **On** or **Off** or **On Power Up** and press .

While in Airplane Mode, your phone's standby screen will display "Phone off."

TTY Use With Sprint Service

A TTY (also known as a TDD or Text Telephone) is a telecommunications phone that allows people who are deaf, hard of hearing, or who have speech or language disabilities, to communicate by telephone.

Your phone is compatible with select TTY devices. Please check with the manufacturer of your TTY device to ensure that it is compatible with digital cell phones. Your phone and TTY device will connect via a special cable that plugs into your phone's headset jack. If this cable was not provided with your TTY device, contact your TTY device manufacturer to purchase the connector cable.

To turn TTY Mode on or off:

1. Highlight  and press  > **Settings** > **Others** > **TTY Options**. (An informational message will be displayed.)
2. Press **DONE** (left softkey).
3. Select **TTY Off** to turn TTY mode off.

– or –

Touch any of the following to enable the feature:

- **TTY Full**, **TTY + Talk**, or **TTY + Hear**.

To access the state Telecommunications Relay Service (TRS) for assistance with TTY calls:

► Dial     and press  to reach an operator.

For additional information about Sprint Relay Services and TTY compatibility, call Sprint Relay Customer Service at **800-676-3777** or visit www.sprintrelay.com.

For additional technical support you may call **1-888-987-4357**, or access the following website: www.samsung.com/us/consumer/learningresources/mobile/accessibility/pop_accessibility.html.

Note: In TTY Mode, your phone will display the TTY access icon.

If TTY mode is enabled, the audio quality of non-TTY devices connected to the headset jack may be impaired.

WARNING: 911 Emergency Calling

Sprint recommends that TTY users make emergency calls by other means, including Telecommunications Relay Services (TRS), analog cellular, and landline communications. Wireless TTY calls to 911 may be corrupted when received by public safety answering points (PSAPs), rendering some communications unintelligible. The problem encountered appears related to software used by PSAPs. This matter has been brought to the attention of the FCC, and the wireless industry and the PSAP community are currently working to resolve this.

Phone Setup Options

Main Screen Shortcuts

Your phone's Sprint One Click main screen lets you customize your phone and provides quick access to the features and functions you use most. See "Personalizing the Carousel" on page 44 for details.

Your phone offers you the option of assigning shortcuts to favorite or often-used functions. Pressing the navigation key to the assigned direction in standby mode will launch your personally designated shortcuts.

To create a new Shortcut:

1. Highlight  > **Add Shortcut** and press .
2. Select from one of the following categories: **My Stuff**, **My Album**, **Bookmark**, or **Menu Item**.
3. Press **ASSIGN** (left softkey) to make the new shortcut assignment.

To select a current Shortcut:

1. Highlight  to access the Shortcuts menu.
2. Using the navigation key, select a current shortcut and press .
3. Press  to return to the standby mode.

Setting Abbreviated Dialing

To activate the Contacts Match feature:

1. Highlight  and press  > **Settings** > **Others** > **Contact Match**.
2. Select **On** or **Off**.

To activate the Prepend feature:

1. Highlight  and press  > **Settings** > **Others** > **Abbreviated Dialing**.
2. Select **On**.
3. Enter the first five- or six-digit prefix in the **ABBREV. DIAL** field and then press **DONE** (left softkey).
 - To deactivate this feature, select **Off** during step 2 above.

Tip: To make an Abbreviated Dial call, see “Abbreviated Dialing” on page 29.

Note: This setting does not apply to 911 or Sprint 411.

Security Settings

Your Phone's Lock Feature

Locking Your Phone

When your phone is locked, you can only receive incoming calls or make calls to 911, Sprint Customer Service, or special numbers.

1. Highlight  and press  > **Settings** > **Lock Phone** > **Lock Now**.

Note: Your current Lock Code is displayed at the top of the screen. If you decide to change it, you must select **Change Lock Code** (page 58).

Unlocking Your Phone

1. From standby mode, press **UNLOCK** (left softkey).
2. Enter your lock code.

Changing the Lock Code

1. Highlight  and press  > **Settings** > **Lock Phone** and enter your lock code.
2. Select **Change Lock Code**.
3. Enter your new lock code and press .
4. Re-enter your new lock code and press .

Calling in Lock Mode

You can place calls to 911 and to your special numbers when in lock mode.

- ▶ To call an emergency number, special number, or Sprint Customer Service, enter the phone number and press .

Deleting Phone Content

Use the Reset/Delete menu to quickly erase all the content you have created or stored in your phone.

1. Highlight  and press  > **Settings** > **Reset/Delete** and enter your lock code.

2. Select **Delete Stuff** and select an option.

- **Text Messages** to erase all text messages from your phone.
- **Call Logs** to erase your entire call log (history) from your phone.
- **Cookies and Cache** to erase all your website cookies and Internet page/content cache from your phone.
- **Downloaded Content** to erase all downloaded content from your phone.
- **Contacts** to erase all from your phone.
- **Pictures/Videos** to erase all pictures and videos stored on your phone.

Note: This does not affect those image and videos stored on the microSD card.

3. Press **DELETE** (left softkey) to confirm the deletion.

Resetting Your Phone's Settings

Resetting the phone settings only restores all of the factory defaults, including the ringer types and display settings. Onboard data such as Contacts, History, and Messaging are not affected.

1. Highlight  and press  > **Settings** > **Reset/Delete**.
2. Enter your lock code.
3. Highlight **Reset Settings** and press .

Note: If Parental Control has been enabled, this code will also need to be entered before continuing.

4. Press **RESET** (left softkey) to reset the phone's settings.

Resetting Your Phone

Resetting the phone restores all of the factory defaults, including the ringer types and display settings and deletes all content stored on the phone.

1. Highlight  and press  > **Settings** > **Reset/Delete** and enter your lock code.
2. Enter your new lock code.
3. Highlight **Reset Phone** and press .
4. Press **RESET** (left softkey) to restore your phone to its factory default state.

Security Features for Data Services

Enabling and Disabling Data Services

You can disable data services without turning off your phone; however, you will not have access to all data services, including Web and messaging. Disabling data services will avoid any charges associated with these services. While signed out, you can still place or receive phone calls, check voicemail, and use other voice services. You may enable data services again at any time.

To disable data services:

1. Highlight  and press  > **Settings** > **Others** > **Data** > **On/Off**. (You will see a message.)
2. Select **NEXT** (left softkey) > **Disable Sprint Data Services** to confirm that you want to sign out and deactivate data.

To enable data services:

1. Highlight  and press  > **Settings** > **Others** > **Data** > **Off**. (A message is displayed.)
2. Highlight **Connect** > **Yes** and press  to enable data services.

Net Guard

When you first connect to the Web, the Net Guard will be displayed to confirm that you want to connect. This feature helps you avoid accidental connections. You can disable the Net Guard in the future by selecting **Always Auto-Connect** when the Net Guard is displayed.

To change your Net Guard settings:

- ▶ Highlight  and press  > **Settings** > **Others** > **Data** > **Net Guard**.
 - Select **On** to activate the Net Guard.
 - Select **Off** to deactivate the Net Guard.

Note: When enabled, the Net Guard appears only once as long as you have not turned the phone off and on.

Using Parental Controls

You can disable certain phone services without turning off your phone. You can restrict access to all data services, including Web and messaging.

Disabling data services will avoid any charges associated with these services. While signed out, you can still place or receive phone calls, check voicemail,

and use other voice services. You may enable data services again at any time.

New Parental Controls provide restrictions to various phone services such as Voice, Messaging, Data, and Camera.

These restrictions are governed by an independent Parental Code that is separate from the previously mentioned Lock code.

To enable Parental Controls:

1. Highlight  and press  > **Settings** > **Parental Controls**.
2. Highlight **On/Off** and press .
3. Highlight **On** and press .
4. If this is your first time to setup these controls, you will be asked to setup a parental lock code that manages the areas that will be locked via this menu.
 - Enter a new four-digit code and press .
 - Re-enter the new code and press  and press **DONE** (left softkey).

To disable Parental Controls:

1. Highlight  and press  > **Settings** > **Parental Controls**.
2. Enter your new parental lock code.
3. Highlight **On/Off** and press .
4. Highlight **Off** and press .

Configuring Restrictions

To disable data services:

1. Highlight  and press  > **Settings** > **Parental Controls** > **Restrictions**.
2. Read the onscreen disclaimer and press **CONTINUE** (left softkey).
3. Select any of the following entries to either activate or deactivate an option.
 - **Voice Calls** to lock the phone and prevent outgoing calls. Incoming calls can still be received.
 - **Text Messaging** to restrict access to the Messaging folder, including all Text and Picture messages.

- **Web** to restrict access to all data features such as Internet, Video Streaming, and other data usage.
- **Camera/Camcorder** to restrict access to both the Camera and Camcorder functionality.
- **Force Location On** to restrict access to the Location functionality.

4. Highlight **On** or **Off** and press .
5. Press  to return to the previous page.

Changing the Parental Control Code

1. Highlight  and press  > **Settings** > **Parental Controls** > **Change Parental Control Code**.
2. Enter your current four-digit code.
3. Enter a new four-digit code.

2D. History


- ◆ Viewing History (page 62)
- ◆ History Options (page 63)
- ◆ Making a Call From History (page 64)
- ◆ Saving a Number From History (page 64)
- ◆ Erasing History (page 65)

Viewing History

History is a list of the last 240 phone numbers for calls you placed, accepted, or missed. History makes redialing a number fast and easy. It is continually updated as your phone automatically adds new numbers to the beginning of the list and removes the oldest entries from the bottom of the list.

When you place, accept, or miss a call, a record of the call is saved in the Recent History list. When you view the numbers in this list, the phone icon to the left of the number indicates the call type:

- **Missed:** Indicates any missed calls.
- **Received:** Indicates any received calls that were answered.
- **Dialed:** Indicates all outgoing calls made from your phone.



Each entry contains the phone number (if it is available) and Contacts entry name (if the number is in your Contacts). Duplicate calls (same number and type of call) may only appear once on the list.

1. Highlight  and press  > **History**.
2. Highlight an entry and press .

Shortcut: You can also press  from standby mode to display your recent calls.

Note: You may also be able to access History from your phone's main screen carousel. See section 2B "Navigating the Main Screen" on page 42 for details.

History records only calls that occur while the phone is turned on. If a call is received while your phone is turned off, it will not be included in history.

If you return a call from the voicemail menu, it will not be included in your phone's history.

History Options

Highlight a History entry from the Recent History screen and press  to display the date and time of the call, the phone number (if available), and the caller's name (if the number is already in your Contacts).

1. Highlight  and press  > **History**.
2. Press **SEND MSG** (left softkey) to send the currently selected history entry a new text message.

– or –

Highlight an entry and press **OPTIONS** (right softkey) to display the following options:

- **New Group** to save the current history entry to a new group.
- **Save** to save the number if it is not already in your Contacts. (See "Saving a Number From History" on page 64.)
- **Contact Details** to display the Contact entries' details.
- **Delete** to delete the entry.
- **Delete All** to delete all History entries.

Tip: You can also view the next History entry by scrolling the navigation key down or view the previous entry by scrolling the navigation key up.

Making a Call From History

1. Highlight  and press  > **History**.
2. Highlight an entry and press .

Note: You cannot make calls from History to entries identified as **No ID** or **Restricted**.

Tip: Press  from the standby screen to also bring up the Recent History screen where you can then select an entry.

Saving a Number From History

Your phone can store up to 1000 Contacts entries. Contacts entries can store up to a total of 7000 phone numbers, and each entry's name can contain 64 characters.

1. Highlight a History entry and press **OPTIONS** (right softkey) > **Save**.
2. Highlight **New Entry** or **Existing Entry** and press .
3. Highlight a label (**Mobile**, **Home**, **Work**, **Pager**, **Fax**, or **Other**) and press .
4. Use the keypad or keyboard to type in the new entry name.
– or –
Highlight an existing Contacts entry and press .
5. Make any other selection or entries for this new Contact.
6. Press **DONE** (left softkey) to save the new entry to your Contacts list and exit.

After you have saved the number, your phone displays the new Contacts entry. (See “Contacts Entry Options” on page 68.)

Note: You cannot save phone numbers already in your Contacts or from calls identified as **No ID** or **Restricted**.

Erasing History

To erase individual History entries, see “History Options” on page 63.

1. Highlight  and press  > **History**.
2. Press **OPTIONS** (right softkey) > **Delete All**.
3. If you are certain you want to erase the History, press **DELETE** (left softkey).

– or –

Select **CANCEL** (right softkey) to return to the previous menu.

2E. Contacts

- ◆ Adding a New Contacts Entry (page 66)
- ◆ Adding a New Group (page 67)
- ◆ Saving a Phone Number (page 67)
- ◆ Contacts Entry Options (page 68)
- ◆ Editing a Contacts Entry (page 68)
- ◆ Adding a Number to a Contacts Entry (page 69)
- ◆ Editing a Contacts Entry's Numbers (page 69)
- ◆ Deleting a Contact (page 70)
- ◆ Assigning Speed Dial Numbers (page 70)
- ◆ Selecting a Ringer Type for an Entry (page 71)
- ◆ Assigning a Picture to an Entry (page 72)
- ◆ Finding Contacts Entries (page 72)
- ◆ Secret Contacts Entries (page 73)
- ◆ Dialing Sprint Services (page 73)
- ◆ Wireless Backup (page 74)

Adding a New Contacts Entry

Your phone can store up to 1000 Contacts entries. Contacts entries can store up to a total of 7000 phone numbers, and each entry's name can contain 64 characters.

1. Highlight  and press  > **Contacts** > **Add New**.

Note: Press **CONTACTS** (right softkey) from the main screen to access the Contacts page.

Shortcut: Enter the phone number in standby mode and press **OPTIONS** (right softkey) > **Save**. Proceed with step 2.

2. Select **New Contact** to create a new Contacts entry.
3. Enter a name for the new entry and scroll the navigation key down. (See “Entering Text in Portrait Mode” on page 31 and “Entering Text in Landscape Mode” on page 35.)
4. Enter a phone number and press .
5. Highlight a label for the entry (**Mobile**, **Home**, **Work**, **Pager**, **Fax**, or **Other**) and press .

6. Press **DONE** (left softkey).

After saving the number, your phone displays the new entry. (See “Contacts Entry Options” on page 68.)

Tip: ICE – In Case of Emergency

To make it easier for emergency personnel to identify important contacts, you can list your local emergency contacts under “ICE” in your phone’s Contacts list. For example, if your mother is your primary emergency contact, list her as “ICE–Mom” in your Contacts. To list more than one emergency contact, use “ICE1–___,” “ICE2–___,” etc.

Adding a New Group

Groups allow you to communicate simultaneously by sending out a broadcast text message to every member of a current group.

1. Highlight  and press  > **Contacts** > **Add New**.
2. Select **New Group** to create a new Group category.
3. Read the onscreen information and press **START** (left softkey).

4. Add multiple entries (two or more) to your new group by highlighting a name from the list and pressing . This action places a check mark alongside the name.
5. Press **CONTINUE** (left softkey) and enter a name for the new group and scroll the navigation key down.
6. Press **SAVE** (left softkey) to assign the selected entries to the new group.

Saving a Phone Number

To save a number from standby mode:

1. Enter a phone number and press **OPTIONS** (right softkey) > **Save Contact**.
2. Highlight **New Entry** or **Existing Entry** and press .
3. Highlight a label for the entry (**Mobile**, **Home**, **Work**, **Pager**, **Fax**, or **Other**) and press .
4. Enter a name for the new entry and scroll the navigation key down. (See “Entering Text in Portrait Mode” on page 31 and “Entering Text in Landscape Mode” on page 35.)

5. Press **DONE** (left softkey).

Contacts Entry Options

To display a Contacts entry:

1. Highlight  and press  > **Contacts**.
2. Highlight an entry and press  to view the Contact Details menu.

Tip: You can view the next entry by scrolling the navigation key right or view the previous entry by scrolling the navigation key left.

To access a Contacts entry's options:

- ▶ Display an entry from the Contact Details page and press **OPTIONS** (right softkey) > **Edit Contact**. Highlight an option and press .
- **[Contact Image]** to edit the image associated with the contact entry.
- **[Contact Name]** to edit the contact entry name.
- **[Current number]** to edit the entry phone number.

- **[Add Number]** to add a phone number to the entry. (See “Adding a Number to a Contacts Entry” on page 69.)
- **[E-mail]** to add an email address to the entry.
- **[IM]** to add an Instant Messenger address to the entry.
- **[Ring]** to assign a preprogrammed or downloaded ringer.
- **[URL]** to add a website's URL to the entry.
- **[Address]** to add a physical address to the entry.
- **[Birthday]** to add Birthday information to the entry.
- **[Memo]** to add a note, street address, or other information.
- **[Job Title]** to add Job Title information to the entry.
- **[Company]** to add Company information to the entry.

Editing a Contacts Entry

1. Display a Contacts entry (see “Contacts Entry Options” on page 68) and press **OPTIONS** (right softkey) > **Edit Contact**.

2. Highlight the information you wish to edit (**Name**, **Number**, **Ringer**, etc.) and press .
3. Add or edit the information and press . Press  to clear one digit at a time, or press  and hold to erase the entire number.
4. Re-enter or edit any number and press **DONE** (left softkey) to save your changes.

Adding a Number to a Contacts Entry

1. Display a Contacts entry's Contact Details menu. (See "Contacts Entry Options" on page 68.)
 2. Press **OPTIONS** (right softkey) > **Edit Contact** > **[Add Number]**.
 3. Enter the new phone number and press .
 4. Highlight a label for the number and press .
 5. Press **DONE** (left softkey) to save the new number.
- or –

Press **OPTIONS** (right softkey) > **Set Speed Dial** to assign a speed dial location, and then press

ASSIGN (right softkey) or  to return the **EDIT CONTACT** screen.

- Other options include: **Hard Pause**, **2sec Pause**, **Set # Type**, and **Set as Main #**.

Editing a Contacts Entry's Numbers

1. Display a Contacts entry (see page 68) and press **OPTIONS** (right softkey) > **Edit Contact**.
 2. Highlight a number and press  to clear one digit at a time, or press and hold  to erase the entire number.
 3. Re-enter or edit the number and press .
 4. Highlight a label for the number and press .
- or –
- Press **OPTIONS** > **Set # Type**, highlight the desired label and press .
5. Press **DONE** (left softkey) to save the number.
- or –

6. Press **DONE** (left softkey) to save the new number.

– or –

Press **OPTIONS** (right softkey) > **Set Speed Dial** to assign a speed dial location, and then press **ASSIGN** (right softkey) or  to return the **EDIT CONTACT** screen.

- Other options include: **Hard Pause**, **2sec Pause**, **Set # Type**, and **Set as Main #**.

Deleting a Contact

1. Display a Contacts entry. (See “Contacts Entry Options” on page 68.)
2. Select **OPTIONS** (right softkey) > **Delete Contact**.
3. Select **DELETE** (left softkey) to confirm the deletion.

Assigning Speed Dial Numbers

Your phone can store up to 99 phone numbers in speed dial locations. (For details on how to make calls using speed dial numbers, see “Speed Dialing” on page 30.)

You can assign speed dial numbers when you add a new Contacts entry, when you add a new phone number to an existing entry, or when you edit an existing number.

To assign a speed dial number to a new phone number:

1. Add a phone number to a new or to an existing Contacts entry. (See “Adding a New Contacts Entry” on page 66 or “Adding a Number to a Contacts Entry” on page 69.)
2. Highlight the recently added number and press **OPTIONS** (right softkey) > **Set Speed Dial**.
3. Highlight an available speed dial location and press **ASSIGN** (right softkey) to return the **EDIT CONTACT** screen.

To assign a speed dial number to an existing phone number:

1. Display a Contacts ‘s Contact Details screen (see page 68).
2. Highlight an existing entry’s phone number and press **OPTIONS** (right softkey) > **Set Speed Dial**.

3. Highlight an available speed dial location and press **ASSIGN** (right softkey).
4. Press **DONE** (left softkey) to return to the Contacts Details menu.

Note: If you attempt to assign an already in-use speed dial location to a new phone number, you will see a message asking if you wish to replace the existing speed dial assignment. Press **REPLACE** to assign the location to the new phone number and delete the previous speed dial assignment.

Finding Speed Dial Numbers

1. Highlight  and press  > **Contacts** > **OPTIONS** (right softkey) > **Settings** > **Speed Numbers**.
2. Scroll through speed dial entries. Speed dial numbers are displayed in numeric order.
– or –
Enter the number of a speed dial location using your keypad.
3. To display an entry, highlight it and press .

Selecting a Ringer Type for an Entry

Assign a ringer type to a Contacts entry so you can identify the caller by the ringer type. (See “Ringer Types” on page 48.)

1. Display a Contacts entry’s Contacts Details menu and press **OPTIONS** (right softkey) > **Edit Contact**.
2. Highlight the current ring type and press  to display the Ringer Type menu.
3. Select a ringer menu, such as **Get New Ringers**, **Default Ringer**, **Downloaded Ringers**, **Other Ringers**, **My Videos**, or **No Ringer**.
4. Scroll through available ringers. (To hear a sample ringer, highlight a ringer type.)
5. Highlight a ringer and press .
6. Press **DONE** (left softkey) to save the new ringer type.

Tip: If you select **Get New Ringers**, you can purchase and download new ringers right from your phone. For details, see “Getting New Ringers” on page 48 and “Downloading Games, Ringers, and More” on page 138.

Assigning a Picture to an Entry

Assign a picture to display each time a certain contact calls you.

1. Display a Contacts entry's Contacts Details screen and press **OPTIONS** (right softkey) > **Edit Contact**.
2. Highlight the current image or picture type and press  to display the Contact ID menu.
3. Select an option, such as **Get New Screen Savers**, **None**, **New Picture**, **My Albums**, or **Screen Savers**.
4. Highlight a picture and press  twice to assign it.
 - If you selected **New Picture**, the camera will launch and you will use it to take a new picture. (See "2I. Camera" on page 97 for details.)
 - If you selected **My Albums**, you may need to select **In Phone**, or **Memory Card** to find the picture.
5. Press **DONE** (left softkey) to save the assigned picture.

Finding Contacts Entries

Finding Contacts by Name

1. Highlight  and press  > **Contacts**.
2. Scroll through all the entries.
 - or –Enter the first letter or letters of a name (such as "dav" for "Dave"). (The more letters you enter, the more your search narrows.)
3. To display an entry, highlight it and press .
4. To dial the entry's default phone number, press .
- or –
- To display additional Contacts entries, press the navigation key left or right.

Finding Group Entries

1. Highlight  and press  > **Contacts**.
2. Scroll through the group titles. To display entries belonging to a group, highlight the group and press .

3. To display an entry within the group, highlight it and press .
4. To dial the entry's default phone number, press .
- or –

To display additional Group entries, scroll the navigation key left or right.

Secret Contacts Entries

Making an entry secret hides its phone number(s) and requires your lock code to edit the entry.

To make an entry secret:

1. Highlight a Contacts entry and press **OPTIONS** (right softkey) > **Set as Secret**.
2. Press **DONE** (left softkey) to save the new setting.

To make an entry public:

1. Highlight a Contacts entry and press **OPTIONS** (right softkey) > **Set as Not Secret**.
2. Press **DONE** (left softkey) to save the new setting.

Tip: If you can't recall your lock code, try using the last four digits of your wireless phone number. If this doesn't work, call Sprint Customer Service at **1-888-211-4727**.

Dialing Sprint Services

Your Contacts list is preprogrammed with contact numbers for various Sprint services.

To dial a service from your Contacts:

1. Highlight  and press  > **Contacts** and highlight an entry.
2. Press **OPTIONS** (right softkey) > **Settings** > **Services** and select an available service, such as **Account Info**, **Customer Service**, **Directory Assistance** (Sprint 411), **Sprint Operator**, or **Voice Command**.

To dial a service from standby mode using your keypad:

- ▶ Dial the appropriate service number:

- **Sprint Customer Service** – * Shift 2 ABC
- **Sprint 411** – 4 GHI 1
- **Account Info.** – * Shift 4 GHI
- **Sprint Operator** – Next +

Wireless Backup

This feature allows you to back up all of your contacts to the Sprint website and restore them if your phone is lost, stolen, damaged, or replaced.

Tip: To use the wireless backup service, you are required to activate the service from your phone.

To subscribe to the wireless backup service, you must purchase a license to use the service through your phone's browser. The license expires after a set period of time and you must renew it regularly. As part of the initial subscription process, the service generates a random wireless backup password. The service sends the password to your phone as a text message.

Activating and Deactivating Wireless Backup

To activate the wireless backup service:

1. Highlight  and press  > **Settings** > **Others** > **Wireless Backup** > **SUBSCRIBE** (left softkey). (The phone prompts you to confirm your license status.)
2. Press **DONE** (left softkey) and follow the onscreen instructions to purchase the license.
3. Please wait while registering the license. (You will see a confirmation screen once registration is complete.)

Note: Once you have completed the registration, you will receive a text message with your password. This password is required for the Wireless Backup website (www.wirelessbackup.sprint.com) in order to edit your contacts from your computer.

Tip: Each time you edit Contacts on your phone, they are backed up at www.wirelessbackup.sprint.com.

To deactivate the wireless backup service:

1. Highlight  and press  > **Settings** > **Others** > **Wireless Backup** > **UNSUBSCRIBE** > **Done** (left softkey).
(A message is displayed.)
2. Follow the onscreen instructions to unsubscribe from the wireless backup service.

Note: You can unsubscribe from the wireless backup service only through the Sprint website.

Tip: To display the wireless backup information, highlight  and press  > **Settings** > **Others** > **Wireless Backup** > **Learn More**. When the service is available, you can also select **Troubleshoot** to display the troubleshooting guide.

Viewing Your Wireless Backup Status

- Highlight  and press  > **Settings** > **Others** > **Wireless Backup** > **View Status**.

Setting the Wireless Backup Alert

This feature turns the pop-up alert on or off when a wireless backup update has been completed.

1. Highlight  and press  > **Settings** > **Others** > **Wireless Backup** > **Alerts**.
2. Select **Alert me** or **No alerts**.

2F. Calendar & Tools

- ◆ Calendar (page 76)
- ◆ File Manager (page 80)
- ◆ Alarm Clock (page 81)
- ◆ Memo Pad (page 82)
- ◆ Calculator (page 83)
- ◆ Tip Calculator (page 83)
- ◆ Eco Calculator (page 83)
- ◆ World Clock (page 84)
- ◆ Updating Your Phone (page 84)
- ◆ Updating the PRL (page 84)

Calendar

Adding an Event to the Calendar

Your Calendar helps organize your time and reminds you of important events.

1. Highlight  and press  **> Tools > Calendar > Personal Calendar > Scheduler.**
2. Highlight the day to which you would like to add an event and press **OPTIONS** (right softkey) **> Add New.**

Tip: Scroll the navigation key up or down to scroll by week through the Scheduler.

3. Enter the event title and press **NEXT** (left softkey).
4. Select a category for the event by highlighting the category field:
 - Select **Appointment, Personal, Business, Birthday,** or **Vacation.**

5. Select an alarm time for the event by highlighting the alarm field:
 - Select **No Alarm**, **On Time**, **10 Min. Before**, **30 Min. Before**, or **1 Hour Before**.
6. Highlight a recurrence cycle for the event:
 - Select **Once**, **Daily**, **Weekly**, **Monthly**, or **Yearly**.
7. Highlight the ringer field and press .
 - Highlight a ringer category (**Downloaded**, **Preloaded**, or **No Ringer**) and then a ringer and press .
8. Select a Start and End time for the event by highlighting the time field and pressing .
 - Using your keypad or navigation keys, set the start and end times for the event and press .
 - Change the AM/PM entry by pressing **AM/PM** (right softkey).
9. Select a single optional contact for the event by highlighting **Go to Contact** and pressing .
 - Highlight a contact from the list and press  to check the box. Press **ASSIGN** (left softkey).
10. Press **DONE** (left softkey) to save the event.

Event Alert Menu

When your phone is turned on and you have an event alarm scheduled, your phone alerts you and displays the event summary. There are several ways your phone alerts you to scheduled events:

- By playing the assigned ringer type.
- By illuminating the backlight.
- By flashing the LED.

To silence the alarm and reset the schedule, press .

To view additional options, press the appropriate softkey:

- **SNOOZE** silences the alarm and schedules it to replay again in 10 minutes.
- **View** view the alarm details screen.
- **DISMISS** (right softkey) displays the event detail screen.

Viewing Events

1. Highlight  and press  > **Tools** > **Calendar** > **Personal Calendar** > **Scheduler**.

2. Highlight the day for which you would like to view events and press . (Your phone lists events in chronological order.)

Tip: In the calendar view, days with events scheduled are outlined.

3. To display an event's details, highlight it and press .

Going to the Current Day's Calendar Menu

- Highlight  and press  > **Tools** > **Calendar** > **Personal Calendar** > **Today**.

Editing a Day's Events

1. Highlight  and press  > **Tools** > **Calendar** > **Personal Calendar** > **Scheduler**.
2. Highlight the day containing the previously created event and press . (Days containing an event are indicated within a red box.)
3. Highlight the event from the Schedule tab listing and press .

4. Press **EDIT** (left softkey). Follow the onscreen procedures to alter any of the previously configured fields.
5. Press **DONE** (left softkey) to store any updates.

Erasing a Day's Events

1. Highlight  and press  > **Tools** > **Calendar** > **Personal Calendar** > **Scheduler**.
2. Highlight the day for which you would like to erase events and press .

Tip: In the calendar view, days with events scheduled are outlined.

3. Highlight an event and press **OPTIONS** (right softkey) > **Delete**. (You will see an alert notifying you of the number of events you will erase.)
4. Select **YES** (left softkey) or **NO** (right softkey).

Erasing All Events

1. Highlight  and press  > **Tools** > **Calendar** > **Personal Calendar** > **Scheduler** > **OPTIONS** (right softkey) > **Delete All**. (You will see an alert.)

Note: If the day for which you are erasing events contains a repeating event, you will receive the following prompt: "Delete all events?"

2. Select **YES** (left softkey) to erase all events or **NO** (right softkey) to return to the calendar view.

Managing the Task List

This option allows you to manage daily tasks that include dates, times, and priority levels.

1. Highlight  and press  > **Tools** > **Calendar** > **Personal Calendar** > **Task List**.

Note: If there are no tasks saved, the **NEW TASK** screen is automatically displayed.

2. Press **ADD NEW** (left softkey).
3. Enter the task name using either the keypad or keyboard and press **NEXT** (left softkey).
4. Select a priority level by highlighting the **Priority** field.
 - Scroll the navigation key left or right to select **Low** or **High**.

5. Select a due time by highlighting the **Due time** field.
 - Using your keypad and/or navigation key, set the alarm time.
 - Change the AM/PM entry by pressing **AM/PM** (right softkey).
6. Select a due date by highlighting the **Due date** field.
 - Using your keypad and/or navigation key, set the date.
7. Press **DONE** (left softkey) to save and exit.

Creating a Countdown

This option allows you to enter a timer that counts down to an event based on a date and time specified.

1. Highlight  and press  > **Tools** > **Calendar** > **Personal Calendar** > **Task List**.

Note: If there are no countdowns saved, the **NEW COUNTDOWN** screen is automatically displayed.

2. Press **ADD NEW** (left softkey).
3. Enter the countdown name using either the keypad or keyboard and press **NEXT** (left softkey).

4. Select a time by highlighting the **Time** field.
 - Using your keypad and/or navigation key, set the time for the countdown.
 - Change the AM/PM entry by pressing **AM/PM** (right softkey).
5. Select a date by highlighting the **Date** field.
 - Using the keypad, enter the date of the countdown.
6. Press **DONE** (left softkey) to save and exit.

File Manager

File Manager allows you to manage files such as pictures, videos, music, and applications stored in your phone or on the microSD card. See “Connecting Your Phone to Your Computer” on page 95.

Accessing File Manager

1. Highlight  and press  > **Tools** > **Mass Storage** > **File Manager**.
2. Highlight an option and press .

- **Phone** to access files stored in your phone’s memory.
- **Memory Card** to access files stored on the microSD card.

Opening Files in File Manager

1. Highlight  and press  > **Tools** > **Mass Storage** > **File Manager** > **Phone** or **Memory Card**.
2. Highlight an folder and press .
3. Highlight an item and press .

File Manager Options

When viewing files or folders in File Manager, press **OPTIONS** (right softkey) to display available options. Highlight an option and press  to select it.

- **Send** to send the currently selected file via either Email or Bluetooth.
- **Delete** to delete a file or folder from File Manager.
- **Copy** to copy a file from the current folder to another folder in your phone.
- **Move** to move a file from the current folder to another folder in your phone.

- **Rename** to change the name of a selected file.
- **Create Folders** to create preset folders on the microSD card. (See “Creating Folders in the microSD Card” on page 93.)
- **Sort** to sort folder contents by Name, Date, or Type.
- **Memory Info** to display the memory information for a selected location (**All**, **Phone**, or **Card**).
- **Find** to search for a file within the current folder location.

Alarm Clock

Your phone comes with a built-in alarm clock that has multiple alarm capabilities.

1. Highlight  and press  > **Tools** > **Alarm**.

Note: If there are no tasks saved, press **Create New** (left softkey).

2. Press **OPTIONS** (right softkey) > **Create New**.
3. Turn the alarm on or off by highlighting the **Alarm** field and scrolling the navigation key left or right.

4. Select a time for the alarm by highlighting the **Time** field.
 - Using your keypad or navigation key, set the alarm time.
 - Change the AM/PM entry by pressing **AM/PM** (right softkey).
5. Select a ringer type for the alarm by highlighting the ringer field and pressing .
 - Highlight and available ringer category (**Downloaded**, **Preloaded**, or **No Ringer**) and press .
6. Select a repeating status for the alarm by highlighting the repeat field and pressing .
 - Highlight **Daily**, **Once**, or **Sunday – Saturday** and press .
7. Select a snooze interval for the alarm by highlighting the **Snooze Interval** field and scrolling your navigation key left or right.
 - Choose either: **Off**, **5 minutes**, **10 minutes**, **15 minutes**, or **20 minutes**.

8. Select a volume level for the alarm by highlighting the **Volume** field and scrolling your navigation key left or right.
 - Choose from: **Level 1 - Level 8**.
9. Press **DONE** (left softkey) to save and exit.

Memo Pad

Your phone comes with a notepad that you can use to compose and store reminders and notes to help keep you organized.

To compose a note:

1. Highlight  and press  > **Tools** > **Memo Pad**.

Note: If there are no memos saved, **Empty** appears on the **MEMO PAD** screen.

2. Press **ADD NEW** (left softkey).
3. Type your note using the keypad or keyboard and press **DONE** (left softkey). (See “Entering Text in Portrait Mode” on page 31 or “Entering Text in Landscape Mode” on page 35.)

To read a saved note:

1. Highlight  and press  > **Tools** > **Memo Pad**.
2. Highlight a note and press .

To edit a note:

1. Highlight  and press  > **Tools** > **Memo Pad**.
2. Highlight a note and press .
3. Press **EDIT** (left softkey).
4. Press  to erase a single character. Press and hold  to erase an entire word.
 - On the QWERTY keyboard, you can use .
5. Type your note using either the keypad or keyboard and press or **DONE** (left softkey). (See “Entering Text in Portrait Mode” on page 31 or “Entering Text in Landscape Mode” on page 35.)

To delete all saved notes:

1. Highlight  and press  > **Tools** > **Memo Pad**.
2. Highlight a note and press **OPTIONS** (right softkey) > **Delete All**.
3. Select **YES** (left softkey) or **NO** (right softkey).

Calculator

Your phone comes with a built-in calculator.

1. Highlight  and press  > **Tools** > **Calculator** > **Calculator**.
2. Enter numbers using your keypad.
 - Press  to enter decimal points.
 - Scroll  to change the sign from positive to negative, and multiply or divide.
 - Press **CLEAR** (right softkey) to clear the values.
3. Press  for the total.

Tip Calculator

1. Highlight  and press  > **Tools** > **Calculator** > **Tip Calculator**.
2. Use your keypad/keyboard and navigation key to enter the bill amount and tip percentage. (The application instantly calculates the correct tip.)

3. If you're splitting the check, highlight # **Paying** and enter the number of people in your party. (The application calculates and displays an equal split.)

Eco Calculator

This calculator can assist you in determining fuel economy.

To create a new Eco calculation:

1. Highlight  and press  > **Tools** > **Calculator** > **Eco Calculator**.
2. Press **CREATE** (left softkey).
 - or –
 - Press **OPTIONS** (right softkey) > **Create**.

Note: If there are no Eco calculations saved, the **Eco Calculator** screen is empty.

3. Use your keyboard and navigation keys to enter the distance, price of gas/gallon, and number of gallons. (The application instantly calculates the fuel efficiency values.)

World Clock

To view the time in over 50 different locations:

1. Highlight  and press  > **Tools** > **World Time**.
2. Use the navigation key left or right to scroll through different cities and time zones.
3. Press **SET DST** (left softkey) to turn daylight saving time on or off.

Updating Your Phone

The update phone option allows you to download and update the software in your phone automatically. Only the internal software is updated; no Contacts entries or other information saved to your phone will be deleted.

1. Highlight  and press  > **Tools** > **Update Phone** > **Update Firmware**.
2. Follow the onscreen instructions. (Your phone automatically downloads any available updates.)

3. Once downloaded, press **INSTALL** (left softkey) to complete the installation process. (You may be required to power your phone off and back on to complete the software upgrade.)

Updating the PRL

This option allows you to download and update the PRL (preferred roaming list) automatically.

1. Highlight  and press  > **Tools** > **Update Phone** > **Update PRL**.
2. Follow the onscreen instructions.

2G. Voice Services

- ◆ Automatic Speech Recognition (ASR) (page 85)
- ◆ Managing Voice Memos (page 88)

Automatic Speech Recognition (ASR)

You can use your phone's built-in automatic speech recognition (ASR) software to dial a phone number in your Contacts or to launch phone functions. All you have to do is to talk into the phone, and ASR will recognize your voice and complete tasks by itself.

Activating ASR

- Press and hold  or .

The screen displays “Say a command” and the phone prompts you to say the name of the command you

want to use. To complete your task, simply follow the voice prompts.

Available ASR commands include:

- **Call** <Name or #> to call an entry in your Contacts list or a spoken phone number. (See “Making a Voice Call With ASR” on page 86.)
- **Send Message** <Name or #> to launch text messaging on your phone and specify a recipient for a new message. (See “Send a Text Message” on page 86.)
- **Lookup** <Name> to lookup a Contacts entry name from your current list of available contacts. (See “Opening Menus With ASR” on page 87.)
- **Go To** <menu> to jump directly to menu items or applications. (See “Opening Menus With ASR” on page 87.)
- **Check** <item> to check your phone's status. (See “Checking Phone Status Using ASR” on page 87.)

Tip: Use ASR in a quiet environment so it can accurately recognize your commands.

During ASR operation, press **Tutorial** (left softkey) to get instructions using the software.

Making a Voice Call With ASR

1. Press and hold  or .
2. If you hear “Say a command,” say “**Call.**”
3. If the location is not recognized or the name does not have a number stored in Contacts, your phone will play the message “No match found, Try Again?”
4. If you hear “Say the name or number,” say a name or a phone number.
5. If you hear “Which location?,” say a number type (for example, “Mobile”).

Tip: You can skip steps 4 and 5 by saying a name and location after “Call” without pausing (for example, “**Call John Jones mobile1**”).

Note: If ASR does not recognize the name or number, it will find the most likely matches and display a list of up to three names or numbers. You will hear “Did you say...” followed by the name or number. You can confirm by saying “**Yes.**” Say “**No**” to change the selection.

Send a Text Message

Use automatic speech recognition to launch text messaging on your phone and specify a recipient for the message.

1. Press and hold  or .
2. Say “Send Message” followed immediately by the name of a person in your Contacts list and, optionally, the type of number (Mobile1, Home1, etc.) you want to send it to. For example, say “**Send Message John Smith Mobile1.**”

If you do not specify the number type and there are multiple numbers for the name, your phone chooses the mobile number by default.

If you say “**Send Message**” without specifying a recipient, your phone prompts you with “Say the name or number.” Say the name of a person in your Contacts list and, optionally, the type of number.

3. Use either the keypad or keyboard to enter text and press **SEND** (left softkey) to complete the process.
 - Selecting **OPTIONS** (right softkey) provide you with additional message selections. See “Messaging (SMS/MMS)” on page 119.

Look Up a Contacts Entry

Look up and display contact information for any person stored in your Contacts list by saying “Contacts” followed by the name.

1. Press and hold  or .
2. Say “**Lookup John Smith.**” The entry information for the specified contact is then displayed.

If you say only “Lookup” your phone prompts you with “Say the name.”

Opening Menus With ASR

You can jump directly to many menu items or applications by saying “Go to” followed by a menu option.

1. Press and hold  or .
2. If you hear “Say a command,” say “**Go To.**”
3. If you hear “Which shortcut?,” say an application name (for example, “Messages”).
4. The phone opens the selected menu.

Checking Phone Status Using ASR

You can use ASR to obtain information about your phone:

- **Status** (all of the previous except My Phone Number)
- **Time**
- **Signal Strength**
- **Network**
- **Battery**
- **My Phone Number**

1. Press and hold  or .
2. If you hear “Say a command,” say “**Check.**”
3. If you hear “Which status item?,” say a command.

ASR Options

To change ASR confirmation:

1. Press and hold  or .
2. Press **SETTINGS** (right softkey) > **Confirmation** and select an option.
 - **Automatic** to ask for confirmation only when the system is not sure what you said.

- **Always Confirm** to always ask for confirmation.
- **Never Confirm** to never ask for confirmation.

To adapt the system to your voice:

1. Press and hold  or .
2. Press **SETTINGS** (right softkey) > **Adaptation** > **Adapt Voice**.
3. Press **START** (left softkey) and repeat each word, phrase, or telephone number you hear.

To reset the adaptation:

1. Press and hold  or .
2. Press **SETTINGS** (right softkey) > **Adaptation** > **Reset Voice** > **YES** (left softkey).

To change the ASR mode:

1. Press and hold  or .
2. Press **SETTINGS** (right softkey) > **Audio Modes** and select an option.
 - **Expert Mode** to sound a beep only.
 - **Prompt Mode** to prompt for required information.

Managing Voice Memos

Use your phone's Voice Services to record brief memos to remind you of important events, phone numbers, or grocery list items.

Recording Voice Memos

1. Highlight  and press  > **Tools** > **Voice Memo** > **Record**.
2. Begin recording after the prompt.

To end the recording of your memo:

- Press  or **FINISH** (right softkey).

To record a conversation during a phone call:

1. During a call, press **OPTIONS** (right softkey) > **Voice Memo**. (A one-minute counter  is displayed on the screen indicating the amount of time a single voice memo can be recorded.)

Note: Incoming audio is recorded when Voice Memo is selected during a call.

To end the recording of your conversation:

- ▶ Press  or **STOP** (right softkey).

Note: Your phone can store a total of 10 one-minute memos.

Voice Memo Options

To play the voice memos you have recorded:

1. Highlight  and press  > **Tools** > **Voice Memo** > **Review**. (The phone displays a list of saved memos, with the first one selected.)
2. Highlight the desired memo and press .
– or –
Press the number corresponding to the memo you want to review.

Note: Voice Memos recorded from a direct phone conversation are shown in the list with the phone number used during the recording process.

Erasing Voice Memos

To erase all voice memos:

1. Highlight  and press  > **Tools** > **Voice Memo** > **Review**.
2. Highlight the desired memo to erase and press **OPTIONS** (right softkey) > **Delete All**.
3. Press **DELETE** (left softkey).

Editing a Voice Memo Caption

By default, the caption assigned to a voice memo is a sequential file name which consists of the date (Month_Day) followed by the memo number. For example, two memos recorded on February 2, 2010, would be listed as: Feb_02x1 and Feb_02x2. These file names (captions) can be changed.

1. Highlight  and press  > **Tools** > **Voice Memo** > **Review**.
2. Highlight the desired memo and press **OPTIONS** (right softkey) > **Edit Caption**.

3. Press  to delete the previous text and then use either the keypad or keyboard to enter a new caption for the selected memo.
4. Press **DONE** (left softkey) to save the memo with the new caption text.

Viewing the Information for a Voice Memo

1. Highlight  and press  > **Tools** > **Voice Memo** > **Review**.
2. Highlight the desired memo to erase and press **OPTIONS** (right softkey) > **Info**.

2H. microSD Card

- ◆ Your Phone's microSD Card and Adapter (page 91)
- ◆ microSD Card Settings (page 93)
- ◆ microSD Card Folders (page 94)
- ◆ Connecting Your Phone to Your Computer (page 95)

Your Phone's microSD Card and Adapter

The microSD Card

Your phone comes with a 2GB microSD™ (Secure Digital) memory card to expand the phone's available memory space. It allows you to store images, videos, and music in your phone.

Inserting the microSD Card

1. Remove the battery cover (located on the back of the phone).



2. Place your fingernail into the Release Latch indentation (adjacent to the microphone) and carefully lift (1) the case off the rear of the phone (2).

3. Locate the microSD card slot on the side of the phone.
4. With the gold contact pins facing downward, carefully insert the microSD card into the opening and firmly push it in until you hear a click indicating the card is securely installed (3).



5. Replace the cover by lining up the tabs and then firmly pressing the cover down until it snaps into place. Check that the battery is still properly installed before turning on the phone.

Note: You can easily damage the microSD card and its adapter by improper operation. Please be careful when inserting, removing, or handling them.

Removing the microSD Card

1. Repeat steps 1-3 from “Inserting the microSD Card” on page 91.
2. Firmly press the card into the slot and release (it should pop partially out of the slot).
3. Remove the card from the slot.
4. Replace the cover by lining up the tabs and then firmly pressing the cover down until it snaps into place. Check that the battery is still properly installed before turning on the phone.

Note: Be sure to use only recommended microSD cards (up to 32GB). Using non-recommended microSD cards could cause data loss and damage your phone.

Note: **DO NOT** remove a microSD card while files are being accessed or transferred. Doing so will result in loss or damage of data.

Make sure your battery is fully charged before using the microSD card. Your data may become damaged or unusable if the battery runs out while using the microSD card.

microSD Adapter

The supplied microSD adapter allows you to use microSD cards in other SD-compatible devices, like computers, cameras, and printers. Before using the microSD card with an SD-compatible device, you will need to insert the microSD card into the microSD adapter.

To insert the microSD card into the microSD adapter:

- ▶ With the label side of the microSD card facing up, insert the card into the supplied microSD adapter, and gently slide the card until it is fully inserted.

To remove the microSD card from the microSD adapter:

- ▶ Hold the front edge of the microSD card, and gently pull it out to remove it from the adapter.

Write Protection

The microSD adapter has a built-in Write Protection lock to prevent accidental overwriting or removal of your data when the microSD card and adapter are inserted in another device.

- ▶ Slide the Write Protection lock tab down into the “Lock” position to prevent overwriting of data. To allow data to be added or removed from the microSD card, slide the Write Protection lock tab up into the normal position.

microSD Card Settings

Creating Folders in the microSD Card

The following steps allow your phone to create default folders for storing files in your microSD card.

- ▶ With the microSD card inserted, highlight  and press  > **Tools > Mass Storage > File Manager > Memory Card > OPTIONS** (right softkey) > **Create Folders.**

Note: With a formatted microSD card, there are no default folders created. Upon initial access to the Camera, the phone creates a Graphic folder. Upon access to the Music Player, the Music/Tone folders are also created.

- ▶ (The phone will create the microSD's default folders: Picture, Video, Voice, and Media.)

Viewing Memory in the microSD Card

- ▶ With the microSD card inserted, highlight  and press  > **Tools** > **Mass Storage** > **Memory Info** > **Card**. (The used and available memory space will be displayed.)

Formatting the microSD Card

Formatting a microSD card permanently removes all files stored on the card.

1. With the microSD card inserted, highlight  and press  > **Tools** > **Mass Storage** > **Format Memory Card**.
2. Enter your lock code.
3. Press **FORMAT** (left softkey). (A warning will be displayed.)

Note: The formatting procedure erases all the data on the microSD card, after which the files CANNOT be retrieved. To prevent the loss of important data, please check the contents before you format the card.

microSD Card Folders

Displaying Your microSD Card Folders

All the files stored in your microSD are accessible through your microSD card folders.

1. With the microSD card inserted, highlight  and press  > **Tools** > **Mass Storage** > **File Manager** > **Memory Card**.
2. Highlight a folder and press .
3. To view or play a file, highlight it and press  or the appropriate softkey.

Note: For information on file and folder options available through File Manager, see “File Manager” on page 80.

Creating Folders in the microSD Card

The following steps allow your phone to create folders for storing files in your microSD card using only the File Manager.

1. With the microSD card inserted, highlight  and press  > **Tools** > **Mass Storage** > **File Manager** > **Memory Card**.
2. Press **OPTIONS** (right softkey) > **Create Folder**.
3. Enter a name for the new folder and press **DONE** (left softkey) to save the new folder onto the card.

Connecting Your Phone to Your Computer

Before using your phone's mass storage capabilities, you need to prepare your phone's data services to synchronize with your desktop or laptop computer. Once you have connected the phone to the computer, you can transfer your data to or from the microSD card.

1. With the phone turned on, plug one end of a compatible USB cable into the phone's Charger/Accessories Jack.

2. Connect the other end of the cable to your computer and turn the phone on.



3. With the microSD card inserted, highlight  and press  > **Tools** > **Mass Storage** > **Connect to PC**.

Note: During this connection via the USB port, you will be unable to use your phone to make or receive calls.

To remove the connection:

- ▶ When you have finished transferring data, click the USB device icon on your computer's taskbar, and follow the onscreen instructions to safely unplug the USB cable.

– or –

Press **DISCONNECT** (right softkey) > **DISCONNECT** (left softkey).

- DO NOT turn off or restart your computer, or put it into standby mode, while using a mass storage device. Doing so will result in loss or damage of data.
- While you are connected to the computer, your phone's screen will display "Phone Off." You cannot make or receive calls.
- If you connect a mass storage device to a peripheral device, your device may not work properly.

Important Connection Information

- No driver installation is required for Windows 2000/ME/XP/Vista users. If you use Windows 98/98SE, you have to download and install the USB Mass Storage Driver from the Sprint website at www.sprint.com.
- To avoid loss of data, DO NOT remove the USB cable, the microSD card, or the battery while files are being accessed or transferred.
- DO NOT use your computer to change or edit folder or file names on the microSD card, and do not attempt to transfer large amounts of data from the computer to the microSD card. Doing so may cause the microSD card to fail.

2l. Camera

- ◆ Taking Pictures (page 97)
- ◆ Recording Videos (page 101)
- ◆ Storing Pictures and Videos (page 102)
- ◆ Sending Pictures and Videos (page 104)
- ◆ Printing Pictures From Your Phone (page 107)
- ◆ Settings (page 107)

Taking Pictures

Taking pictures with your phone's built-in camera is as simple as choosing a subject, pointing the lens, and pressing a button. You can activate the phone's camera mode whether the phone is open or closed.

To take a picture:

1. Highlight  and press  > **Photos & Videos** > **Camera** to activate the camera mode. (Additional camera options are available through the camera mode **OPTIONS** menu. See "Camera Mode Options" on page 98 for more information.)

Shortcut: To activate camera mode, you can also press and hold the side camera button (). (See illustration on page 8.)

2. Using the phone's display screen as a viewfinder, aim the camera lens at your subject.
3. Press  or the side camera button until the shutter sounds. (Your phone automatically saves the picture to the selected storage area.)
 - To return to camera mode to take another picture, press .
4. Once you've taken your picture, press **OPTIONS** (right softkey) for more options:
 - **Send Picture** to send your picture in a message. (See page 104 for details.)
 - **Camera** to return to the camera to take additional pictures.

- **Assign** to assign the picture as a Picture ID or Screen Saver.
- **Erase** to delete the picture you just took.
- **Review Album** to go to the **My Photos & Videos** folder where you can review your saved pictures.

Assigning Pictures

After taking a picture, assign it as a screen saver or as a picture ID for a Contacts entry.

1. Take a picture. (See steps 1–3 on page 97.)
2. With the picture displayed, press **OPTIONS** (right softkey) > **Assign**, and select an option.
 - **Picture ID** to assign the picture to either a **Contacts** entry, **Unsaved Numbers**, or to a **Private/Unknown** number. Highlight an entry and press  to assign the picture.
 - **Screensaver** to assign the picture as a screen saver. Press  to assign the picture.

Tip: You can also assign pictures from the **My Photos & Videos** menu. See “In Phone Folder and microSD Card Options” on page 103.

Camera Mode Options

When the phone is open and in camera mode, press **OPTIONS** (right softkey) to display additional camera options:

- **MODE** to select a cameras mode: **Camera** or **Camcorder**. To switch to video mode. (See “Recording Videos” on page 101.)
- **SHOOTING MODE** to select the picture mode. Choose from the following:
 - **Single Shot** to take a single image.
 - **Continuous** to take multiple shots. (See “Taking Multiple Shots” on page 100.)
 - **Mosaic** to take a series of pictures and then combine them into a single image.
 - **Panorama** to take multiple images and have them combined to create a panoramic image.
 - **Night Shot** to take a photo in low light conditions.
- **RESOLUTION** to set the picture’s resolution (**2M**, **1.3M**, **High**, **Med**, and **Low**).

- **WHITE BALANCE** to adjust white balance based on changing lighting conditions (**Auto**, **Daylight**, **Cloudy**, **Incandescent**, **Fluorescent**, or **Manual**). (The default setting is **Auto**.)
- **Brightness** to adjust the image brightness level. Press the navigation key up (increase) or down (decrease) to select a setting. (The default setting is **0**.)
- **SELF TIMER** to activate the camera's timer. (See "Self Timer" on page 99.)
- **EFFECT** to apply an image effect. Selects a wide variety of color tones for the picture. (The default setting is **None**.)
- **QUALITY** to select the picture quality setting (**Fine**, **Normal**, or **Economy**).
- **Shutter Sound** to select a shutter sound (**Shutter 1-3** or **Off**).
- **AUTO-SEND** to select whether to automatically send the new taken image to the assigned storage location (**On**) or be prompted after an image is taken (**Off**).
- **Storage** to select the destination for the image files (**Phone** or **Card**).

Self Timer

1. From camera mode, press **OPTIONS** (right softkey) **> SELF TIMER**.
2. Highlight the length of delay you want the timer to use (**5 Sec** or **10 Sec**) and press .
3. Press  when you are ready to start the timer. (The timer is displayed on the upper-left portion of the display screen during the self-timer countdown.)
4. Get ready for the picture. (When the timer is down to three seconds, the self-timer icon will turn red and the phone will begin to beep.)

To cancel the self-timer after it has started:

► Press .

Note: While the Self Timer is active, all keys are disabled except .

Taking Multiple Shots

This feature allows you to take up to nine shots in a continuous sequence.

1. From camera mode, press **OPTIONS** (right softkey) > **SHOOTING MODE** > **Continuous**.
2. Highlight an option and press 
 - **Off** to deactivate the multiple shots option.
 - **5 Shots** to take a series of five pictures.
 - **10 Shots** to take a series of ten pictures (image resolution is set to **Low**).

Note: Your phone automatically saves the pictures in your selected storage area at 320 x 240 resolution.

Customized Screen

These features allow you to customize how the onscreen viewfinder is displayed.

1. From camera mode, press the QWERTY up or down arrows, or scroll over the navigation key up or down. You will see the following options:

- **View/Hide information bars** to toggle on or off the display all of the current camera information such as battery level (Image size, quality, storage location, etc...



- **View/Hide quadrants** to toggle on or off an onscreen quadrant that can be used to position your subjects.

2. Press the side camera button to take the picture.
(Your phone automatically saves the picture in your designated storage area.)

Note: The Zoom gauge will not be displayed when the Resolution setting is High.

Recording Videos

In addition to taking pictures, you can record, view, and send videos with your phone's built-in video camera.

1. Highlight  and press  > **Photos & Videos** > **Camcorder** to activate video mode.
2. Select **Video Mail** or **Long Video**.

Note: Video Mail can be at most 30 seconds in length, but the length of a Long Video is dependent on both the quality settings and storage type used (phone or memory card).

3. Using the phone's display screen as a viewfinder, aim the camera lens at your subject.
4. Press  or the side camera button to begin recording.
 - To return to camcorder mode to take another video, press .
5. Press , , or the side camera button to stop recording. (Your phone automatically saves the video in your designated storage area.)
6. Press **OPTIONS** (right softkey) and select an option:
 - **Send Video** to send the video. (See "Sending Pictures and Videos" on page 104.)
 - **Play** to play the video.
 - **Assign** to assign the video as a video ringer or to voice calls.
 - **Erase** to delete the video.
 - **Camcorder** to return to camcorder mode.
 - **Review Album** to review all pictures and videos saved in the In Phone folder.

Video Mode Options

When the phone is in camcorder mode, press **OPTIONS** (right softkey) to display additional camcorder options:

- **MODE** to select a camera mode: **Camera** or **Camcorder**. To switch to camera mode. (See “Taking Pictures” on page 97.)
- **WHITE BALANCE** to adjust white balance based on changing lighting conditions (**Auto**, **Daylight**, **Cloudy**, **Incandescent**, **Fluorescent**, or **Manual**). (The default setting is **Auto**.)
- **Brightness** to adjust the image brightness level. Press the navigation key up (increase) or down (decrease) to select a setting. (The default setting is **0**.)
- **SELF TIMER** to activate the camcorder’s timer. (See “Self Timer” on page 99.)
- **EFFECT** to apply an image effect. Selects a wide variety of color tones for the video. (The default setting is **None**.)
- **QUALITY** to select the picture quality setting (**Fine**, **Normal**, or **Economy**).

- **AUTO-SEND** to select whether to automatically send the new video to the assigned storage location (**On**) or be prompted after a video is shot (**Off**).
- **Storage** to select the destination for the video files (**Phone** or **Card**).

Storing Pictures and Videos

Your phone’s picture and video storage area is called **My Photos & Videos**. There are two types of folders:

- **In Phone**
- **Memory Card**

Storage Options

1. Highlight  and press  > **Photos & Videos** > **Settings** > **Auto Save to**.
2. Select **Phone** or **Card**.

In Phone Folder

Your phone's internal storage area is called the **In Phone** folder. From the In Phone folder, you can view all the pictures and videos you have stored there, send items to your Places, delete files, and access additional options.

To review your stored pictures and videos in the In Phone folder:

1. Highlight  and press  > **Photos & Videos** > **My Photo & Videos** > **In Phone**.
2. Use your navigation key to view and scroll through the pictures and videos.

microSD Picture and Video Folders

You can save pictures and videos directly to the microSD card using your phone's pictures and videos settings.

To review your stored pictures and videos on the microSD card:

1. Highlight  and press  > **Photos & Videos** > **My Photo & Videos** > **Memory Card**.

2. Use your navigation key to scroll through and view saved pictures and videos.

In Phone Folder and microSD Card Options

When you are viewing the In Phone folder or the memory Card folders, press **OPTIONS** (right softkey) to display the following options:

- **Expand view/Thumbnail view** to switch the display from expanded view to thumbnail view (up to nine pictures per screen).
- **Play** to play a selected video.
- **Slide show** to view all current folder images as an onscreen slideshow (only available when you save two or more pictures to the folder). Press left or right keys (or scroll over the navigation key) to skip or any other key to stop the slideshow.
- **Select Multiple** to select multiple images or videos.
- **Assign** to assign the current image as a Picture ID or Screen Saver or the selected video clip as a Video Ringer or Voice Calls.
- **Delete** to erase the image or selected videos.

Note: Deleting pictures will free up memory space in your phone to enable you to take more pictures. Once deleted, pictures cannot be uploaded to your online Sprint Picture Mail account.

- **Print..** to print an image by either PictBridge Print or Bluetooth connection.
- **Copy/Move** to copy or move an image or video to an installed memory card.
- **Details/Edit** to attach a text caption or view the media information associated with a file.
- **Camera/Camcorder Mode** to switch to either the camera or camcorder mode.

Sending Pictures and Videos

Once you have taken a picture or a video, you can use the messaging capabilities of your phone to instantly share it with family and friends. You can send a picture to up to 25 people at a time using their email addresses or their wireless phone numbers.

Sending Pictures and Videos From Messaging

1. Select  > **Send Message**.
 - or –
 - Highlight  and press  > **Messages** > **Send Message**.
 - or –
 - Press  on the QWERTY keyboard.
2. Select an entry method:
 - **Go to Contacts** to select a recipient from your Contacts. (Qualifying Contacts entries must contain a wireless phone number or an email address.)
 - or –
 - Press **MULTIPLE** (left softkey) to select more than one recipient and press .
 - or –
 - Press **NEW ADDR** (right softkey) to manually enter either a phone number or email address.

- **Phone Number** to use the keypad to enter a wireless phone number directly.
 - **Email Address** to enter the recipient's email address.
3. Press **CONTINUE** (left softkey) when you have finished entering recipients. (You may include up to 25 recipients per message.)
 4. Press **OPTIONS** (right softkey), highlight **Add/Change Attachment** and press .
 5. Highlight an option and press .
 - **My album** to select a picture or video stored in the phone.
 - **Take new picture** to take a new picture to attach to the message.
 - **Take new video** to record a new video to attach to the message.
 - **Voice** to attach a new voice memo.
 6. Enter a message, use a preset message, or use smiley's/symbol.
 - To type a message, use your keypad to enter your message. Use the right softkey to select an input mode. (See "Entering Text in Portrait Mode" on page 31 or See "Entering Text in Landscape Mode" on page 35.)
 - Use the **OPTIONS** (right softkey) to select a **Text Mode** (such as Predictive Text, Smiley's, or Symbols).
 - To use a preset message, press **OPTIONS** (right softkey), select **Add Preset Message**, and then select a message and press .
 - To use a smiley or symbol, press **OPTIONS** (right softkey) > **Text Mode** and select **Smiley's** or **Symbols**.
 7. Review your message and press **SEND** (left softkey) to deliver your message.

Sending Pictures and Videos From the In Phone Folder

1. Highlight  and press  > **Photos & Videos** > **My Photo & Videos** > **In Phone**.
2. Highlight a picture or video to send and press .

3. Press **SEND** (left softkey). (You will see a message about updating your places list.)
4. Highlight an option and press :
 - **Contact** to select recipients from your Contacts. Highlight a recipient and press .
 - **Bluetooth** to select a target Bluetooth device.
 - **New Place...** to send your image or video to an external site “place”. Choices include: **My PC/Email**, **EA Tips and Tricks**, **MySpace**, **Snapfish**, **YouTube**, **Photobucket**, and **Facebook**.

Note: The **My PC/Email** option allows you to send your currently selected file to an email account and then download it to a computer. See “Email” on page 135.

5. Follow the onscreen instructions.

Sending Pictures and Videos to an Email

You can also send Sprint Picture Mail from your phone’s Messages menu.

1. Highlight  and press  > **Photos & Videos** > **My Photo & Videos** > **In Phone**.
2. Highlight a picture or video to send and press .

3. Press **SEND** (left softkey). (You will see a message about updating your places list.)
4. Select **New Place... > My PC/Email**.
5. Enter the recipient’s email address.

Important: To automatically upload all new images and videos to your designated email address, enable the “**Automatically send...**”field.

6. Press **DONE** (left softkey) to send the email.

Uploading Pictures and Videos to a Place

1. Highlight  and press  > **Photos & Videos** > **My Photo & Videos**.
2. Select a location (**In Phone** or **Memory Card**). (You will see the thumbnail pictures.)
3. Highlight a picture or video to send and press .
4. Press **SEND** (left softkey). (You will see a message about updating your places list.)
5. Select **New Place..**, select a target place, login to your account, and follow the onscreen instructions.

Printing Pictures From Your Phone

Your phone is PictBridge compatible, allowing you to print directly from your phone without connecting to a computer. Simply connect your phone to a PictBridge-enabled printer and print your photos.

Note: Make sure your battery is fully charged before using the PictBridge.

To print pictures directly from your phone:

1. Highlight  and press  > **Photos & Videos** > **My Photo & Videos**.
2. Select a location (**In Phone** or **Memory Card**). (You will see the thumbnail pictures.)
3. Press **OPTIONS** (right softkey) > **Print...** > **PictBridge Print**.
4. Connect your phone to the PictBridge-enabled printer by using a USB cable (not included). (Wait until the connection is completed.)
5. Set the printer settings using your navigation key. These settings can vary among bluetooth-capable printers.

6. When you have finished selecting the printer settings, select **Print**.

Note: While you are connected to the printer, your phone's screen will display "Phone Off." You cannot make or receive calls during this time.

7. When printing is finished, press .
8. Select **Yes**. Follow the instructions on the display to unplug the USB cable from the phone.

PictBridge Error Messages –

From time to time you may encounter printing problems. Your phone will display any printer error messages informing you of the specific problems encountered. Please refer to the user's guide that came with your printer for descriptions, explanations, and possible resolutions for any error messages.

Settings

This menu allows you to configure where pictures are saved, view your account information, or set the view between portrait or landscape mode.

1. Highlight  and press  > **Photos & Videos** > **Settings**.

2. Select one of the following options:

- **Auto Save to** to choose between Phone and Memory Card as the default location to save pictures or videos.
- **Status Bar** to select whether the Status Bar is displayed onscreen when the camera/camcorder is active.

2J. Bluetooth

- ◆ Turning Bluetooth On and Off (page 109)
- ◆ Using the Bluetooth Settings Menu (page 110)
- ◆ Pairing Bluetooth Devices (page 110)
- ◆ Sending Items via Bluetooth (page 111)

About Bluetooth

Bluetooth is a short-range communications technology that allows you to connect wirelessly to a number of Bluetooth devices, such as headsets and hands-free car kits, and Bluetooth-enabled handhelds, computers, printers, and wireless phones. The Bluetooth communication range is usually up to approximately 30 feet.

Turning Bluetooth On and Off

By default, your device's Bluetooth feature is set to **Off**. Turning Bluetooth on makes your phone “discoverable” by other in-range Bluetooth devices.

To turn Bluetooth on:

1. Highlight  and press  > **Tools** > **Bluetooth** > **On/Off**.
2. Highlight **On** and press  to enable Bluetooth.

To turn Bluetooth off:

1. Highlight  and press  > **Tools** > **Bluetooth** > **On/Off**.
2. Highlight **Off** and press  to disable Bluetooth.

Bluetooth Status Indicators

The following icons show your Bluetooth connection status at a glance:



– Bluetooth is active



– Bluetooth is Visible (active and enabled)



– Bluetooth is visible and connected to a device or transferring data.



– Bluetooth is visible and connected to a Bluetooth headset.



– Bluetooth is active, connected and playing music via the Stereo Bluetooth Headset.

Using the Bluetooth Settings Menu

The **Bluetooth Settings** menu allows you to set up many of the characteristics of your phone's Bluetooth service, including:

- Entering or changing the name your phone uses for Bluetooth communication
- Setting your phone's visibility (or "discoverability") for other Bluetooth devices
- Displaying your phone's Bluetooth address

To access the Bluetooth Settings menu:

1. Highlight  and press  > **Tools** > **Bluetooth**.

2. Set your Bluetooth options.

- Select **Visibility** > **Hidden**, **Visible for 3 Min**, or **Always Visible** to set your Bluetooth visibility.
- Select **My Bluetooth Info** to display your phone's Bluetooth profiles and address.
 - Press **EDIT** (left softkey) to rename your phone for Bluetooth.
- Select **Trusted Devices** to display your phone's current list of external trusted Bluetooth devices.

Pairing Bluetooth Devices

Paired Devices

The Bluetooth pairing process allows you to establish trusted connections between your phone and another Bluetooth device. When you pair devices, they share a passkey, allowing for fast, secure connections while bypassing the discovery and authentication process.

To pair your phone with another Bluetooth device:

1. Highlight  and press  > **Tools** > **Bluetooth** > **Add new**. (Your phone will display a list of discovered in-range Bluetooth devices.)

2. Highlight a device and press . Different device categories are indicated by a different icon adjacent to the detected Bluetooth device.
3. Enter the passkey and press .
4. Enter a unique Device Name and press **DONE** (left softkey).

Note: Due to different specifications and features of other Bluetooth-compatible devices, display and operations may be different, and functions such as transfer or exchange may not be possible with all Bluetooth-compatible devices.

Pairing With a Computer

If you are going to be pairing with a computer's Bluetooth interface, you will need to allow the computer to initiate pairing with your phone.

To allow your phone to be paired with another Bluetooth device:

1. Highlight  and press  > **Tools** > **Bluetooth** > **Add new**.
2. Select a Bluetooth device from the list showing an adjacent Computer icon.

3. Follow the onscreen prompts to enter your passkey and press .

Sending Items via Bluetooth

Depending on your paired devices' settings and capabilities, you may be able to send pictures, Contacts information, or other items using a Bluetooth connection.

To send contacts information via Bluetooth:

1. Highlight  and press  > **Contacts**.
2. Highlight an entry and press **OPTIONS** (right softkey) > **Send Contact**.
3. Place a checkmark next to the Contact entry you want to send by first selecting an entry and pressing .
4. Press **SEND CONTACTS** (left softkey). (The phone begins searching for available Bluetooth devices. Bluetooth-capable phones will appear in the list with an adjacent phone icon.)
 - If the device isn't in the list, select **OPTIONS** (right softkey) > **Refresh**.

5. From the list of Found Devices, highlight the target Bluetooth device and press **SELECT** (left softkey).
6. Select **Yes** to confirm you want to send the contact. (The recipient's phone displays an onscreen message asking whether the person would like to receive and save your Contact entry to his or her list.)
7. The recipient must either accept and save the contact, or reject the incoming data.

To send pictures via Bluetooth:

1. Highlight  and press  > **Photos & Videos** > **My Photos & Videos**.
2. Select an album (In Phone, or Memory Card) and press .
3. Select a picture by highlighting it and then pressing .
4. Press **SEND** (left softkey) > **Bluetooth** > **Yes**. (The phone begins searching for available Bluetooth devices. Bluetooth-capable phones will appear in the list with an adjacent phone icon.)

5. From the list of Found Devices, select the Bluetooth device and press .
6. Select **Yes**. (The recipient's phone displays an onscreen message asking whether the person would like to receive and save your Contact entry to his or her list.)
7. The recipient must either accept and save the image, or reject the incoming data.

To send files via Bluetooth:

1. Highlight  and press  > **Tools** > **Mass Storage** > **File Manager**.
2. Select a source location (**Phone** or **Memory Card**).
3. Highlight a file and press **OPTIONS** (right softkey).
4. Select **Send** > **Bluetooth**.
5. Select a file by highlighting it and then pressing  to place a checkmark adjacent to the selected files.
6. Press **Done** (left softkey).

7. Highlight a trusted Bluetooth device and press **SELECT** (left softkey).
8. Select **Yes** to confirm the file transfer process. (The phone begins the transfer process.) The target Bluetooth device must accept the incoming file transfer to complete the delivery process.

Section 3
Sprint Service



3A. Sprint Service: The Basics

- ◆ Voicemail (page 116)
- ◆ Messaging (SMS/MMS) (page 119)
- ◆ Caller ID (page 121)
- ◆ Call Waiting (page 122)
- ◆ Making a 3-Way Call (page 122)
- ◆ Call Forwarding (page 123)
- ◆ Roaming (page 123)

Voicemail

Setting Up Your Voicemail

Your phone automatically transfers all unanswered calls to your voicemail, even if your phone is in use or turned off. You should set up your Sprint Voicemail and personal greeting as soon as your phone is activated.

Always use a passcode to protect against unauthorized access.

1. Press and hold .
2. Follow the system prompts to:
 - Create your passcode.
 - Record your name announcement.
 - Record your greeting.

Note: Voicemail Passcode

Sprint strongly recommends that you create a passcode when setting up your voicemail to protect against unauthorized access. Without a passcode, anyone who has access to your phone is able to access your voicemail messages.

Voicemail Notification

There are several ways your phone alerts you to a new message:

- By displaying a message on the screen.
- By sounding the assigned ringer type.
- By the LED blinking red.
- By displaying  at the top of your screen.

New Voicemail Message Alerts

When you receive a new voice message, your phone alerts you and prompts you to call your voicemail.

To call your voicemail:

- ▶ Press and hold .

To display your Missed Log:

- ▶ Highlight  and press  > **Missed Alerts**.

Note: When you are roaming off the Nationwide Sprint Network, you may not receive notification of new voicemail messages. Sprint recommends that you periodically check your voicemail by dialing 1 + area code + your wireless phone number. When your voicemail answers, press  and enter your passcode. Roaming rates apply when you access voicemail while roaming off the Nationwide Sprint Network.

Your phone accepts messages even when it is turned off. However, your phone notifies you of new messages only when it is turned on and you are in a Sprint service area.

Retrieving Your Voicemail Messages

You can review your messages directly from your wireless phone or from any other touch-tone phone. To dial from your wireless phone, either speed dial your voicemail or use the menu keys.

Using One-Touch Message Access

- ▶ Press and hold . (Your phone will dial your voicemail box.)

– or –

From the lock screen, press **LISTEN** (left softkey)

Using the Menu Keys on Your Phone to Access Your Messages

1. Highlight  and press  > **Messages** > **Voicemail** > **Call Voicemail**.

– or –

Select  > **Voicemail**.

Note: You are charged for airtime minutes when you are accessing your voicemail from your wireless phone.

Using Another Phone to Access Messages

1. Dial your wireless phone number.
2. When your voicemail answers, press .
3. Enter your passcode.

Tip: When you call into voicemail, you first hear the header information (date, time, and sender information) for the message. To skip directly to the message, press **4** during the header.

Clearing the Message Icon

Your phone may temporarily continue to display the message icon after you have checked your voice and text messages.

1. Highlight  and press  **Messages** > **Voicemail** > **Clear Envelope**.
2. Highlight **Yes** or **No** and press .

Voicemail Key Guide

Here's a quick guide to your keypad functions while listening to voicemail messages.

		
Date/Time	Send Reply	Advance
		
Replay	Rewind	Forward
		
Erase	Return Call	Save
		
Cancel	Help	Skip

Messaging (SMS/MMS)

With text and picture messaging (SMS/MMS), you can send and receive instant text and picture messages between your wireless phone and another messaging-ready phone. When you receive a new message, it will automatically display on your phone's screen.

In addition, text messaging includes a variety of preset messages, such as "I'm running late, I'm on my way," that make composing messages fast and easy. Use your phone to customize your own preset messages (up to 160 characters).

Tip: You can instantly access all your phone's messaging options, including text messaging, using the main screen carousel. See section 2B "Navigating the Main Screen" on page 42 for details.

Note: See your service plan for applicable charges for text messaging and SMS voice messaging.

Note: Creating messages can also be accessed from the **Main Menu > Messages** or by pressing  on the QWERTY keyboard.

Composing Text/Picture Messages

1. Select  > **Send Message > Message**.
 - or –
 - Highlight  and press  > **Messages > Send Message**.
 - or –
 - Press  on the QWERTY keyboard.
2. Select an entry method:
 - **Go to Contacts** to select a recipient from your Contacts. (Qualifying Contacts entries must contain a wireless phone number or an email address.)
 - or –
 - Press **MULTIPLE** (left softkey) to select more than one recipient and press .
 - or –
 - Press **NEW ADDR** (right softkey) to manually enter either a phone number or email address.
 - **Phone Number** to use the keypad to enter a wireless phone number directly.

- **Email Address** to enter the recipient's email address.
3. Press **CONTINUE** (left softkey) when you have finished entering recipients. (You may include up to 25 recipients per message.)
 4. Enter a message, use a preset message, or use smiley's/symbol.
 - To type a message, use your keypad to enter your message. Use the right softkey to select an input mode. (See "Entering Text in Portrait Mode" on page 31 or See "Entering Text in Landscape Mode" on page 35.)
 - Use the **OPTIONS** (right softkey) to select a **Text Mode** (such as Predictive Text, Smiley's, or Symbols).
 - To use a preset message, press **OPTIONS** (right softkey), select **Add Preset Message**, and then select a message and press .
 - To use a smiley or symbol, press **OPTIONS** (right softkey) > **Text Mode** and select **Smiley's** or **Symbols**.

5. Add a picture, video, or voice message to a text message as an attachment:
 - Press **OPTIONS** (right softkey), highlight **Add/Change Attachments** and press .
 - Select an attachment option and follow the onscreen prompts to select a file.
 - Options include: **My album**, **Take new picture**, **Take new video**, or **Voice**.
6. Review your message and press **SEND** (left softkey) to deliver your message.

Accessing Text Messages

To read an SMS Text message:

- When you receive a text message, you will see it on your phone's screen. Use your navigation key to scroll down and view the entire message.

To reply to a text message:

1. While the message is open, press **REPLY** (left softkey).

2. Compose your reply or use the preset messages or icons.
 - To type a message, use your keypad to enter your message. Use the right softkey to select an input mode. (See “Entering Text in Portrait Mode” on page 31 or See “Entering Text in Landscape Mode” on page 35.)
 - To use a preset message, press the right softkey, press **OPTIONS > Add Preset Message**, highlight a message and press .
 - To use a Smiley or Symbol, press the right softkey, press **OPTIONS > Text Mode > Smiley's** or **Symbols**, highlight a selection and press .
 - You may select additional messaging options by pressing **OPTIONS** (right softkey) > **Mark as Urgent** or **Set Callback #**.
3. Review your reply and press **SEND** (left softkey) to deliver your message.

Preset Messages

Preset messages make it easy to compose text messages.

To add or edit preset messages:

1. Highlight  and press  > **Messages** > **Settings** > **Preset Messages** > **OPTIONS** (right softkey) > **Add New**.
 - or –
 - Highlight a preset message and press **EDIT** (left softkey).
 - Highlight a preset message and press **OPTIONS** (right softkey) > **Delete**.
2. Enter your new message or changes and press . (See “Entering Text in Portrait Mode” on page 31 or See “Entering Text in Landscape Mode” on page 35.)

Caller ID

Caller ID allows people to identify a caller before answering the phone by displaying the number of the incoming call. If you do not want your number displayed when you make a call, follow these steps.

1. Press   .

2. Enter a phone number.

3. Press .

To permanently block your number, call Sprint Customer Service.

Call Waiting

When you're on a call, Call Waiting alerts you to incoming calls by sounding two beeps. Your phone's screen informs you that another call is coming in and displays the caller's phone number (if it is available and you are in digital mode).

To respond to an incoming call while you're on a call:

- ▶ Press . (This puts the first caller on hold and answers the second call.)

To switch back to the first caller:

- ▶ Press  again.

Tip: For those calls where you don't want to be interrupted, you can temporarily disable Call Waiting by pressing    before placing your call. Call Waiting is automatically reactivated once you end the call.

Making a 3-Way Call

With 3-Way Calling, you can talk to two people at the same time. When using this feature, the normal airtime rates will be charged for each of the two calls.

1. Enter a number and press .

Important: It is recommended that the first line be active for **at least 20 seconds** prior to initiating a 3-way call with a second party.

2. Once you have established the connection, press **OPTIONS** (right softkey) > **3-way call**.
3. Choose the second number by selecting one of the following:
 - **Contacts** to select a recipient from your Contacts (qualifying Contacts entries must contain a wireless phone number).
 - Highlight the entry and press .
 - Highlight the number (from the **CONTACT DETAILS** page) and press .
 - Highlight **Call** and press .

- **Recent History** to select a number from your Recent History entries.
 - Highlight the entry (from the **RECENT HISTORY** page) and press .
 - Highlight the number or time entry and press .
 - Highlight **Call** and press .
 - **Enter phone number** to use the keyboard to enter a wireless phone number directly.
 - Enter the phone number and press .
4. When you're connected to the second party, press **JOIN** (right softkey) to begin your 3-way call.

If one of the people you called hangs up during your call, you and the remaining caller stay connected. If you initiated the call and are the first to hang up, all callers are disconnected.

Call Forwarding

Call Forwarding lets you forward all your incoming calls to another phone number – even when your phone is turned off. You can continue to make calls from your phone when you have activated Call Forwarding.

To activate Call Forwarding:

1. Press   .
2. Enter the area code and phone number to which you want your calls forwarded.
3. Press . (You will see a message and hear a tone to confirm the activation of Call Forwarding.)

To deactivate Call Forwarding:

1. Press    .
2. Press . (You will see a message and hear a tone to confirm the deactivation.)

Note: You are charged a higher rate for calls you have forwarded.

Roaming

Roaming Icon

Your display screen always lets you know when you're off the Nationwide Sprint Network. Anytime you are roaming, the phone displays the roaming icon (). If you are roaming on a digital system, you will see the roaming icon along with the text – **Digital Roam** –.

Tip: Remember, when you are using your phone off the Nationwide Sprint Network, always dial numbers using 11 digits (1 + area code + number).

Roaming on Other Digital Networks

When you're roaming on digital networks, your call quality and security will be similar to the quality you receive when making calls on the Nationwide Sprint Network. However, you may not be able to access certain features, such as data services, depending on the available network.

Note: If you're on a call when you leave the Nationwide Sprint Network, your call is dropped. If your call is dropped in an area where you think Sprint service is available, turn your phone off and on again to reconnect to the network.

Checking for Voicemail Messages While Roaming

When you are roaming off the Nationwide Sprint Network, you may not receive on-phone notification of new voicemail messages.

Callers can still leave messages, but you will need to periodically check your voicemail for new messages if you are in a roaming service area for an extended period of time.

1. Dial 1 + area code + your phone number.
2. When you hear your voicemail greeting, press .
3. Enter your passcode at the prompt and follow the voice prompts.

When you return to the Nationwide Sprint Network, voicemail notification will resume as normal.

Setting Roam Mode

Your phone allows you to control your roaming capabilities. By using the Roaming menu option, you can determine which signals your phone accepts.

Choose from three different settings on your dual-band phone to control your roaming experience.

1. Highlight  and press  > **Settings** > **Others** > **Roaming** > **Set Mode**.

2. Highlight an option and press .
- **Automatic** to seek service on the Nationwide Sprint Network. When Sprint service is unavailable, the phone searches for an alternate system.
- **Sprint Only** to access only the Nationwide Sprint Network and prevent roaming on other networks.

Call Guard

Your phone has two ways of alerting you when you are roaming off the Nationwide Sprint Network: the onscreen roaming icon and Call Guard. Call Guard makes it easy to manage your roaming by requiring an extra step before you can place or answer a roaming call. (This additional step is not required when you make or receive calls while on the Nationwide Sprint Network.)

To turn Call Guard on or off:

1. Highlight  and press  > **Settings** > **Others** > **Roaming** > **Call Guard**.
2. Highlight **On** or **Off** and press .

Note: Call Guard is turned on by default on your phone.

Voice dialing and speed dialing are not available when you are roaming with Call Guard enabled.

To place roaming calls with Call Guard on:

1. From standby mode, dial 1 + area code + the seven-digit number and press .
2. Press  to send a call.

To answer incoming roaming calls with Call Guard on:

1. Press . (A message will be displayed notifying you that roaming charges will apply.)
2. Press  to complete the call.

Note: If the Call Guard feature is set to **On**, you need to take extra steps to make and receive roaming calls.

Data Roam Guard

Depending on service availability and roaming agreements, your phone may be able to access data services while roaming on certain digital systems.

You can set your phone to alert you when you are roaming off the Nationwide Sprint Network and try to use data services such as messaging.

Note: Data Roam Guard is turned off by default on your phone.

To set your Data Roam Guard notification:

1. Highlight  and press  > **Settings** > **Others** > **Roaming** > **Data Roam Guard**.
2. Highlight an option and press .
 - **Always Ask** sets your phone's Data Roam Guard feature on. You will see a prompt and will be required to respond anytime you access data services while roaming.
 - **Never Ask** turns your phone's Data Roam Guard feature off. You will not be notified of your roaming status when accessing data services.

To use data services when Data Roam Guard is active:

- ▶ When a pop-up notification appears informing you that data roam charges may apply, press **ROAM** (left softkey) to connect.

3B. Web and Data Services

- ◆ Getting Started With Data Services (page 127)
- ◆ Browser Menu (page 131)
- ◆ Accessing Messages (page 135)
- ◆ Downloading Games, Ringers, and More (page 138)
- ◆ Applications (page 141)
- ◆ Data Services FAQs (page 149)

Getting Started With Data Services

With your Sprint service, you are ready to start enjoying the advantages of data services. This section will help you learn the basics of using your data services, including managing your user name, launching a data connection, and navigating the Web with your phone.

Your User Name

When you buy your phone and sign up for service, you're automatically assigned a user name, which is typically based on your name and a number, followed by "@sprintpcs.com." (For example, the third John Smith to sign up for Sprint data services might have jsmith003@sprintpcs.com as his user name.)

When you use data services, your user name is submitted to identify you to the Nationwide Sprint Network. Your user name will be automatically programmed into your phone. You don't have to enter it.

Finding Your User Name

If you aren't sure what your user name is, you can easily find it online or on your phone.

- At www.sprint.com. Sign on to your account using your phone number and password. To display your user name, click on the **Settings & Passwords** menu, then under the **Account Admin Tools** column, click on **Phone Labels > Username**.
- On your phone, highlight  and press  > **Settings > Phone Information > Phone Number/User ID**.

Updating Your User Name

If you choose to change your user name and select a new one online, you must then update the user name on your phone.

- ▶ Highlight  and press  > **Settings** > **Others** > **Data** > **Update Data Profile**. (To cancel, press  before completing the update.)

Launching a Web Connection


- ▶ Select  > **Home**.
 - or –
- ▶ Highlight  and press  > **Web**. (Your data connection starts and you see the SprintWebSM home page.)
 - or –
- ▶ Press  on the QWERTY keyboard.

Note: If Net Guard is enabled and displayed, press **ROAM** (left softkey) to continue and launch the Web. For more information, see “Net Guard” on page 60.

Tip: For instant access to the Internet, including the Sprint home page, Favorites, Recent Pages, and Google search, use the main screen carousel. See section 2B “Navigating the Main Screen” on page 42 for details.

While connecting, you may see an animation and a “Connecting” message.

The SprintWebSM Home Page




Note: The default view for the Browser window is to show the page at full screen with only the **GO/STOP** and **TOOLBAR** buttons visible.

Tip: To change the default launch page to the last page you viewed, press **TOOLBAR** (right softkey) > **OPTIONS** > **Set as Homepage**.

Data Connection Status and Indicators

Your phone displays the current status of your data connection through indicators at the top of the screen. The following symbols are used:



Your data connection is active (data is being transferred). When the triangles are animated, your phone is transferring data (for example, when you are opening a Web page); when the triangles are gray, your phone is connected to the network but is not currently transferring data (for example, when you are viewing a Web page that is completely open). In either state, you can receive incoming calls.



Your data connection is dormant (no data is being sent or received). When the arrows are gray, your phone is connected to the network but is not currently transferring data. Though not currently active, when dormant the phone can restart an active connection quickly; voice calls can be made and received.

If you do not see an indicator, your phone does not have a current data connection. To launch a connection, see “Launching a Web Connection” on page 128.

Data Restrictions

Parental Controls determine what features you have access to on your phone. (See “Using Parental Controls” on page 60.)

When you first connect to the Web, access is confirmed against the current Parental Restrictions. If data access has been restricted, you will be notified with an onscreen warning. This feature helps prevent any accidental data connections. You can disable the data restriction feature by changing the setting from within the Parental Controls menu.

Note: To access Parental Controls, the feature must first be active (page 60).

To change your Restriction settings:

1. Highlight  and press  > **Settings** > **Parental Controls** > **On/Off**.
2. Select either:
 - **On** to activate the Parental Control function.
 - **Off** to deactivate the Parental Control function.
3. Select **Restrictions** > **CONTINUE** (right softkey) and change your settings.

Navigating the Web

Navigating through menus and websites during a data session is easy once you've learned a few basics. Here are some tips for getting around:

Softkeys

During a data session, the bottom line of your phone's display contains one or more softkeys. These keys are shortcut controls for navigating around the Web, and they correspond to the softkeys directly below the phone's display screen.

Tip: Depending on which websites you visit, the labels on the softkeys may change to indicate their function.

To use softkeys:

- Press a softkey. (If you see an additional pop-up menu when you press the softkey, select the menu items using your keypad [if they're numbered], or by highlighting the option and pressing .)



Tip: Pressing  jumps to the top of the Web page.
Pressing  jumps to the bottom of the Web page.


Browser Menu

Although the home page offers a broad and convenient array of sites and services for you to browse, not all sites are represented, and certain functions, such as going directly to specific websites, are not available. For these and other functions, you will need to use the browser menu. The browser menu offers additional options to expand your use of the Web on your phone.

The browser menu or toolbar may be opened anytime you have an active data session, from any page you are viewing.

To open the browser menu:

1. Select  > **Home**.
– or –
Highlight  and press  > **Web**.
2. Select an existing Web page icon from the listing or enter an address manually at the top of the page within the search field.



3. Select **TOOLBAR** from the bottom right to view the browser menu.
4. Select an available icon to launch and option:
 - **MY HOMEPAGE** () returns the browser to the SprintWebSM home page.
 - **MY PAGES** () accesses your favorite and recently viewed Web pages.
 - **SPRINT SEARCH** () launches the Google[®] search engine.

■ **OPTIONS** () accesses the Browser options:

- **Set as Homepage** assigns the current Web page as your new homepage.
- **Font size** allows use of a slider to adjust the current text size displayed within the browser. Touch **Save** to store your new setting.
- **Send this page to...** copies the current Web address and attaches it to an outgoing text message.
- **Clear private data** allows you to delete the current browsing history, browser cache, cookies, and stored passwords.
- **Help** provides help information related to the Browser.
- **Advanced** allows you to access additional Browser menu options such as: **Icon Row**, **Startup page**, **Page info**, **Images on/off**, **Reset browser**, **Turn on error logging**, **Send referrer**, **Redirect prompt**, and **Reset browser settings**.

Scrolling

As with other parts of your phone's menu, you'll have to scroll up and down to see everything on some websites.

To scroll line by line through websites:

- ▶ Scroll over the navigation key in an up or down direction.

– or –

Press the keyboard's up or down directional keys.

See "Navigating Through the Menus" on page 19.

To scroll page by page through websites:

- ▶ Press the volume buttons on the side of the phone.

Selecting

Once you've learned how to use softkeys and scroll, you can start navigating the Web.

To select onscreen items:

- ▶ Use the navigation key to highlight an item, and then press the left softkey (or press ).

Tip: You'll find that the left softkey is used primarily for selecting items. This softkey is often labeled "OK."

If the items on a page are numbered, you can use your keypad (number keys) to select an item.

Links, which are displayed as underlined text, allow you to jump to Web pages, select special functions, or even place phone calls.

To select links:

- Highlight the link and press the appropriate softkey.

Entering Text Into a Search or Text Field

- Select an onscreen text field or **Search** field to display the text input screen.

Going Back

To go back one page:

- Press the  key on your phone.

Note: You can also use the  key for deleting text (like the  key.)

Going Home

To return to the home page from any other page:

- Press **TOOLBAR** (right softkey) and select .

Reloading the Web Page

- From a currently active Web page, select . (The browser will reload the current page.)

Restarting the Web Browser

If the Web browser seems to be malfunctioning or stops responding, you can usually fix the problem by simply restarting the browser.

- Select  > **Home**.
 - or –
- Highlight  and press  > **Web**.
 - or –
- Press  on the QWERTY keyboard.

Going to a Specific Website

To go to a particular website address by entering a URL:

1. Select  > **Home**.
 - or –
 - Highlight  and press  > **Web**.
 - or –
 - Press  on the QWERTY keyboard.
2. Scroll to the very top of the Web page and highlight the Address bar (top)
 - Clear any existing address by either typing in the new data or pressing and holding  or .
3. Use the keyboard to enter a new URL and touch  or .

Note: Not all websites are viewable on your phone.

Creating a Bookmark

Bookmarks allow you to store the address of your favorite websites for easy access at a later time.

1. Go to the Web page you want to mark.

2. Press **TOOLBAR** (right softkey) and highlight **MY PAGES** ().
3. Press **ADD NEW** (left softkey).
4. Enter a descriptive title for the new Bookmark and press **ADD** (left softkey) > **OK** to add the currently active web page to your current Favorites list.
 - The newly added bookmark is inserted at the top of your list.

Note: Bookmarking a page does not store the page contents, just its address.

Some pages cannot be bookmarked. Whether a particular Web page may be marked is controlled by its creator.

Accessing a Bookmark

1. Select  > **Home**.
 - or –
 - Highlight  and press  > **Web**.
 - or –
 - Press  on the QWERTY keyboard.

2. Press **TOOLBAR** (right softkey) and select **MY PAGES** () to open the **MY FAVORITES** page that lists all of your bookmarks.

Note: The bookmark containing the Home icon indicates the current home page.

3. Select an entry from the list to automatically launch that Web page.

Deleting a Bookmark

1. Select  > **Home**.
– or –
Highlight  and press  > **Web**.
– or –
Press  on the QWERTY keyboard.
2. Press **TOOLBAR** (right softkey) and select **MY PAGES** () to open the **MY FAVORITES** page that lists all of your bookmarks.
3. Highlight the entry from the list and press **OPTIONS** (right softkey).
4. Highlight **Delete this Favorite** and press .

5. Confirm deletion by pressing **REMOVE** (left softkey).

Accessing Messages

You can send and receive email and text messages and participate in Web-based chat rooms right from your phone. Messaging allows you to stay connected 24 hours a day anywhere on the Nationwide Sprint Network.

Email

Your phone's Email application lets you access and manage multiple email accounts simultaneously in one convenient location.

Getting Started With Email

1. Select  > **Email**.
– or –
Highlight  and press  > **Messages** > **Email**.
2. Read the onscreen text and press **CONTINUE** (right softkey).

3. Select an email provider (such as **Yahoo!® Mail**, **Hotmail®**, **Gmail®**, or **AOL® Mail**) and press the right softkey.

– or –

Select **Work** to set up a corporate email account using either Outlook Web Access from a Microsoft Exchange Server or the Sprint Mobile Email connector for direct access.

– or –

Select **More...** to choose from additional options. There are many available email options listed, or you may add your own POP or IMAP email accounts.

Note: Work Email Setup: Consult your company's IT department for required information and permissions for any Work email accounts. Read the onscreen setup instructions for additional information about setting up and using Work email options on your phone.

4. Follow the setup wizard instructions to enter the required sign-up information and press **CONTINUE** (right softkey).

- Follow any onscreen instructions to complete the registration process.


Note: The information required to sign in will vary depending on the email provider you are accessing.

5. If applicable to Work email, read the notice regarding Mail Push. If you would like to enable Mail Push, press **YES** (right softkey). If another notice appears, review it and press **YES** (right softkey) again to enable Mail Push.

Note: Mail Push allows your phone to automatically retrieve new email messages without having to select the **Check Mail** option. When you enable Mail Push, you will receive an onscreen notice of new email messages. These notices may be charged as text messages. Please consult your service plan for details.

Creating an Additional Email Account

1. Select  > **Email**.
– or –
Highlight  and press  > **Messages** > **Email**.
(The default email account Inbox is displayed.)
2. Use your navigation keys or scroll over to the **Home** tab and press .
3. Select **Add Account**.
4. Follow the procedures outlined in “Getting Started With Email” on page 135.
5. Read the onscreen text and press **CONTINUE** (right softkey).



Accessing Email

Using Email on your phone is even easier than using multiple email accounts on your computer. Launch the application for instant access to all your accounts.

1. Select  > **Email**.
– or –
Highlight  and press  > **Messages** > **Email**.
(The default email account Inbox is displayed.)
2. Use your navigation keys or scroll over to the **Home** tab and press .
3. Highlight your desired email account and press .

Note: The first time you access your Email, you will have the option of completing a Help program. This series of screens demonstrates the application's navigation and available tools.

4. Use your keypad and directional keys to read, manage, and reply to your email messages.
 - Press **Menu** (right softkey) to select messaging options, such as **Delete**, **Reply to Sender**, **Reply All**, **Forward**, **Attachments**, **Call Sender**, **Read More**, **Save**, or **Mark as Unread**.

- To view a different email account, use your navigation or directional keys to select the **Home** tab at the top of the screen and select an available account from there.
- To add a new account, use your navigation key to select the **Home** tab at the top of the screen, and then select **Add Account**. Follow the instructions in “Creating an Additional Email Account” on page 137 to set up a new account.

Tip: You can also customize your main screen carousel to provide direct access to your email. See “Personalizing the Carousel” on page 44.

Note: You can also access certain email accounts through the home page. Highlight  and press  > **Web** and then select **Messages > Email > [AOL & AIM Mail, MSN Hotmail, or Yahoo! Mail]**. Follow the onscreen instructions to enter your account information and access your email messages.

Downloading Games, Ringers, and More

You have access to a dynamic variety of downloadable content, such as games, ringers, screen savers, and other applications. (Additional charges may apply.) Follow the basic steps below to access and download these items.

Accessing the Download Menus

1. Highlight  and press  > **My Stuff**.
– or –
Select  > **My Stuff**.
2. Select a download category (**Games, Ringers, Screen Savers, Applications, or Call Tones**), and then select **Get New**. (The browser will start and take you to the corresponding download menu.)

To access the download menus from the Web browser:

1. Select  > **Home**.
 - or –
 - Highlight  and press  > **Web**.
 - or –
 - Press  on the QWERTY keyboard.
2. From the home page, select **Downloads**.
3. Select **GAMES**, **VIDEOS**, or **TONES** to go to the corresponding download menu. (For more information on navigating the Web, see “Navigating the Web” on page 130.)

Selecting an Item to Download

You can search for available items to download in a number of ways:

- **Featured** displays a selection of featured items.
- **Categories** allows you to narrow your search to a general category. (There may be several pages of available content in a list. Select **Next 9** to view additional items.)

- **Search** field allows you to use your keypad to enter search criteria to locate an item. You may enter an entire word or title or perform a partial-word search.

Downloading an Item

Once you’ve selected an item, highlight it and press , or press **OK** (left softkey). You will see a summary page for the item including its title, the vendor, the download details, the file size, and the cost. Links allow you to view the **License Info** page, which outlines the price, license type, and length of license for the download, and the **Terms of Use** page, which details the Premium Services Terms of Use and your responsibility for payment.

To download a selected item:

1. From the information page, select **Buy**. (The item will download automatically. When you see the **SUCCESS** screen, you have successfully downloaded the item to your phone.)

Note: If you have not previously purchased an item, you will be prompted to create your purchasing profile.

2. Choose one of the following to continue:

- Select **Listen/View/Run** to assign the downloaded item (or to start, in the case of a game or an application). Your data session will end, and you will be redirected to the appropriate phone menu screen.
- Select **Set as** to assign a ringer or screen saver to a phone function.
- Select **Shop** to browse for other items to download.
- Press  to quit the browser and return to standby mode.

For complete information and instructions on downloading Games, Ringers, Screen Savers, and Applications, visit the Digital Lounge at www.sprint.com.

My Content Manager

Whether you purchase your content from your phone or from your online account management page at www.sprint.com, **My Content Manager** stores all of your purchases and you may download them to your phone from there.

My Content Manager is a storage area on the Nationwide Sprint Network that allows you to store all your purchased files. The files remain in My Content Manager until their license terms have expired – even after you have downloaded the content to your phone. This provides you with a convenient place to access information about your downloaded files without having to store the information in your phone's memory.

To access My Content Manager:

1. Select  > **Home**.
– or –
Highlight  and press  > **Web**.
– or –
Press  on the QWERTY keyboard.
2. From the home page, select **Downloads** > **My Content Manager**. (You will see a list of your purchased items.)

To download purchased content from My Content Manager:

1. From the **My Content Manager** display, highlight an item and press . (You will see the information page for the selected item.)
2. Highlight **Download** and press . (The item will download automatically. When you see the **SUCCESS** screen, you have successfully downloaded the item to your phone.)
3. Choose one of the following to continue:
 - Select **Listen/View/Run** to assign the downloaded item (or to start, in the case of a game or an application). Your data session will end, and you will be redirected to the appropriate phone menu screen.
 - Select **Set as** to assign a ringer or screen saver to a phone function.
 - Select **Shop** to browse for other items to download.
 - Press  to quit the browser and return to standby mode.

Tip: You can also access My Content Manager through the main menu. Highlight  and press  **> My Stuff > [Games, Ringers, Screen Savers, Applications or Call Tones] > My Stuff Manager**. The browser will open and take you to the corresponding content.

For complete information and instructions on downloading **Games, Ringers, Screen Savers**, and **Applications**, visit the Digital Lounge at www.sprint.com.

Applications

You can access a wide variety of applications in many different categories with your phone and data service. Your phone comes preloaded with links to the following applications:

- **Google**
- **NASCAR Sprint Cup Mobile**
- **Sprint Football Live**
- **ScanLife**
- **Sprint Social Zone**
- **MySpace**
- **Facebook**

● Twitter

Important Privacy Message – Sprint's policies often do not apply to third-party applications. Third-party applications may access your personal information or require Sprint to disclose your customer information to the third-party application provider. To find out how a third-party application will collect, access, use, or disclose your personal information, check the application provider's policies, which can usually be found on their website. If you aren't comfortable with the third-party application's policies, don't use the application.

Google

Launching Google via the Carousel

This page provides access to Web features such as Google™ search, online Maps, Gmail™, and YouTube™.

1. From carousel, select .
2. Select an onscreen option: **Google search**, **Maps**, **Gmail**, or **YouTube**.
3. Follow the onscreen instructions.

Using Google Search

1. From carousel, select .
2. Use the keyboard to enter a string into the search field and press .

NASCAR Sprint Cup Mobile

Now you have the ability to get every bit of NASCAR coverage, news, and stats right on your phone.

1. Highlight  and press  > **My Stuff** > **Applications** > **NASCAR Sprint Cup Mobile**.
– or –
Select  > **My Stuff** > **Applications** > **NASCAR Sprint Cup Mobile**.
2. Scroll down the list of available NASCAR drivers and press  to select your desired driver.
3. If prompted, read the permission check disclaimer, make a selection and press **OK** (left softkey). Follow the onscreen instructions until you reach the main NASCAR Sprint Cup Mobile page.

4. Navigate the main page by either scrolling around using your navigation key or pressing the directional keys.
5. Access any of the following onscreen options by highlighting a button and pressing . Features include:
 - **Home** to return to the main NASCAR homepage where you can view stats on a current race, choose to follow a specific driver, view special NASCAR promotions and other NASCAR-specific multimedia content.
 - **Point Standings** to display the current NASCAR point standings.
 - Press **HOME** (left softkey) to return to the main NASCAR page.
 - **Race Recap** provides overviews of the current races, pictures, commentary, additional photos, and race stats.
 - Press **HOME** (left softkey) to return to the main NASCAR page.
 - **Speed** displays a list of selectable multimedia video clips from the SPEED channel that are specific to NASCAR.
 - Press **HOME** (left softkey) to return to the main NASCAR page.
 - **All-Star** displays race stats, driver info, news, photos, etc. for the All-Star race.
 - **My Driver** to customize your NASCAR experience by following specific drivers. Information includes driver-specific stats and NASCAR RSS feeds. You can also get additional stats, review other driver info, or change drivers.
 - **Stats/Sched** lets you track race information such as: **NSCS Recap**, **NNS Recap**, **Point Standings**, **Season Stats**, and **Schdeule**.
 - **Miss Sprint Cup** is your insider to NASCAR by providing news, information, blogs and twitter updates to the goings-on within NASCAR.
 - **Video** displays a list of selectable multimedia content. Other features include streaming multimedia content from NASCAR radio stations or other racing radio shows.

- **News & Alerts** provides you with quick access to NASCAR-specific news, photos, and driver stats. You can also customize alerts for new information such as ALL NASCAR News, Sprint Cup News, etc.
- **Community** where you can connect with other NASCAR fans directly from your phone.
- **Fantasy** lets you take part in online fantasy racing, access **Games**, take part in **Polls**, and access other **Special Promotions**.
- **FanZone** displays a list of selectable content available to Sprint subscribers such as Sweepstakes and Video clips (footage and music).
- **Settings and Help** displays help information for usage of the NASCAR application and features.
- **EXIT** (right softkey) allows you to exit the NASCAR application. Press **YES** (left softkey) to exit.

Sprint Football Live

Get the Football live on your phone. It lets you be right in the middle of your favorite game by being a part of previews, blogs, discussions groups, fantasy football, etc.

1. Highlight  and press  > **My Stuff** > **Applications** > **Sprint Football Live**.

– or –

Select  > **My Stuff** > **Applications** > **Sprint Football Live**.

2. Select your favorite team.
3. Follow the remaining onscreen instructions to customize your football experience such as choosing your favorite team.
4. Access any of the following features by pressing **MENU** (right softkey):
 - **Draft** (default home page) displays a screen full of draft information such as Draft Coverage, Draft Insider, Exclusive Blog, Mock Drafts, and Draft Prospects.

- **Favorite Team** launches a team-specific page with content such as top stories, RSS feeds, Rumor information, Schedules, Team Alerts, and the ability to change your favorite team selection.
- **News** provides AP league news, Rumor and News, PFTV, Injury Info, Transactions, Legal, and other football related information, photos and videos.
- **Tweets** launches an onscreen Twitter page. Also included onscreen is a real-time RSS new feed.
- **Team Pages** allows you select from wither the AFC or NFC conferences, then display content such as top stories, RSS feeds, Rumor information, Schedules, Team Alerts, and the ability to change your favorite team selection.
- **Help/About** displays help information for Sprint Football Live topics such as: General, Home, News, Twitter, Team Page, About, or Alerts.

ScanLife

With ScanLife, you scan a 2D barcode (EZcode) with your camera phone and you're instantly connected to any information related to the scanned product, article, or image.

1. Highlight  and press  > **My Stuff** > **Applications** > **ScanLife**.
– or –
Select  > **My Stuff** > **Applications** > **ScanLife**.
2. Read the terms of use disclaimer, make a selection and press **Agree** (left softkey).
 - You can also press **Disagree** (right softkey).
3. With the camera feature now activated, position the camera so the EZcode is both centered in the viewfinder and takes up at least half the screen area.
 - A sample of an EZcode .

Note: Do not confuse EZcodes with the UPC barcodes currently used on most products, they are not the same.

4. Take the photo. If the scan was successful, you will hear a short chime and your browser will then launch to reveal more information associated with the selected EZcode. This can be either a specific Web page or downloadable content.

Sprint Social Zone

Social Zone provides users with a web-based social networking application and community sites that can help bring social networking to your mobile phone.

1. Highlight  and press  > **My Stuff** > **Applications** > **Social Zone**.
– or –
Select  > **My Stuff** > **Applications** > **Social Zone**.
2. Navigate among the various social network applications.
3. Highlight an application and press . Choose from: **Photobucket**, **Xanga**, **Black Planet**, **Asian Avenue**, **MiGente**, and **Glee**.
4. Follow the applications login and usage procedures.
5. Press **OPTIONS** (left softkey) > **Exit** to close the social zone application.

MySpace

MySpace is a popular social networking website that offers users an interactive portal within which they can submit personal profiles, blogs, groups, photos, and music among their peers.

Note: Before continuing with these steps you must first have an active MySpace account which is able to receive photo uploads.

1. Select .
2. Select the **Email** and **Password** fields and then enter your information using the keyboard.
3. Highlight **Submit** and press  to continue onto the site.

Adding MySpace as a New Place

1. Highlight  and press  > **Photos & Videos** > **My Photos & Videos** to view the **MY ALBUM** screen.
2. Select an image location (**In Phone** or **Memory Card**).
3. Highlight a picture or video to send and press .

4. Press **SEND** (left softkey). (You will see a message about updating your places list.)
5. Highlight **New Place...** and press .
6. Select **MySpace** and use your keyboard to enter the necessary login information (MySpace login and password).

Important: To automatically upload all new images and videos to your designated email address, enable the “**Automatically send...**”field.


7. Touch **Done** to complete the process.

Facebook

Facebook™ is a popular free-access social networking website where users can join networks organized by various criteria and then interact with other connected people. Users can both add friends and send them messages, as well as update their personal profiles to notify friends about new ideas, actions, status, etc..

Note: Before continuing with these steps you must first have an active Facebook account.

1. Select .
2. Select the **Email** and **Password** fields and then enter your information using the keyboard.
3. Highlight **Login** and press  to continue onto the site.
4. Navigate through the pages.



Adding Facebook as a New Place

1. Highlight  and press  > **Photos & Videos** > **My Photos & Videos** to view the **MY ALBUM** screen.
2. Select an image location (**In Phone** or **Memory Card**).
3. Highlight a picture or video to send and press .
4. Press **SEND** (left softkey). (You will see a message about updating your places list.)
5. Highlight **New Place..** and press .

6. Select **Facebook** and use your keyboard to enter the necessary login information (Facebook login and password).

Uploading Photos to Your Facebook Page

1. Highlight  and press  > **Photos & Videos** > **My Photos & Videos** to view the **MY ALBUM** screen.
2. Select an image location (**In Phone** or **Memory Card**).
3. Highlight a picture or video to send and press .
4. Press **SEND** (left softkey). (You will see a message about updating your places list.)
5. From the **MY PLACES** screen, select **Facebook** and choose your album to begin queuing your media file for upload.

Twitter

Twitter™ is a free social networking and micro-blogging service where its users can send and read each others' updates, known as "tweets".

Tweets are text-based posts of up to 140 characters, displayed on the author's profile page and delivered to other users (or subscribers).

Users can send and receive tweets via the Twitter website, Short Message Service (SMS) or external applications. The Twitter service may incur data fees.

Note: Before continuing with these steps you must first have an active Twitter account.

1. Select .
2. Select the **Username** and **Password** fields and then enter your information using the keyboard.
3. Highlight **Sign In** and press  to continue onto the site.
4. Navigate through the pages.

Best of Green

With Best of Green, you have instant access to a collection of green, earth-friendly information and tips.

1. Select .

2. Highlight one of the following options and press :
- **Five Simple Things** to show how you can make a big difference for the environment by making simple changes, from how you commute to what you eat for dinner.
 - **Green Guides** for access to handy guides that will help you "green" your life with ease, and understand why.
 - **Green Glossary** to learn every word and explanation you need to know about the Earth and climate change--from acid rain to wind power, this is your go-to green glossary.
 - **All Things Green** to find up-do-date green headlines, green websites, links to downloadable content, and green text alert options.

Data Services FAQs

How will I know when my phone is ready for data service?
Your user name (for example, bsmith01@sprintpcs.com) will be displayed when you access **Menu > Settings > Phone Information > Phone Number/User ID**.

How do I sign in for the first time?

You are automatically signed in to access data services when you turn on your phone.

How do I know when my phone is connected to data services?

Your phone automatically connects when you use data service or an incoming message arrives. You will also see the  or  indicator.

Can I make calls and use data services at the same time?

You cannot use voice and data services simultaneously. If you receive a call while data service is active, your phone forwards the call to voicemail. You can place an outgoing call anytime, but it will interrupt any in-progress data session.

When is my data connection active?

Your connection is active when data is being transferred. Outgoing calls are allowed; incoming calls go directly to voicemail. When active, the  or  indicator is animated on the display screen.

When is my data connection dormant?

If your phone receives no data for 10 seconds, the connection goes dormant. When the connection is dormant, you can make and receive voice calls. (The connection may become active again quickly.) If your phone receives no data for an extended period, the connection will terminate.

Can I sign out of data services?

You can sign out without turning off your phone; however, you will not be able to browse the Web or use other data services. While signed out, you can still place or receive phone calls, check voicemail, and use other voice services. You may sign in again at any time. To sign out, go to  > **Settings** > **Others** > **Data** > **On/Off** > **Disable Sprint Data Services** in your phone's menu.

3C. Entertainment: TV and Music

- ◆ TV (page 151)
- ◆ Music – Sprint Music Store (page 154)
- ◆ Streaming Music (page 160)

Sprint TV gives you the ability to listen to audio clips and to view video clips right from your phone's display. Watch live TV and catch up on episodes of your favorite shows – anywhere on the Nationwide Sprint Network.*

Sprint Music lets you preview, purchase, download, and listen to over a million songs right on your phone. You can even add songs from your own library to round out your on-the-go playlist.

* Sprint TV coverage not available everywhere. Content and lineup subject to change. Select channels also available for casual usage. Visit www.sprint.com/tvguide for more information.

TV

Your Sprint TV Channel Options

The Sprint TV application offers a wide variety of accessible channels. Subscription options include comprehensive basic packages as well as a full menu of “a la carte” channels. Visit www.sprint.com/tvguide for more information on channels and pricing.

Some of the available categories may include:

- Sprint Radio
- Primetime TV
- Sprint TV Live
- Sports
- Cartoons
- Movies & Shorts
- Sprint Power View
- Music Videos
- Music & Radio
- Entertainment
- News & Weather
- Mobile Previews

Note: Available categories and content are subject to change.

Watching TV

1. Highlight  and press  > **Entertainment** > **Sprint TV** > **TV**. Depending on your settings, your phone may prompt you to accept a data connection.
2. Select **Featured**, **Recommended**, **Recently Played**, **All Channels**, **Live**, or **On Demand** to display channel options.
3. Navigate around by either scrolling up over your navigation key or using your keyboard's directional keys and press the channel icon to view the current channel from the Sprint TV listings or to select an available category. Current channel will continue to play on top till you select another channel.

Note: The first time you access a channel, the system will prompt you to purchase access (unless the channel doesn't have a monthly fee). Select **Subscribe** to purchase access, or select **Preview** to view a preview of the selected channel.

4. If applicable, highlight a clip and press  to view the program. The clip will automatically load and begin playing.

Tip: While you are playing a clip, you can press the navigation key up or down to surf to a different channel. You will see a small pop-up screen that tells you which channel you are watching as well as other channels that you have access to. Use the navigation key to scroll through the channels. Once you find a channel that you want to watch or listen to, scroll to it and press  (or simply wait approximately three seconds), and the channel will begin loading.

TV FAQs

1. **Will I know if I'm receiving an incoming call while I'm viewing or listening to a media clip?**

Yes. All incoming calls will stop the Sprint TV app and provide you with the option to either **SILENCE** (left softkey) or **IGNORE** (right softkey). The Sprint TV application will start from beginning after rejecting or ending the call. All interruptions such as a new message / Voicemail / Alarm / Calendar notifications stops the Sprint TV app and provides you with the corresponding notification. The Sprint TV application will start from beginning after returning back from the notifications.

2. **How long are the clips? Will I know the estimated time it will take to play the clip prior to accessing it?**
Once you have selected a channel, you will see a listing of the available clips, with each clip's length displayed after the clip's title. In general, a clip's duration will depend on the story or content being provided, and can be fairly short or as long as a few minutes.
3. **Can I access a clip wherever I am, as long as I have my phone?**
As long as you are on the Nationwide Sprint Network, you will have access to the audio and video clips.

Note: Sprint TV service does not work while roaming off of the Nationwide Sprint Network or where service is unavailable.

4. **Are the videos that I'm viewing "live" videos?**
It depends on the content provider. Some of the channels available through Sprint TV stream live content. Others provide media on demand with video and audio clips that are refreshed throughout the day, but that are not "live."

5. **After purchasing access to an Available Channel for a monthly fee, do I receive any confirmation? That is, how do I know it has been purchased?**
The next time you access the channel, you bypass the Preview/Purchase page and go directly to the available content.
6. **If I don't subscribe to a data plan, will I still be able to view the multimedia clips?**
Yes. For service access charges, please consult your Sprint service plan or visit www.sprint.com.
7. **What does it mean when the video pauses and I see the word "loading" at the bottom of the screen?**
This happens when the phone is loading the data necessary to play the clip. It typically occurs when there is heavy traffic on the network.
8. **How can I cancel service if I decide I don't want it?**
To cancel your Sprint TV service, visit www.sprint.com and sign on to **My Sprint** with your account number and password. From this page, you have the ability to cancel the service or any channels to which you subscribe.

9. **If I put on my stereo headset and insert it into the phone's headset jack, can I close the phone while I am playing an audio (or video) clip without interrupting the clip?**

Yes. When you insert your stereo headset into the phone's headset jack, the phone automatically goes into "headset mode," allowing you to close the phone and continue playing the clip. (Likewise, if your phone is in "headset mode," a phone call will not disconnect when you close the phone.)

10. **Can I surf to a different channel while I am playing a clip?**

Yes. While you are playing a clip, you can use the up and down navigation keys to surf to a different channel. You will see a small pop-up screen that tells you which channel you are watching as well as other channels that you have access to. Use the navigation keys to scroll through the different channels. Once you find a channel that you want to watch, scroll to it and press  (or simply wait approximately three seconds), and the channel will begin loading.

Music – Sprint Music Store

The Sprint Music Store lets you purchase and download digital music files to play on your phone or computer.

Note: A microSD memory card must be inserted in the phone prior to using the Sprint Music function.

Accessing the Sprint Music Store

You can access the Sprint Music Store right from your phone's main menu, anywhere on the Nationwide Sprint Network. When you enter the store for the first time, the system will prompt you to set up your user identification and password.

1. Highlight  and press  > **Entertainment** > **Music**.
2. If prompted, follow the onscreen instructions to establish your User ID and password.

Tip: Your User ID for the Sprint Music Store is your 10-digit wireless phone number. The password may be any 4-digit number.

3. After you have entered your password, highlight **Create New Account** and press .

4. Use your keypad and navigation key to explore the store.

Note: With a formatted microSD card, there are no default folders created. Upon access to the Music Player, the Music/Tone folders are also created.

Purchasing and Downloading Music

Now that you're in the store, you can shop for songs to purchase and download to your phone's microSD card.

1. From the Sprint Music Store opening page, press **Menu** (right softkey) and select **Store Search** to browse the store. Other options include:
 - **Home** to navigate to the music store home page.
 - **Now Playing** to display the information on the current file being played.
 - **My Library** displays a list of your currently available music files.
 - **Store Search** gives you the option of searching for specific songs or artists. Just use your keypad to enter your search criteria in the available field.

2. Highlight a song and press . (You will see the song information screen.)
3. Highlight an option and press :
 - **Preview** to play an audio clip of the selected song.
 - **Buy Song** to purchase the song and download it to your phone's microSD card.
 - When you select **Buy Song**, the file will download to your phone's microSD card. (If there is no microSD card installed or if there is not enough free memory space on the card, you will see an alert.)
 - Once the song has been downloaded to your microSD card, you will see options allowing you to listen to the song, add it to a playlist, or continue shopping.

Playing Music From the Sprint Music Store


The Sprint Music Store not only gives you access to great music, it also gives you a place to listen to and organize your music library.

Accessing the Music Player

1. From the Sprint Music Store opening page, press **Menu** (right softkey) and select **My Library**.

- If prompted, highlight **Update My Library** and press  to re-index your microSD card's **Music** folder and list all available music files.

2. Highlight **My Library** and press .
3. Make your selection based on category types or use the **Search** field to look for a specific music file.
4. To play a song, highlight it and press .




Accessing the Music Player Configuration

1. Launch the Sprint Music Store application. (Highlight  and press  > **Entertainment** > **Music**.)

2. From the Sprint Music Store opening page, press **Menu** (right softkey) and select **My Library**.

- Select **Update My Library** and press **OK** to update the content of your current library (if new material was recently added).

3. Select a category.
4. Highlight a file and press  to play the selected song.



5. From the Player display, press **Menu** (right softkey) and select an option:
 - **View Tracklist** display information for the currently playing song.
 - **Add to Playlist** inserts the current song into a previously created playlist.
 - **Switch shuffle on/off** toggles the activity state of the shuffle feature that randomly selects different songs from your currently available music files.
 - **Switch repeat on/off** toggles the activity state of the repeat function that repeats the current song once completed.
 - **Delete Track** to delete the track from your current list of available music files. From the confirmation screen, press **OK** (left softkey) to confirm deletion or **CANCEL** (right softkey) to quit this operation.
 - **Exit** to exit the music player application.

To create a playlist:

1. From the My Library screen, select **Playlists > Create Mobile Playlist. > Add Tracks.**
2. From the **ALL TRACKS** screen, select the songs you want to add to the new playlist.

3. Press **DONE** (right softkey) to complete the creation process and return to the **MY MOBILE PLAYLIST** screen.

Backing Up Your Downloaded Music Files

Sprint recommends you back up your downloaded music files to your computer. Although the downloaded files can only be played on your phone and on your account, backing them up to your computer lets you access the files in case your microSD card is lost or damaged, or if you install a new microSD card. See “Connecting Your Phone to Your Computer” on page 95.

1. Connect your phone using a USB cable or the built-in connection on Bluetooth-enabled phones.
2. Use your computer to navigate to the microSD card’s **Music** folder.
3. Select and copy the music files to a folder on your computer’s hard drive.

Note: Although you can store purchased and downloaded music files on your computer, they will only be playable on your phone and on your account.

If you copy the files to a new microSD card, you will need to create a folder on the card called “**Music**” to be able to play the music files.

Multitasking

Multitasking is a way of maintaining one application active while using another. While your current music selection is playing, you can activate the Application Manager screen and choose from a list of available applications which can be run in tandem with your music.


To multitask on your phone:

1. Launch the Sprint Music Store application.
(Highlight  and press  > **Entertainment** > **Music**.)
2. From the Sprint Music Store opening page, press **Menu** (right softkey) and select **My Library**.

3. Highlight a file and press  to play the selected song.
4. Press  to exit the Music Store application without closing it and launch the popup menu, where you can choose from the following options: **Resume**, **Exit**, **App.Manager**, and **Send to Background**.
 - If you press  from the **DO YOU WANT TO EXIT** screen, the phone will reactivate the song's playback screen and resume playback.
5. Highlight **App. Manager** and press  to launch an Application Manager screen which provides you access to several applications:
 - Application Manager manages all currently active applications. With your music still playing, the Sprint Music Store entry appears in the list.

6. Press **OPTIONS** (right softkey) to access the following management options:

- **Bring to Foreground** reactivates the current application screen. For example, if your music is currently playing in the background, selecting this option activates the Player tab with the song displayed.
- **Exit Application** terminates the currently selected application and returns you to the standby screen.
- **Exit All Background** terminates all currently active applications and returns you to the standby screen.
- **Launch New App** allows you to launch an application from the My Stuff listing.



Receiving an Incoming Call While Playing Music

An incoming call pauses the currently playing music file while the phone call is active. Once you end the call, the paused music resumes playing automatically.)

1. Answer an incoming call by highlighting **Answer** and pressing




– or –

Press .

2. When you are done with your call, press  to end the call. The previously paused application then resumes.

Note: When placing an outgoing call, the Application Manager pauses your current music playback and allows you to proceed with your outgoing call. When you end the call, the Application Manager restarts the music playback.



If the phone is running more than one simultaneous application (such as **Music Store**, **Application** [from **My Stuff**], and **Games**), the user interface can begin to slow down and result in music or sound interruptions.

- To solve this type of issue, it is best to close down all other applications (highlight  and press  > **My Stuff > Application Manager > Options > Exit All Background**) before initiating a new application.

Also, in some situations, the camera or camcorder may have limited functionality or become unavailable. For example, if you were currently playing music (via the Music Store), or playing a game in the background, and then wanted take a photo, the phone may prompt you with a “CPU Low, Kill the Application” dialog.

This indicates that the current phone resources are low and you should terminate one of the current applications before continuing. Refer to the procedure above to exit either a specific application or all current applications, and then launch the camera or camcorder again.

Streaming Music

In addition to the Sprint Music Store, Sprint offers a variety of musical options through the Music category in the Sprint TV menu, including SIRIUS Music, Music Choice, VH1, and many others. Choose from rock, pop, hip-hop, and R&B, and access exclusive video clips, music industry news, performances, and interviews with your favorite artists.

1. Highlight  and press  > **Sprint TV > Radio > [selection]**.
 - The keyboard directional keys (up/down/left/right) are best suited for navigation around this screen and among the various stations.
 - To make a selection using the keyboard, highlight an station and press .

Note: If a streaming type (TV, Radio, etc..) can not be selected via the directional arrows, scroll using the navigation key.

2. Select **Preview** to see and hear a preview of your selected channel (if available).
 - or –
 - Select **Subscribe** to purchase a monthly subscription to your selected channel.
 - Once you have purchased access to a music or radio channel, you can select from a variety of stations to listen to your favorite music or get caught up on what's new in music.
3. From the station preview window you can choose from several onscreen options:
 - **Information** to display station information.
 - **Channel listing** to display the available channel listing at the bottom of the current preview window.
 - **Add to favorites** to add the current station to your favorites list.
 - **Scale** to rescale the current song album art.

3D. GPS Navigation

- ◆ GPS Services (page 162)
- ◆ Sprint Navigation (page 162)
- ◆ Sprint Family Locator (page 164)
- ◆ Getting Driving Directions (page 164)
- ◆ Configuring Your Navigation Preferences (page 170)
- ◆ Launching the Product Tour (page 172)

GPS Services

Your phone's built-in GPS capability gives you access to a number of location-based services, including **Sprint Navigation** and **Sprint Family Locator**.

Activating Location Mode

Before using any of the location-based services, you must turn on your phone's location mode.

1. Highlight  and press  > **Settings** > **Location**. (You will see the Location disclaimer.)
2. Read the disclaimer and press **OK** (left softkey).
3. Highlight **On** and press .
4. Press **DONE** (left softkey) to complete the process.

Sprint Navigation

Sprint Navigation gives you turn-by-turn directions onscreen and over speakerphone.

Note: Depending on your service plan, Sprint Navigation may require a monthly subscription. Contact Sprint for information and pricing.

Note: Some features may be available only with a subscription to Sprint Navigation Premium.

Registering Sprint Navigation

Before you can use Sprint Navigation, your phone and service must be registered.

1. Highlight  and press  > **Maps** > **Sprint Navigation**.
– or –
Select  > **Drive To**.
2. Read the onscreen terms and Conditions and press **Accept** (right softkey) to agree to these terms of service.
3. Follow the onscreen instructions to enter and submit the required information.

Using Sprint Navigation

1. Highlight  and press  > **Maps** > **Sprint Navigation**.
2. Select an option and follow the onscreen instructions to get directions or view maps.
 - **Drive To** lets you enter an address (vocally or using the keypad) or select from categories such as:
 - **My Favorites**: user-defined favorite locations.
 - **Recent Places**: recently entered locations.
 - **Address**: manually entered street addresses.

- **Intersection**: used to locate a specific address by using two separate street addresses to identify an intersection.
 - **City**: used when you do not know a physical address but would like driving directions to a city.
 - **Business**: locations based on business categories.
 - **Airport**: local airports based on current GPS location.
- **Search** lets you search for locations based on Name, Category, or Location. You can choose **Type it** or **Speak it** to begin your search.
 - Category entries include options such as Food/Coffee, Gas Stations, Gas by Price, Banks/ATMs, WiFi Spots, Parking Lots, Hotels & Motels, and Movie Theaters.
 - **Maps & Traffic** lets you view maps and get traffic information for your current location or for any other location (same categories as Drive To).

- **Share & More** offers additional options, such as sharing your location with contacts, creating and storing My Favorites locations, accessing the product tour, and setting detailed application preferences.

Note: For more information about Sprint Navigation, visit www.sprint.com/navigation.

Sprint Family Locator

Sprint Family Locator uses GPS technology to locate your child's phone and display the location on an interactive map.

Note: Sprint Family Locator service requires an additional monthly fee. Visit www.sprint.com/familylocator for complete details.

Signing Up for Sprint Family Locator

1. Highlight  and press  > **Maps** > **Sprint Family Locator**.
2. Follow the onscreen instructions to enter and submit the required information.

Note: You can also sign up for Sprint Family Locator online at www.sprint.com/familylocator.

Using Sprint Family Locator

1. Highlight  and press  > **Maps** > **Sprint Family Locator**.
2. Enter the parent phone number and password to sign in to your account.
3. Select a phone to locate from the available child phone list.
4. When you are finished, select **Sign Out**.

Note: You may also use Sprint Family Locator with any computer with an Internet connection. Visit www.sprint.com/familylocator for complete details.

Getting Driving Directions

The built-in GPS hardware (when enabled) allows you to get driving directions to selected locations or establishments based on your current location.

Using a Physical Address

1. Highlight  and press  > **Maps** > **Sprint Navigation** > **Drive To**.
– or –
Select  > **Drive To**.
2. Highlight **Address** and press .
3. Highlight **Type It** and press .
 - **Type It** requires that you enter the physical address using either the keypad or keyboard.
 - **Speak It** to place a call to the TeleNav™ operator where you will speak the desired address. This is similar to calling 411 for directory assistance. (A fee may be incurred.)
4. If typing in the address, enter the following:
 - **Address**: used to enter a specific address by using a number, street name, and city/state or zip code.
 - **City**: used when you do not know a physical address but would like driving directions to a city.


- As you enter in the text, a list of possible city matches appears onscreen. Use your navigation key to choose one and press .

- **State, ZIP** or **Country** used when the specific address information is not available but you would like to provide some general driving parameters.

5. Press **GO** (right softkey) to enter the new address and receive driving directions from the GPS network.
6. Press  to begin the navigation session.

Note: When similar address matches are found, select the appropriate match and press .

7. Follow both the onscreen and audio directions.



Navigation Screen

Once you have entered your desired location and your phone has begun providing you with driving directions, you can alter the information being displayed by using one of three other driving options, press **Option** (right softkey): **3D Moving Maps**, **2D Moving maps**, **Turn Icons**, **Recalculate route**, **Map Summary**, **Route Summary**, **Traffic Summary**, and **Search Along**.

To review real-time traffic information along your route:

1. Highlight and press > **Maps > Sprint Navigation > Drive To**.
– or –
Select > **Drive To**.
2. Highlight **Address** and press .
3. Enter the physical address information. See “Using a Physical Address” on page 165.
4. Press **Options** (right softkey) > **Traffic Summary** and press . This action displays onscreen current traffic conditions along your current route.
5. Press **Back** (left softkey) to return to your previous driving screen.

To receive turn by turn directions (2D):

1. Highlight and press > **Maps > Sprint Navigation > Drive To**.
– or –
Select > **Drive To**.
2. Highlight **Address** and press .

3. Enter the physical address information. See “Using a Physical Address” on page 165.
4. Press **Options** (right softkey) > **2D Moving Maps** and press . This action provides both an outlined map view and a detailed turn by turn description for navigating to your desired location.

To search nearby locations based on type:

1. Highlight  and press  > **Maps > Sprint Navigation > Drive To.**
– or –
Select  > **Drive To.**
2. Highlight **Address** and press .
3. Enter the physical address information. See “Using a Physical Address” on page 165.
4. Press **Options** (right softkey) > **Search Along** and press . This allows you to then search for a location based on a name, location, or category such as Food/Coffee, etc.
 - See “Using a Local Business Category” on page 167.

Using a Local Business Category

The Restore™ can also cross-reference your current location with local business and points of interest, such as Grocery Stores, Gas Stations, Wi-Fi Spots, Malls, Hospitals, etc.

1. Highlight  and press  > **Maps > Sprint Navigation > Drive To.**
– or –
Select  > **Drive To.**
2. Highlight **Business** and press .
3. Select a desired field and then use either your keypad or keyboard to enter the information.
 - **What** lets you use a keyword search for your business.
 - **Category** lets you refine your search by using a business category type such as: **Food/Coffee, Gas Stations, Banks/ATMs, WiFi Spots, Parking Lots, Hotels & Motels**, etc...

- **Where** returns you to the Search Near page where you can choose from a set of seven location categories.

- Entries with more than one available category (a subcategory) appear with an adjacent gray arrow. These entries can be expanded and then closed.

To organize and arrange your search results:

1. Select a category entry from the Search page. By default the Search Results page lists the Best Matches based on closest location first (top).
2. Highlight an onscreen location and press .
3. Press **Options** (right softkey) to apply the available filter options to best display the matching results:
 - **Map Results**: overlaps your current list over a map of your current location. The numeric onscreen entries correspond to your current sorted list.
 - **Sort by Relevance**: sorts a list of matching results by placing the most likely match (to your present search criteria) at the top and least likely at the bottom.

- **More Results**: sorts the results by additional criteria.

To search for the least expensive gas in your area:

1. Highlight  and press  > **Maps > Sprint Navigation > Search > Type It > Category > Gas By Price**.
 - or –
 - Select  > **Search > Type It > Category > Gas By Price**.
2. Select a grade of gasoline: **Any, Regular, Plus 89, Premium, or Diesel**.
 - By default the Search Results page lists the Best Price at the top of the list.
3. Highlight **Search** and press **Go** (right softkey).
4. Highlight a gas station from the list, and press .
5. With the destination information onscreen, press **Options** (right softkey) and select **Drive To** to be provided with a new route to the selected gas station.
 - See “Using a Physical Address” on page 165.

Creating a My Favorites Location

Once you have begun using Sprint Navigation to find your destination, you can then either recall those locations and add them to your list of favorite destinations or create a new entry from one of the available location categories (Address, Business, Airport, or Contacts).

To create a My Favorites entry from your Current Location:

1. Highlight  and press  > **Maps > Sprint Navigation > Share & More > Record Location.**
– or –
Select  > **Share & More > Record Location.**
2. Press **GO** (right softkey) and enter a label for the newly stored location.
3. Press **GO** (right softkey).

To create a My Favorites location from a Recent Place:

1. Highlight  and press  > **Maps > Sprint Navigation > Drive To > Recent Places.**
– or –
Select  > **Drive To > Recent Places.**

2. Select an entry from the list and press **Options** (right softkey) > **Save as Favorite.**
3. Enter a label for the newly stored location.
4. Select the **Save** field.

Sharing a Recent Location with Others

Recently queried locations can be saved to your My Favorites list and also shared with other cellular devices.

1. Highlight  and press  > **Maps > Sprint Navigation > Share & More > Share Address.**
– or –
Select  > **Share & More > Share Address.**
2. Highlight the Address field and press .
3. Select a category from the Share Address page, such as your Current Location, My Favorites location, Recent Places, etc..
4. Highlight an address and press . You are then returned to the previous Share Address page.

5. Select a recipient by selecting the **Sent To** field, pressing , and then choosing from one of the following options:
 - Use either the keypad or keyboard to manually enter the recipients phone number.
– or –
 - Choose an existing Contacts entry and press .
 - **Select from Contacts** to use the **Find** search field to select a recipient from your Contacts (qualifying Contacts entries must contain a wireless phone number).

Note: Only Contact entry numbers that are associated to a Mobile profile are allowed to receive this address information. The target phone number must be assigned to a Mobile profile.

6. Select **Continue** (right softkey) to store the recipients and return to Share Address page.
7. Select **Send Now** to complete the delivery process.

Configuring Your Navigation Preferences

1. Highlight  and press  > **Maps > Sprint Navigation > Share & More > Preferences**.
– or –
Select  > **Share & More > Preferences**.
2. Scroll down the list and select an entry to change its current setting:
 - **General:** allows you to configure application settings such as:
 - **My Name:** allows you to alter the current first and last name registered with the service.
 - **Region:** allows you to select your current region. Default: North America.
 - **Language:** allows you to change the language currently used for announcements. Default is **English (US)**.
 - **Distance Units:** allows you to alter the descriptions used for distances: **Miles/Feet** (Miles/Feet) or **Kilometers/Meters**.

- **Help Card:** allows you to configure the settings for the onscreen help message (card). Options include: **Always On** or **Always Off**.
- **Exit after (minutes):** turns the application off after there has been no activity for 20 minutes.
- **Map Colors:** allows you to configure the appearance of the onscreen map. Options include: **Auto**, **Daytime**, or **Nighttime**.
- **Init Volume:** allows you to assign the initial default volume level for the audio readout. Options include: **Normal**, **Very Soft**, **Soft**, **Loud**, and **Very Loud**.
- **Navigation:** allows you to configure navigation-related parameters such as:
 - **Route Style:** allows you to choose the method which is used to provide you directions from Point A to Point B. The default is **Fastest route**. Choose from one of the following options: **Fastest**, **Shortest**, **Prefer Streets**, **Prefer Highway**, **Pedestrian**, or **Ask me each trip**.
 - **Avoid:** allows you to specify those in-route obstacles that should be avoided during configuration of the best route. Options include: **HOV Lanes**, **Tolls**, and **Traffic Delays**.
- **Moving Maps:** allows you to select the default map type displayed for your navigation: **3D Moving Maps** or **2D Moving Maps**.
- **Backlight:** allows you to configure the Backlight setting between **On**, **Off**, or **On at Turns**.
- **Traffic Alerts:** allows you to either enable (**On**) or disable (**Off**) real-time traffic alerts along your current route.
- **Navigation Audio:** allows you to choose whether the street names are announced during your navigation.
 - **Settings:** allows you to configure the level of audio detail given for directions. Options include: **Full Audio**, **Instructions Only**, or **No Audio**.
 - **Guide Tone:** allows you to configure a voice type of the audio readout. Options include **Sara(English)** or **Maria(Spanish)**.

- **Speech Input:** allows you to configure how the application handles spoken input into the system.
 - **Input Method** (available with Sprint Navigation Premium): to enter input data into the system. Options are **Speak In Directly** or **Call In**.
 - **Address Input:** to determine how address data is input into the system. Options are **Always Ask**, **Always Speak In**, or **Always Type In**.
 - **Search Input:** to determine how search data is input into the system. Options are **Always Ask**, **Always Speak In**, or **Always Type In**.
- **Opt-in Features** (available with Sprint Navigation Premium): allows you to enable/disable additional customer deals/offers. Options are: **Messages from Merchant**, **Deals**, **Menu**, or **Sponsored Results**.

Launching the Product Tour

- ▶ Highlight  and press  > **Maps > Sprint Navigation > Share & More > Product Tour.**
- or –
- Select  > **Share & More > Product Tour.**

Section 4

***Safety and Warranty
Information***



4A. Important Safety Information

- ◆ General Precautions (page 174)
- ◆ Maintaining Safe Use of and Access to Your Phone (page 175)
- ◆ Using Your Phone With a Hearing Aid Device (page 176)
- ◆ Caring for the Battery (page 178)
- ◆ Radio Frequency (RF) Energy (page 179)
- ◆ Owner's Record (page 181)
- ◆ User Guide Proprietary Notice (page 181)

This phone guide contains important operational and safety information that will help you safely use your phone. Failure to read and follow the information provided in this phone guide may result in serious bodily injury, death, or property damage.

General Precautions

There are several simple guidelines to operating your phone properly and maintaining safe, satisfactory service.

- To maximize performance, do not touch the bottom portion of your phone where the internal antenna is located while using the phone.
- Speak directly into the mouthpiece.
- Avoid exposing your phone and accessories to rain or liquid spills. If your phone does get wet, immediately turn the power off and remove the battery.
- Do not expose your phone to direct sunlight for extended periods of time (such as on the dashboard of a car).
- Although your phone is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending, or sitting on it.
- Any changes or modifications to your phone not expressly approved in this document could void your warranty for this equipment and void your authority to operate this equipment.

Note: For the best care of your phone, only Sprint-authorized personnel should service your phone and accessories. Failure to do so may be dangerous and void your warranty.

Maintaining Safe Use of and Access to Your Phone

Do Not Rely on Your Phone for Emergency Calls

Mobile phones operate using radio signals, which cannot guarantee connection in all conditions. Therefore you should never rely solely upon any mobile phone for essential communication (e.g., medical emergencies). Emergency calls may not be possible on all cellular networks or when certain network services or mobile phone features are in use. Check with your local service provider for details.

Using Your Phone While Driving

Talking on your phone while driving (or operating the phone without a hands-free device) is prohibited in some jurisdictions. Laws vary as to specific restrictions. Remember that safety always comes first.

Tip: Purchase an optional hands-free accessory at your local Sprint Store, or call Sprint at 1-866-866-7509. You can also dial **#222** on your phone.

Following Safety Guidelines

To operate your phone safely and efficiently, always follow any special regulations in a given area. Turn your phone off in areas where use is forbidden or when it may cause interference or danger.

Using Your Phone Near Other Electronic Devices

Most modern electronic equipment is shielded from radio frequency (RF) signals. However, RF signals from wireless phones may affect inadequately shielded electronic equipment.

RF signals may affect improperly installed or inadequately shielded electronic operating systems or entertainment systems in motor vehicles. Check with the manufacturer or their representative to determine if these systems are adequately shielded from external RF signals. Also check with the manufacturer regarding any equipment that has been added to your vehicle.

Consult the manufacturer of any personal medical devices, such as pacemakers and hearing aids, to determine if they are adequately shielded from external RF signals.

Note: Always turn off the phone in healthcare facilities, and request permission before using the phone near medical equipment.

Turning Off Your Phone Before Flying

Turn off your phone before boarding any aircraft. To prevent possible interference with aircraft systems, the U.S. Federal Aviation Administration (FAA) regulations require you to have permission from a crew member to use your phone while the plane is on the ground. To prevent any risk of interference, FCC regulations prohibit using your phone while the plane is in the air.

Turning Off Your Phone in Dangerous Areas

To avoid interfering with blasting operations, turn your phone off when in a blasting area or in other areas with signs indicating two-way radios should be turned off. Construction crews often use remote-control RF devices to set off explosives.

Turn your phone off when you're in any area that has a potentially explosive atmosphere. Although it's rare, your phone and accessories could generate sparks. Sparks can cause an explosion or fire, resulting in bodily injury or even death. These areas are often, but not always, clearly marked. They include:

- Fueling areas such as gas stations.
- Below deck on boats.
- Fuel or chemical transfer or storage facilities.
- Areas where the air contains chemicals or particles such as grain, dust, or metal powders.
- Any other area where you would normally be advised to turn off your vehicle's engine.

Note: Never transport or store flammable gas, flammable liquids, or explosives in the compartment of your vehicle that contains your phone or accessories.

Restricting Children's Access to Your Phone

Your phone is not a toy. Do not allow children to play with it as they could hurt themselves and others, damage the phone or make calls that increase your Sprint invoice.

Please Note the Following Information When Using Your Handset

1. WARNING REGARDING DISPLAY

- The display on your handset is made of glass or acrylic and could break if your handset is dropped or if it receives significant impact. Do not use if screen is broken or cracked as this could cause injury to you.

2. WARRANTY DISCLAIMER: PROPER USE OF A TOUCH SCREEN HANDSET

- If your handset has a touchscreen display, please note that a touchscreen responds best to a light touch from the pad of your finger or a non-metallic stylus. Using excessive force or a metallic object when pressing on the touchscreen may damage the tempered glass surface and void the warranty. For more information, please refer to the "Manufacturer's Warranty" on page 182.

Using Your Phone With a Hearing Aid Device

A number of Sprint phones have been tested for hearing aid device compatibility. When some wireless phones are used with certain hearing devices (including hearing aids and cochlear implants), users may detect a noise which can interfere with the effectiveness of the hearing device.

Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference noise they may generate. ANSI standard C63.19 was developed to provide a standardized means of measuring both wireless phone and hearing devices to determine usability rating categories for both.

Ratings have been developed for mobile phones to assist hearing device users find phones that may be compatible with their hearing device. Not all phones have been rated for compatibility with hearing devices. Phones that have been rated have a label located on the box. **Your SPH-M570 has an M4 and T3 rating.**

These ratings are not guarantees. Results will vary depending on the user's hearing device and individual type and degree of hearing loss. If a hearing device is particularly vulnerable to interference noise; even a phone with a higher rating may still cause unacceptable noise levels in the hearing device. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements for hearing aid compatibility and are likely to generate less interference to hearing devices than unrated phones. (M4 is the better/higher of the two ratings.)

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. (T4 is the

better/higher of the two ratings. Note that not all hearing devices have telecoils in them.)

Note: New Technologies, Including Wi-Fi

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be newer wireless technologies (including Wi-Fi) used in this phone that have not been tested for use with hearing aids.

Hearing aid devices may also be measured for immunity to interference noise from wireless phones and should have ratings similar to phones. Ask your hearing healthcare professional for the rating of your hearing aid. Add the rating of your hearing aid and your phone to determine probable usability:

- Any combined rating equal to or greater than six offers excellent use.
- Any combined rating equal to five is considered normal use.
- Any combined rating equal to four is considered usable.

Thus, if you pair an M3 hearing aid with an M3 phone, you will have a combined rating of six for "excellent use." This is synonymous for T ratings.

Sprint further suggests you experiment with multiple phones (even those not labeled M3/T3 or M4/T4) while in the store to find the one that works best with your hearing aid device. Should you experience interference or find the quality of service unsatisfactory after purchasing your phone, promptly return it to the store within 30 days of purchase. (A restocking

fee may be applied to exchanges. Visit www.sprint.com/returns for details.) More information about hearing aid compatibility may be found at: www.fcc.gov, www.fda.gov, and www.accesswireless.org.

Getting the Best Hearing Device Experience With Your Phone

To further minimize interference:

- Set the phone's display and keypad backlight settings to ensure the minimum time interval:
 1. Highlight  and press  > **Settings > Display > Backlight Control > Backlight Dim or Backlight Off.**
 2. Highlight the minimum time interval setting and press .
- Position the phone so the internal antenna is farthest from your hearing aid.
- Move the phone around to find the point with least interference.

Caring for the Battery

Protecting Your Battery

The guidelines listed below help you get the most out of your battery's performance.

- Recently there have been some public reports of wireless phone batteries overheating, catching fire, or exploding. It appears that many, if not all, of these reports involve counterfeit or inexpensive, aftermarket-brand batteries with unknown or questionable manufacturing standards. Sprint is not aware of similar problems with Sprint phones resulting from the proper use of batteries and accessories approved by Sprint or the manufacturer of your phone. Use only Sprint-approved or manufacturer-approved batteries and accessories found at Sprint Stores or through your phone's manufacturer, or call 1-866-866-7509 to order. They're also available at www.sprint.com — click **Accessories**. Buying the right batteries and accessories is the best way to ensure they're genuine and safe.
- In order to avoid damage, charge the battery only in temperatures that range from 32° F to 113° F (0° C to 45° C).
- Don't use the battery charger in direct sunlight or in high humidity areas, such as the bathroom.
- Never dispose of the battery by incineration.
- Keep the metal contacts on top of the battery clean.
- Don't attempt to disassemble or short-circuit the battery.
- The battery may need recharging if it has not been used for a long period of time.
- It's best to replace the battery when it no longer provides acceptable performance. It can be recharged hundreds of times before it needs replacing.
- Don't store the battery in high temperature areas for long periods of time. It's best to follow these storage rules:
 - Less than one month:
-4° F to 140° F (-20° C to 60° C)

- More than one month:
-4° F to 113° F (-20° C to 45° C)

Disposal of Lithium Ion (Li-Ion) Batteries

Do not handle a damaged or leaking Li-Ion battery as you can be burned.

For safe disposal options of your Li-Ion batteries, contact your nearest Sprint authorized service center.

Special Note: Be sure to dispose of your battery properly. In some areas, the disposal of batteries in household or business trash may be prohibited.

Radio Frequency (RF) Energy

Understanding How Your Phone Operates

Your phone is basically a radio transmitter and receiver. When it's turned on, it receives and transmits radio frequency (RF) signals. When you use your phone, the system handling your call controls the power level. This power can range from 0.006 watt to 0.2 watt in digital mode.

Knowing Radio Frequency Safety

The design of your phone complies with updated NCRP standards described below.

In 1991–92, the Institute of Electrical and Electronics Engineers (IEEE) and the American National Standards Institute (ANSI) joined in updating ANSI's 1982 standard for safety levels with respect to human exposure to RF signals. More than 120

scientists, engineers and physicians from universities, government health agencies and industries developed this updated standard after reviewing the available body of research. In 1993, the Federal Communications Commission (FCC) adopted this updated standard in a regulation. In August 1996, the FCC adopted hybrid standard consisting of the existing ANSI/IEEE standard and the guidelines published by the National Council of Radiation Protection and Measurements (NCRP).

Body-Worn Operation

To maintain compliance with FCC RF exposure guidelines, if you wear a handset on your body, use a Sprint-supplied or Sprint-approved carrying case, holster or other body-worn accessory. If you do not use a body-worn accessory, ensure the antenna is at least **7/16 inch (1.5 centimeters)** from your body when transmitting. Use of non-Sprint-approved accessories may violate FCC RF exposure guidelines.

For more information about RF exposure, visit the FCC website at www.fcc.gov.

Specific Absorption Rates (SAR) for Wireless Phones

The SAR value corresponds to the relative amount of RF energy absorbed into the head of a user of a wireless handset.

The SAR value of a phone is the result of an extensive testing, measuring and calculation process. It does not represent how much RF the phone emits. All phone models are tested at their

highest value in strict laboratory settings. But when in operation, the SAR of a phone can be substantially less than the level reported to the FCC. This is because of a variety of factors including its proximity to a base station antenna, phone design and other factors. What is important to remember is that each phone meets strict federal guidelines. Variations in SARs do not represent a variation in safety.

All phones must meet the federal standard, which incorporates a substantial margin of safety. As stated above, variations in SAR values between different model phones do not mean variations in safety. SAR values at or below the federal standard of 1.6 W/kg are considered safe for use by the public.

The highest reported SAR values of the SPH-M570 are:

Cellular CDMA mode (Part 22):

Head: 0.72 W/kg; Body-worn: 0.98 W/kg

PCS mode (Part 24):

Head: 0.99 W/kg; Body-worn: 0.56 W/kg

FCC Radio Frequency Emission

This phone meets the FCC Radio Frequency Emission Guidelines.

FCC ID number: A3LSPHM570.

More information on the phone's SAR can be found from the following FCC website: <http://www.fcc.gov/oet/ea/>.

FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the direction of the internal antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

T9 Text Input is licensed by Nuance Communications, Inc. and is covered by U.S. Pat. 5,818,437, U.S. Pat. 5,953,541, U.S. Pat. 6,011,554 and other patents pending.

User Guide template version 9a_FM (April 2009)

Owner's Record

The model number, regulatory number, and serial number are located on a nameplate inside the battery compartment. Record the serial number in the space provided below. This will be helpful if you need to contact us about your phone in the future.

Model: SPH-M570 Restore™

Serial No.:

User Guide Proprietary Notice

CDMA Technology is licensed by QUALCOMM Incorporated under one or more of the following patents:

5,267,262	5,416,797	5,506,865
5,544,196	5,657,420	5,267,261
5,414,796	5,504,773	5,535,239
5,600,754	5,778,338	5,228,054
5,337,338	5,710,784	5,568,483
5,659,569	5,490,165	5,511,073

Important Safety Information

4B. Manufacturer's Warranty

◆ Manufacturer's Warranty (page 182)

Your phone has been designed to provide you with reliable, worry-free service. If for any reason you have a problem with your equipment, please refer to the manufacturer's warranty in this section.

For information regarding the terms and conditions of service for your phone, please visit www.sprint.com or call Sprint Customer Service at **1-888-211-4727**.

Note: In addition to the warranty provided by your phone's manufacturer, which is detailed on the following pages, Sprint offers a number of optional plans to cover your equipment for non-warranty claims. **Sprint Total Equipment Protection** provides the combined coverage of the **Sprint Equipment Replacement Program** and the **Sprint Equipment Service and Repair Program**, both of which are available separately. Each of these programs may be signed up for within 30 days of activating your phone. For more details, please visit your nearest Sprint Store or call Sprint at **1-800-584-3666**.

Manufacturer's Warranty

STANDARD LIMITED WARRANTY

What is Covered and For How Long?

SAMSUNG TELECOMMUNICATIONS AMERICA, LLC ("SAMSUNG") warrants to the original purchaser ("Purchaser") that SAMSUNG's phones and accessories ("Products") are free from defects in material and workmanship under normal use and service for the period commencing upon the date of purchase and continuing for the following specified period of time after that date:

Phone	1 Year
Batteries	1 Year
Leather Case	90 Days
Other Phone Accessories	1 Year

What is Not Covered?

This Limited Warranty is conditioned upon proper use of Product by Purchaser. This Limited Warranty does not cover: (a) defects or damage resulting from accident, misuse, abnormal use, abnormal conditions, improper storage, exposure to moisture or dampness, neglect, unusual physical, electrical or electromechanical stress, or defects in appearance, cosmetic, decorative or structural items, including framing, and any non-operative parts unless caused by SAMSUNG; (b) defects or damage resulting from excessive

force or use of a metallic object when pressing on a touch screen; (c) equipment that has the serial number or the enhancement data code removed, defaced, damaged, altered or made illegible; (d) any plastic surfaces or other externally exposed parts that are scratched or damaged due to normal use; (e) malfunctions resulting from the use of Product in conjunction or connection with accessories, products, or ancillary/peripheral equipment not furnished or approved by SAMSUNG; (f) defects or damage from improper testing, operation, maintenance, installation, service, or adjustment not furnished or approved by SAMSUNG; (g) defects or damage from external causes such as collision with an object, or from fire, flooding, sand, dirt, windstorm, lightning, earthquake, or from exposure to weather conditions, or battery leakage, theft, blown fuse, or improper use of any electrical source; (h) defects or damage caused by cellular signal reception or transmission, or viruses or other software problems introduced into the Product; (j) any other acts which are not the fault of SAMSUNG; or (i) Product used or purchased outside the United States. This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if (i) the battery has been charged by a battery charger not specified or approved by SAMSUNG for charging the battery, (ii) any of the seals on the battery are broken or show evidence of tampering, or (iii) the battery has been used in equipment other than the SAMSUNG phone for which it is specified.

What are SAMSUNG's Obligations?

During the applicable warranty period, SAMSUNG will repair or replace, at SAMSUNG's sole option, without charge to Purchaser, any defective component part of Product. To obtain service under this Limited Warranty, Purchaser must return Product to an authorized phone service facility in an adequate container for shipping, accompanied by Purchaser's sales receipt or comparable substitute proof of sale showing the original date of purchase, the serial number of Product and the sellers' name and address. To obtain assistance on where to deliver the Product, call Samsung Customer Care at 1-888-987-4357. Upon receipt, SAMSUNG will promptly repair or replace the defective Product. SAMSUNG may, at SAMSUNG's sole option, use rebuilt, reconditioned, or new parts or components when repairing any Product or replace Product with a rebuilt, reconditioned or new Product. Repaired/replaced cases, pouches and holsters will be warranted for a period of ninety (90) days. All other repaired/replaced Product will be warranted for a period equal to the remainder of the original Limited Warranty on the original Product or for 90 days, whichever is longer. All replaced parts, components, boards and equipment shall become the property of SAMSUNG. If SAMSUNG determines that any Product is not covered by this Limited Warranty, Purchaser must pay all parts, shipping, and labor charges for the repair or return of such Product.

What Are The Limits On Samsung's Warranty/liability?

SET FORTH IN THE EXPRESS WARRANTY CONTAINED HEREIN, PURCHASER TAKES THE PRODUCT "AS IS," AND SAMSUNG MAKES NO WARRANTY OR REPRESENTATION AND THERE ARE NO CONDITIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO:

- THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE;
- WARRANTIES OF TITLE OR NON-INFRINGEMENT;
- DESIGN, CONDITION, QUALITY, OR PERFORMANCE OF THE PRODUCT;
- THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR
- COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO.

NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. ALL IMPLIED WARRANTIES AND CONDITIONS THAT MAY ARISE BY OPERATION OF LAW, INCLUDING IF APPLICABLE THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY LIMITED TO THE SAME DURATION OF TIME AS THE EXPRESS WRITTEN WARRANTY STATED HEREIN. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED

WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE, USE, OR MISUSE OF, OR INABILITY TO USE THE PRODUCT OR ARISING DIRECTLY OR INDIRECTLY FROM THE USE OR LOSS OF USE OF THE PRODUCT OR FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL, CONSEQUENTIAL OR SIMILAR DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS, OR FOR DAMAGES ARISING FROM ANY TORT (INCLUDING NEGLIGENCE OR GROSS NEGLIGENCE) OR FAULT COMMITTED BY SAMSUNG, ITS AGENTS OR EMPLOYEES, OR FOR ANY BREACH OF CONTRACT OR FOR ANY CLAIM BROUGHT AGAINST PURCHASER BY ANY OTHER PARTY. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE. THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THIS PRODUCT AND STATES PURCHASER'S EXCLUSIVE REMEDY. IF ANY PORTION OF THIS LIMITED WARRANTY IS HELD ILLEGAL OR UNENFORCEABLE BY REASON OF ANY LAW, SUCH PARTIAL ILLEGALITY OR UNENFORCEABILITY SHALL NOT AFFECT THE ENFORCEABILITY FOR THE REMAINDER OF THIS LIMITED

WARRANTY WHICH PURCHASER ACKNOWLEDGES IS AND WILL ALWAYS BE CONSTRUED TO BE LIMITED BY ITS TERMS OR AS LIMITED AS THE LAW PERMITS.

THE PARTIES UNDERSTAND THAT THE PURCHASER MAY USE THIRD-PARTY SOFTWARE OR EQUIPMENT IN CONJUNCTION WITH THE PRODUCT. SAMSUNG MAKES NO WARRANTIES OR REPRESENTATIONS AND THERE ARE NO CONDITIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, AS TO THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE OR SUITABILITY OF ANY THIRD-PARTY SOFTWARE OR EQUIPMENT, WHETHER SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT IS INCLUDED WITH THE PRODUCT DISTRIBUTED BY SAMSUNG OR OTHERWISE, INCLUDING THE ABILITY TO INTEGRATE ANY SUCH SOFTWARE OR EQUIPMENT WITH THE PRODUCT. THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE AND SUITABILITY OF ANY SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT LIE SOLELY WITH THE PURCHASER AND THE DIRECT VENDOR, OWNER OR SUPPLIER OF SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT, AS THE CASE MAY BE.

This Limited Warranty allocates risk of Product failure between Purchaser and SAMSUNG, and SAMSUNG's Product pricing reflects this allocation of risk and the limitations of liability contained in this Limited Warranty. The agents, employees, distributors, and dealers of SAMSUNG are not authorized to make modifications to this Limited Warranty, or make additional warranties binding on SAMSUNG. Accordingly, additional

statements such as dealer advertising or presentation, whether oral or written, do not constitute warranties by SAMSUNG and should not be relied upon.

Samsung Telecommunications America, LLC

1301 E. Lookout Drive

Richardson, Texas 75082

Phone: 1-800-SAMSUNG

Phone: 1-888-987-HELP (4357)

©2010 Samsung Telecommunications America, LLC. All rights reserved.

No reproduction in whole or in part allowed without prior written approval. Specifications and availability subject to change without notice. [021710]

End User License Agreement for Software

IMPORTANT. READ CAREFULLY: This End User License Agreement ("EULA") is a legal agreement between you (either an individual or a single entity) and Samsung Electronics Co., Ltd. for software owned by Samsung Electronics Co., Ltd. and its affiliated companies and its third party suppliers and licensors that accompanies this EULA, which includes computer software and may include associated media, printed materials, "online" or electronic documentation ("Software"). BY CLICKING THE "I ACCEPT" BUTTON (OR IF YOU BYPASS OR OTHERWISE DISABLE THE "I ACCEPT", AND STILL INSTALL, COPY, DOWNLOAD, ACCESS OR OTHERWISE USE

THE SOFTWARE), YOU AGREE TO BE BOUND BY THE TERMS OF THIS EULA. IF YOU DO NOT ACCEPT THE TERMS IN THIS EULA, YOU MUST CLICK THE "DECLINE" BUTTON, DISCONTINUE USE OF THE SOFTWARE.

1. GRANT OF LICENSE. Samsung grants you the following rights provided that you comply with all terms and conditions of this EULA: You may install, use, access, display and run one copy of the Software on the local hard disk(s) or other permanent storage media of one computer and use the Software on a single computer or a mobile device at a time, and you may not make the Software available over a network where it could be used by multiple computers at the same time. You may make one copy of the Software in machine-readable form for backup purposes only; provided that the backup copy must include all copyright or other proprietary notices contained on the original.

2. RESERVATION OF RIGHTS AND OWNERSHIP. Samsung reserves all rights not expressly granted to you in this EULA. The Software is protected by copyright and other intellectual property laws and treaties. Samsung or its suppliers own the title, copyright and other intellectual property rights in the Software. The Software is licensed, not sold.

3. LIMITATIONS ON END USER RIGHTS. You may not reverse engineer, decompile, disassemble, or otherwise attempt to discover the source code or algorithms of, the Software (except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation), or modify, or disable any features of, the Software, or create derivative works

based on the Software. You may not rent, lease, lend, sublicense or provide commercial hosting services with the Software.

4. CONSENT TO USE OF DATA. You agree that Samsung and its affiliates may collect and use technical information gathered as part of the product support services related to the Software provided to you, if any, related to the Software. Samsung may use this information solely to improve its products or to provide customized services or technologies to you and will not disclose this information in a form that personally identifies you.

5. UPGRADES. This EULA applies to updates, supplements and add-on components (if any) of the Software that Samsung may provide to you or make available to you after the date you obtain your initial copy of the Software, unless we provide other terms along with such upgrade. To use Software identified as an upgrade, you must first be licensed for the Software identified by Samsung as eligible for the upgrade. After upgrading, you may no longer use the Software that formed the basis for your upgrade eligibility.

6. SOFTWARE TRANSFER. You may not transfer this EULA or the rights to the Software granted herein to any third party unless it is in connection with the sale of the mobile device which the Software accompanied. In such event, the transfer must include all of the Software (including all component parts, the media and printed materials, any upgrades, this EULA) and you may not retain any copies of the Software. The transfer may not be an indirect transfer, such as a consignment. Prior to the

transfer, the end user receiving the Software must agree to all the EULA terms.

7. EXPORT RESTRICTIONS. You acknowledge that the Software is subject to export restrictions of various countries. You agree to comply with all applicable international and national laws that apply to the Software, including the U.S. Export Administration Regulations, as well as end user, end use, and destination restrictions issued by U.S. and other governments.

8. TERMINATION. This EULA is effective until terminated. Your rights under this License will terminate automatically without notice from Samsung if you fail to comply with any of the terms and conditions of this EULA. Upon termination of this EULA, you shall cease all use of the Software and destroy all copies, full or partial, of the Software.

9. DISCLAIMER OF WARRANTIES. You expressly acknowledge and agree that use of the Software is at your sole risk and that the entire risk as to satisfactory quality, performance, accuracy and effort is with you. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE SOFTWARE IS PROVIDED "AS IS" AND WITH ALL FAULTS AND WITHOUT WARRANTY OF ANY KIND, AND SAMSUNG AND ITS LICENSORS (COLLECTIVELY REFERRED TO AS "SAMSUNG" FOR THE PURPOSES OF SECTIONS 9, 10 and 11) HEREBY DISCLAIM ALL WARRANTIES AND CONDITIONS WITH RESPECT TO THE SOFTWARE, EITHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES AND/OR CONDITIONS OF MERCHANTABILITY,

OF SATISFACTORY QUALITY OR WORKMANLIKE EFFORT, OF FITNESS FOR A PARTICULAR PURPOSE, OF RELIABILITY OR AVAILABILITY, OF ACCURACY, OF LACK OF VIRUSES, OF QUIET ENJOYMENT, AND NON-INFRINGEMENT OF THIRD PARTY RIGHTS. SAMSUNG DOES NOT WARRANT AGAINST INTERFERENCE WITH YOUR ENJOYMENT OF THE SOFTWARE, THAT THE FUNCTIONS CONTAINED IN THE SOFTWARE WILL MEET YOUR REQUIREMENTS, THAT THE OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE, OR THAT DEFECTS IN THE SOFTWARE WILL BE CORRECTED. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY SAMSUNG OR A SAMSUNG AUTHORIZED REPRESENTATIVE SHALL CREATE A WARRANTY. SHOULD THE SOFTWARE PROVE DEFECTIVE, YOU ASSUME THE ENTIRE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR LIMITATIONS ON APPLICABLE STATUTORY RIGHTS OF A CONSUMER, SO THESE EXCLUSIONS AND LIMITATIONS MAY NOT APPLY TO YOU.

10. EXCLUSION OF INCIDENTAL, CONSEQUENTIAL AND CERTAIN OTHER DAMAGES. TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT SHALL SAMSUNG BE LIABLE FOR PERSONAL INJURY, OR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES WHATSOEVER, OR FOR LOSS OF PROFITS, LOSS OF DATA, BUSINESS INTERRUPTION, OR FOR ANY PECUNIARY DAMAGES OR LOSSES, ARISING OUT OF OR RELATED TO

YOUR USE OR INABILITY TO USE THE SOFTWARE, THE PROVISION OF OR FAILURE TO PROVIDE SUPPORT OR OTHER SERVICES, INFORMATION, SOFTWARE, AND RELATED CONTENT THROUGH THE SOFTWARE OR OTHERWISE ARISING OUT OF THE USE OF THE SOFTWARE, OR OTHERWISE UNDER OR IN CONNECTION WITH ANY PROVISION OF THIS EULA, HOWEVER CAUSED, REGARDLESS OF THE THEORY OF LIABILITY (CONTRACT, TORT OR OTHERWISE) AND EVEN IF SAMSUNG HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME JURISDICTIONS DO NOT ALLOW THE LIMITATION OF LIABILITY FOR PERSONAL INJURY, OR OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THIS LIMITATION MAY NOT APPLY TO YOU.

11. LIMITATION OF LIABILITY. Notwithstanding any damages that you might incur for any reason whatsoever (including, without limitation, all damages referenced herein and all direct or general damages in contract or anything else), the entire liability of Samsung under any provision of this EULA and your exclusive remedy hereunder shall be limited to the greater of the actual damages you incur in reasonable reliance on the Software up to the amount actually paid by you for the Software or US\$5.00. The foregoing limitations, exclusions and disclaimers (including Sections 9, 10 and 11) shall apply to the maximum extent permitted by applicable law, even if any remedy fails its essential purpose.

12. U.S. GOVERNMENT END USERS. The Software is licensed only with "restricted rights" and as "commercial items" consisting of "commercial software" and "commercial software documentation" with only those rights as are granted to all other end users pursuant to the terms and conditions herein.

13. APPLICABLE LAW. This EULA is governed by the laws of TEXAS, without regard to conflicts of laws principles. This EULA shall not be governed by the UN Convention on Contracts for the International Sale of Goods, the application of which is expressly excluded. If a dispute, controversy or difference is not amicably settled, it shall be finally resolved by arbitration in Seoul, Korea in accordance with the Arbitration Rules of the Korean Commercial Arbitration Board. The award of arbitration shall be final and binding upon the parties.

14. ENTIRE AGREEMENT; SEVERABILITY. This EULA is the entire agreement between you and Samsung relating to the Software and supersedes all prior or contemporaneous oral or written communications, proposals and representations with respect to the Software or any other subject matter covered by this EULA. If any provision of this EULA is held to be void, invalid, unenforceable or illegal, the other provisions shall continue in full force and effect.

Precautions for Transfer and Disposal

If data stored on this device is deleted or reformatted using the standard methods, the data only appears to be removed on a superficial level, and it may be possible for someone to retrieve and reuse the data by means of special software.

To avoid unintended information leaks and other problems of this sort, it is recommended that the device be returned to Samsung's Customer Care Center for an Extended File System (EFS) Clear which will eliminate all user memory and return all settings to default settings. Please contact the **Samsung Customer Care Center** for details.

Important: Please provide warranty information (proof of purchase) to Samsung's Customer Care Center in order to provide this service at no charge. If the warranty has expired on the device, charges may apply.

Customer Care Center:

1000 Klein Rd.

Plano, TX 75074

Toll Free Tel: 1.888.987.HELP (4357)

Samsung Telecommunications America, LLC:

1301 East Lookout Drive

Richardson, Texas 75082

Phone: 1-800-SAMSUNG (726-7864)

Phone: 1-888-987-HELP (4357)

Important: If you are using a handset other than a standard numeric dialpad, dial the numbers listed in brackets.

©2010 Samsung Telecommunications America. All rights reserved.

No reproduction in whole or in part allowed without prior written approval. Specifications and availability subject to change without notice.

Index

Numerics

2sec Pause 69, 70

3-Way Call 122

A

Abbreviated Dialing 29, 57

Activation 3

Adapter

 microSD Card 93

Airplane Mode 54

Alarm Clock 81

Answering Calls 23

Applications 141

 Downloading 138

Asian Avenue 146

Automatic Speech Recognition
(ASR) 85

B

Backlight 50

 Dimming 50

 Java 51

 Off Timer 51

Battery 16–19

 Capacity 17

 Charging 18

 Disposal 179

 Installing 17

Best of Green 148

Black Planet 146

Bluetooth 109–113

 Pairing 110

 Sending Files 112

 Sending Items 111

 Settings 110

Bookmarks

 Accessing 134

 Creating 134

 Deleting 135

Brightness

 Changing 51

Browser Menu 131–135

 Clear private data 132

 Font size 132

 Help 132

 Icon Row 132

 OPTIONS 132

 Page info 132

 Redirect prompt 132

 Reset browser 132

 Reset browser settings 132

 Send this page to 132

 Set as Homepage 132

 Startup page 132

 Toolbar 131

Buying Ringers and Games
138

C

Calculator 83

 Eco Calculator 83

 Tip Calculator 83

- Calendar 76–80
 - Adding an Event 76
 - Adding Events 76
 - Event Alert Menu 77
 - Viewing Events 77
- Call Forwarding 123
- Call Guard 125
- Call Waiting 122
- Callback Number 54
- Caller ID 121
- Camera 97–108
 - see also Pictures
 - Multiple Shots 100
 - Options 98
 - Self Timer 99
 - Taking Pictures 97
- Carousel
 - Adding a Tile 44
 - Removing a Tile 45
 - Replacing Tiles 46
 - Resetting One Click 47
- Clear Envelope 118

- Contacts 66–75
 - Adding a Number 69
 - Adding an Entry 66
 - Assigning a Picture 72, 98
 - Assigning Ringers 71
 - Dialing From 29
 - Editing 68
 - Editing a Number 69
 - Entry Options 68
 - Finding Entries 72
 - Saving a Phone Number 67
 - Secret Entries 73
 - Sending Via Bluetooth 111
 - Wireless Backup 74

D

- Data Restrictions 129
- Data Roam Guard 125
- Data Services 127–150
 - see also Web
- Enabling and Disabling 59, 130
- FAQs 149

- Launching the Web 128
- Password 5
- Security Features 59
- User Name 127
- Delete Stuff 58
 - Call Logs 58
 - Contacts 58
 - Cookies and Cache 58
 - Downloaded Content 58
 - Pictures/Videos 58
 - Text Messages 58
- Deleting Phone Content 58
- Dialing Options 22
- Display Screen 11, 51
 - Language 52
- Downloading Ringers and Games 138
- Driving Directions 164
- Dual Language 35

E

- Eco Calculator 83

Email 135
 Creating an Additional Account 137
 Getting Started 135
 Sending Pictures and Videos 106
 Emergency Numbers 24
 Emoticons 38
 End-of-Call Options 26
 Enhanced 911 (E911) 25
 Entering Characters
 Dual Language 35
 Emoticons 40
 Letters 39
 Numbers 39
 Punctuation 39
 Smiley's 40
 Symbols 40
 Entering Text 31–41
 ABC Mode 32
 Emoticons 33
 Multi-tap Entry 32

Numbers 33
 Preset Messages 33
 Selecting Mode 31
 Smileys 33
 Symbols 33
 Erasing Content 58
 Event
 Editing 78
 Erasing 78
 Erasing All 78
 Viewing 77
 Event Alert Menu 77
F
 Facebook 147–148
 Adding as a Space 147
 Overview 147
 Uploading Photos 148
 Family Locator 164
 FCC Notice 180
 File Manager 80
 Force 61

G
 Games
 Buying and Downloading 138
 Glee 146
 Google 142
 Launching via the Carousel 142
 Searching 142
 GPS Navigation 162
 GPS Services 162
H
 Hard Pause 69, 70
 History 62–65
 Erasing 65
 Making a Call 64
 Saving a Number 64
I
 In-Call Options 25
 Internet
 see Web

J

Java Backlight 51

K

Key Beeps 50

Key Functions 9

Key Tone 50

Keyboard

Using 38

L

Language 52

Location Settings 52

Lock Code

Changing 58

Locking Your Phone 57

M

Main Screen Navigation 42–47

Carousel 44

Tiles 44

Tutorial 43

Main Screen Shortcuts 56

Making Calls 22

Memo Pad 82

Menu i

Navigation 19

Menu Style 52

GRID VIEW 52

LIST VIEW 52

Messaging 119

Email 135

Notification 53

Preset Messages 53

Signature 53

Voicemail 116

microSD Card 91–96

Adapter 93

Creating Folders 93

File Manager 80

Formatting 94

Write Protection 93

MiGente 146

Missed Calls 24

MMS Text Messaging 119

Multiple Shots 100

Multitasking 158

Music 154–157

Player 156

Playing Music 155

Purchasing and

Downloading 155

Sprint Music Store 154

Streaming Music 160

My Content Manager 140

My Driver 143

My Favorites

Creating from a Recent Place

169

Creating from Current

Location 169

MySpace 146–147

Adding as a Space 146

Overview 146

N

NASCAR

All Star 143

EXIT 144

Fantasy 144

- FanZone 144
- Miss Sprint 143
- News & Alerts 144
- Point Standings 143
- Race Recap 143
- Schedule 144
- Settings and Help 144
- Speed 143
- Stats/Sched 143
- Video 143
- NASCAR Sprint Cup Mobile 141
- Navigating the Main Screen 42–47
- Navigating the Menus 19
- Navigating the Web 130
- Navigation
 - 2D Moving Map 166
 - 3D Moving Map 166
 - Address 165
 - Businesses 167
 - Finding the Cheapest Gas 168
 - Map Results 168
 - Summary 166
 - Traffic Conditions 166
- Navigation Preferences 170
- Navigation, GPS 162
- Net Guard 60
- O**
- Owner's Record 181
- P**
- Pairing Bluetooth Devices 110
- Parental Controls 60–61
 - Changing the Code 61
 - Restrictions 61
- Pauses 28
- Personal Calendar 76
- Phone (illus.) 8
- Phone Book
 - see Contacts
- Phone Number
 - Displaying 21
 - Finding 27
 - Saving 27, 67
 - With Pauses 28
- Phone Settings 48–61
 - Airplane Mode 54
 - Display Settings 50–52
 - Language 52
 - Location Settings 52
 - Messaging Settings 53–54
 - Sound Settings 48–50
 - TTY Use 55
- Phone Updates 84
- Photobucket 146
- Photos
 - Uploading 148
- PictBridge 107
- Picture
 - Adding to Text Message 120

- Picture Mail
 - Uploading Pictures to Place 106
- Pictures
 - Assigning as Screen Saver 98
 - Assigning to Contacts 98
 - In Phone Folder 103
 - microSD Folders 103
 - PictBridge 107
 - Printing 107
 - Sending 104
 - Sending Via Bluetooth 111
 - Storing 102
 - Taking Pictures 97
 - Uploading 106
- Playing Music 155
- Playlist
 - Creating 157
- Plus (+) Code Dialing 30
- PowerSave Mode
 - Activating 52

- Predictive Text 32
- Prepend 29
- Preset Messages 53, 121
- PRL 84
- Product Tour 172

R

- Recent Location
 - Sharing 169
- Recent Place
 - Adding to My Favorites 169
- Reset 132
- Resetting Your Phone 58, 59
- Restrictions
 - Camera/Camcorder 61
 - Force Location On 61
 - Text Messaging 61
 - Voice Calls 61
 - Web 61
- Ringer Types
 - Alarm 48
 - Battery Alert 48
 - Calendar 48

- Incoming Calls 48
- Messages 48
- Power Down 48
- Power Up 48
- Voicemail 48

Ringers

- Assigning to Contacts 71
- Buying and Downloading 48, 138
- Setting for Voice Calls 48
- Silence All 50
- Types 48
- Vibrate 49

- Roaming 123–126
 - Call Guard 125
 - Data Roam Guard 125
 - Roam Mode 124

S

- Safety Information 174–181
- Saving a Phone Number 27, 67
- ScanLife 141, 145

- Screen Saver 51
- Screen Savers
 - Assigning Pictures 98
 - Downloading 138
- Security 57–61
 - Configuring Restrictions 61
 - Data Services 59
 - Parental Control Code 61
 - Parental Controls 60
 - Reset Settings 58
- Sending Pictures 104
- Sending Videos 104
- Set # Type 69, 70
- Set as Main # 69, 70
- Set as Secret 73
- Settings 48–61, 107
- Shortcuts 56
- Silence All 50
- Smiley's 38
- SMS Text Messaging 119
- Social Zone 146
- Softkeys
 - Landscape Mode 11
 - Portrait Mode 9
- Software Updates
 - Downloading 84
- Speed Dial 30
 - Assigning Numbers 70
- Sprint Family Locator 164
- Sprint Football Live 141
 - Draft 144
 - Favorite Team 145
 - Help/About 145
 - News 145
 - Team Pages 145
 - Tweets 145
- Sprint Music Store 154
- Sprint Navigation 162
- Sprint One Click 42–47
 - see also Main Screen
 - Navigation
- Sprint Service
 - Account Passwords 4
 - Activation 3
 - Dialing Sprint Services 73
 - Operator Services 6
 - Sprint 411 6
 - Sprint Social Zone 141
 - Sprint TV 151
 - Sprint Zone 44
 - SprintWeb
 - Home Page 128
 - Streaming Music 160
- T**
 - Taking Pictures 97
 - Text Entry
 - see Entering Text
 - Text Messaging
 - Adding a Preset Message 120
 - Adding a Smiley 105, 120
 - Adding a Symbol 105, 120
 - Adding an Attachment 120
 - Attaching a Voice Message 120

- Attaching an Image 120
- Composing 119
- Preset Messages 121
- Restrictions 61
- Text Mode 38
- Text Options
 - Auto-Capital 34
 - Auto-Space 34
 - Dual Language 34
 - Setting 38
 - Use My Words 34
 - Word Choice List 34
 - Word Completion 34
 - Word Prediction 34
- Text Settings 35
- Three-Way Calling 122
- Tip Calculator 83
- Tone Type
 - DTMF 50
 - Lucid 50
 - Voice 50
- TOOLBAR 131
- TRS 55
- TTY Use 55
- Turning Your Phone On and Off 16
- TV 151
- Twitter
 - Overview 148
- U**
 - Unlocking Your Phone 57
 - Updating the PRL 84
 - Updating Your Phone 84
- V**
 - Vibrate 49
 - Video
 - Sending 104
 - Videos
 - Options 102
 - Recording 101
 - Storing 102
 - Voice
 - Adding to Text Message 120
- Voice Dialing 86
- Voice Memo
 - Editing 89
 - Erasing 89
 - Options 89
 - Playback 89
 - Recording 88
 - Recording Phone
 - Conversation 88
- Voice Memos 88
- Voicemail
 - Clear Icon 118
 - Notification 116
 - Retrieving 117
 - Setting Up 4, 116
- Volume 49
- W**
 - Warranty 182
 - Web 127–150
 - see also Data Services
 - Browser Menu 131–135
 - Downloading Content 138

Email 135
Launching 128
Navigating 130
Navigating To 134
User Name 127

Wireless Backup 74
World Clock 84
World Time 84
Write Protection 93

X

Xanga 146