

alcatel



ideal XTRA™

# Table of Contents

|          |                                                          |           |
|----------|----------------------------------------------------------|-----------|
| <b>1</b> | <b>Your device.....</b>                                  | <b>1</b>  |
| 1.1      | Keys and connectors .....                                | 1         |
| 1.2      | Getting started .....                                    | 4         |
| 1.3      | Home screen .....                                        | 5         |
| <b>2</b> | <b>Text input .....</b>                                  | <b>13</b> |
| 2.1      | Using onscreen keyboard.....                             | 13        |
| 2.2      | Google keyboard .....                                    | 13        |
| 2.3      | Text editing .....                                       | 14        |
| <b>3</b> | <b>AT&amp;T Services .....</b>                           | <b>15</b> |
| 3.1      | AT&T services.....                                       | 15        |
| <b>4</b> | <b>Call and Contacts.....</b>                            | <b>16</b> |
| 4.1      | Call .....                                               | 16        |
| 4.2      | Contacts .....                                           | 23        |
| <b>5</b> | <b>Message.....</b>                                      | <b>28</b> |
| <b>6</b> | <b>Calendar &amp; Alarm clock &amp; Calculator .....</b> | <b>33</b> |
| 6.1      | Calendar .....                                           | 33        |
| 6.2      | Clock .....                                              | 34        |
| 6.3      | Calculator .....                                         | 38        |
| <b>7</b> | <b>Getting connected .....</b>                           | <b>39</b> |
| 7.1      | Connecting to the Internet .....                         | 39        |
| 7.2      | Connecting to Bluetooth devices .....                    | 41        |
| 7.3      | Connecting to a computer.....                            | 42        |
| 7.4      | Sharing your mobile data connection .....                | 42        |
| 7.5      | Connecting to virtual private networks.....              | 43        |
| <b>8</b> | <b>Multimedia applications.....</b>                      | <b>45</b> |
| 8.1      | Camera.....                                              | 45        |

|           |                                  |           |
|-----------|----------------------------------|-----------|
| 8.2       | Gallery .....                    | 47        |
| <b>9</b>  | <b>Others .....</b>              | <b>49</b> |
| 9.1       | Other applications .....         | 49        |
| <b>10</b> | <b>Google applications .....</b> | <b>50</b> |
| 10.1      | Play Store.....                  | 50        |
| 10.2      | Chrome .....                     | 50        |
| 10.3      | Gmail.....                       | 51        |
| 10.4      | Maps.....                        | 53        |
| 10.5      | YouTube .....                    | 53        |
| 10.6      | Drive.....                       | 53        |
| 10.7      | Duo.....                         | 54        |
| 10.8      | Play Music .....                 | 54        |
| 10.9      | Play Movies & TV .....           | 54        |
| 10.10     | Photos .....                     | 54        |
| <b>11</b> | <b>Settings .....</b>            | <b>55</b> |
| 11.1      | Network & internet .....         | 55        |
| 11.2      | Connected devices .....          | 57        |
| 11.3      | Apps & notifications.....        | 57        |
| 11.4      | Battery.....                     | 57        |
| 11.5      | Smart Manager.....               | 58        |
| 11.6      | Display.....                     | 58        |
| 11.7      | Sound .....                      | 58        |
| 11.8      | Storage.....                     | 59        |
| 11.9      | Security & location .....        | 60        |
| 11.10     | Users & accounts.....            | 62        |
| 11.11     | Accessibility.....               | 62        |
| 11.12     | Google.....                      | 64        |
| 11.13     | System .....                     | 64        |

|    |                          |    |
|----|--------------------------|----|
| 12 | Software update .....    | 69 |
| 13 | Accessories.....         | 69 |
| 14 | Safety information ..... | 70 |
| 15 | General information..... | 79 |
| 16 | Warranty.....            | 82 |
| 17 | Troubleshooting .....    | 84 |



[www.sar-tick.com](http://www.sar-tick.com)

This device meets applicable national SAR limits of 1.6 W/kg. SAR values can be found on page 76 of this user guide. When carrying the device or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 15 mm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not using it.




To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.




The device contains magnets which may interfere with other devices and items (such as credit card, pacemakers, defibrillators, etc.). Please maintain at least 15 cm of separation between your phone and the devices/items mentioned above.

# 1 Your device.....

## 1.1 Keys and connectors .....





### Back

- Touch to go back to the previous screen, or to close a dialog box, options menu, the notification panel, etc.



### Home

- While on any application or screen, touch to return to the Home screen.
- Long press to open Google now.



### Recent apps

- Touch to open a card view of applications you've worked with recently.



## Volume up/down

- In Music/Video/Streaming mode, adjusts the media volume.
- In call mode, adjusts the earpiece or headset volume.
- In general mode, adjusts the ringtone volume.
- Mutes the ringtone of an incoming call.
- In camera preview mode, press Volume key to take a photo.



## Power/Lock

- Press: Lock the screen/Light up the screen.
- Press and hold: Show the pop-up menu to select from **Power off/Restart/Airplane mode**.
- Press and hold the **Power** key for at least 8 seconds to power off or hold it longer to reboot.
- Press the **Power** key and **Volume down** key to capture a screenshot.

## 1.2 Getting started.....

### 1.2.1 Set-up

#### Inserting or removing the Nano/microSD card

A Nano card is required to make phone calls and use cellular networks. If you have a Nano card, insert it before setting up the phone. Do not attempt to insert other SIM types like mini or micro-SIM cards, as you may damage your phone.

Power off your phone before inserting or removing the Nano/microSD card.

#### Charging the battery

You are advised to fully charge the battery. Charging status is indicated by a percentage displayed on screen while the phone is powered off. The percentage increases as the phone is charged.



To reduce power consumption and energy waste, disconnect your charger when the battery is fully charged; switch off Wi-Fi, GPS, Bluetooth or apps running in the background when not needed. In Settings you can also lower the brightness of the screen, and shorten the length of time before the screen goes to sleep.

### 1.2.2 Power on your phone

To turn your phone on, hold down the **Power** key until the phone powers on. It will take a few seconds before the screen lights up. Unlock your phone with a swipe, PIN, password or pattern before the Home screen can display if you've set a screen lock in Settings.


If you do not know your PIN code or if you have forgotten it, contact your network carrier. Do not leave your PIN code with your phone. Store this information in a safe place when not in use.

### 1.2.3 Power off your phone

To turn your phone off, hold down the **Power** key until the phone options appear, then select **Power off**.

## 1.3 Home screen .....

You can bring all your favorite icons (applications, shortcuts, folders and widgets) to your Home screen for quick access. Touch the **Home** key to switch to Home screen.



#### Status bar

- Status/Notification indicators.

#### Favorite tray applications

- Touch to enter the application.
- Long press to remove applications.

The Home screen extends on the right side of the screen to allow more space for adding applications, shortcuts etc. Slide the Home screen horizontally right to get a complete view of the Home screen. The white dot at the lower part of the screen indicates which screen you are viewing.

### 1.3.1 Using the touchscreen

#### Touch



To access an application, touch it with your finger.

#### Long press




Long press the Home screen to access **WALLPAPERS/WIDGETS** screen.

#### Drag




Place your finger on any item to drag it to another location.

#### Slide/Swipe



Slide the screen to scroll up and down the applications, images, web pages... at your convenience.

#### Flick




Similar to swiping, but flicking makes it moves quicker.

## Pinch/Spread



Place your fingers of one hand on the screen surface and draw them apart or together to scale an element on the screen.

## Rotate



Automatically change the screen orientation from portrait to landscape by turning the device sideways to have a better view.

### 1.3.2 Status bar


From the status bar, you can view both phone status (on the right side) and notification information (on the left side).

Drag down the status bar to view notifications and drag again to enter the quick settings panel.

Touch and drag up to close it. When there are notifications, you can touch them to access notifications.

#### Notification panel


Touch and drag down the Status bar to open the Notification panel to read the detailed information.



Touch to clear all event-based notifications (other ongoing notifications will remain)

## Quick settings panel


Touch  to open the Quick settings panel, where you may enable or disable functions or change modes by touching the icons.



Touch to access **Settings**, where you can set more items.

### 1.3.3 Search bar

The device provides a Search function which can be used to locate information within applications, the device or the web.



#### ① Search by text

- Touch the Search bar from the Home screen.
- Enter the text/phrase you want to search for.
- Touch  on the keyboard if you want to search on the web.

#### ② Search by voice

- Touch  from Search bar to display a dialog screen.
- Speak the word/phrase you want to search for. A list of search results will display for you to select from.

### 1.3.4 Lock/Unlock your screen

To protect your device and privacy, you can lock the device screen by choosing swipe or creating a password, PIN or unlock pattern.

## To create a screen unlock pattern

- Swipe up on the Home screen and select **Settings**, then touch **Security & location/Screen lock/Pattern**.
- Draw your own pattern.


## To lock device screen

Press the **Power** key once to lock the screen.

## To unlock device screen

Press the **Power** key once to light up the screen, slide to draw the unlock pattern you have created or enter your PIN or password, etc. to unlock the screen.

If you have chosen **Swipe** as the screen lock, you can press the **Power** key to light up the screen, then swipe up to unlock the screen, swipe up or double touch the icons on the bottom to enter the applications.



Double touch to enter the detailed screen

Swipe up to unlock the screen

Swipe up or double touch to enter Camera

### 1.3.5 Personalize your Home screen

#### Add

You can long press a folder, an application or a widget to activate the Move mode, and drag the item to your preferred Home screen.

#### Reposition

Long press the item to be repositioned to activate the Move mode, drag the item to the desired position and then release. You can move items both on the Home screen and the favorite tray. Hold the icon on the left or right edge of the screen to drag the item to another Home screen.

#### Remove

Long press the item to be removed to activate the Move mode, drag the item up to **Remove** at the top, and release after the item turns red.

#### Create folders

To improve the organization of items (shortcuts or applications) on the Home screen, you can add them to a folder by stacking one item on top of another.

#### Wallpaper customization

Long press the empty area in the Home screen, then touch **WALLPAPERS** to customize wallpaper.

### 1.3.6 Widgets and recently-used applications


#### Consult widgets

Long press the empty area in the Home screen, then touch **WIDGETS** to display all widgets.

Touch the selected widget and slide it to move to your preferred screen.

#### Consult recently-used applications

To consult recently-used applications, touch the **Recent apps** key. Touch a thumbnail in the window to open the application.



Touch one thumbnail and slide it right/left or touch **X** to close the application.

### 1.3.7 Volume adjustment

#### Using volume key

Press **Volume** key to adjust the volume. To activate the Vibrate mode, press the **Volume down** key until the device vibrates.

#### Using Settings menu

Touch the settings icon  on application list to enter **Settings**, then touch **Sound**, you can set the volume of media, notification, ring and etc. to your preference.



## 2 Text input.....

### 2.1 Using onscreen keyboard.....

#### Onscreen Keyboard settings

Touch the Application tab from the Home screen, select **Settings > System > Language & input**, choose a keyboard under **Keyboard & inputs**.

### 2.2 Google keyboard.....



## 2.3 Text editing.....

You can edit the text you have entered.

- Long press or double-tap within the text you would like to edit.
- Drag the tabs to change the high-lighted selection.
- The following options will show: **CUT, COPY, SHARE, SELECT ALL, SHARE.**
- Touch the other words that haven't been selected or empty place in entry bar to go back without any action.

**You can also insert new text**

- Touch where you want to type, or long press a blank space. The cursor will blink and the tab will show. Drag the tab to move the cursor.
- If you have selected any text, touch the tab to show **PASTE** and **SELECT ALL** icon which allows you to complete paste immediately.

## 3 AT&T Services .....

### 3.1 AT&T services .....



**DriveMode:** Silence notifications, set an auto-reply so people will know you are driving, and more.



**myAT&T:** Manage your account, track your usage, review and pay your bill, and update your data plan service.




**AT&T Visual Voicemail:** Review and manage your voicemail from your phone.



**AT&T Smart Wi-Fi:** Helps you make your data plan last longer.

Remembers and connects to your favorite hotspots and finds more Wi-Fi options when you're on the go.



**AT&T Smart Limits:** Set up text alerts to switch to Wi-Fi and allows you to manage your kids' phone usage.


## 4 Call and Contacts.....

### 4.1 Call.....



#### 4.1.1 Making a call

You can launch a call by using **Call**. Touch the  icon on the Home screen to access the **Call** application.



Slide to access **RECENT** and **CONTACTS**.

Call history is empty

**MAKE A CALL**




Touch to display keyboard.



Long press to access voicemail.

Display the suggested number(s).



Enter the desired number from the keyboard and touch  to place the call or select a contact from **CONTACTS** or **RECENT** by sliding or touching tabs, then touch  to make the call.

The number you entered can be saved to **Contacts** by touching  and then touching **Create new contact**.

If you make a mistake, you can delete the incorrect digits by touching .

To hang up a call, touch .


## International call

To dial an international call, long press  to enter "+", then enter the international country prefix followed by the full phone number and touch .

## Emergency call

If your phone has network coverage, dial the emergency number and touch  to make an emergency call. This works even without a SIM card and without typing the PIN code.

### 4.1.2 Answering or rejecting a call



When you receive a call, you can touch ANSWER to answer the call, or touch the incoming call and then:

- Slide the  icon up to answer;
- Slide the  icon up to reject;
- Select the  to reject the call by sending a preset message.

To mute the ringtone volume of an incoming call, press the **Volume up/down** key.

### 4.1.3 Calling your voicemail

Your voicemail is provided by your network to avoid missing calls. It works like an answering machine that you can consult at any time.

To access your voicemail, long press **1**.


To set your voicemail number:

Long press **1**, then touch **ADD NUMBER/Voicemail/Setup/Voicemail number**.

If you receive a voicemail, a voicemail icon  appears on the Status bar. Open the Notification panel and touch **New voicemail**.

#### 4.1.4 During a call

To adjust the volume during a call, press the **Volume up/down** key.



Touch to end the current call.



Touch to activate the speaker during the current call. Touch this icon again to deactivate the speaker.



Touch to mute the current call. Touch this icon again to unmute the call.



Touch to display the Dial pad.



Touch to hold the current call. Touch this icon again to retrieve the call.



Touch to add a call.



To avoid accidental operation of the touchscreen during a call, the screen will be locked automatically when you put the cellphone close to your ear; and it will be unlocked when the cellphone is taken away from your ear.

### 4.1.5 Managing multiple calls

With this phone you can handle multiple calls at the same time.

#### Swap calls

When you accept two calls, touch the  icon to switch between the two lines. The current call will be put on hold and you are able to join the other call.

#### Conference calls <sup>(1)</sup>

You can set up a conference call as follows.

- Place a call to the first participant of the conference call.
- Touch the  icon.
- Then touch the  icon and then touch the  icon to start the conference.
- Touch  to end the conference call and disconnect all callers.

### 4.1.6 Call settings

Touch  from the Call screen, then touch **Settings**. The following options are available:

<sup>(1)</sup> Depending on your network carrier.

## Phone settings

**Quick responses:** Touch to edit quick responses which will be used when you reject a call with messages.

**Dial pad tones:** Turn on the switch to enable playing tones when using the dial pad.

## Call settings

- **Fixed Dialing Numbers**

Fixed dialing number (FDN) is a SIM service mode, where outgoing calls are restricted to a set of phone numbers. These numbers are added to the FDN list. The most common practical application of FDN is for parents to restrict the phone numbers to which their children can dial. For security reasons, you'll be prompted to enable FDN by entering SIM PIN2 which is usually acquired from your service provider or SIM maker.

- **Call duration**

Touch to check the duration for your latest, incoming, outgoing, and total calls.

- **Call forwarding**

Touch to configure how your calls are forwarded when you are busy or unanswered.

- **Additional settings**

Touch to use default carrier settings to display your number in outgoing calls.

## Voicemail

- **Notifications**

Touch to select notification sound and so on.

## Advanced Settings

- **Service**

Touch to select the carrier.

- **Setup**

Touch to set voicemail number for listening to and managing your voicemail.

## Accessibility

- **TTY mode**

TTY mode enables people who are deaf, hard of hearing, or speech-impaired to use the telephone to communicate. After connecting the phone and TTY devices that includes a keyboard and a text display mechanism, calls are linked to a relay service, which converts incoming speech to text and converts outgoing text to a spoken voice.

- **Hearing aids**

Touch the switch to enable hearing aid compatibility.

- **Noise reduction**

Touch the switch to enable your background noise during calls.

**Quick dial:** Touch to add quick dial numbers.

**Incoming call Full-screen:** Touch the switch enable incoming call full-screen.

## Contact settings

**Import/Export:** Import or export contacts between phone, SIM card, microSD card and phone storage.

**Merge contacts:** Select duplicate contacts to merge.

## Manage account

Manage the synchronization settings for different accounts.

## Display options

- **Sort by**

Set the contacts display by First name or Last name.

- **Name format**

Set the name format by First name first or Last name first.


## 4.2 Contacts.....



**Contacts** app enables quick and easy access to the people you want to reach.

You can view and create contacts on your device and synchronize these with your Gmail contacts or other applications.

### 4.2.1 Consult your contacts



Touch to search in **Contacts**.

Touch to open Quick Contact panel.

Touch to add a new contact.

### Delete a contact

To delete a contact, touch and hold the icon on the left of contact you want to delete, the icon will turn to , then touch  and confirm to delete. Touch  to select all contacts, then touch  and confirm to delete all contacts.



The contact you have deleted will also be removed from other applications on the phone or web the next time you synchronize your phone.

Touch the **Menu** icon  to display the contacts list option menu.

Following actions are enabled:

**Group:** Touch to add and manage contact group.

**Contacts to display:** Choose contacts to display.

## Settings

- **My info**

Touch to create my local profile.

- **Accounts**

Touch to edit the users and accounts information.

- **Merge contacts**

Touch to merge the duplicate contacts.

- **Display options**

Touch to change the display of the sort list and contact names.

- **Import/Export**

Import or export contacts between phone, SIM card, microSD card and phone storage.

- **Blocked numbers**

Touch to manage the block numbers, you won't receive calls or texts from blocked numbers.


- **Default account for new contacts**

Touch to choose Phone or SIM card as default account for new contacts.

## 4.2.2 Adding a contact

Touch the icon  in the contact list to create a new contact.

You are required to enter the contact's name and other contact information. By scrolling up and down the screen, you can move from one field to another easily.



Touch to save.

Touch to select a picture for the contact.

Touch to unfold the other predefined labels of this category.

When finished, touch ✓ to save.

To exit without saving, you can touch **Back** and select **Discard**.

### Add to/remove from Favorites

To add a contact to Favorites, you can touch a contact to view details then touch ☆ (the star will turn ★).

To remove a contact from favorites, touch ★ on contact details screen.

### 4.2.3 Editing your contacts

To edit contact information, touch to choose the contact, then touch ✎ on top of the screen. When finished, touch ✓ to save the edits.

### 4.2.4 Communicating with your contacts

From the contacts list, you can communicate with your contacts by making a call or exchanging messages.

To launch a call to a contact, touch the contact to enter the detail screen, then touch the number.

To send a message to a contact, touch the contact to enter the detail screen, then touch the  icon on the right side of the number.

#### 4.2.5 Contacts importing, exporting and sharing

This device enables you to import or export contacts between phone storage, SIM card, and SD card storage.

From the Contacts screen, touch the Menu icon to open the options menu, touch **Import/Export**, then select the location to copy contacts from, touch **NEXT**, then select the location to copy contacts to and touch **NEXT**.

To import/export a single contact from/to your SIM card, select the contact you want to import/export, and touch the  icon to confirm.

You can share a single contact or contacts with others by sending the contact's vCard to them via Bluetooth, Gmail, etc.

Touch a contact you want to share, touch the **Menu** icon  from Contact details screen, and select **Share**, then touch  and select the application to perform this action.

#### 4.2.6 Accounts

Contacts, data or other information can be synchronized from multiple accounts, depending on the applications installed on your device.

To add an account, Swipe up on homescreen then **Settings/ Users & accounts/Add account**.

You are required to select the kind of account you are adding, like Google, Corporate, etc.

To add an account you will need to enter detailed information, like username, password, etc.

You can remove an account to delete it and all associated information from the phone. Touch the account you want to delete, touch  and select **Remove account**, then confirm.

#### 4.2.7 Turn on/off the auto-sync


In the **Accounts** screen, touch  and mark the **Auto-sync data** checkbox. When activated, all changes to information on the phone or online will be automatically synchronized with each other.

## 5 Message.....

You can create, edit and receive SMS and MMS with this phone. To send a message, Swipe up from the Home screen then select **Messaging**.

### 5.2.1 Write a message

On the message list screen, touch the new message icon  to write text/multimedia messages.



- Touch to view the whole message thread.
- Long press to activate delete mode.



Touch to create a new message.



For saved contacts, touch the photo to open the Quick contact panel to communicate with the contact. For unsaved contacts, touch the photo to add the number to your **Contacts**.

### 5.2.2 Sending a text message

Enter the mobile phone number of the recipient in the **To** bar or touch  to add recipients from contacts. Touch the **Send message** bar to enter the text of the message. Touch the  icon to insert emoticons. When finished, touch  to send the text message.

An SMS message of more than 160 characters will be charged as several SMS. A counter will be on the right of the text box to remind you how many characters are allowed to be entered in one message.



Specific letters (accented) will also increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.

### 5.2.3 Sending a multimedia message

MMS enables you to send video clips, images, photos, animations, slides and sounds to other compatible mobiles and e-mail addresses.

An SMS will be converted to MMS automatically when media files (image, video, audio, slides, etc.) are attached or email addresses are added.

To send a multimedia message, enter the recipient's phone number in the **To** bar and touch the **Type message** bar to enter the text of the message. Touch the  icon to attach a picture, video, audio and so on.

When finished, touch  to send the multimedia message.

## 5.2.4 Manage messages

When receiving a message, an  icon will appear on the status bar as a notification. Drag down the status bar to open the Notification panel, touch the new message to open and read it. You can also access the Messaging application and touch the message to open it.

Messages are displayed in conversational order.

Touch a message to enter the message composing screen:

- Touch  to call the number;
- Touch  to save the number to contacts or view the contact details if the number has been saved;
- To reply to a message, enter the text, or touch  to insert quick text, contact etc., after edit then touch  SMS.
- Long press a message to show the following icons: copy text , forward , view details , delete  etc., touch  to lock/unlock the message or save the message to SIM card.

## 5.2.5 Adjust message settings

You can adjust a range of message settings. From the Messaging application screen, touch  and touch **Settings**.

### GENERAL

- **SMS enable**

Touch to change your default SMS app.

- **Quick text**

Touch to add or edit message templates.

### Storage

- **Delete old messages**

Select to delete old messages when the maximum number of stored messages is reached.

- **Text message limit**

Touch to set the maximum number of text messages to be saved per conversation.

- **Multimedia message limit**

Touch to set the maximum number of multimedia messages to be saved per conversation.

## **Notifications**

- **Notifications**

Select to display message notifications in the status bar.

- **Select ringtone**

Touch to select a ringtone as a new message notification tone.

- **Vibrate**

Select to have phone vibrate as a notification when receiving a new message.

- **Beep when on an active call**

Mark the checkbox to have the phone beep when a new message is received on an active call.

## **WAP push messages**

- **Enable WAP push**

Mark the checkbox to enable receive of push message from network.

## **ADVANCED**

### **Text message (SMS) settings**

- **Manage SIM messages**

Touch to manage text messages stored on your SIM card.

- **SMS Service Centre**

You can find the service center number here.

- **Character code**

Touch to set SMS character code.

- **SMS signature**

Touch to enable add signature when sending a message.

- **Edit SMS signature**

Touch to edit SMS signature.

## Multimedia message (MMS) settings

- **Group messaging**

Touch to enable use MMS to send a single message when there are multiple recipients.

- **Auto-retrieve**

Mark the checkbox to retrieve messages automatically.

- **Creation mode**

Touch to select MMS creation mode.

- **Maximum message size**

Select to input the maximum message size.

## 6 Calendar & Alarm clock & Calculator.....

### 6.1 Calendar.....



Use Calendar to keep track of important meetings, appointments, etc.

#### Multimode view

To change your Calendar view, touch the ▼ icon besides the month title to open the month view, or touch ≡ and select Schedule, Day, 3-Day, Week or Month to open different views. Touch the icon <sup>(1)</sup> to return to Today's view.


#### Schedule view

#### Day view

#### 3-day view

#### Week view

#### Month view



<sup>(1)</sup> The number indicates the date.

## To create new events

You can add new events from any Calendar view except Year.

- Touch the icon  then select **Event** to access to access new event edit screen.
- Fill in all required information for this new event. If it is a whole-day event, you can select **ALL DAY**.
- Invite people to the event. Enter the email addresses of the guests and separate with commas. Then all guests will receive an invitation from Calendar and Email.
- When finished, touch **SAVE** from the top of the screen.

## To delete or edit an event

Touch an event to open its detailed screen, then touch  and then touch **DELETE** to delete.

## Event reminder


If a reminder is set for an event, the upcoming event icon  will appear on Status bar as a notification when the reminder time arrives.

Touch and drag down the status bar to open the notification panel, touch event name to view Calendar notification list.

Touch **SNOOZE** to turn off all event reminders for 10 minutes.

Touch the **Back** key to keep the reminders pending on the status bar and the notification panel.

## 6.2 Clock .....



Your mobile phone has a built-in clock. To open it, touch the Swipe up from the Home screen, then touch **Clock**.

### 6.2.1 Alarm

#### To set an alarm

From the Clock screen, touch  to enter the Alarms screen, then touch  to add a new alarm. Following options will show:

- **Time**

Touch numbers to set the time for your alarm.

- **Repeat**

Mark the checkbox of Repeat and then select the days you want your alarm to go off.

- **Ringtone**

Select an alarm ringtone.

- **Vibrate**

Mark the checkbox to activate/deactivate vibration.

- **Label**

Touch to set a name for the alarm.

- **Delete**

Touch  to delete the alarm.

## To adjust alarm settings

Touch  from the **Alarms** screen. The following options will be available under **Settings**:

### Clock

- **Style**

Touch to set **Analog** or **Digital** style.

- **Automatic home clock**

Will automatically add a home clock while travelling outside.  
To disable it, unmark the checkbox.

- **Home time zone**

Touch to set Home time zone.

- **Change Date & time**

Touch to set up date and time.

### Alarms

- **Silence after**

Select a silence time.

- **Snooze length**

Touch to choose length of snooze.

- **Alarm volume**

Touch to set alarm volume.

- **Gradually increase volume**

Touch to set up a time, and then the volume of alarm ringtone will increase gradually after seconds you set up.

- **Volume buttons**

Preset volume up/down buttons' behaviors when alarm sounds: **Snooze**, **Dismiss**, or **Do nothing**.

- **Start week on**

Select to start week on Saturday, Sunday, or Monday.

## Timers

- **Timer sound**

Touch to select a timer ringtone.

- **Gradually increase volume**

Touch to set up a time, and then the volume of timer ringtone will increase gradually after seconds you set up.

- **Timer Vibrate**

Touch to set vibrate.

## Screen saver

- **Style**

Touch to set as Digital or Analog.

- **Night mode**

Touch to select night mode.

### 6.2.2 World clock

To view the world clock, touch  on the **Clock** screen.


- Touch  to add a time zone from list.

### 6.2.3 Countdown

From the **Clock** screen, touch  to enter the **Countdown** screen.

Touch the digits to set the countdown time. Type the time in hour, minute and second number sequence.

Touch  to start the countdown.



### 6.2.4 Timer

From the **Time** screen, touch  to enter the **Timer** screen.


Touch  to start the timer.

To save a lap time: Touch **LAP**.

Pause: Touch .

Share the timer through Bluetooth, Gmail, etc.: Touch **SHARE**.

## 6.3 Calculator .....



To solve mathematical problems with **Calculator**, swipe up from the Home screen, then touch **Calculator**.


There are two panels available: Basic calculation and Scientific calculation.

To switch between panels, select one of the following two ways:


- Swipe the basic calculation screen to the left to open the scientific calculation.
- Or turn the device to the landscape mode from the basic panel to open the scientific calculation. This option only available if **Settings > Display > Auto-rotate screen > Rotate screen contents** is on.



DEG



DEG



Enter a number and the arithmetic operation to be performed, enter the second number, then touch “=” to display the result. Touch **DEL** to delete digits one by one, or touch and hold **DEL** to delete all at once.

## 7 Getting connected .....

To connect to the internet with this device, you can use 3G/4G networks or Wi-Fi, whichever is most convenient.

### 7.1 Connecting to the Internet .....

#### 7.1.1 3G/4G

##### To activate/deactivate Data roaming

When roaming, you can decide to connect/disconnect to a data service.

- Swipe up on the Home screen and touch **Settings**.
- Touch **Network & internet > Mobile network**.
- Select **International data Roaming** then select **Cellular data**.
- When Data roaming is disabled, you can still perform data exchange with a Wi-Fi connection (refer to “6.1.2 Wi-Fi”).

#### 7.1.2 Wi-Fi

Using Wi-Fi, you can connect to the Internet when your device is within range of a wireless network. Wi-Fi can be used on your device even without a SIM card inserted.

##### To turn Wi-Fi on and connect to a wireless network

- Swipe up on the Home screen and touch **Settings**.
- Touch **Network & internet > Wi-Fi**,
- **Wi-Fi** is turned on by default, the detailed information of detected Wi-Fi networks is displayed in the Wi-Fi networks section. Touch the switch  to turn off Wi-Fi.
- Touch a Wi-Fi network to connect. If the network you selected is secured, you are required to enter a password or other credentials (you may contact your network carrier for details). When finished, touch **CONNECT**.

## To activate notification when a new network is detected

When Wi-Fi is on and the network notification is activated, the Wi-Fi icon will appear on the status bar whenever the device detects an available wireless network within range. The following steps activate the notification function when Wi-Fi is on:

- Swipe up on the Home screen and touch **Settings**.
- Touch **Network & internet > Wi-Fi**. Then touch the **Settings** icon .
- Turn on/off the **Network notification** to activate/deactivate this function.

## To add a Wi-Fi network

When Wi-Fi is on, you may add new Wi-Fi networks according to your preference.

- Swipe up on the Home screen and touch **Settings**.
- Touch **Network & internet > Wi-Fi**, and then touch **+ Add network** at the bottom of Wi-Fi screen.
- Enter the network SSID and required network information.
- Touch **SAVE**.

When successfully connected, your device will be connected automatically the next time you are within range of this network.

## To forget a Wi-Fi network

The following steps prevent automatic connections to networks which you no longer wish to use.

- Turn on Wi-Fi, if it's not already on.
- In the Wi-Fi screen, touch & hold the name of the saved network.
- Touch **FORGET** in the dialog that opens.

## 7.2 Connecting to Bluetooth devices <sup>(1)</sup>...

Bluetooth is a short-range wireless communication technology that you can use to exchange data, or connect to other Bluetooth devices for various uses.

To exchange data, touch  on the Quick settings bar to get to **Settings**, then touch **Bluetooth**. Your device and other available ones will show on the screen once your Bluetooth is activated.

### To turn on Bluetooth

Touch  to turn this function on or off.

To make your phone more recognizable, you can change your phone's name which is visible to others.

1. Go to **Settings > Connected devices > Bluetooth**.
2. Touch  and select **Rename this device**. Bluetooth must be activated to select this option.
3. Enter a name, and touch **RENAME** to confirm.

### To pair/connect your phone with a Bluetooth device

To exchange data with another device, you need to turn Bluetooth on and pair your phone with the Bluetooth device with which you want to exchange data.

1. Go to **Settings > Connected devices > Bluetooth**.
2. Touch a desired Bluetooth device in the list.
3. A dialog will pop up, touch **PAIR** to confirm.
4. If the pairing is successful, your phone will connect to the device.

### To disconnect/unpair from a Bluetooth device

1. Touch  after the device name you want to unpair.
2. Touch **FORGET** to confirm.

<sup>(1)</sup> You are recommended to use **alcatel** Bluetooth headsets, which have been tested and proved compatible with your phone. You can go to [www.alcatel-mobile.com](http://www.alcatel-mobile.com) for more information about the **alcatel** Bluetooth headset.

## 7.3 Connecting to a computer .....

With a USB cable, you can transfer media files and other files between microSD card/internal storage and computer.

**To connect/disconnect your device to/from the computer:**

- Use the USB cable that came with your device to connect the device to a USB port on your computer. You will receive a notification that the USB is connected.

**To disconnect (from mass storage):**

- Unmount the microSD card on your computer.

To locate the data you have transferred or downloaded in the internal storage, touch **Settings > Smart Manager**, all data you have downloaded is stored in **Settings > Smart Manager**, where you can view media files (videos, photos, music and others), rename files, install applications into your device, etc.

**To format a microSD card**

- Swipe up on the Home screen and touch **Settings**.
- Touch **Storage**.
- Touch **FREE UP SPACE**. On the screen a popup warns you that formatting the microSD card will erase its contents.

## 7.4 Sharing your mobile data connection.....

You can share your device's mobile data connection with other devices via AT&T AllAccess by turning your device into a portable Wi-Fi hotspot.

**To share your device's data connection as a portable Wi-Fi hotspot**

- Swipe up on the Home screen.
- Touch  then select **Network & internet > Tethering & mobile hotspot**.
- Touch the on/off switch to turn on/off your device's mobile hotspot.

- Then following the instructions on your device to share your device's internet connection with other devices.

## 7.5 Connecting to virtual private networks .....

Virtual private networks (VPNs) allow you to connect to the resources inside a secured local network from outside that network. VPNs are commonly deployed by corporations, schools, and other institutions so that their users can access local network resources when not inside that network, or when connected to a wireless network.

### To add a VPN

- Swipe up on the Home screen and touch **Settings**.
- Touch **Network & internet > VPN** and then touch .
- In the screen that opens, follow the instructions from your network administrator to configure each component of the VPN settings.
- Touch **Save**.

The VPN is added to the list on the VPN settings screen.



Before adding a VPN, you should set a lock screen pattern, PIN code or password for your device.

### To connect/disconnect to a VPN

#### To connect to a VPN

- Swipe up on the Home screen and touch **Settings**.
- Touch **Network & internet/VPN**.
- VPNs you have added are listed; touch the VPN you want to connect with.
- In the dialog that opens, enter any requested credentials and touch **Connect**.

#### To disconnect

- Touch a connected VPN, then select **Disconnect**.

## To edit/delete a VPN

To edit a VPN:


- Swipe up on the Home screen and touch **Settings**.
- Touch **Network & internet/VPN**.
- VPNs you have added are listed; touch  and touch **Edit profile**.
- After finished, touch **Save**.

## To delete

- Touch  and touch Delete profile.

## 8 Multimedia applications .....

### 8.1 Camera .....



Your mobile phone is fitted with a camera for taking photos and videos.

Before using the camera, make sure that you remove the protective lens cover to avoid it affecting your picture quality.

To take a photo or video, touch  from the Home screen and then touch **Camera**.


#### **Filter button**

Touch to preview the viewfinder with live filter applied. Touch any filter to apply filter and return to the previous screen.

Touch the screen to focus

Pinch/spread two fingers together/apart to zoom out/in

View the photos or videos you have taken



#### **Flash mode**

Touch to turn on/off the camera flash.

Switch between front/back camera

Take a photo

## To take a photo

The screen acts as the viewfinder. First, position the object or landscape in the viewfinder, touch the screen to focus if necessary and touch  to capture. The photo will be automatically saved. You can also long press  to take burst shots.

## To take a video

Touch the right part of this icon  to change the camera mode to video, then touch the left part of this icon  to start video recording. You can also touch the left part of this icon  to take a picture during video recording.

Touch  to pause video recording and touch  to continue. Touch  to stop recording. The video will be automatically saved.

## Further operations when viewing a picture/video you have taken

- Slide left or right to view the photos or videos you have taken.
- Touch , then Gmail/Bluetooth/MMS/etc. to share the photo or video.
- Touch  to return to **Camera**.

### 8.1.1 Modes and settings

Touch  to switch between modes.

- **Auto**

Auto is the default mode for Camera.

- **Pano**

Touch to turn on panorama function. Touch the shutter button to start taking panoramic photo and move the phone steadily along the direction indicated by the onscreen line. Once the slots are filled, the photo will be automatically saved. If the slots are not fully filled, touch the shutter button again to save the photo.

- **Time-lapse**

Capture a series of photos and convert them into a sped up time-lapse video.

## Settings

- **Grid**

Turn on  to enable grid view. It divides the screen into equal parts and helps you take better photos by making it simple to align elements, such as the horizon or buildings, to the lines in the grid.

- **Video stabilisation (EIS)**

Turn on  to enable the Electronic Image stabilization (EIS) feature. It helps reduce blurring associated with the motion of a camera during exposure.

- **Save location information**


Turn on  to tag photos and videos with your location. This option is available when the GPS location service is enabled.

## 8.2 Gallery .....




Gallery acts as a media player for you to view photos and playback videos. In addition, a set of further operations to pictures and videos are available for your choice.

To open your Gallery, swipe up from the Home screen, then touch **Gallery**.



Touch to access more options, such as Select items, Slideshow, etc..

Scroll up to view more pictures and videos.



Touch to setup display of albums.

Touch to create album.

Scroll up to view more albums.



## To view a picture/play a video

Pictures and videos are displayed by moments and albums in **Gallery**.

- All pictures and videos are divided by moments, and by albums. Touch an album to view pictures and videos spread on the screen.
- Touch the picture/video directly to view or play.
- Slide left/right to view previous or next pictures/videos.

## Working with pictures

Gallery provides a multi-select function, so that you can work with pictures/videos in batches.

You can touch one album, then slide up to view the pictures.

Touch a picture you want to work on, then, touch the  icon to delete selected photos. Touch  to share selected ones.

Touch  and select Set as... to set the picture as Contact photo, or Wallpaper

Touch  from full-screen picture view, more options will display for you to choose from.

## 9 Others .....

### 9.1 Other applications <sup>(1)</sup> .....

The previous applications in this section are preinstalled on your device. To read a brief introduction of the preinstalled 3rd party applications, please refer to the leaflet provided with the device. You can also download thousands of 3rd party applications by going to Google Play Store on your device.

<sup>(1)</sup> Application availability depends on country and carrier.

## 10 Google applications <sup>(1)</sup>.....

Google apps are preinstalled on your phone to improve work efficiency and help you enjoy life.

This manual briefly introduces these apps. For detailed features and user guides, refer to related websites or the introduction provided in the apps.

You are recommended to register with a Google account to enjoy all the functions.

### 10.1 Play Store .....

Serves as the official app store for the Android operating system, allowing users to browse and download applications and games. Applications are either free of charge or available for purchase.

In the Play Store, search for the app you need, download it and then follow the installation guide to install the app. You can also uninstall, update an app, and manage your downloads.

### 10.2 Chrome.....


Using the Chrome browser you can enjoy surfing the Web. Your bookmarks, browsing history, and settings across all devices with the browser installed can be synchronized with your Google account.

To get onto the Web, go to the Home screen and touch the Chrome icon  in the Favorites tray.

#### 10.2.1 To go to a web page

On the Chrome browser screen, touch the URL box at the top, enter the address of the web page, then touch  on Swiftkey keyboard, or touch  on Google keyboard to confirm.

<sup>(1)</sup> Availability depends on phone variants.



Delete all contents

During web page surfing, touch  for settings or more options.

## 10.3 Gmail.....

As the Google's web-based email service, Gmail is configured when you first set up your phone. Gmail on your phone can be automatically synchronized with your Gmail account on the web. With this application, you can receive and send emails, manage emails by labels, archive emails, etc.

### 10.3.1 To open Gmail

From the Home screen, touch the **Gmail** icon  in the Favorites tray.

Gmail displays messages and conversations from one single Gmail account at a time. If you own more than one account, you can add an account by touching the icon  and then  after your account name from the Inbox screen, then touch **Add account**. When finished, you can switch to another account by touching the name of the account you want to view.

## To create and send emails

- 1 Touch  from the Inbox screen.
- 2 Enter the recipient(s)'s email address in **To** field.
- 3 If necessary, touch the **Add Cc/Bcc** menu icon  to add a copy or a blind copy to the message.
- 4 Enter the subject and the content of the message.
- 5 Touch  icon and select **Attach file** to add an attachment.
- 6 Finally, touch the icon  to send.
- 7 If you do not want to send the mail out right away, you can touch the  icon and then **Save draft** or touch the **Back** key to save a copy. To view the draft, touch your account name to display all labels, then select **Drafts**.

If you do not want to send or save the mail, you can touch the  icon and then touch **Discard**.

To add a signature to emails, touch the  icon and then touch **Settings** from inbox screen, choose an account, then touch **Signature**.

### 10.3.2 To receive and read your emails

When a new email arrives, you will be notified by a ringtone or vibration, and an icon  will appear on the Status bar.

Touch and drag down the Status bar to display the Notification panel, touch the new email to view it. Or you can also open the Gmail Inbox label and touch the new mail to read it.

You can search for an email by sender, recipient, subject, etc.

- 1 Touch the icon  from Inbox screen.
- 2 Enter the keyword you want to search for in the searching box and touch  on the software keyboard.

### 10.3.3 To reply or forward emails

- **Reply**

When viewing an email, touch  to reply to it.

- **Reply all**

Touch  and select **Reply all** to send a message to all people in a mail loop.

- **Forward**

Touch  and select **Forward** to forward the received mail to other people.

## 10.4 Maps.....

Google Maps offers satellite imagery, street maps, 360° panoramic views of streets, real-time traffic conditions, and route planning for traveling by foot, car, or public transportation. By using this application, you can get your own location, search for a place, and get suggested route planning for your trips.

## 10.5 YouTube .....

YouTube is an online video-sharing application where users can upload, view, and share videos. Available content includes video clips, TV clips, music videos, and other content such as video blogging, short original videos, and educational videos. It supports a streaming function that allows you to start watching videos almost as soon as they begin downloading from the Internet.

## 10.6 Drive.....

A file storage and synchronization service created by Google, which allows users to store, share and edit files in the cloud.

Files in Drive are well kept and you can reach your files from any device by logging in to your Google account. Files or folders can be shared privately with particular users having a Google account.

## **10.7 Duo .....**

Google Duo is a video chat mobile app, it allows users to use phone numbers to easily call people from their contact list. The app will automatically control the video quality by sensing the network connectivity.

## **10.8 Play Music.....**

A music streaming service and online music locker operated by Google.

You can upload and listen to a large number of songs for free. In addition to offering music streaming for Internet-connected devices, the Google Play Music app allows music to be stored and listened to offline. Songs purchased through the Play Music are automatically added to the user's account.

## **10.9 Play Movies & TV .....**

Movies and television shows can be viewed online via Google Play Movies & TV. You can also download movies and TV shows for offline viewing. Some content are only available for rental or purchase.

## **10.10 Photos.....**

Google Photos stores and backs up your photos and videos. It also automatically analyses photos and organizes them into groups, so that you can quickly locate the photos you need.

## 11 Settings .....



To access this function, swipe up from Home screen and then touch the **Settings** icon.

### 11.1 Network & internet.....

#### 11.1.1 Wi-Fi

Using Wi-Fi you can now to surf the Internet without using your SIM card whenever you are in range of a wireless network. The only thing you have to do is to enter the **Wi-Fi** screen and configure an access point to connect your device to the wireless network.

For detailed instructions on using Wi-Fi, please refer to “**6.1.2 Wi-Fi**”.

#### 11.1.2 Mobile networks

##### Mobile Data

Touch to enable mobile data such as email, web browsing and push notifications over the cellular network.

##### International Data roaming

If you don't need to transmit data on other operators' cellular networks, disable **International Data roaming** to avoid incurring significant roaming charges.

##### Access Point Names

You can select your preferred network with this menu.

### 11.1.3 Data usage

Touch  you can view settings related to your cellular networks. Select **Cellular data usage** >  > **Set data limit** and then type in the desired amount under Data Limit to set cellular data limit. Your cellular data connection will be disabled when the specified limit is reached. You can also choose a data usage cycle to view the statistics and related applications of used data by your phone.



Data usage is measured by your phone and your provider may count differently. You can set conservative limit to control data usage.

### 11.1.4 Tethering & mobile hotspot

This function allows you to share your phone's mobile data connection via USB or as a portable Wi-Fi access point (refer to “**7.5 Sharing your phone's mobile data connection**”).

### 11.1.5 VPN

A mobile virtual private network (mobile VPN or mVPN) provides mobile devices with access to network resources and software applications on their home network, when they connect via other wireless or wired networks. Mobile VPNs are used in environments where workers need to keep application sessions open at all times, throughout the working day, as the user connects via various wireless networks, encounters gaps in coverage, or suspends-and-resumes their devices to preserve battery life. A conventional VPN can't survive such events because the network tunnel is disrupted, causing applications to disconnect, time out, fail, or even the computing device itself to crash.

For more information on VPN, refer to “**7.6 Connecting to virtual private networks**”.

### 11.1.6 Airplane mode

Touch the switch  to turn on **Airplane mode** to simultaneously disable all wireless connections including Wi-Fi, Bluetooth and more.

## 11.2 Connected devices .....

### 11.2.1 Bluetooth

Bluetooth allows your device to exchange data (videos, images, music, etc.) in a small range with another Bluetooth supported device (phone, computer, printer, headset, car kit, etc.).

For more information on Bluetooth, please refer to “6.3 Connecting to Bluetooth devices”.

## 11.3 Apps & notifications .....

### 11.3.1 Apps

Touch to view details about the applications installed on your phone, to manage their data usage and force them to stop.

In the Permissions menu of an application, you can grant permissions for the app, such as allowing the app to access your Camera, Contacts, Location, etc.

In the Notifications menu, you can configure whether to block the notifications from this app, hide sensitive content, etc.

### 11.3.2 Notifications

Touch to manage apps notification. You can set permission of apps notification, the authority to show the notifications on lock screen, etc..

## 11.4 Battery.....

On the Battery screen you can select whether to display battery percentage in the status bar or to enable intelligent power saving.

You can also view the battery usage data since your last full charge. The screen also shows your battery status and how long it can still be used before your next charge. Touch one category, then you can learn its specific power consumption.

## 11.5 Smart Manager .....

Touch to view the total memory and the memory used by applications.

## 11.6 Display .....

- **Brightness level**

Touch to adjust screen brightness manually.

- **Adaptive brightness**

When the function is turned on, the screen brightness level will optimize automatically according to the surrounding light.

- **Wallpaper**

Touch to set the wallpaper.

- **Sleep**

Touch to set screen timeout.

- **Auto-rotate screen**

Touch to select whether the screen rotates automatically or not.

- **Font size**

Touch to set the font size.

- **Display size**

Touch to set the display size.

- **Screen saver**

Touch to set what happens when the phone is docked and/or sleeping.

## 11.7 Sound.....

Use the Sound settings to configure many aspects of call ringtones, music, and other audio settings.

- **Sound**  
Set volume for media, ringtone, and alarms.
- **Also vibrate for calls**  
Switch the toggle to enable vibration for incoming calls.
- **Do not disturb preferences**  
Touch to set how calls and notifications interrupt whatever you are doing on your phone.
- **Phone ringtone**  
Touch to set your incoming call ringtone.
- **Default notification sound**  
Touch to set the default sound for notifications.
- **Default alarm sound**  
Touch to set your alarm ringtone.
- **Other sounds**  
Touch to set dial pad tones, screen locking sounds, charging sounds, touch sounds and vibrate on touch.
- **Wireless emergency alerts**  
Touch to set emergency alerts.
- **Sound enhancement**  
Touch to set sound enhancement.

## 11.8 Storage.....

This menu displays the amount of internal phone storage. It shows the amount of internal phone storage used by applications (including those you downloaded), images, videos, etc.. Touch the items to view details and touch  in the details screen to access more available options.

## 11.9 Security & location.....

### 11.9.1 Security

#### Function shortcuts

Touch to customize the application shortcuts displayed on your lock screen.

#### Screen lock

Touch to set your screen unlock method. For example, you can unlock your phone by sliding the screen, entering a password, or drawing a pattern, etc Touch for further setting of screen lock. You can make pattern visible, select the duration to lock the phone after the screen is off, or input owner information which will display on the locked screen..

#### Smart Lock

You must set a screen lock first when you enable this function.

#### Location

Touch the switch to enable the use of information from Wi-Fi and cellular networks to determine your approximate location, for use in Google Maps, when you search, and so on. When you select this option, you're asked whether you consent to share your location anonymously with Google's location service.

#### Make passwords visible

Switch the toggle to show passwords as you type.

#### Auto device wipe

Touch the switch to active auto device wipe.

#### Device administrators

Touch to view activate or deactivate device administrators.

#### SIM card lock

Touch to set and manage SIM PIN.

## Encryption & credentials

### Encrypt phone

You can encrypt your accounts, settings, download apps and their data, media and other files by touching Encrypt device.

### Storage type

Show storage type.

### Trusted credentials

Touch to display trusted CA certificates.

### User credentials

Touch to check and manage stored credentials.

### Install from SD card

Touch to install encrypted certificates from SD card.

### Clear credentials

Touch to remove all credentials.

### Trust agents

Touch to activate or deactivate trust agents.

### Screen pinning

When this function is enabled, you can always keep a window in view by touching the **Recent apps** key and then the pin icon. In this case, the user cannot go to any other window or open any other app.

To stop pinning a window in view, long press both the **Back** and **Recent apps** key together, then entering your screen unlock password or drawing your unlock pattern.

### Apps with usage access

When you allow Apps access, the app can view general information about the apps on your device, such as how often you use them.

## 11.9.2 Location

Touch the switch to enable the use of information from Wi-Fi and cellular networks to determine your approximate location, for use in Google Maps, when you search, and so on. When you select this option, you're asked whether you give consent to share your location anonymously with Google's location service.

## 11.10 Users & accounts .....

Contacts, data or other information can be synchronized from multiple accounts, depending on the applications installed on your phone.

You are required to select the kind of account you are adding, like Google, Corporate, etc.

As with other account setup, you need to enter detailed information, like username, password, etc.

You can remove an account to delete it and all associated information from the phone. Touch the account you want to delete, touch  and select **Remove account**, then confirm.

In the **Accounts** screen, touch  and mark the **Auto-sync data** checkbox. When activated, all changes to information on the phone or online will be automatically synchronized with each other.

## 11.11 Accessibility .....

You use the Accessibility settings to configure any accessibility plug-ins you have installed on your device.

### Volume key shortcut

Touch to turn on/off to activate/deactivate shortcut service.

### Select to Speak

Touch to turn on/off to activate/deactivate the function.

## **Switch access**

Switch access allow you to control your device using configurable key combination. You can move focus to clickable items and select them. Touch the switch icon to turn on/off the function. Touch SETTINGS to get more options.

## **Talkback**

Touch to turn on/off to activate/deactivate talkback function.

## **Text-to-speech settings**

Touch to update the settings for text-to-speech output, such as the speech rate.

## **Font size**

Touch the setup the font size of text on screen to normal, larger and largest.

## **Display size**

Touch to setup the display size of items, such as app icon, message, etc.. Some apps on your screen may change position.

## **Magnification**

Touch to turn on/off to activate/deactivate zoom in/out function by triple-tapping the screen.

## **Large mouse pointer**

Touch the switch to activate large mouse pointer.

## **Click after pointer stops moving**

Touch to turn on/off the delay before click. Draw the indicate line to adjust how long to delay before click.

## **Power button ends call**

Touch the switch to enable power button ends call.

## **Auto-rotate screen**

Touch the switch to activate auto-rotate screen. Content on the screen or the keyboard will be automatically rotated when you rotate your phone.

## **Touch & hold delay**

Touch to adjust the duration of touch and hold delay. This function enables your phone to differ touch and touch & hold, which may avoid incorrect operations.

## **Mono audio**

Touch the to enable/disable combine channels when playing audio.

## **Captions**

Touch to set the caption type.

## **High contrast text**

Touch the switch to activate high contrast text.

## **Color correction**

Touch to turn on/off color correction.

## **Color inversion**

Touch the switch to turn on/off color inversion.

## **11.12 Google.....**

Tap to modify Google settings.

## **11.13 System .....**

### **11.13.1 Language & input**

Use the Language & input settings to select the language for the text on your phone and for configuring the onscreen keyboard. You can also configure voice input settings and the pointer speed.

#### **Language**

Touch to select the language and the region you want.

#### **Virtual keyboard**

##### **Google keyboard**

The Google keyboard settings apply to the onscreen keyboard that is included with your phone. The correction and capitalization features affect only the English version of the keyboard.

## **Google voice typing**

Google voice typing is free speech-to-text capabilities which can let you input words by talking instead of typing by hand.

Tap the microphone icon on the on-screen keyboard to start Voice Typing.

## **Physical keyboard**

### **Show virtual keyboard**

Touch the switch to enable virtual keyboard on screen while physical keyboard is active.

### **Keyboard shortcuts helper**

Touch to view the available keyboard shortcuts.

### **Spell checker**

Mark the checkbox to enable the system to show suggested words.

### **Personal dictionary**

Touch to open a list of the words you've added to the dictionary. Touch a word to edit or delete it. Touch the add button (+) to add a word.

### **Pointer speed**

Select how fast the pointer/mouse should scroll when you connect the phone to a trackpad or mouse accessory.

## **Text-to-speech settings**

### **Preferred engine**

Choose a preferred text-to-speech engine, Touch the settings icon to show more choices for each engine.

### **Language**

This will show status of your default language.

### **Speech rate**

Touch to open a dialog where you can select how quickly you want the synthesiser to speak.

### **Pitch**

Adjust the tone of the spoken text.

## 11.13.2 Gestures

### Jump to camera

Touch the switch to active jump to camera.

## 11.13.3 Date & time

Use Date & Time settings to customize your preferences for how date and time are displayed.

### Automatic date & time

Touch to choose use network-provided time, GPS-provided time or off.

### Automatic time zone

Touch the switch  to turn off using network-provided time zone. Or touch again to disable it, and then you can set time zone manually in **Select time zone**.

### Set date

Touch to open a dialog where you can manually set the device's date.

### Set time

Touch to open a dialog where you can manually set the device's time.

### Select time zone

Touch to open a dialog where you can set the device's time zone.

### Use 24-hour format

Mark the checkbox to display the time using 24-hour clock format.

#### 11.13.4 Backup

Turn on the switch to back up your device's settings and other application data to Google Servers, with your Google account. If you replace your device, the settings and data you've backed up are restored onto the new device for the first time you sign in with your Google account. If you mark this option, a wide variety of settings and data are backed up, including your Wi-Fi passwords, bookmarks, a list of the applications you've installed, the words you've added to the dictionary used by the onscreen keyboard, and most of the settings that you configure with the Settings application. If you unmark this option, you stop backing up your settings, and any existing backups are deleted from Google Servers.

#### 11.13.5 Reset options

Device reset will erase all of your personal data from internal device storage, including information about your Google account, any other accounts, your system and application settings, and any downloaded applications. Resetting the device does not erase any system software updates you've downloaded or any files on your microSD card, such as music or photos. If you mark the checkbox - Reserve the content of Device storage before touching RESET PHONE, any files stored on your device's storage will not be erased. If you reset the device in this way, you're prompted to re-enter the same kind of information as when you first started Android.

When you are unable to power on your device, there is another way to perform a factory data reset by using hardware keys. Press the Volume up key and the Power key at same time until the screen lights up.

#### 11.13.6 AT&T Software Updates

Touch to check for system updates.

### 11.13.7 Regulatory & Safety

Touch to check regulatory and safety information, such as IMEI, CU reference, Bluetooth declaration ID, etc..

### 11.13.8 About phone

This contains information about things ranging from Status, Legal information, Model number, Android version, Android security patch level, Baseband version, Kernel version, Build number to those listed below:

#### **Status**

This contains the status of the Battery status, Battery level, My device number, Network, Signal strength, etc.

#### **Legal information**

Touch to view legal information.

## 12 Software update .....

To access **Software update**, open **Settings>System >AT&T Software Updates**. Touch **Check for Updates**, and the device will search for the latest software. Software update requires Wi-Fi networks. If there is a software update available but you haven't connect Wi-Fi, touch **CONTINUE** to connect to Wi-Fi network, the software will download automatically when Wi-Fi connected. You also can find a notification **AT&T Software Update Available** on notification panel when an update is available for your device.

## 13 Accessories.....

### Included accessories

1. Charger
2. USB cable



Only use your device with the charger and accessories in your box.

## 14 Safety information .....

We recommend that you read this chapter carefully before using your device. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

### • TRAFFIC SAFETY

Given that studies show that using a device while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to refrain from using their device when the vehicle is not parked.

When driving, do not use your device or headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some areas. When switched on, your device emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that there is no problem:

- do not place your device on top of the dashboard or within an airbag deployment area,
- check with your car dealer or the car manufacturer to make sure that the dashboard is adequately shielded from device RF energy.

### • CONDITIONS OF USE

You are advised to switch off the device from time to time to optimize its performance.

Switch the device off before boarding an aircraft.

Switch the device off when you are in healthcare facilities, except in designated areas. As with many other types of equipment now in regular use, these devices can interfere with other electrical or electronic devices, or equipment using radio frequencies.

Switch the device off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in any potentially explosive atmosphere.

When the device is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid, or insulin pump, etc. In particular when using the device, you should hold it against the ear on the opposite side of the device, if any.

To avoid hearing impairment, move the device away from your ear while using the “hands-free” mode because the amplified volume might cause hearing damage.

Do not let children use the device and/or play with the device and accessories without supervision.

When replacing the cover, note that your device may contain substances that could create an allergic reaction.

Always handle your device with care and keep it in a clean and dust-free place.

Do not allow your device to be exposed to adverse weather or environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc.). The manufacturer’s recommended operating temperature range is 32°F to +140°F.

At over 140°F the legibility of the device’s display may be impaired, though this is temporary and not serious.

Emergency call numbers may not be reachable on all cellular network. You should never rely only on your phone for emergency calls.

Do not open, dismantle, or attempt to repair your device yourself.

Do not drop, throw, or bend your device.

Do not use the device if the screen is damaged, cracked, or broken to avoid any injury.

Do not paint it.

Only use battery chargers and accessories which are recommended by TCL Communication Ltd. and its affiliates and are compatible with your device model. TCL Communication Ltd. and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries.

Remember to make back-up copies or keep a written record of all important information stored in your device.

- **PRIVACY**

Please note that you must respect the laws and regulations in force in your jurisdiction or other jurisdiction(s) where you will use your device regarding taking photographs and recording sounds with your device. Pursuant to such laws and regulations, it may be strictly forbidden to take photographs and/or record the voices of other people or any of their personal attributes, and duplicate or distribute them, as this may be considered to be an invasion of privacy. It is the user's sole responsibility to ensure that prior authorization be obtained, if necessary, in order to record private or confidential conversations or take a photograph of another person; the manufacturer, the seller, or vendor of your device (including the operator) disclaim any liability which may result from the improper use of the device.

- **BATTERY**

Following air regulation, the battery of your product is not charged. Please charge it first.


For a unibody device:

Observe the following precautions:

- Do not attempt to open the back cover;
- Do not attempt to eject, replace, or open battery;

- Do not puncture the back cover of your phone;
- Do not burn or dispose of your phone in household rubbish or store it at temperature above 60°C (140°F);

Phone and battery as a unibody device must be disposed of in accordance with locally applicable environmental regulations.



This symbol on your device and the accessories means that these products must be taken to collection points at the end of their life:



- Municipal waste disposal centers with specific bins for these items of equipment.
- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

### **In European Union countries:**

These collection points are accessible free of charge.

All products with this sign must be brought to these collection points.

### **In non-European Union jurisdictions:**

Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

#### **• CHARGERS**

Main powered chargers will operate within the temperature range of: 32°F to 113°F.

The chargers designed for your device meet with the standard for safety of information technology equipment and office equipment use. They are also compliant to the eco design directive 2009/125/EC. Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose only.

The charger shall be installed near the device and shall be easily accessible.

- Federal Communications Commission (FCC) Declaration of Conformity

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device has been tested and found to comply with the limits for a Class B digital pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **FCC Caution:**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **FCC RF Exposure Information (SAR):**

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

During SAR testing, this is set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage near the body with the separation of 10 mm. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The exposure standard for wireless employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg.

Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands.

The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model device is on file with the FCC and can be found under the Display Grant section of HYPERLINK “<http://www.fcc.gov/oet/ea/fccid>” [www.fcc.gov/oet/ea/fccid](http://www.fcc.gov/oet/ea/fccid) after searching on:

FCC ID: 2ACCJH092

This device is HAC M4/T3 compatible. Reference ANSI C63.19 (2011).

For this device, the highest reported SAR value for usage near the body is:

|                                                                        |           |
|------------------------------------------------------------------------|-----------|
| Maximum SAR for this model and conditions under which it was recorded: |           |
| Body-worn SAR                                                          | 1.41 W/kg |
| Head SAR                                                               | 1.29 W/kg |

SAR compliance for body operation is based on a separation distance of 10 mm between the device and the human body. During use, the actual SAR values for this device are usually well below the values stated above. This is because, for purposes of system efficiency and to minimize interference on the network, the operating power of your device is automatically decreased when full power is not needed. The lower the power output of the device, the lower its SAR value.

Body-worn SAR testing has been carried out at a separation distance of 10 mm. To meet RF exposure guidelines during body-worn operation, the device should be positioned at least this distance away from the body.

If you are not using an approved accessory ensure that whatever product is used is free of any metal and that it positions the device the indicated distance away from the body.

Organizations such as the World Health Organization and the US Food and Drug Administration have suggested that if people are concerned and want to reduce their exposure they could use a hands-free accessory to keep the wireless device away from the head or body during use, or reduce the amount of time spent on the device.

Please note by using the device some of your personal data may be shared with the main device. It is under your responsibility to protect your own personal data, not to share with it with any unauthorized devices or third party devices connected to yours. For devices with Wi-Fi features, only connect to trusted Wi-Fi networks. Also when using your device as a hotspot (where available), use network security. These precautions will help prevent unauthorized access to your device. Your device can store personal information in various locations, including a SIM card, memory card, and built-in memory. Be sure to remove or clear all personal information before you recycle, return, or give away your device. Choose your apps and updates carefully, and install from trusted sources only. Some apps can impact your device's performance and/or have access to private information, including account details, call data, location details, and network resources.

Note that any data shared with TCL Communication Ltd. is stored in accordance with applicable data protection legislation. For these purposes TCL Communication Ltd. implements and maintains appropriate technical and organizational measures to protect all personal data, for example, against unauthorized or unlawful processing and accidental loss or destruction of or damage to such personal data whereby the measures shall provide a level of security that is appropriate having regard to:

- (i) the technical possibilities available,
- (ii) the costs for implementing the measures,

(iii) the risks involved with the processing of the personal data, and

(iv) the sensitivity of the personal data processed.

You can access, review, and edit your personal information at any time by logging into your user account, visiting your user profile, or contacting us directly. Should you require us to edit or delete your personal data, we may ask you to provide us with evidence of your identity before we can act on your request.

- LICENCES



microSD Logo is a trademark.



The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by TCL Communication Ltd. and its affiliates is under license. Other trademarks and trade names are those of their respective owners.

**Alcatel 5059R** Bluetooth Declaration ID D038401



The Wi-Fi Logo is a certification mark of the Wi-Fi Alliance.

## 15 General information.....

- Internet address: <https://us.alcatelmobile.com>  
<https://ca.alcatelmobile.com>
- Facebook: <https://www.facebook.com/alcatelmobileus>  
<https://www.facebook.com/alcatelmobileca>
- Call support: U.S.A.: 855-368-0829  
Canada: 855-844-6058
- Email support: U.S.A.: <https://us.alcatelmobile.com/contact>  
Canada: <https://ca.alcatelmobile.com/contact>
- Manufacturer: TCL Communication Ltd.  
5/F, Building 22E, 22 Science Park East  
Avenue, Hong Kong Science Park, Shatin, NT,  
Hong Kong

An electronic version of this user guide is available in English and other languages according to availability on our website: <https://us.alcatelmobile.com>

Your device is a transceiver that operates on Wi-Fi with 2.4GHz and Bluetooth with 2.4GHz.

**Electronic labeling path:** Touch **Settings > System > Regulatory & Safety** or press \*#07#, you can find more information about labeling <sup>(1)</sup>, such as FCC ID.

<sup>(1)</sup> It depends on countries.

## Protection against theft <sup>(1)</sup>

Your device is identified by an IMEI (phone serial number) shown on the packaging label and in the product's memory. We recommend that you note the number the first time you use your device by entering \*#06# and keep it in a safe place. It may be requested by the police or your operator if your device is stolen. This number allows your device to be blocked, preventing a third person from using it, even with a different SIM card.

## Disclaimer

There may be certain differences between the user manual description and the device's operation, depending on the software release of your device or specific operator services.

TCL Communication Ltd. shall not be held legally responsible for such differences, if any, nor for their potential consequences, which responsibility shall be borne by the operator exclusively.

This device may contain materials, including applications and software in executable or source code form, which is submitted by third parties for inclusion in this device ("Third Party Materials").

All third party materials in this device are provided "as is", without warranty of any kind, whether express or implied, including the implied warranties of merchantability, fitness for a particular purpose or use/third party application, interoperability with other materials or applications of the purchaser and non-infringement of copyright. The purchaser undertakes that TCL Communication Ltd. has complied with all quality obligations incumbent upon it as a manufacturer of mobile devices and devices in complying with Intellectual Property rights. TCL Communication Ltd. will at no stage be responsible for the inability or failure of the Third Party

<sup>(1)</sup> Contact your network operator to check service availability.

Materials to operate on this device or in interaction with any other devices of the purchaser. To the maximum extent permitted by law, TCL Communication Ltd. disclaims all liability for any claims, demands, suits, or actions, and more specifically – but not limited to – tort law actions, under any theory of liability, arising out of the use, by whatever means, or attempts to use, such Third Party Materials. Moreover, the present Third Party Materials, which are provided free of charge by TCL Communication Ltd., may be subject to paid updates and upgrades in the future; TCL Communication Ltd. waives any responsibility regarding such additional costs, which shall be borne exclusively by the purchaser. The availability of the applications may vary depending on the countries and the operators where the device is used; in no event shall the list of possible applications and software provided with the devices be considered as an undertaking from TCL Communication Ltd.; it shall remain merely as information for the purchaser. Therefore, TCL Communication Ltd. shall not be held responsible for the lack of availability of one or more applications wished for by the purchaser, as its availability depends on the country and the operator of the purchaser. TCL Communication Ltd. reserves the right at any time to add or remove Third Party Materials from its devices without prior notice; in no event shall TCL Communication Ltd. be held responsible by the purchaser for any consequences that such removal may have on the purchaser regarding the use or attempt to use such applications and Third Party Materials.

### **Accessory**

- ◆ SIM Tray Pin
- ◆ Wall charger
- ◆ Safety and warranty information
- ◆ Quick Start Guide
- ◆ USB cable

## 16 Warranty.....

Your device is warranted against any defect or malfunctioning which may occur in conditions of normal use during the warranty period of twelve (12) months <sup>(1)</sup> from the date of purchase as shown on your original invoice.

Accessories sold with your device are also warranted against any defect which may occur during the first six (6) months <sup>(1)</sup> from the date of purchase as shown on your original invoice.

In case of any defect of your device which prevents you from normal use thereof, you must immediately inform your vendor and present your device with your proof of purchase.

If the defect is confirmed, your device or part thereof will be either replaced or repaired, as appropriate. Repaired device and accessories are entitled to a one (1) month warranty for the same defect. Repair or replacement may be carried out using reconditioned components offering equivalent functionality.

This warranty covers the cost of parts and labor but excludes any other costs.

This warranty shall not apply to defects to your device and/or accessory due to (without any limitation):

- 1) Non-compliance with the instructions for use or installation, or with technical and safety standards applicable in the geographical area where your device is used;
- 2) Connection to any equipment not supplied or not recommended by TCL Communication Ltd. ;
- 3) Modification or repair performed by individuals not authorized by TCL Communication Ltd. or its affiliates or your vendor;

<sup>(1)</sup> The warranty period may vary depending on your country.

- 4) Modification, adjustment, or alteration of software or hardware performed by individuals not authorized by TCL Communication Ltd.;
- 5) Inclement weather, lightning, fire, humidity, infiltration of liquids or foods, chemical products, download of files, crash, high voltage, corrosion, oxidation...

Your device will not be repaired if labels or serial numbers (IMEI/SN) have been removed or altered.

There are no express warranties, whether written, oral, or implied other than this printed limited warranty or the mandatory warranty provided by your country or jurisdiction.

In no event shall TCL Communication Ltd. or any of its affiliates be liable for indirect, incidental, or consequential damages of any nature whatsoever, including but not limited to commercial or financial loss or damage, loss of data, or loss of image to the full extent those damages can be disclaimed by law.

Some countries/states do not allow the exclusion or limitation of indirect, incidental, or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

### **Electronic Recycling (Within USA Only):**

For more information on Electronic Recycling, please:

- 1) Visit Alcatel Electronic Recycling Program website at [us.alcatelmobile.com/accessibility-compliance/electronic-recycling-program/](http://us.alcatelmobile.com/accessibility-compliance/electronic-recycling-program/), or
- 2) Call Alcatel US Customer Support at 1-855-368-0829.

## 17 Troubleshooting .....

Before contacting the service center, you are advised to follow the instructions below:

- You are advised to fully charge (  ) the battery for optimal operation.
- Avoid storing large amounts of data in your device as this may affect its performance.
- Use **Erase all data** and the upgrade tool to perform device formatting or software upgrading. ALL User device data: contacts, photos, messages and files, downloaded applications will be lost permanently. It is strongly advised to fully backup the device data and profile via Android Manager before doing formatting and upgrading.

### **My device cannot be switched on or is frozen**

- When the device cannot be switched on, charge for at least 20 minutes to ensure the minimum battery power needed, then try to switch on again.
- When the device falls into a loop during power on-off animation and the user interface cannot be accessed, long press the **Power** key and **Volume up** key at the same time to enter Safe Mode. This eliminates any abnormal OS booting issues caused by 3rd party apps.
- If neither method is effective, please power off the device using the Power and the Volume up key, (holding both together).

### **My device has not responded for several minutes**

- Restart your device by pressing and holding the **Power** key.
- Long press the **Power** key for 8 seconds to power off your phone.
- Long press the **Power** key for 10 seconds or more to reboot.

### **My device turns off by itself**

- Check that your screen is locked when you are not using your device, and make sure the **Power** key is not mis-contacted due to unlocked screen.
- Check the battery charge level.
- My device cannot charge properly
- Make sure that your battery is not completely discharged; if the battery power is empty for a long time, it may take around 20 minutes to display the battery charger indicator on the screen.
- Make sure charging is carried out under normal conditions (32°F to +104°F).
- When abroad, check that the voltage input is compatible.

### **My device cannot connect to a network or “No service” is displayed**

- Try connecting in another location.
- Verify the network coverage with your operator.
- Check with your operator that your SIM card is valid.
- Try selecting the available network(s) manually
- Try connecting at a later time if the network is overloaded.

### **My device cannot connect to the Internet**

- Make sure that the internet access service of your SIM card is available.
- Check your device’s Internet connecting settings.
- Make sure you are in a place with network coverage.
- Try connecting at a later time or another location.

### **Invalid SIM card**

- Make sure the SIM card has been correctly inserted (see “1.2.1 Set -up”).

- Make sure the chip on your SIM card is not damaged or scratched.
- Make sure the service of your SIM card is available.

### **I cannot find my contacts**

- Make sure your SIM card is not broken.
- Make sure your SIM card is inserted properly.
- Import all contacts stored in SIM card to device.

### **I am unable to use the features described in the manual**

- Check with your operator to make sure that your subscription includes this service.

### **I am unable to add a contact in my contacts**

- Make sure that your SIM card contacts are not full; delete some files or save the files in the device contacts (i.e. your professional or personal directories).

### **SIM card PIN locked**

- Contact your network operator to obtain the PUK code (Personal Unblocking Key).

### **I am unable to connect my device to my computer**

- Install User Center.
- Check that your USB driver is installed properly.
- Open the Notification panel to check if the Android Manager Agent has been activated.
- Check that you have marked the checkbox of USB debugging.
- To access this function, touch **Settings/About phone**, then touch **Build number** for 7 times. Now you may touch **Settings/Developer options/USB debugging**.
- Check that your computer meets the requirements for User Center Installation.

- Make sure that you're using the right cable from the box.

### **I am unable to download new files**

- Make sure there is sufficient device memory for your download.
- Check your subscription status with your operator.

### **The device cannot be detected by others via Bluetooth**


- Make sure that Bluetooth is turned on and your device is visible to other users (see "6.3 Connecting to Bluetooth devices").
- Make sure that the two devices are within Bluetooth's detection range.

### **How to make your battery last longer**

- Make sure you follow the complete charge time (minimum 2.5 hours).
- After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication.
- Adjust the brightness of screen as appropriate
- Extend the email auto-check interval for as long as possible.
- Update news and weather information on manual demand, or increase their auto-check interval.
- Exit background-running applications if they are not being used for a long time.
- Deactivate Bluetooth, Wi-Fi, or GPS when not in use.

### **The device will become warm following prolonged game playing, internet surfing or running other complex applications.**

- This heating is a normal consequence of the CPU handling excessive data. Ending above actions will make your device return to normal temperatures.



To download the complete user manual and learn more about your phone, visit [alcatelonetouch.us](http://alcatelonetouch.us)